

Make	Model	Variants	Part Number	Product Description	Bush Size	定価(税別)	SET入数	図面番号
BMW	E28 5 Series (1982 - 1988), E24 6 Series (1982 - 1989)		BS2003K	Bump Stop Kit	Front	7500	1	
BMW	E28 5 Series (1982 - 1988), E24 6 Series (1982 - 1989)		PFF5-310-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	7750	2	3
BMW	E28 5 Series (1982 - 1988), E24 6 Series (1982 - 1989)		PFF5-801	Front Lower Tie Bar To Chassis Bush		10340	2	1
BMW	E28 5 Series (1982 - 1988), E24 6 Series (1982 - 1989)		PFF5-802	Front Inner TCA Bush		10340	2	2
BMW	E28 5 Series (1982 - 1988), E24 6 Series (1982 - 1989)		PFR5-308-15.5	Rear Roll Bar Mounting Bush 15.5mm	15.5mm	7500	2	7
BMW	E28 5 Series (1982 - 1988), E24 6 Series (1982 - 1989)		PFR5-308-17	Rear Anti Roll Bar Mounting Bush 17mm	14mm	7500	2	7
BMW	E28 5 Series (1982 - 1988), E24 6 Series (1982 - 1989)		PFR5-308-18	Rear Anti Roll Bar Mounting Bush 18mm	18mm	7500	2	7
BMW	E28 5 Series (1982 - 1988), E24 6 Series (1982 - 1989)		PFR5-308-19	Rear Anti Roll Bar Mounting Bush 19mm	19mm	7500	2	7
BMW	E28 5 Series (1982 - 1988), E24 6 Series (1982 - 1989)		PFR5-315	Rear Anti Roll Bar Link To Arm Bush		6500	2	15
BMW	E28 5 Series (1982 - 1988), E24 6 Series (1982 - 1989)		PFR5-316	Rear Anti Roll Bar Link To Anti Roll Bar Bush		5250	2	16
BMW	E28 5 Series (1982 - 1988), E24 6 Series (1982 - 1989)		PFR5-504-13	Front Anti Roll Bar Mounting Bush 13mm	13mm	7500	2	3
BMW	E28 5 Series (1982 - 1988), E24 6 Series (1982 - 1989)		PFR5-504-14	Front Anti Roll Bar Mounting Bush 14mm	14mm	7500	2	3
BMW	E28 5 Series (1982 - 1988), E24 6 Series (1982 - 1989)		PFR5-504-15	Front Anti Roll Bar Mounting Bush 15mm	15mm	7500	2	3
BMW	E28 5 Series (1982 - 1988), E24 6 Series (1982 - 1989)		PFR5-504-165	Front Roll Bar Mounting Bush 16.5mm	16.5mm	7500	2	3
BMW	E28 5 Series (1982 - 1988), E24 6 Series (1982 - 1989)		PFR5-504-18	Front Anti Roll Bar Mounting Bush 18mm	18mm	7500	2	3
BMW	E28 5 Series (1982 - 1988), E24 6 Series (1982 - 1989)		PFR5-504-19	Front Anti Roll Bar Mounting Bush 19mm	19mm	7500	2	3
BMW	E28 5 Series (1982 - 1988), E24 6 Series (1982 - 1989)		PFR5-504-21	Front Anti Roll Bar Mounting Bush 21mm	21mm	7500	2	3
BMW	E28 5 Series (1982 - 1988), E24 6 Series (1982 - 1989)		PFR5-504-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	7250	2	3
BMW	E28 5 Series (1982 - 1988), E24 6 Series (1982 - 1989)		PFR5-807	Rear Beam Bush		11440	2	6
BMW	E30 3 Series (1982 - 1991)		BS2003K	Bump Stop Kit	Front	7500	1	
BMW	E30 3 Series (1982 - 1991)		PFF5-301	Front Lower Wishbone Rear Bush		8580	2	1
BMW	E30 3 Series (1982 - 1991)		PFF5-302-19	Front Anti Roll Bar Bush 19mm	19mm	7500	2	2
BMW	E30 3 Series (1982 - 1991)		PFF5-302-20	Front Anti Roll Bar Bush 20mm	20mm	7500	2	2
BMW	E30 3 Series (1982 - 1991)		PFF5-302-21	Front Anti Roll Bar Bush 21mm	21mm	7500	2	2
BMW	E30 3 Series (1982 - 1991)		PFF5-302-22	Front Anti Roll Bar Bush 22mm	22mm	7500	2	2
BMW	E30 3 Series (1982 - 1991)		PFF5-302-24	Front Anti Roll Bar Bush 24mm	24mm	7500	2	2
BMW	E30 3 Series (1982 - 1991)		PFF5-303	Front Lower Wishbone Rear Bush Eccentric		10120	2	1
BMW	E30 3 Series (1982 - 1991)		PFF5-304	Anti Roll Bar Link Rod Bush		8000	2	3
BMW	E30 3 Series (1982 - 1991)		PFR5-300	Rear Diff Mounting Bush		6250	1	7
BMW	E30 3 Series (1982 - 1991)		PFR5-305	Rear Beam Mounting Bush		14520	2	4
BMW	E30 3 Series (1982 - 1991)		PFR5-306	Rear Trailing Arm Bush		20240	4	5
BMW	E30 3 Series (1982 - 1991)		PFR5-306G	Rear Trailing Arm Bush Adjustable		28160	4	5
BMW	E30 3 Series (1982 - 1991)		PFR5-308-12	Rear Roll Bar Mounting Bush 12mm	12mm	7500	2	6
BMW	E30 3 Series (1982 - 1991)		PFR5-308-14	Rear Roll Bar Mounting Bush 14mm	14mm	7500	2	6
BMW	E30 3 Series (1982 - 1991)		PFR5-308-15.5	Rear Roll Bar Mounting Bush 15.5mm	15.5mm	7500	2	6
BMW	E30 3 Series (1982 - 1991)		PFR5-308-16	Rear Roll Bar Mounting Bush 16mm	16mm	7500	2	6
BMW	E30 3 Series (1982 - 1991)		PFR5-308-18	Rear Roll Bar Mounting Bush 18mm	18mm	7500	2	6
BMW	E30 3 Series (1982 - 1991)		PFR5-315	Rear Anti Roll Bar Link To Arm Bush		6500	2	15
BMW	E30 3 Series (1982 - 1991)		PFR5-316	Rear Anti Roll Bar Link To Anti Roll Bar Bush		5250	2	16
BMW	E32 7 Series (1988-1994)		BS2003K	Bump Stop Kit	Front	7500	1	
BMW	E32 7 Series (1988-1994)		PFF5-310-23	Front Anti Roll Bar Mounting 23mm	23mm	7750	2	3
BMW	E32 7 Series (1988-1994)		PFF5-310-24	Front Anti Roll Bar Mounting 24mm	24mm	7750	2	3
BMW	E32 7 Series (1988-1994)		PFF5-310-25	Front Anti Roll Bar Mounting 25mm	25mm	7750	2	3
BMW	E32 7 Series (1988-1994)		PFF5-310-28	Front Anti Roll Bar Mounting 28mm	28mm	7750	2	2
BMW	E32 7 Series (1988-1994)		PFF5-601	Front Lower Tie Bar To Chassis Bush		10780	2	1
BMW	E32 7 Series (1988-1994)		PFF5-602	Front Inner TCA Bush		10340	2	2
BMW	E32 7 Series (1988-1994)		PFF5-620	Front Inner TCA Bush		10340	2	2
BMW	E32 7 Series (1988-1994)		PFR5-504-15	Rear Roll Bar Mounting Bush 15mm	15mm	7500	2	7
BMW	E32 7 Series (1988-1994)		PFR5-504-165	Rear Roll Bar Mounting Bush 16.5mm	16.5mm	7500	2	7
BMW	E32 7 Series (1988-1994)		PFR5-504-18	Rear Roll Bar Mounting Bush 18mm	18mm	7500	2	7
BMW	E32 7 Series (1988-1994)		PFR5-507	Rear Beam Mount Bush		12760	2	6
BMW	E34 5 Series (1988 - 1996)		BS2003K	Bump Stop Kit	Front	7500	1	
BMW	E34 5 Series (1988 - 1996)		PFF5-310-23	Front Anti Roll Bar Mounting 23mm	23mm	7750	2	3
BMW	E34 5 Series (1988 - 1996)		PFF5-310-24	Front Anti Roll Bar Mounting 24mm	24mm	7750	2	3
BMW	E34 5 Series (1988 - 1996)		PFF5-310-25	Front Anti Roll Bar Mounting 25mm	25mm	7750	2	3
BMW	E34 5 Series (1988 - 1996)		PFF5-310-28	Front Anti Roll Bar Mounting 28mm	28mm	7750	2	3
BMW	E34 5 Series (1988 - 1996)		PFF5-601	Front Lower Tie Bar To Chassis Bush		10780	2	1
BMW	E34 5 Series (1988 - 1996)		PFF5-602	Front Inner TCA Bush		10340	2	2
BMW	E34 5 Series (1988 - 1996)		PFF5-620	Front Inner TCA Bush		10340	2	2
BMW	E34 5 Series (1988 - 1996)		PFR5-504-15	Rear Roll Bar Mounting Bush 15mm	15mm	7500	2	7
BMW	E34 5 Series (1988 - 1996)		PFR5-504-165	Rear Roll Bar Mounting Bush 16.5mm	16.5mm	7500	2	7
BMW	E34 5 Series (1988 - 1996)		PFR5-504-18	Rear Roll Bar Mounting Bush 18mm	18mm	7500	2	7
BMW	E34 5 Series (1988 - 1996)		PFR5-507	Rear Beam Mount Bush		12760	2	6
BMW	E36 3 Series (1990 - 1998)		BS2003K	Bump Stop Kit	Front	7500	1	
BMW	E36 3 Series (1990 - 1998)		PFF5-301	Front Lower Wishbone Rear Bush		8580	2	1
BMW	E36 3 Series (1990 - 1998)		PFF5-303	Front Lower Wishbone Rear Bush Eccentric		10120	2	1
BMW	E36 3 Series (1990 - 1998)		PFF5-304	Anti Roll Bar Link Rod Bush		8000	2	3
BMW	E36 3 Series (1990 - 1998)		PFF5-310-23	Front Anti Roll Bar Mounting 23mm	23mm	7750	2	2
BMW	E36 3 Series (1990 - 1998)		PFF5-310-24	Front Anti Roll Bar Mounting 24mm	24mm	7750	2	2
BMW	E36 3 Series (1990 - 1998)		PFF5-310-25	Front Anti Roll Bar Mounting 25mm	25mm	7750	2	2
BMW	E36 3 Series (1990 - 1998)		PFF5-310-26	Front Anti Roll Bar Mounting 26mm	26mm	7750	2	2
BMW	E36 3 Series (1990 - 1998)		PFF5-310-27	Front Anti Roll Bar Mounting 27mm	27mm	7750	2	2
BMW	E36 3 Series (1990 - 1998)		PFF5-310-28	Front Anti Roll Bar Mounting 28mm	28mm	7750	2	2
BMW	E36 3 Series (1990 - 1998)		PFR5-315	Rear Anti Roll Bar Link To Arm Bush		6500	2	15
BMW	E36 3 Series (1990 - 1998)		PFR5-316	Rear Anti Roll Bar Link To Anti Roll Bar Bush		5250	2	16
BMW	E36 3 Series (1990 - 1998)		PFR5-324	Rear Diff Front Mounting Bush, M3 Evo Only		6750	1	25

BMW	E36 3 Series (1990 - 1998)		PFR5-325	Rear Diff Front Mounting Bush		750	1	25
BMW	E36 3 Series (1990 - 1998)		PFR5-326	Rear Diff Rear Mounting Bush		10560	2	26
BMW	E36 3 Series (1990 - 1998)		PFR5-3606	Rear Subframe Rear Mounting Bush		9680	2	7
BMW	E36 3 Series (1990 - 1998)		PFR5-3607	Rear Subframe Front Mounting Bush		9680	2	6
BMW	E36 3 Series (1990 - 1998)		PFR5-3608	Rear Trailing Arm Front Bush		9680	2	8
BMW	E36 3 Series (1990 - 1998)		PFR5-504-15	Rear Roll Bar Mounting Bush 15mm	15mm	7500	2	5
BMW	E36 3 Series (1990 - 1998)		PFR5-504-18	Rear Roll Bar Mounting Bush 18mm	18mm	7500	2	5
BMW	E36 3 Series (1990 - 1998)		PFR5-504-19	Rear Roll Bar Mounting Bush 19mm	19mm	7500	2	5
BMW	E36 3 Series (1990 - 1998)		PFR5-504-20	Rear Roll Bar Mounting Bush 20mm	20mm	7500	2	5
BMW	E36 3 Series (1990 - 1998)		PFR5-5630-10	Rear Shock Top Mount Bracket and Bush 10mm	10mm	15620	2	30
BMW	E36 3 Series (1990 - 1998)		PFR5-5630-12	Rear Shock Top Mount Bracket and Bush 12mm	12mm	15620	2	30
BMW	E36 3 Series Compact		BS2003K	Bump Stop Kit	Front	7500	1	
BMW	E36 3 Series Compact		PFF5-301	Front Lower Wishbone Rear Bush		8580	2	1
BMW	E36 3 Series Compact		PFF5-303	Front Lower Wishbone Rear Bush Eccentric		10120	2	1
BMW	E36 3 Series Compact		PFF5-304	Anti Roll Bar Link Rod Bush		8000	2	3
BMW	E36 3 Series Compact		PFF5-310-23	Front Anti Roll Bar Mounting 23mm	23mm	7750	2	2
BMW	E36 3 Series Compact		PFF5-310-24	Front Anti Roll Bar Mounting 24mm	24mm	7750	2	2
BMW	E36 3 Series Compact		PFF5-310-25	Front Anti Roll Bar Mounting 25mm	25mm	7750	2	2
BMW	E36 3 Series Compact		PFF5-310-26	Front Anti Roll Bar Mounting 26mm	26mm	7750	2	2
BMW	E36 3 Series Compact		PFF5-310-27	Front Anti Roll Bar Mounting 27mm	27mm	7750	2	2
BMW	E36 3 Series Compact		PFF5-310-28	Front Anti Roll Bar Mounting 28mm	28mm	7750	2	2
BMW	E36 3 Series Compact		PFR5-300	Rear Diff Mounting Bush		6250	1	7
BMW	E36 3 Series Compact		PFR5-306	Rear Trailing Arm Bush		20240	4	5
BMW	E36 3 Series Compact		PFR5-306G	Rear Trailing Arm Bush Adjustable		28160	4	5
BMW	E36 3 Series Compact		PFR5-308-12	Rear Roll Bar Mounting Bush 12mm	12mm	7500	2	6
BMW	E36 3 Series Compact		PFR5-308-14	Rear Roll Bar Mounting Bush 14mm	14mm	7500	2	6
BMW	E36 3 Series Compact		PFR5-308-16	Rear Roll Bar Mounting Bush 16mm	16mm	7500	2	6
BMW	E36 3 Series Compact		PFR5-311	Rear Beam Bush		14520	2	4
BMW	E36 3 Series Compact		PFR5-5630-10	Rear Shock Top Mount Bracket and Bush 10mm	10mm	15620	2	30
BMW	E36 3 Series Compact		PFR5-5630-12	Rear Shock Top Mount Bracket and Bush 12mm	12mm	15620	2	30
BMW	E38 7 Series (1994 - 2002)		BS2003K	Bump Stop Kit	Front	7500	1	
BMW	E38 7 Series (1994 - 2002)		PFF5-1001	Front Upper Control Arm Bush		10340	2	1
BMW	E38 7 Series (1994 - 2002)		PFF5-1002	Front Lower Control Arm Bush		9680	2	2
BMW	E38 7 Series (1994 - 2002)		PFF5-503-205	Front Anti Roll Bar Mounting Bush 20.5mm	20.5mm	7500	2	3
BMW	E38 7 Series (1994 - 2002)		PFF5-503-225	Front Anti Roll Bar Mounting Bush 22.5mm	22.5mm	7500	2	3
BMW	E38 7 Series (1994 - 2002)		PFF5-503-24	Front Anti Roll Bar Mounting Bush 24mm	24mm	7500	2	3
BMW	E38 7 Series (1994 - 2002)		PFF5-503-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	7500	2	3
BMW	E38 7 Series (1994 - 2002)		PFF5-503-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	7500	2	3
BMW	E38 7 Series (1994 - 2002)		PFR5-1007-10	Rear Anti Roll Bar Mounting Bush 10mm	10mm	7500	2	7
BMW	E38 7 Series (1994 - 2002)		PFR5-524	Rear Diff Front Mounting Bush		5750	1	25
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	BS2003K	Bump Stop Kit	Front	7500	1	
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFF5-4602-23	Front Anti Roll Bar Bush 23mm	23mm	9250	2	3
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFF5-4602-24	Front Anti Roll Bar Bush 24mm	24mm	9250	2	3
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFF5-4602-25	Front Anti Roll Bar Bush 25mm	25mm	9250	2	3
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFF5-4602-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	9250	2	3
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFF5-503-225	Front Anti Roll Bar Mounting Bush 22.5mm	22.5mm	7500	2	3
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFF5-503-24	Front Anti Roll Bar Mounting Bush 24mm	24mm	7500	2	3
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFF5-503-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	7500	2	3
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFF5-503-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	7500	2	3
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFF5-510	Front Lower Tie Bar To Chassis Bush		10780	2	1
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFF5-511	Front Inner Track Control Arm Bush		9680	2	2
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFR5-504-13	Rear Anti Roll Bar Mounting Bush 13mm	13mm	7500	2	4
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFR5-504-14	Rear Anti Roll Bar Mounting Bush 14mm	14mm	7500	2	4
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFR5-504-15	Rear Roll Bar Mounting Bush 15mm	15mm	7500	2	4
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFR5-504-165	Rear Roll Bar Mounting Bush 16.5mm	16.5mm	7500	2	4
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFR5-520	Rear Subframe Front Mounting Bush		17600	2	20
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFR5-521	Rear Subframe Mounting Front Insert		9240	2	20
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFR5-522	Rear Subframe Rear Mounting Bush		17600	2	22
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFR5-523	Rear Subframe Rear Mounting Insert		9240	2	22
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFR5-524	Rear Diff Front Mounting Bush		5750	1	25
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFR5-525	Rear Diff Front Mounting Bush		5750	1	25
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFR5-526	Rear Diff Rear Mounting Bush		10560	2	26
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFR5-710-10	Rear Lower Arm Front Bush	10mm Bore Sleeve	10560	2	10
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFR5-711	Rear Lower Arm Rear Bush	14mm Bore Sleeve	11440	2	11
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFR5-711-12	Rear Lower Arm Rear Bush	12mm Bore Sleeve	11440	2	11
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFR5-712	Rear Upper Arm Inner Bush		12320	2	12
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFR5-713	Rear Toe Adjust Inner Bush		10120	2	13
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFR5-715	Rear Outer Integral Link Upper Bush		11440	2	15
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530	PFR5-716	Rear Outer Integral Link Lower Bush		9240	2	16
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530 Touring	BS2003K	Bump Stop Kit	Front	7500	1	
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530 Touring	PFF5-4602-23	Front Anti Roll Bar Bush 23mm	23mm	9250	2	3
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530 Touring	PFF5-4602-24	Front Anti Roll Bar Bush 24mm	24mm	9250	2	3
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530 Touring	PFF5-4602-25	Front Anti Roll Bar Bush 25mm	25mm	9250	2	3
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530 Touring	PFF5-4602-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	9250	2	3
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530 Touring	PFF5-503-225	Front Anti Roll Bar Mounting Bush 22.5mm	22.5mm	7500	2	3
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530 Touring	PFF5-503-24	Front Anti Roll Bar Mounting Bush 24mm	24mm	7500	2	3
BMW	E39 5 Series (1996 - 2004)	E39 5 Series 520 to 530 Touring	PFF5-503-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	7500	2	3

BMW	E46 3 SERIES (1999 – 2006)	E46 3 Series Xi/XD	PFR5-504-15	Rear Roll Bar Mounting Bush 15mm	15mm	7500	2	4
BMW	E46 3 SERIES (1999 – 2006)	E46 3 Series Xi/XD	PFR5-504-18	Rear Roll Bar Mounting Bush 18mm	18mm	7500	2	4
BMW	E46 3 SERIES (1999 – 2006)	E46 3 Series Xi/XD	PFR5-504-19	Rear Roll Bar Mounting Bush 19mm	19mm	7500	2	4
BMW	E46 3 SERIES (1999 – 2006)	E46 3 Series Xi/XD	PFR5-504-215	Rear Roll Bar Mounting Bush 21.5mm	21.5mm	7500	2	4
BMW	E46 3 SERIES (1999 – 2006)	E46 3 Series Xi/XD	PFR5-504-22.5	Rear Roll Bar Mounting Bush 22.5mm	22.5mm	7500	2	4
BMW	E46 3 SERIES (1999 – 2006)	E46 3 Series Xi/XD	PFR5-5630-10	Rear Shock Top Mount Bracket and Bush 10mm	10mm	15620	2	30
BMW	E46 3 SERIES (1999 – 2006)	E46 3 Series Xi/XD	PFR5-5630-12	Rear Shock Top Mount Bracket and Bush 12mm	12mm	15620	2	30
BMW	E53 X5 (1999-2006)		PFA100-16	PowerAlign Camber Bolt Kit (16mm)	16mm	4250	1	
BMW	E53 X5 (1999-2006)		PFF5-901	Front Lower Radius Arm To Chassis		14520	2	1
BMW	E53 X5 (1999-2006)		PFF5-902	Front Control Arm To Chassis		10560	2	2
BMW	E53 X5 (1999-2006)		PFF5-905-29	Front Anti Roll Bar To Chassis 29mm	29mm	10000	2	3
BMW	E53 X5 (1999-2006)		PFR5-4609-22	Rear Anti Roll Bar Mounting Bush 22mm	22mm	9250	2	5
BMW	E53 X5 (1999-2006)		PFR5-4609-23.5	Rear Anti Roll Bar Mounting Bush 23.5mm	23.5mm	9250	2	5
BMW	E53 X5 (1999-2006)		PFR5-710	Rear Lower Arm Front Bush	12mm Bore Sleeve	10560	2	10
BMW	E53 X5 (1999-2006)		PFR5-711	Rear Lower Arm Rear Bush	14mm Bore Sleeve	11440	2	11
BMW	E53 X5 (1999-2006)		PFR5-715	Rear Outer Integral Link Upper Bush		11440	2	15
BMW	E53 X5 (1999-2006)		PFR5-716	Rear Outer Integral Link Lower Bush		9240	2	16
BMW	E53 X5 (1999-2006)		PFR5-908	Rear Subframe To Chassis Bush		64900	4	4
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFF5-701	Front Radius Arm To Chassis Bush		13200	2	1
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFF5-702	Front Control Arm To Chassis Bush		10120	2	2
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFF5-703-24.6	Front Anti Roll Bar Mount 24.6mm	24.6mm	9750	2	3
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFF5-703-25	Front Anti Roll Bar Mount 25mm	25mm	9750	2	3
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFF5-703-25.6	Front Anti Roll Bar Mount 25.6mm	25.6mm	9750	2	3
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFR5-4609-13.5	Rear Anti Roll Bar Mount 13.5mm	13.5mm	9250	2	14
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFR5-4609-14	Rear Anti Roll Bar Mount 14mm	14mm	9250	2	14
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFR5-4609-14.5	Rear Anti Roll Bar Mount 14.5mm	14.5mm	9250	2	14
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFR5-4609-16	Rear Anti Roll Bar Mount 16mm	16mm	9250	2	14
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFR5-4609-18	Rear Anti Roll Bar Mount 18mm	18mm	9250	2	14
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFR5-710	Rear Lower Arm Front Bush	12mm Bore Sleeve	10560	2	10
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFR5-711	Rear Lower Arm Rear Bush	14mm Bore Sleeve	11440	2	11
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFR5-712	Rear Upper Arm Inner Bush		12320	2	12
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFR5-713	Rear Toe Adjust Inner Bush		10120	2	13
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFR5-715	Rear Outer Integral Link Upper Bush		11440	2	15
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFR5-716	Rear Outer Integral Link Lower Bush		9240	2	16
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFR5-720	Rear Subframe Front Mounting Bush		18920	2	20
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFR5-721	Rear Subframe Rear Mounting Insert		9680	2	21
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFR5-722	Rear Subframe Rear Mounting Bush		18920	2	21
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFR5-723	Rear Subframe Front Mounting Insert		9680	2	20
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFR5-725	Rear Diff Front Mounting Bush		9680	2	25
BMW	E60, E61 5 Series (2003-2010)	E60 5 Series, Saloon	PFR5-726	Rear Diff Rear Mounting Bush		8000	1	26
BMW	E60, E61 5 Series (2003-2010)	E61 5 Series, Touring	PFF5-701	Front Radius Arm To Chassis Bush		13200	2	1
BMW	E60, E61 5 Series (2003-2010)	E61 5 Series, Touring	PFF5-702	Front Control Arm To Chassis Bush		10120	2	2
BMW	E60, E61 5 Series (2003-2010)	E61 5 Series, Touring	PFF5-703-24.6	Front Anti Roll Bar Mount 24.6mm	24.6mm	9750	2	3
BMW	E60, E61 5 Series (2003-2010)	E61 5 Series, Touring	PFF5-703-25	Front Anti Roll Bar Mount 25mm	25mm	9750	2	3
BMW	E60, E61 5 Series (2003-2010)	E61 5 Series, Touring	PFF5-703-25.6	Front Anti Roll Bar Mount 25.6mm	25.6mm	9750	2	3
BMW	E60, E61 5 Series (2003-2010)	E61 5 Series, Touring	PFR5-4609-13.5	Rear Anti Roll Bar Mount 13.5mm	13.5mm	9250	2	14
BMW	E60, E61 5 Series (2003-2010)	E61 5 Series, Touring	PFR5-4609-14	Rear Anti Roll Bar Mount 14mm	14mm	9250	2	14
BMW	E60, E61 5 Series (2003-2010)	E61 5 Series, Touring	PFR5-4609-14.5	Rear Anti Roll Bar Mount 14.5mm	14.5mm	9250	2	14
BMW	E60, E61 5 Series (2003-2010)	E61 5 Series, Touring	PFR5-4609-16	Rear Anti Roll Bar Mount 16mm	16mm	9250	2	14
BMW	E60, E61 5 Series (2003-2010)	E61 5 Series, Touring	PFR5-4609-18	Rear Anti Roll Bar Mount 18mm	18mm	9250	2	14
BMW	E60, E61 5 Series (2003-2010)	E61 5 Series, Touring	PFR5-712	Rear Upper Arm Inner Bush		12320	2	12
BMW	E60, E61 5 Series (2003-2010)	E61 5 Series, Touring	PFR5-713	Rear Toe Adjust Inner Bush		10120	2	13
BMW	E60, E61 5 Series (2003-2010)	E61 5 Series, Touring	PFR5-715	Rear Outer Integral Link Upper Bush		11440	2	15
BMW	E60, E61 5 Series (2003-2010)	E61 5 Series, Touring	PFR5-716	Rear Outer Integral Link Lower Bush		9240	2	16
BMW	E60, E61 5 Series (2003-2010)	E61 5 Series, Touring	PFR5-720	Rear Subframe Front Mounting Bush		18920	2	20
BMW	E60, E61 5 Series (2003-2010)	E61 5 Series, Touring	PFR5-721	Rear Subframe Rear Mounting Insert		9680	2	21
BMW	E60, E61 5 Series (2003-2010)	E61 5 Series, Touring	PFR5-722	Rear Subframe Rear Mounting Bush		18920	2	21
BMW	E60, E61 5 Series (2003-2010)	E61 5 Series, Touring	PFR5-723	Rear Subframe Front Mounting Insert		9680	2	20
BMW	E60, E61 5 Series (2003-2010)	E61 5 Series, Touring	PFR5-725	Rear Diff Front Mounting Bush		9680	2	25
BMW	E60, E61 5 Series (2003-2010)	E61 5 Series, Touring	PFR5-726	Rear Diff Rear Mounting Bush		8000	1	26
BMW	E70 X5 (2006-2013)		PFF5-1401	Front Radius Arm To Chassis Bush		15840	2	1
BMW	E70 X5 (2006-2013)		PFF5-1403-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	10000	2	3
BMW	E70 X5 (2006-2013)		PFF5-1404	Front Anti Roll Bar Mounting Bush		9000	2	3
BMW	E70 X5 (2006-2013)		PFR5-1413-22	Rear Anti Roll Bar Mounting Bush 22mm	22mm	9250	2	13
BMW	E70 X5 (2006-2013)		PFR5-1413-24	Rear Anti Roll Bar Mounting Bush 24mm	24mm	9250	2	13
BMW	E70 X5 (2006-2013)		PFR5-1414	Rear Anti Roll Bar Mounting Bush		9000	2	14
BMW	E70 X5 (2006-2013)		PFR5-1421	Rear Subframe Front Bush Insert		10780	2	21
BMW	E70 X5 (2006-2013)		PFR5-1423	Rear Subframe Rear Bush Insert		10780	2	23
BMW	E71 X6 (2007-)		PFF5-1401	Front Radius Arm To Chassis Bush		15840	2	1
BMW	E71 X6 (2007-)		PFF5-1403-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	10000	2	3
BMW	E71 X6 (2007-)		PFF5-1404	Front Anti Roll Bar Mounting Bush		9000	2	3
BMW	E71 X6 (2007-)		PFR5-1413-22	Rear Anti Roll Bar Mounting Bush 22mm	22mm	9250	2	13
BMW	E71 X6 (2007-)		PFR5-1413-24	Rear Anti Roll Bar Mounting Bush 24mm	24mm	9250	2	13
BMW	E71 X6 (2007-)		PFR5-1414	Rear Anti Roll Bar Mounting Bush		9000	2	14
BMW	E71 X6 (2007-)		PFR5-1421	Rear Subframe Front Bush Insert		10780	2	21
BMW	E71 X6 (2007-)		PFR5-1423	Rear Subframe Rear Bush Insert		10780	2	23
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	E81, E82, E87 & E88 1 Series (2004-2013)	PFF5-401	Front Radius Arm To Chassis Bush		13860	2	1

BMW	F15 X5 (2013-)		PFF5-1403-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	10000	2	3
BMW	F15 X5 (2013-)		PFF5-1404	Front Anti Roll Bar Mounting Bush		9000	2	3
BMW	F15 X5 (2013-)		PFR5-1413-24	Rear Anti Roll Bar Mounting Bush 24mm	24mm	9250	2	13
BMW	F15 X5 (2013-)		PFR5-1414	Rear Anti Roll Bar Mounting Bush		9000	2	14
BMW	F15 X5 (2013-)		PFR5-1421	Rear Subframe Front Bush Insert		10780	2	21
BMW	F15 X5 (2013-)		PFR5-1423	Rear Subframe Rear Bush Insert		10780	2	23
BMW	Mini Generation 1		BS009K	Universal Bump Stop and Cover Kit		7750	1	
BMW	Mini Generation 1		PFF5-101	Front Wishbone Rear Bush		10780	2	1
BMW	Mini Generation 1		PFF5-101MS	PFF5-101 Support Kit		3080	2	1
BMW	Mini Generation 1		PFF5-102-16	Front Anti Roll Bar Bush 16mm	16mm	7500	2	2
BMW	Mini Generation 1		PFF5-102-225	Front Anti Roll Bar Bush 22.5mm	22.5mm	7500	2	2
BMW	Mini Generation 1		PFF5-102-24	Front Anti Roll Bar Bush 24mm	24mm	7500	2	2
BMW	Mini Generation 1		PFF5-103	Steering Rack Mount		3750	1	3
BMW	Mini Generation 1		PFF5-104	Engine Support Bracket Small Mount		3750	1	4
BMW	Mini Generation 1		PFF5-104	Engine Support Bracket Small		3750	1	6
BMW	Mini Generation 1		PFF5-105	Upper Engine Mount Large Bush Insert		4500	1	5
BMW	Mini Generation 1		PFF5-107	Lower Engine Mount Large Bush Insert		4500	1	7
BMW	Mini Generation 1		PFF5-108	Gearbox Mounting Bush Insert		4500	1	8
BMW	Mini Generation 1		PFF5-120	Lower Engine Mount Large Bush		8000	1	7
BMW	Mini Generation 1		PFF5-211	Super Charger Belt Damper Bushes		4620	2	12
BMW	Mini Generation 1		PFR5-109	Rear Control Arm Bushes		34540	8	9
BMW	Mini Generation 1		PFR5-110	Rear Trailing Arm Front Bush Inserts		7700	2	10
BMW	Mini Generation 1		PFR5-1102	Rear Trailing Arm Front Bush Inserts		9240	2	10
BMW	Mini Generation 1		PFR5-1104	Rear Trailing Arm Front Bush		14740	2	10
BMW	Mini Generation 1		PFR5-1105	Rear Trailing Arm Front Bush		14960	2	10
BMW	Mini Generation 1		PFR5-111-16	Rear Anti Roll Bar Bush 16mm	16mm	5750	2	11
BMW	Mini Generation 1		PFR5-111-17	Rear Anti Roll Bar Bush 17mm	17mm	5750	2	11
BMW	Mini Generation 1		PFR5-111-18	Rear Anti Roll Bar Bush 18mm	18mm	5750	2	11
BMW	Mini Generation 1		PFR5-115	Rear Shock Top Mounting Bush		8800	2	15
BMW	Mini Generation 2		BS009K	Universal Bump Stop and Cover Kit		7750	1	
BMW	Mini Generation 2		PFF5-102-225	Front Anti Roll Bar Bush 22.5mm	22.5mm	7500	2	2
BMW	Mini Generation 2		PFF5-102-24	Front Anti Roll Bar Bush 24mm	24mm	7500	2	2
BMW	Mini Generation 2		PFF5-201	Front Wishbone Rear Bush		10780	2	1
BMW	Mini Generation 2		PFF5-206	Lower Engine Mount Small Bush		4750	1	6
BMW	Mini Generation 2		PFF5-207	Lower Engine Mount Large Bush Insert		5250	1	7
BMW	Mini Generation 2		PFR5-109	Rear Control Arm Bush		34540	8	9
BMW	Mini Generation 2		PFR5-1102	Rear Trailing Arm Front Bush Inserts		9240	2	10
BMW	Mini Generation 2		PFR5-1103	Rear Trailing Arm Front Bush		14740	2	10
BMW	Mini Generation 2		PFR5-111-16	Rear Anti Roll Bar Bush 16mm	16mm	5750	2	11
BMW	Mini Generation 2		PFR5-111-17	Rear Anti Roll Bar Bush 17mm	17mm	5750	2	11
BMW	Mini Generation 2		PFR5-111-18	Rear Anti Roll Bar Bush 18mm	18mm	5750	2	11
BMW	Mini Generation 2		PFR5-115	Rear Shock Top Mounting Bush		8800	2	15
BMW	Mini Generation 3 (F56)		PFF5-1301	Front Arm Front Bush		11000	2	1
BMW	Mini Generation 3 (F56)		PFF5-1301G	Front Arm Front Bush Camber Adjustable		22880	2	1
BMW	Mini Generation 3 (F56)		PFF5-1302	Front Arm Rear Bush		16720	2	2
BMW	Mini Generation 3 (F56)		PFF5-1303-24.5	Front Anti Roll Bar Bush 24.5mm	24.5mm	9750	2	3
BMW	Mini Generation 3 (F56)		PFF5-1320	Lower Engine Mount Large Bush		8750	1	20
BMW	Mini Generation 3 (F56)		PFR5-1310	Rear Trailing Arm Front Bush		11440	2	10
BMW	Mini Generation 3 (F56)		PFR5-1311	Rear Lower Lateral Arm Outer Bush		12320	2	11
BMW	Mini Generation 3 (F56)		PFR5-1313	Rear Lateral Arm Inner Bush		23320	4	13
BMW	Mini Generation 3 (F56)		PFR5-1314-21.4	Rear Anti Roll Bar Bush 21.4mm	21.4mm	8000	2	14
BMW	Mini Generation 3 (F56)		PFR5-1315	Rear Anti Roll Bar Link Rod Bush		7500	2	15
BMW	Z1 (1988 - 1991)		PFF5-301	Front Lower Wishbone Rear Bush		8580	2	1
BMW	Z1 (1988 - 1991)		PFF5-302-21	Front Anti Roll Bar Bush 21mm	21mm	7500	2	2
BMW	Z1 (1988 - 1991)		PFF5-303	Front Lower Wishbone Rear Bush Eccentric		10120	2	1
BMW	Z1 (1988 - 1991)		PFF5-304	Anti Roll Bar Link Rod Bush		8000	2	3
BMW	Z1 (1988 - 1991)		PFR5-308-14	Rear Roll Bar Mounting Bush 14mm	14mm	7500	2	6
BMW	Z3 (1994 - 2002)		PFF5-301	Front Lower Wishbone Rear Bush		8580	2	1
BMW	Z3 (1994 - 2002)		PFF5-303	Front Lower Wishbone Rear Bush Eccentric		10120	2	1
BMW	Z3 (1994 - 2002)		PFF5-304	Anti Roll Bar Link Rod Bush		8000	2	3
BMW	Z3 (1994 - 2002)		PFF5-310-23	Front Anti Roll Bar Mounting 23mm	23mm	7750	2	2
BMW	Z3 (1994 - 2002)		PFF5-310-24	Front Anti Roll Bar Mounting 24mm	24mm	7750	2	2
BMW	Z3 (1994 - 2002)		PFF5-310-25	Front Anti Roll Bar Mounting 25mm	25mm	7750	2	2
BMW	Z3 (1994 - 2002)		PFF5-310-26	Front Anti Roll Bar Mounting 26mm	26mm	7750	2	2
BMW	Z3 (1994 - 2002)		PFF5-310-27	Front Anti Roll Bar Mounting 27mm	27mm	7750	2	2
BMW	Z3 (1994 - 2002)		PFF5-310-28	Front Anti Roll Bar Mounting 28mm	28mm	7750	2	2
BMW	Z3 (1994 - 2002)		PFR5-300	Rear Diff Mounting Bush		6250	1	7
BMW	Z3 (1994 - 2002)		PFR5-306	Rear Trailing Arm Bush		20240	4	5
BMW	Z3 (1994 - 2002)		PFR5-306G	Rear Trailing Arm Bush Adjustable		28160	4	5
BMW	Z3 (1994 - 2002)		PFR5-311	Rear Beam Bush		14520	2	4
BMW	Z3 (1994 - 2002)		PFR5-504-14	Rear Anti Roll Bar Bush 14mm	14mm	7500	2	6
BMW	Z3 (1994 - 2002)		PFR5-504-15	Rear Roll Bar Mounting Bush 15mm	15mm	7500	2	6
BMW	Z3 (1994 - 2002)		PFR5-504-16	Rear Anti Roll Bar Bush 16mm	16mm	7500	2	6
BMW	Z3 (1994 - 2002)		PFR5-504-17	Rear Anti Roll Bar Bush 17mm	17mm	7500	2	6
BMW	Z3 (1994 - 2002)		PFR5-504-18	Rear Anti Roll Bar Bush 18mm	18mm	7500	2	6
BMW	Z3 (1994 - 2002)		PFR5-5630-10	Rear Shock Top Mount Bracket and Bush 10mm	10mm	15620	2	30
BMW	Z3 (1994 - 2002)		PFR5-5630-12	Rear Shock Top Mount Bracket and Bush 12mm	12mm	15620	2	30

BMW	Z4 (E85 & E86)		PFF5-4601	Front Wishbone Rear Bush	66mm	10780	2	1
BMW	Z4 (E85 & E86)		PFF5-4601-60	Front Wishbone Rear Bush	60mm	10780	2	1
BMW	Z4 (E85 & E86)		PFF5-4602-24	Front Anti Roll Bar Bush 24mm	24mm	9250	2	2
BMW	Z4 (E85 & E86)		PFF5-4602-25	Front Anti Roll Bar Bush 25mm	25mm	9250	2	2
BMW	Z4 (E85 & E86)		PFF5-4602-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	9250	2	2
BMW	Z4 (E85 & E86)		PFF5-5601	Front Wishbone Rear Bush, Aluminium Outer	66mm	25740	2	1
BMW	Z4 (E85 & E86)		PFF5-5601-60	Front Wishbone Rear Bush, Aluminium Outer	60mm	25740	2	1
BMW	Z4 (E85 & E86)		PFF5-5601G	Front Wishbone Rear Bush, Caster Adjust	66mm	26400	2	1
BMW	Z4 (E85 & E86)		PFF5-5601G-60	Front Wishbone Rear Bush, Caster Adjust	60mm	26400	2	1
BMW	Z4 (E85 & E86)		PFR5-3608	Rear Trailing Arm Bush		9680	2	3
BMW	Z4 (E85 & E86)		PFR5-4609-22.5	Rear Roll Bar Mounting Bush 22.5mm	22.5mm	9250	2	4
BMW	Z4 (E85 & E86)		PFR5-4611	Rear Subframe Rear Bush		16060	2	11
BMW	Z4 (E85 & E86)		PFR5-4621	Rear Diff Front Mount		5500	1	21
BMW	Z4 (E85 & E86)		PFR5-504-18	Rear Roll Bar Mounting Bush	18mm	7500	2	4
BMW	Z4 (E85 & E86)		PFR5-504-19	Rear Roll Bar Mounting Bush	19mm	7500	2	4
BMW	Z4 (E85 & E86)		PFR5-5630-10	Rear Shock Top Mount Bracket and Bush 10mm	10mm	15620	2	30
BMW	Z4 (E85 & E86)		PFR5-5630-12	Rear Shock Top Mount Bracket and Bush 12mm	12mm	15620	2	30