

Make	Model	Part Number	Product Description	Bush Size	入数	SET価格	Diag Ref
BMW	02 Series 1502-2002 (1962 - 1977)	PFF5-2001	Front Lower Arm Inner Bush		2	11000	1
BMW	02 Series 1502-2002 (1962 - 1977)	PFF5-2002	Front Lower Arm Outer Bush		2	11000	2
BMW	02 Series 1502-2002 (1962 - 1977)	PFF5-2003-15	Anti Roll Bar Bush 15mm	15mm	2	7000	3
BMW	02 Series 1502-2002 (1962 - 1977)	PFF5-2003-16	Anti Roll Bar Bush 16mm	16mm	2	7000	3
BMW	02 Series 1502-2002 (1962 - 1977)	PFF5-2004	Anti Roll Bar Link Rod Bush		2	11500	4
BMW	02 Series 1502-2002 (1962 - 1977)	PFF5-2005	Tie Bar To Chassis Front Bush		2	12000	5
BMW	02 Series 1502-2002 (1962 - 1977)	PFR5-2020	Rear Beam Mount Bush Inserts		2	10500	20
BMW	02 Series 1502-2002 (1962 - 1977)	PFR5-2021	Rear Beam Mount Bush		2	15500	20
BMW	02 Series 1502-2002 (1962 - 1977)	PFR5-2025	Rear Diff Rear Mounting Bush		2	12000	25
BMW	02 Series 1502-2002 (1962 - 1977)	PFR5-306	Rear Trailing Arm Bush		4	25000	6
BMW	02 Series 1502-2002 (1962 - 1977)	PFR5-306G	Rear Trailing Arm Bush Adjustable		4	34000	6
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFF5-401	Front Radius Arm To Chassis Bush		2	17000	1
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFF5-402	Front Control Arm To Chassis Bush		2	30000	2
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFF5-4602-26.5	Front Anti Roll Bar Mounting Bush 26.5mm	26.5mm	2	9500	3
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-1220	Rear Subframe, Front Bush		2	30500	19
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-411	Rear Upper Control Arm To Chassis Bush		2	16500	11c
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-411	Rear Trailing Arm Inner & Outer Bush		4	33000	11b
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-411	Rear Toe Adjust Arm Inner & Outer Bush		4	33000	11a
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-412	Rear Upper Control Arm To Hub Bush		2	17000	12a
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-412	Rear Upper Lateral Arm To Hub Bush		2	17000	12b
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-413	Rear Upper Lateral Arm To Chassis Bush		2	22500	13
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-414	Rear Lower Lateral Arm To Hub Bush		2	22500	14
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-415	Rear Lower Lateral Arm To Chassis Bush		2	14000	15
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-416	Rear Shock Absorber Upper Mounting Bush	10mm	2	11000	16
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-416-12	Rear Shock Absorber Upper Mounting Bush 12mm	12mm	2	11000	16
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-419	Rear Subframe Front Mount Insert		2	12500	19
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-420	Rear Subframe Front Mounting Bush		2	28000	19
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-421	Rear Subframe Rear Mounting Insert		2	12500	20
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-422	Rear Subframe Rear Mounting Bush		2	24000	20
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-423	Rear Subframe Rear Mounting Insert		2	12500	20
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-425	Rear Diff Front Mounting Bush		2	14500	25
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-426	Rear Diff Rear Mounting Bush		1	7500	26
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-4609-11	Rear Anti Roll Bar Mounting Bush 11mm	11mm	2	9500	10
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-4609-12	Rear Anti Roll Bar Mounting Bush 12mm	12mm	2	9500	10
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-4609-13	Rear Anti Roll Bar Mounting Bush 13mm	13mm	2	9500	10
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-4609-14	Rear Anti Roll Bar Mounting Bush 14mm	14mm	2	9500	10
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-4609-15	Rear Anti Roll Bar Mounting Bush 15mm	15mm	2	9500	10
BMW	E82 1 Series M Coupe (2010-2012)	PFF5-1203-26.5	Front Anti Roll Bar Bush 26.5mm	26.5mm	2	9000	3
BMW	E82 1 Series M Coupe (2010-2012)	PFF5-1203-28	Front Anti Roll Bar Bush 28mm	28mm	2	9000	3
BMW	E82 1 Series M Coupe (2010-2012)	PFF5-401	Front Radius Arm To Chassis Bush		2	17000	1
BMW	E82 1 Series M Coupe (2010-2012)	PFR5-1210-22.5	Rear Anti Roll Bar Bush 22.5mm	22.5mm	2	9000	10
BMW	E82 1 Series M Coupe (2010-2012)	PFR5-1210-23.6	Rear Anti Roll Bar Bush 23.6mm	23.6mm	2	9000	10
BMW	E82 1 Series M Coupe (2010-2012)	PFR5-1212	Rear Upper Arm Outer Bush		4	32000	12
BMW	E82 1 Series M Coupe (2010-2012)	PFR5-1213	Rear Lower Front Arm Inner Bush		2	13500	13
BMW	E82 1 Series M Coupe (2010-2012)	PFR5-1215	Rear Lower Lateral Arm Inner Bush		2	21500	15
BMW	E82 1 Series M Coupe (2010-2012)	PFR5-1220	Rear Subframe, Front Bush		2	30500	19
BMW	E82 1 Series M Coupe (2010-2012)	PFR5-1226	Rear Diff Rear Mounting Bush		1	7250	26
BMW	E82 1 Series M Coupe (2010-2012)	PFR5-411	Rear Trailing Arm Outer Bush		2	16500	11
BMW	E82 1 Series M Coupe (2010-2012)	PFR5-422P	Rear Subframe Rear Mounting Bush		2	26500	20
BMW	E82 1 Series M Coupe (2010-2012)	PFR5-425	Rear Diff Front Mounting Bush		2	14500	25
BMW	F20, F21 1 Series	PFF5-1901	Front Radius Arm To Chassis Bush		2	19500	1
BMW	F20, F21 1 Series	PFF5-1901G	Front Radius Arm To Chassis Bush Caster Adjustable		2	23500	1
BMW	F20, F21 1 Series	PFF5-1902	Front Control Arm To Chassis Bush		2	15500	2
BMW	F20, F21 1 Series	PFF5-1902G	Front Control Arm to Chassis Bush - Camber Adjustable		2	21000	2
BMW	F20, F21 1 Series	PFF5-1903-24	Front Anti Roll Bar Bush 24mm	24mm	2	9500	3
BMW	F20, F21 1 Series	PFF5-1903-25	Front Anti Roll Bar Bush 25mm	25mm	2	9500	3
BMW	F20, F21 1 Series	PFR5-1913-12	Rear Anti Roll Bar Bush 12mm	12mm	2	8500	13
BMW	F20, F21 1 Series	PFR5-1913-13	Rear Anti Roll Bar Bush 13mm	13mm	2	8500	13

BMW	F20, F21 1 Series	PFR5-1920	Rear Subframe Front Bush Insert		2	11500	20
BMW	F20, F21 1 Series	PFR5-1921	Rear Subframe Rear Bush Insert		2	11500	21
BMW	F20, F21 1 Series	PFR5-1927	Rear Diff Front Bush Insert		2	10000	27
BMW	F20, F21 1 Series xDrive	PFF5-1903-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	9500	3
BMW	F20, F21 1 Series xDrive	PFF5-1903-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	9500	3
BMW	F20, F21 1 Series xDrive	PFF5-4101	Front Radius Arm To Chassis Bush		2	19500	1
BMW	F20, F21 1 Series xDrive	PFF5-4102	Front Control Arm To Chassis Bush		2	15500	2
BMW	F20, F21 1 Series xDrive	PFR5-1913-12	Rear Anti Roll Bar Bush 12mm	12mm	2	8500	13
BMW	F20, F21 1 Series xDrive	PFR5-1913-13	Rear Anti Roll Bar Bush 13mm	13mm	2	8500	13
BMW	F20, F21 1 Series xDrive	PFR5-1920	Rear Subframe Front Bush Insert		2	11500	20
BMW	F20, F21 1 Series xDrive	PFR5-1921	Rear Subframe Rear Bush Insert		2	11500	21
BMW	F20, F21 1 Series xDrive	PFR5-1927	Rear Diff Front Bush Insert		2	10000	27
BMW	F22, F23 2 Series	PFF5-1901	Front Radius Arm To Chassis Bush		2	19500	1
BMW	F22, F23 2 Series	PFF5-1901G	Front Radius Arm To Chassis Bush Caster Adjustable		2	23500	1
BMW	F22, F23 2 Series	PFF5-1902	Front Control Arm To Chassis Bush		2	15500	2
BMW	F22, F23 2 Series	PFF5-1902G	Front Control Arm to Chassis Bush - Camber Adjustable		2	21000	2
BMW	F22, F23 2 Series	PFF5-1903-24	Front Anti Roll Bar Bush 24mm	24mm	2	9500	3
BMW	F22, F23 2 Series	PFF5-1903-25	Front Anti Roll Bar Bush 25mm	25mm	2	9500	3
BMW	F22, F23 2 Series	PFR5-1913-12	Rear Anti Roll Bar Bush 12mm	12mm	2	8500	13
BMW	F22, F23 2 Series	PFR5-1913-13	Rear Anti Roll Bar Bush 13mm	13mm	2	8500	13
BMW	F22, F23 2 Series	PFR5-1920	Rear Subframe Front Bush Insert		2	11500	20
BMW	F22, F23 2 Series	PFR5-1921	Rear Subframe Rear Bush Insert		2	11500	21
BMW	F22, F23 2 Series	PFR5-1927	Rear Diff Front Bush Insert		2	10000	27
BMW	F22, F23 2 Series xDrive	PFF5-1903-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	9500	3
BMW	F22, F23 2 Series xDrive	PFF5-4101	Front Radius Arm To Chassis Bush		2	19500	1
BMW	F22, F23 2 Series xDrive	PFF5-4102	Front Control Arm To Chassis Bush		2	15500	2
BMW	F22, F23 2 Series xDrive	PFR5-1913-12	Rear Anti Roll Bar Bush 12mm	12mm	2	8500	13
BMW	F22, F23 2 Series xDrive	PFR5-1913-13	Rear Anti Roll Bar Bush 13mm	13mm	2	8500	13
BMW	F22, F23 2 Series xDrive	PFR5-1920	Rear Subframe Front Bush Insert		2	11500	20
BMW	F22, F23 2 Series xDrive	PFR5-1921	Rear Subframe Rear Bush Insert		2	11500	21
BMW	F22, F23 2 Series xDrive	PFR5-1927	Rear Diff Front Bush Insert		2	10000	27
BMW	F87 2 Series M2	PFF5-1203-26.5	Front Anti Roll Bar Bush 26.5mm	26.5mm	2	9000	3
BMW	F87 2 Series M2	PFF5-1203-28	Front Anti Roll Bar Bush 28mm	28mm	2	9000	3
BMW	F87 2 Series M2	PFF5-4001	Front Radius Arm To Chassis Bush		2	19500	1
BMW	F87 2 Series M2	PFF5-4001G	Front Radius Arm To Chassis BushCaster Offset		2	21000	1
BMW	F87 2 Series M2	PFR5-4025	Rear Diff Front Mounting Bush		4	47000	21
BMW	F87 2 Series M2	PFR5-4026	Rear Diff Rear Mounting Bush		1	15500	22
BMW	E21 3 Series (1975 - 1978)	PFF5-1601	Front Arm Inner Bush		2	11000	1
BMW	E21 3 Series (1975 - 1978)	PFF5-1603-22	Front Anti Roll Bar Bush 22mm	22mm	2	7000	3
BMW	E21 3 Series (1975 - 1978)	PFF5-1603-23.5	Front Anti Roll Bar Bush 23.5mm	23.5mm	2	7000	3
BMW	E21 3 Series (1975 - 1978)	PFF5-1702	Front Arm Outer Bush		2	10500	2
BMW	E21 3 Series (1975 - 1978)	PFR5-1610-16	Rear Anti Roll Bar Bush 16mm	16mm	2	7000	10
BMW	E21 3 Series (1975 - 1978)	PFR5-1611	Rear Anti Roll Bar Link Rod Bush		2	10500	11
BMW	E21 3 Series (1975 - 1978)	PFR5-1620	Rear Axle Carrier Mount Bush		2	14500	20
BMW	E21 3 Series (1975 - 1978)	PFR5-1625	Rear Diff Mounting Bush		2	12000	25
BMW	E21 3 Series (1975 - 1978)	PFR5-306	Rear Trailing Arm Bush		4	25000	5
BMW	E21 3 Series (1975 - 1978)	PFR5-306G	Rear Trailing Arm Bush Adjustable		4	34000	5
BMW	E21 3 Series (1978 - 1983)	PFF5-1601	Front Arm Inner Bush		2	11000	1
BMW	E21 3 Series (1978 - 1983)	PFF5-1602	Front Arm Outer Bush		2	13500	2
BMW	E21 3 Series (1978 - 1983)	PFF5-1603-22	Front Anti Roll Bar Bush 22mm	22mm	2	7000	3
BMW	E21 3 Series (1978 - 1983)	PFF5-1603-23.5	Front Anti Roll Bar Bush 23.5mm	23.5mm	2	7000	3
BMW	E21 3 Series (1978 - 1983)	PFR5-1610-16	Rear Anti Roll Bar Bush 16mm	16mm	2	7000	10
BMW	E21 3 Series (1978 - 1983)	PFR5-1611	Rear Anti Roll Bar Link Rod Bush		2	10500	11
BMW	E21 3 Series (1978 - 1983)	PFR5-1620	Rear Axle Carrier Mount Bush		2	14500	20
BMW	E21 3 Series (1978 - 1983)	PFR5-1625	Rear Diff Mounting Bush		2	12000	25
BMW	E21 3 Series (1978 - 1983)	PFR5-306	Rear Trailing Arm Bush		4	25000	5
BMW	E21 3 Series (1978 - 1983)	PFR5-306G	Rear Trailing Arm Bush Adjustable		4	34000	5
BMW	E30 3 Series (1982 - 1991)	PF5K-1001	Powerflex Handling Pack		1	57750	
BMW	E30 3 Series (1982 - 1991)	PFF5-301	Front Lower Wishbone Rear Bush		2	10500	1

BMW	E30 3 Series (1982 - 1991)	PFF5-302-19	Front Anti Roll Bar Bush 19mm	19mm	2	7500	2
BMW	E30 3 Series (1982 - 1991)	PFF5-302-20	Front Anti Roll Bar Bush 20mm	20mm	2	7500	2
BMW	E30 3 Series (1982 - 1991)	PFF5-302-21	Front Anti Roll Bar Bush 21mm	21mm	2	7500	2
BMW	E30 3 Series (1982 - 1991)	PFF5-302-22	Front Anti Roll Bar Bush 22mm	22mm	2	7500	2
BMW	E30 3 Series (1982 - 1991)	PFF5-302-24	Front Anti Roll Bar Bush 24mm	24mm	2	7500	2
BMW	E30 3 Series (1982 - 1991)	PFF5-303	Front Lower Wishbone Rear Bush Caster Offset		2	12500	1
BMW	E30 3 Series (1982 - 1991)	PFF5-304	Anti Roll Bar Link Rod Bush		2	8500	3
BMW	E30 3 Series (1982 - 1991)	PFR5-300	Rear Diff Mounting Bush		1	6500	7
BMW	E30 3 Series (1982 - 1991)	PFR5-305	Rear Beam Mounting Bush		2	17500	4
BMW	E30 3 Series (1982 - 1991)	PFR5-306	Rear Trailing Arm Bush		4	25000	5
BMW	E30 3 Series (1982 - 1991)	PFR5-306G	Rear Trailing Arm Bush Adjustable		4	34000	5
BMW	E30 3 Series (1982 - 1991)	PFR5-308-12	Rear Roll Bar Mounting Bush 12mm	12mm	2	7500	6
BMW	E30 3 Series (1982 - 1991)	PFR5-308-13	Rear Anti Roll Bar Mounting Bush 13mm		2	7500	6
BMW	E30 3 Series (1982 - 1991)	PFR5-308-14	Rear Roll Bar Mounting Bush 14mm	14mm	2	7500	6
BMW	E30 3 Series (1982 - 1991)	PFR5-308-15.5	Rear Anti Roll Bar Mounting Bush 15.5mm	15.5mm	2	7500	6
BMW	E30 3 Series (1982 - 1991)	PFR5-308-16	Rear Roll Bar Mounting Bush 16mm	16mm	2	7500	6
BMW	E30 3 Series (1982 - 1991)	PFR5-308-18	Rear Roll Bar Mounting Bush 18mm	18mm	2	7500	6
BMW	E30 3 Series (1982 - 1991)	PFR5-315	Rear Anti Roll Bar Link To Arm Bush		2	7000	15
BMW	E30 3 Series (1982 - 1991)	PFR5-316	Rear Anti Roll Bar Link To Anti Roll Bar Bush		2	6500	16
BMW	E30 3 Series (1982 - 1991)	PFR5-5630-10	Rear Shock Top Mount Bracket and Bush 10mm	10mm	2	18500	30
BMW	E30 3 Series (1982 - 1991)	PFR5-5630-12	Rear Shock Top Mount Bracket and Bush 12mm	12mm	2	18500	30
BMW	E36 3 Series (1990 - 1998)	PF5K-1002	Powerflex Handling Pack		1	53750	
BMW	E36 3 Series (1990 - 1998)	PFF5-301	Front Lower Wishbone Rear Bush		2	10500	1
BMW	E36 3 Series (1990 - 1998)	PFF5-303	Front Lower Wishbone Rear Bush Caster Offset		2	12500	1
BMW	E36 3 Series (1990 - 1998)	PFF5-304	Anti Roll Bar Link Rod Bush		2	8500	3
BMW	E36 3 Series (1990 - 1998)	PFF5-310-23	Front Anti Roll Bar Mounting 23mm	23mm	2	8500	2
BMW	E36 3 Series (1990 - 1998)	PFF5-310-24	Front Anti Roll Bar Mounting 24mm	24mm	2	8000	2
BMW	E36 3 Series (1990 - 1998)	PFF5-310-25	Front Anti Roll Bar Mounting 25mm	25mm	2	8000	2
BMW	E36 3 Series (1990 - 1998)	PFF5-310-26	Front Anti Roll Bar Mounting 26mm	26mm	2	8000	2
BMW	E36 3 Series (1990 - 1998)	PFF5-310-27	Front Anti Roll Bar Mounting 27mm	27mm	2	8000	2
BMW	E36 3 Series (1990 - 1998)	PFF5-310-28	Front Anti Roll Bar Mounting 28mm	28mm	2	8000	2
BMW	E36 3 Series (1990 - 1998)	PFR5-315	Rear Anti Roll Bar Link To Arm Bush		2	7000	15
BMW	E36 3 Series (1990 - 1998)	PFR5-316	Rear Anti Roll Bar Link To Anti Roll Bar Bush		2	6500	16
BMW	E36 3 Series (1990 - 1998)	PFR5-324	Rear Diff Front Mounting Bush, M3 Evo Only		1	7000	25
BMW	E36 3 Series (1990 - 1998)	PFR5-325	Rear Diff Front Mounting Bush		1	6000	25
BMW	E36 3 Series (1990 - 1998)	PFR5-326	Rear Diff Rear Mounting Bush		2	19000	26
BMW	E36 3 Series (1990 - 1998)	PFR5-3606	Rear Subframe Rear Mounting Bush		2	15500	7
BMW	E36 3 Series (1990 - 1998)	PFR5-3607	Rear Subframe Front Mounting Bush		2	15500	6
BMW	E36 3 Series (1990 - 1998)	PFR5-3608	Rear Trailing Arm Front Bush		2	13500	8
BMW	E36 3 Series (1990 - 1998)	PFR5-3616	Rear Subframe Rear Mounting Bush Insert		2	11500	7
BMW	E36 3 Series (1990 - 1998)	PFR5-3617	Rear Subframe Front Mounting Bush Insert		2	11500	6
BMW	E36 3 Series (1990 - 1998)	PFR5-4615G	Adjustable Rear Lower Control Arm Kit		1	31250	19
BMW	E36 3 Series (1990 - 1998)	PFR5-4616	Rear lower Control Arm Inner Bush		2	16000	19
BMW	E36 3 Series (1990 - 1998)	PFR5-4617	Rear Upper Arm Inner Bush		2	11000	17
BMW	E36 3 Series (1990 - 1998)	PFR5-4618	Rear Lower Arm Outer Bush		2	12000	18
BMW	E36 3 Series (1990 - 1998)	PFR5-504-15	Rear Roll Bar Mounting Bush 15mm	15mm	2	7500	5
BMW	E36 3 Series (1990 - 1998)	PFR5-504-18	Rear Roll Bar Mounting Bush 18mm	18mm	2	7500	5
BMW	E36 3 Series (1990 - 1998)	PFR5-504-19	Rear Roll Bar Mounting Bush 19mm	19mm	2	7500	5
BMW	E36 3 Series (1990 - 1998)	PFR5-504-20	Rear Roll Bar Mounting Bush 20mm	20mm	2	7500	5
BMW	E36 3 Series (1990 - 1998)	PFR5-5630-10	Rear Shock Top Mount Bracket and Bush 10mm	10mm	2	18500	30
BMW	E36 3 Series (1990 - 1998)	PFR5-5630-12	Rear Shock Top Mount Bracket and Bush 12mm	12mm	2	18500	30
BMW	E36 3 Series Compact (1993-2000)	PFF5-301	Front Lower Wishbone Rear Bush		2	10500	1
BMW	E36 3 Series Compact (1993-2000)	PFF5-303	Front Lower Wishbone Rear Bush Caster Offset		2	12500	1
BMW	E36 3 Series Compact (1993-2000)	PFF5-304	Anti Roll Bar Link Rod Bush		2	8500	3
BMW	E36 3 Series Compact (1993-2000)	PFF5-310-23	Front Anti Roll Bar Mounting 23mm	23mm	2	8500	2
BMW	E36 3 Series Compact (1993-2000)	PFF5-310-24	Front Anti Roll Bar Mounting 24mm	24mm	2	8000	2
BMW	E36 3 Series Compact (1993-2000)	PFF5-310-25	Front Anti Roll Bar Mounting 25mm	25mm	2	8000	2
BMW	E36 3 Series Compact (1993-2000)	PFF5-310-26	Front Anti Roll Bar Mounting 26mm	26mm	2	8000	2
BMW	E36 3 Series Compact (1993-2000)	PFF5-310-27	Front Anti Roll Bar Mounting 27mm	27mm	2	8000	2

BMW	E36 3 Series Compact (1993-2000)	PFF5-310-28	Front Anti Roll Bar Mounting 28mm	28mm	2	8000	2
BMW	E36 3 Series Compact (1993-2000)	PFR5-300	Rear Diff Mounting Bush		1	6500	7
BMW	E36 3 Series Compact (1993-2000)	PFR5-306	Rear Trailing Arm Bush		4	25000	5
BMW	E36 3 Series Compact (1993-2000)	PFR5-306G	Rear Trailing Arm Bush Adjustable		4	34000	5
BMW	E36 3 Series Compact (1993-2000)	PFR5-308-12	Rear Roll Bar Mounting Bush 12mm	12mm	2	7500	6
BMW	E36 3 Series Compact (1993-2000)	PFR5-308-14	Rear Roll Bar Mounting Bush 14mm	14mm	2	7500	6
BMW	E36 3 Series Compact (1993-2000)	PFR5-308-16	Rear Roll Bar Mounting Bush 16mm	16mm	2	7500	6
BMW	E36 3 Series Compact (1993-2000)	PFR5-311	Rear Beam Bush		2	17500	4
BMW	E36 3 Series Compact (1993-2000)	PFR5-5630-10	Rear Shock Top Mount Bracket and Bush 10mm	10mm	2	18500	30
BMW	E36 3 Series Compact (1993-2000)	PFR5-5630-12	Rear Shock Top Mount Bracket and Bush 12mm	12mm	2	18500	30
BMW	E46 3 Series Compact	PF5K-1003	Powerflex Handling Pack		1	60250	
BMW	E46 3 Series Compact	PFF5-4601	Front Wishbone Rear Bush	66mm	2	13000	1
BMW	E46 3 Series Compact	PFF5-4601-60	Front Wishbone Rear Bush	60mm	2	13000	1
BMW	E46 3 Series Compact	PFF5-4602-21	Front Anti Roll Bar Bush 21.5mm	21.5mm	2	9500	2
BMW	E46 3 Series Compact	PFF5-4602-23	Front Anti Roll Bar Bush 23mm	23mm	2	9500	2
BMW	E46 3 Series Compact	PFF5-4602-23.5	Front Anti Roll Bar Bush 23.5mm	23.5mm	2	9500	2
BMW	E46 3 Series Compact	PFF5-4602-24	Front Anti Roll Bar Bush 24mm	24mm	2	9500	2
BMW	E46 3 Series Compact	PFF5-4602-26	Front Anti Roll Bar Bush 26mm	26mm	2	9500	2
BMW	E46 3 Series Compact	PFF5-4602-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	9500	2
BMW	E46 3 Series Compact	PFF5-4602-30.8	Front Anti Roll Bar Bush 30.8mm	30.8mm	2	9500	2
BMW	E46 3 Series Compact	PFF5-5601	Front Wishbone Rear Bush, Aluminium Outer	66mm	2	31000	1
BMW	E46 3 Series Compact	PFF5-5601-60	Front Wishbone Rear Bush, Aluminium Outer	60mm	2	31000	1
BMW	E46 3 Series Compact	PFF5-5601G	Front Wishbone Rear Bush, Caster Offset	66mm	2	31500	1
BMW	E46 3 Series Compact	PFF5-5601G-60	Front Wishbone Rear Bush, Caster Offset	60mm	2	31500	1
BMW	E46 3 Series Compact	PFR5-3608	Rear Trailing Arm Bush		2	13500	3
BMW	E46 3 Series Compact	PFR5-4610	Rear Subframe Front Bush		2	18500	10
BMW	E46 3 Series Compact	PFR5-4611	Rear Subframe Rear Bush		2	18500	11
BMW	E46 3 Series Compact	PFR5-4613	Rear Subframe Rear Bush Insert		2	11500	11
BMW	E46 3 Series Compact	PFR5-4614	Rear Subframe Front Bush Insert		2	11500	10
BMW	E46 3 Series Compact	PFR5-4615G	Adjustable Rear Lower Control Arm Kit		1	31250	19
BMW	E46 3 Series Compact	PFR5-4616	Rear lower Control Arm Inner Bush		2	16000	19
BMW	E46 3 Series Compact	PFR5-4617	Rear Upper Arm Inner Bush		2	11000	17
BMW	E46 3 Series Compact	PFR5-4618	Rear Lower Arm Outer Bush		2	12000	18
BMW	E46 3 Series Compact	PFR5-4625	Rear Diff Front Bush		2	13000	25
BMW	E46 3 Series Compact	PFR5-4626	Rear Diff Rear Bush		1	7750	26
BMW	E46 3 Series Compact	PFR5-504-15	Rear Roll Bar Mounting Bush 15mm	15mm	2	7500	4
BMW	E46 3 Series Compact	PFR5-504-18	Rear Roll Bar Mounting Bush 18mm	18mm	2	7500	4
BMW	E46 3 Series Compact	PFR5-504-19	Rear Roll Bar Mounting Bush 19mm	19mm	2	7500	4
BMW	E46 3 Series Compact	PFR5-504-215	Rear Roll Bar Mounting Bush 21.5mm	21.5mm	2	7500	4
BMW	E46 3 Series Compact	PFR5-504-22.5	Rear Roll Bar Mounting Bush 22.5mm	22.5mm	2	7500	4
BMW	E46 3 Series Compact	PFR5-5630-10	Rear Shock Top Mount Bracket and Bush 10mm	10mm	2	18500	30
BMW	E46 3 Series Compact	PFR5-5630-12	Rear Shock Top Mount Bracket and Bush 12mm	12mm	2	18500	30
BMW	E46 3 Series inc Touring	PF5K-1003	Powerflex Handling Pack		1	60250	
BMW	E46 3 Series inc Touring	PFF5-4601	Front Wishbone Rear Bush	66mm	2	13000	1
BMW	E46 3 Series inc Touring	PFF5-4601-60	Front Wishbone Rear Bush	60mm	2	13000	1
BMW	E46 3 Series inc Touring	PFF5-4602-21	Front Anti Roll Bar Bush 21.5mm	21.5mm	2	9500	2
BMW	E46 3 Series inc Touring	PFF5-4602-23	Front Anti Roll Bar Bush 23mm	23mm	2	9500	2
BMW	E46 3 Series inc Touring	PFF5-4602-23.5	Front Anti Roll Bar Bush 23.5mm	23.5mm	2	9500	2
BMW	E46 3 Series inc Touring	PFF5-4602-24	Front Anti Roll Bar Bush 24mm	24mm	2	9500	2
BMW	E46 3 Series inc Touring	PFF5-4602-26	Front Anti Roll Bar Bush 26mm	26mm	2	9500	2
BMW	E46 3 Series inc Touring	PFF5-4602-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	9500	2
BMW	E46 3 Series inc Touring	PFF5-4602-30.8	Front Anti Roll Bar Bush 30.8mm	30.8mm	2	9500	2
BMW	E46 3 Series inc Touring	PFF5-5601	Front Wishbone Rear Bush, Aluminium Outer	66mm	2	31000	1
BMW	E46 3 Series inc Touring	PFF5-5601-60	Front Wishbone Rear Bush, Aluminium Outer	60mm	2	31000	1
BMW	E46 3 Series inc Touring	PFF5-5601G	Front Wishbone Rear Bush, Caster Offset	66mm	2	31500	1
BMW	E46 3 Series inc Touring	PFF5-5601G-60	Front Wishbone Rear Bush, Caster Offset	60mm	2	31500	1
BMW	E46 3 Series inc Touring	PFR5-3608	Rear Trailing Arm Bush		2	13500	3
BMW	E46 3 Series inc Touring	PFR5-4610	Rear Subframe Front Bush		2	18500	10
BMW	E46 3 Series inc Touring	PFR5-4611	Rear Subframe Rear Bush		2	18500	11

BMW	E46 3 Series inc Touring	PFR5-4613	Rear Subframe Rear Bush Insert		2	11500	11
BMW	E46 3 Series inc Touring	PFR5-4614	Rear Subframe Front Bush Insert		2	11500	10
BMW	E46 3 Series inc Touring	PFR5-4615G	Adjustable Rear Lower Control Arm Kit		1	31250	19
BMW	E46 3 Series inc Touring	PFR5-4616	Rear lower Control Arm Inner Bush		2	16000	19
BMW	E46 3 Series inc Touring	PFR5-4617	Rear Upper Arm Inner Bush		2	11000	17
BMW	E46 3 Series inc Touring	PFR5-4618	Rear Lower Arm Outer Bush		2	12000	18
BMW	E46 3 Series inc Touring	PFR5-4625	Rear Diff Front Bush		2	13000	25
BMW	E46 3 Series inc Touring	PFR5-4626	Rear Diff Rear Bush		1	7750	26
BMW	E46 3 Series inc Touring	PFR5-504-15	Rear Roll Bar Mounting Bush 15mm	15mm	2	7500	4
BMW	E46 3 Series inc Touring	PFR5-504-18	Rear Roll Bar Mounting Bush 18mm	18mm	2	7500	4
BMW	E46 3 Series inc Touring	PFR5-504-19	Rear Roll Bar Mounting Bush 19mm	19mm	2	7500	4
BMW	E46 3 Series inc Touring	PFR5-504-20	Rear Roll Bar Mounting Bush 20mm	20mm	2	7500	4
BMW	E46 3 Series inc Touring	PFR5-504-215	Rear Roll Bar Mounting Bush 21.5mm	21.5mm	2	7500	4
BMW	E46 3 Series inc Touring	PFR5-504-22.5	Rear Roll Bar Mounting Bush 22.5mm	22.5mm	2	7500	4
BMW	E46 3 Series inc Touring	PFR5-5630-10	Rear Shock Top Mount Bracket and Bush 10mm	10mm	2	18500	30
BMW	E46 3 Series inc Touring	PFR5-5630-12	Rear Shock Top Mount Bracket and Bush 12mm	12mm	2	18500	30
BMW	E46 3 Series M3	PF5K-1006	Handling Pack		1	61500	
BMW	E46 3 Series M3	PFF5-4601M3	Front Wishbone Rear Bush	60mm	2	14500	1
BMW	E46 3 Series M3	PFF5-4602-26	Front Anti Roll Bar Bush 26mm	26mm	2	9500	2
BMW	E46 3 Series M3	PFF5-4602-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	9500	2
BMW	E46 3 Series M3	PFF5-4602-30.8	Front Anti Roll Bar Bush 30.8mm	30.8mm	2	9500	2
BMW	E46 3 Series M3	PFF5-5601GM3	Front Wishbone Rear Bush, Caster Offset	60mm	2	31500	1
BMW	E46 3 Series M3	PFF5-5601M3	Front Wishbone Rear Bush, Aluminium Outer	60mm	2	31000	1
BMW	E46 3 Series M3	PFR5-3608	Rear Trailing Arm Bush		2	13500	3
BMW	E46 3 Series M3	PFR5-4609-21.5	Rear Roll Bar Mounting Bush 21.5mm	21.5mm	2	9500	4
BMW	E46 3 Series M3	PFR5-4609-22.5	Rear Roll Bar Mounting Bush 22.5mm	22.5mm	2	9500	4
BMW	E46 3 Series M3	PFR5-4610M3	Rear Subframe Front Bush		2	18500	10
BMW	E46 3 Series M3	PFR5-4611	Rear Subframe Rear Bush		2	18500	11
BMW	E46 3 Series M3	PFR5-4612	Rear Subframe Front Bush Insert		2	11500	10
BMW	E46 3 Series M3	PFR5-4613	Rear Subframe Rear Bush Insert		2	11500	11
BMW	E46 3 Series M3	PFR5-4615G	Adjustable Rear Lower Control Arm Kit		1	31250	19
BMW	E46 3 Series M3	PFR5-4616	Rear lower Control Arm Inner Bush		2	16000	19
BMW	E46 3 Series M3	PFR5-4617	Rear Upper Arm Inner Bush		2	11000	17
BMW	E46 3 Series M3	PFR5-4618	Rear Lower Arm Outer Bush		2	12000	18
BMW	E46 3 Series M3	PFR5-4620	Rear Diff Rear Mount		2	20000	20
BMW	E46 3 Series M3	PFR5-4621	Rear Diff Front Mount		1	6000	21
BMW	E46 3 Series M3	PFR5-5630-10	Rear Shock Top Mount Bracket and Bush 10mm	10mm	2	18500	30
BMW	E46 3 Series M3	PFR5-5630-12	Rear Shock Top Mount Bracket and Bush 12mm	12mm	2	18500	30
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFF5-4601XI	Front Wishbone Rear Bush	60mm	2	13000	1
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFF5-4602-21	Front Anti Roll Bar Bush 21.5mm	21.5mm	2	9500	2
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFF5-4602-23	Front Anti Roll Bar Bush 23mm	23mm	2	9500	2
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFF5-4602-23.5	Front Anti Roll Bar Bush 23.5mm	23.5mm	2	9500	2
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFF5-4602-24	Front Anti Roll Bar Bush 24mm	24mm	2	9500	2
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFF5-4602-26	Front Anti Roll Bar Bush 26mm	26mm	2	9500	2
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFF5-4602-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	9500	2
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFF5-4602-30.8	Front Anti Roll Bar Bush 30.8mm	30.8mm	2	9500	2
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-3608	Rear Trailing Arm Bush		2	13500	3
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-4610	Rear Subframe Front Bush		2	18500	10
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-4611	Rear Subframe Rear Bush		2	18500	11
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-4613	Rear Subframe Rear Bush Insert		2	11500	11
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-4614	Rear Subframe Front Bush Insert		2	11500	10
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-4615G	Adjustable Rear Lower Control Arm Kit		1	31250	19
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-4616	Rear lower Control Arm Inner Bush		2	16000	19
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-4617	Rear Upper Arm Inner Bush		2	11000	17
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-4618	Rear Lower Arm Outer Bush		2	12000	18
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-4625	Rear Diff Front Bush		2	13000	25
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-4626	Rear Diff Rear Bush		1	7750	26
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-504-15	Rear Roll Bar Mounting Bush 15mm	15mm	2	7500	4
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-504-18	Rear Roll Bar Mounting Bush 18mm	18mm	2	7500	4

BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-504-19	Rear Roll Bar Mounting Bush 19mm	19mm	2	7500	4
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-504-215	Rear Roll Bar Mounting Bush 21.5mm	21.5mm	2	7500	4
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-504-22.5	Rear Roll Bar Mounting Bush 22.5mm	22.5mm	2	7500	4
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-5630-10	Rear Shock Top Mount Bracket and Bush 10mm	10mm	2	18500	30
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-5630-12	Rear Shock Top Mount Bracket and Bush 12mm	12mm	2	18500	30
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFF5-401	Front Radius Arm To Chassis Bush		2	17000	1
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFF5-402	Front Control Arm To Chassis Bush		2	30000	2
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFF5-4602-26.5	Front Anti Roll Bar Mounting Bush 26.5mm	26.5mm	2	9500	3
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-1220	Rear Subframe, Front Bush		2	30500	19
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-411	Rear Upper Control Arm To Chassis Bush		2	16500	11c
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-411	Rear Trailing Arm Inner & Outer Bush		4	33000	11b
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-411	Rear Toe Adjust Arm Inner & Outer Bush		4	33000	11a
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-412	Rear Upper Control Arm To Hub Bush		2	17000	12a
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-412	Rear Upper Lateral Arm To Hub Bush		2	17000	12b
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-413	Rear Upper Lateral Arm To Chassis Bush		2	22500	13
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-414	Rear Lower Lateral Arm To Hub Bush		2	22500	14
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-415	Rear Lower Lateral Arm To Chassis Bush		2	14000	15
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-416	Rear Shock Absorber Upper Mounting Bush	10mm	2	11000	16
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-416-12	Rear Shock Absorber Upper Mounting Bush 12mm	12mm	2	11000	16
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-419	Rear Subframe Front Mount Insert		2	12500	19
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-420	Rear Subframe Front Mounting Bush		2	28000	19
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-421	Rear Subframe Rear Mounting Insert		2	12500	20
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-422	Rear Subframe Rear Mounting Bush		2	24000	20
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-423	Rear Subframe Rear Mounting Insert		2	12500	20
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-425	Rear Diff Front Mounting Bush		2	14500	25
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-426	Rear Diff Rear Mounting Bush		1	7500	26
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-4609-11	Rear Anti Roll Bar Mounting Bush 11mm	11mm	2	9500	10
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-4609-12	Rear Anti Roll Bar Mounting Bush 12mm	12mm	2	9500	10
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-4609-13	Rear Anti Roll Bar Mounting Bush 13mm	13mm	2	9500	10
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-4609-14	Rear Anti Roll Bar Mounting Bush 14mm	14mm	2	9500	10
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-4609-15	Rear Anti Roll Bar Mounting Bush 15mm	15mm	2	9500	10
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFF5-5701	Front Control Arm to Chassis Bush		2	17000	2
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFF5-5703-26.5	Front Anti Roll Bar Mounting Bush 26.5mm	26.5mm	2	9500	3
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-1220	Rear Subframe, Front Bush		2	30500	19
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-411	Rear Upper Control Arm To Chassis Bush		2	16500	11c
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-411	Rear Trailing Arm Inner & Outer Bush		4	33000	11b
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-411	Rear Toe Adjust Arm Inner & Outer Bush		4	33000	11a
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-412	Rear Upper Control Arm To Hub Bush		2	17000	12a
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-412	Rear Upper Lateral Arm To Hub Bush		2	17000	12b
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-413	Rear Upper Lateral Arm To Chassis Bush		2	22500	13
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-414	Rear Lower Lateral Arm To Hub Bush		2	22500	14
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-415	Rear Lower Lateral Arm To Chassis Bush		2	14000	15
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-416	Rear Shock Absorber Upper Mounting Bush	10mm	2	11000	16
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-416-12	Rear Shock Absorber Upper Mounting Bush 12mm	12mm	2	11000	16
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-419	Rear Subframe Front Mount Insert		2	12500	19
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-420	Rear Subframe Front Mounting Bush		2	28000	19
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-421	Rear Subframe Rear Mounting Insert		2	12500	20
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-422	Rear Subframe Rear Mounting Bush		2	24000	20
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-423	Rear Subframe Rear Mounting Insert		2	12500	20
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-425	Rear Diff Front Mounting Bush		2	14500	25
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-426	Rear Diff Rear Mounting Bush		1	7500	26
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-4609-11	Rear Anti Roll Bar Mounting Bush 11mm	11mm	2	9500	10
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-4609-12	Rear Anti Roll Bar Mounting Bush 12mm	12mm	2	9500	10
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-4609-13	Rear Anti Roll Bar Mounting Bush 13mm	13mm	2	9500	10
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-4609-14	Rear Anti Roll Bar Mounting Bush 14mm	14mm	2	9500	10
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-4609-15	Rear Anti Roll Bar Mounting Bush 15mm	15mm	2	9500	10
BMW	E90, E92 & E93 3 Series M3 (2006-2013)	PFF5-1203-26.5	Front Anti Roll Bar Bush 26.5mm	26.5mm	2	9000	3
BMW	E90, E92 & E93 3 Series M3 (2006-2013)	PFF5-1203-28	Front Anti Roll Bar Bush 28mm	28mm	2	9000	3
BMW	E90, E92 & E93 3 Series M3 (2006-2013)	PFF5-401	Front Radius Arm To Chassis Bush		2	17000	1

BMW	E90, E92 & E93 3 Series M3 (2006-2013)	PFR5-1210-22.5	Rear Anti Roll Bar Bush 22.5mm	22.5mm	2	9000	10
BMW	E90, E92 & E93 3 Series M3 (2006-2013)	PFR5-1210-23.6	Rear Anti Roll Bar Bush 23.6mm	23.6mm	2	9000	10
BMW	E90, E92 & E93 3 Series M3 (2006-2013)	PFR5-1212	Rear Upper Arm Outer Bush		4	32000	12
BMW	E90, E92 & E93 3 Series M3 (2006-2013)	PFR5-1213	Rear Lower Front Arm Inner Bush		2	13500	13
BMW	E90, E92 & E93 3 Series M3 (2006-2013)	PFR5-1215	Rear Lower Lateral Arm Inner Bush		2	21500	15
BMW	E90, E92 & E93 3 Series M3 (2006-2013)	PFR5-1220	Rear Subframe, Front Bush		2	30500	19
BMW	E90, E92 & E93 3 Series M3 (2006-2013)	PFR5-1226	Rear Diff Rear Mounting Bush		1	7250	26
BMW	E90, E92 & E93 3 Series M3 (2006-2013)	PFR5-411	Rear Trailing Arm Outer Bush		2	16500	11
BMW	E90, E92 & E93 3 Series M3 (2006-2013)	PFR5-422P	Rear Subframe Rear Mounting Bush		2	26500	20
BMW	E90, E92 & E93 3 Series M3 (2006-2013)	PFR5-425	Rear Diff Front Mounting Bush		2	14500	25
BMW	F30, F31, F34 3 Series	PFF5-1901	Front Radius Arm To Chassis Bush		2	19500	1
BMW	F30, F31, F34 3 Series	PFF5-1901G	Front Radius Arm To Chassis Bush Caster Adjustable		2	23500	1
BMW	F30, F31, F34 3 Series	PFF5-1902	Front Control Arm To Chassis Bush		2	15500	2
BMW	F30, F31, F34 3 Series	PFF5-1902G	Front Control Arm to Chassis Bush - Camber Adjustable		2	21000	2
BMW	F30, F31, F34 3 Series	PFF5-1903-24	Front Anti Roll Bar Bush 24mm	24mm	2	9500	3
BMW	F30, F31, F34 3 Series	PFF5-1903-25	Front Anti Roll Bar Bush 25mm	25mm	2	9500	3
BMW	F30, F31, F34 3 Series	PFR5-1913-12	Rear Anti Roll Bar Bush 12mm	12mm	2	8500	13
BMW	F30, F31, F34 3 Series	PFR5-1913-13	Rear Anti Roll Bar Bush 13mm	13mm	2	8500	13
BMW	F30, F31, F34 3 Series	PFR5-1920	Rear Subframe Front Bush Insert		2	11500	20
BMW	F30, F31, F34 3 Series	PFR5-1921	Rear Subframe Rear Bush Insert		2	11500	21
BMW	F30, F31, F34 3 Series	PFR5-1927	Rear Diff Front Bush Insert		2	10000	27
BMW	F30, F31, F34 3 Series xDrive	PFF5-1903-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	9500	3
BMW	F30, F31, F34 3 Series xDrive	PFF5-1903-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	9500	3
BMW	F30, F31, F34 3 Series xDrive	PFF5-4101	Front Radius Arm To Chassis Bush		2	19500	1
BMW	F30, F31, F34 3 Series xDrive	PFF5-4102	Front Control Arm To Chassis Bush		2	15500	2
BMW	F30, F31, F34 3 Series xDrive	PFR5-1913-12	Rear Anti Roll Bar Bush 12mm	12mm	2	8500	13
BMW	F30, F31, F34 3 Series xDrive	PFR5-1913-13	Rear Anti Roll Bar Bush 13mm	13mm	2	8500	13
BMW	F30, F31, F34 3 Series xDrive	PFR5-1920	Rear Subframe Front Bush Insert		2	11500	20
BMW	F30, F31, F34 3 Series xDrive	PFR5-1921	Rear Subframe Rear Bush Insert		2	11500	21
BMW	F30, F31, F34 3 Series xDrive	PFR5-1927	Rear Diff Front Bush Insert		2	10000	27
BMW	F80 3 Series M3	PFF5-1203-26.5	Front Anti Roll Bar Bush 26.5mm	26.5mm	2	9000	3
BMW	F80 3 Series M3	PFF5-1203-28	Front Anti Roll Bar Bush 28mm	28mm	2	9000	3
BMW	F80 3 Series M3	PFF5-4001	Front Radius Arm To Chassis Bush		2	19500	1
BMW	F80 3 Series M3	PFF5-4001G	Front Radius Arm To Chassis BushCaster Offset		2	21000	1
BMW	F80 3 Series M3	PFR5-4025	Rear Diff Front Mounting Bush		4	47000	21
BMW	F80 3 Series M3	PFR5-4026	Rear Diff Rear Mounting Bush		1	15500	22
BMW	F32, F33, F36 4 Series	PFF5-1901	Front Radius Arm To Chassis Bush		2	19500	1
BMW	F32, F33, F36 4 Series	PFF5-1901G	Front Radius Arm To Chassis Bush Caster Adjustable		2	23500	1
BMW	F32, F33, F36 4 Series	PFF5-1902	Front Control Arm To Chassis Bush		2	15500	2
BMW	F32, F33, F36 4 Series	PFF5-1902G	Front Control Arm to Chassis Bush - Camber Adjustable		2	21000	2
BMW	F32, F33, F36 4 Series	PFF5-1903-24	Front Anti Roll Bar Bush 24mm	24mm	2	9500	3
BMW	F32, F33, F36 4 Series	PFF5-1903-25	Front Anti Roll Bar Bush 25mm	25mm	2	9500	3
BMW	F32, F33, F36 4 Series	PFR5-1913-12	Rear Anti Roll Bar Bush 12mm	12mm	2	8500	13
BMW	F32, F33, F36 4 Series	PFR5-1913-13	Rear Anti Roll Bar Bush 13mm	13mm	2	8500	13
BMW	F32, F33, F36 4 Series	PFR5-1920	Rear Subframe Front Bush Insert		2	11500	20
BMW	F32, F33, F36 4 Series	PFR5-1921	Rear Subframe Rear Bush Insert		2	11500	21
BMW	F32, F33, F36 4 Series	PFR5-1927	Rear Diff Front Bush Insert		2	10000	27
BMW	F32, F33, F36 4 Series xDrive	PFF5-1903-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	9500	3
BMW	F32, F33, F36 4 Series xDrive	PFF5-1903-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	9500	3
BMW	F32, F33, F36 4 Series xDrive	PFF5-4101	Front Radius Arm To Chassis Bush		2	19500	1
BMW	F32, F33, F36 4 Series xDrive	PFF5-4102	Front Control Arm To Chassis Bush		2	15500	2
BMW	F32, F33, F36 4 Series xDrive	PFR5-1913-12	Rear Anti Roll Bar Bush 12mm	12mm	2	8500	13
BMW	F32, F33, F36 4 Series xDrive	PFR5-1920	Rear Subframe Front Bush Insert		2	11500	20
BMW	F32, F33, F36 4 Series xDrive	PFR5-1921	Rear Subframe Rear Bush Insert		2	11500	21
BMW	F32, F33, F36 4 Series xDrive	PFR5-1927	Rear Diff Front Bush Insert		2	10000	27
BMW	F82, F83 4 Series M4	PFF5-1203-26.5	Front Anti Roll Bar Bush 26.5mm	26.5mm	2	9000	3
BMW	F82, F83 4 Series M4	PFF5-1203-28	Front Anti Roll Bar Bush 28mm	28mm	2	9000	3
BMW	F82, F83 4 Series M4	PFF5-4001	Front Radius Arm To Chassis Bush		2	19500	1
BMW	F82, F83 4 Series M4	PFF5-4001G	Front Radius Arm To Chassis BushCaster Offset		2	21000	1

BMW	F82, F83 4 Series M4	PFR5-4025	Rear Diff Front Mounting Bush		4	47000	21
BMW	F82, F83 4 Series M4	PFR5-4026	Rear Diff Rear Mounting Bush		1	15500	22
BMW	E28 5 Series (1982 - 1988)	PFF5-310-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	8000	3
BMW	E28 5 Series (1982 - 1988)	PFF5-801	Front Lower Tie Bar To Chassis Bush		2	12500	1
BMW	E28 5 Series (1982 - 1988)	PFF5-802	Front Inner TCA Bush		2	12500	2
BMW	E28 5 Series (1982 - 1988)	PFR5-308-13	Rear Anti Roll Bar Mounting Bush 13mm		2	7500	7
BMW	E28 5 Series (1982 - 1988)	PFR5-308-15.5	Rear Anti Roll Bar Mounting Bush 15.5mm	15.5mm	2	7500	7
BMW	E28 5 Series (1982 - 1988)	PFR5-308-17	Rear Anti Roll Bar Mounting Bush 17mm	14mm	2	7500	7
BMW	E28 5 Series (1982 - 1988)	PFR5-308-18	Rear Anti Roll Bar Mounting Bush 18mm	18mm	2	7500	7
BMW	E28 5 Series (1982 - 1988)	PFR5-308-19	Rear Anti Roll Bar Mounting Bush 19mm	19mm	2	7500	7
BMW	E28 5 Series (1982 - 1988)	PFR5-315	Rear Anti Roll Bar Link To Arm Bush		2	7000	15
BMW	E28 5 Series (1982 - 1988)	PFR5-316	Rear Anti Roll Bar Link To Anti Roll Bar Bush		2	6500	16
BMW	E28 5 Series (1982 - 1988)	PFR5-504-13	Front Anti Roll Bar Mounting Bush 13mm	13mm	2	7500	3
BMW	E28 5 Series (1982 - 1988)	PFR5-504-14	Front Anti Roll Bar Mounting Bush 14mm	14mm	2	7500	3
BMW	E28 5 Series (1982 - 1988)	PFR5-504-15	Front Anti Roll Bar Mounting Bush 15mm	15mm	2	7500	3
BMW	E28 5 Series (1982 - 1988)	PFR5-504-16.5	Front Roll Bar Mounting Bush 16.5mm	16.5mm	2	7500	3
BMW	E28 5 Series (1982 - 1988)	PFR5-504-18	Front Anti Roll Bar Mounting Bush 18mm	18mm	2	7500	3
BMW	E28 5 Series (1982 - 1988)	PFR5-504-19	Front Anti Roll Bar Mounting Bush 19mm	19mm	2	7500	3
BMW	E28 5 Series (1982 - 1988)	PFR5-504-21	Front Anti Roll Bar Mounting Bush 21mm	21mm	2	7500	3
BMW	E28 5 Series (1982 - 1988)	PFR5-504-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	7500	3
BMW	E28 5 Series (1982 - 1988)	PFR5-606	Rear Trailing Arm Bush		4	25000	10
BMW	E28 5 Series (1982 - 1988)	PFR5-606G	Rear Trailing Arm Bush Adjustable		4	42000	10
BMW	E28 5 Series (1982 - 1988)	PFR5-807	Rear Beam Bush		2	14000	6
BMW	E34 5 Series (1988 - 1996)	PFF5-310-23	Front Anti Roll Bar Mounting 23mm	23mm	2	8500	3
BMW	E34 5 Series (1988 - 1996)	PFF5-310-24	Front Anti Roll Bar Mounting 24mm	24mm	2	8000	3
BMW	E34 5 Series (1988 - 1996)	PFF5-310-25	Front Anti Roll Bar Mounting 25mm	25mm	2	8000	3
BMW	E34 5 Series (1988 - 1996)	PFF5-310-28	Front Anti Roll Bar Mounting 28mm	28mm	2	8000	3
BMW	E34 5 Series (1988 - 1996)	PFF5-601	Front Lower Tie Bar To Chassis Bush		2	13000	1
BMW	E34 5 Series (1988 - 1996)	PFF5-602	Front Inner TCA Bush		2	12500	2
BMW	E34 5 Series (1988 - 1996)	PFF5-620	Front Inner TCA Bush		2	12500	2
BMW	E34 5 Series (1988 - 1996)	PFR5-504-15	Rear Roll Bar Mounting Bush 15mm	15mm	2	7500	7
BMW	E34 5 Series (1988 - 1996)	PFR5-504-16.5	Rear Roll Bar Mounting Bush 16.5mm	16.5mm	2	7500	7
BMW	E34 5 Series (1988 - 1996)	PFR5-504-18	Rear Roll Bar Mounting Bush 18mm	18mm	2	7500	7
BMW	E34 5 Series (1988 - 1996)	PFR5-507	Rear Beam Mount Bush		2	15500	6
BMW	E34 5 Series (1988 - 1996)	PFR5-606	Rear Trailing Arm Bush		4	25000	10
BMW	E34 5 Series (1988 - 1996)	PFR5-606G	Rear Trailing Arm Bush Adjustable		4	42000	10
BMW	E39 5 Series 520 to 530	PFF5-4602-23	Front Anti Roll Bar Bush 23mm	23mm	2	9500	3
BMW	E39 5 Series 520 to 530	PFF5-4602-24	Front Anti Roll Bar Bush 24mm	24mm	2	9500	3
BMW	E39 5 Series 520 to 530	PFF5-4602-25	Front Anti Roll Bar Bush 25mm	25mm	2	9500	3
BMW	E39 5 Series 520 to 530	PFF5-4602-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	9500	3
BMW	E39 5 Series 520 to 530	PFF5-503-22.5	Front Anti Roll Bar Mounting Bush 22.5mm	22.5mm	2	8500	3
BMW	E39 5 Series 520 to 530	PFF5-503-24	Front Anti Roll Bar Mounting Bush 24mm	24mm	2	8000	3
BMW	E39 5 Series 520 to 530	PFF5-503-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	8000	3
BMW	E39 5 Series 520 to 530	PFF5-503-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	8000	3
BMW	E39 5 Series 520 to 530	PFF5-510	Front Lower Tie Bar To Chassis Bush		2	13000	1
BMW	E39 5 Series 520 to 530	PFF5-511	Front Inner Track Control Arm Bush		2	12000	2
BMW	E39 5 Series 520 to 530	PFR5-504-13	Rear Anti Roll Bar Mounting Bush 13mm	13mm	2	7500	4
BMW	E39 5 Series 520 to 530	PFR5-504-14	Rear Anti Roll Bar Mounting Bush 14mm	14mm	2	7500	4
BMW	E39 5 Series 520 to 530	PFR5-504-15	Rear Roll Bar Mounting Bush 15mm	15mm	2	7500	4
BMW	E39 5 Series 520 to 530	PFR5-504-16.5	Rear Roll Bar Mounting Bush 16.5mm	16.5mm	2	7500	4
BMW	E39 5 Series 520 to 530	PFR5-520	Rear Subframe Front Mounting Bush		2	21000	20
BMW	E39 5 Series 520 to 530	PFR5-521	Rear Subframe Mounting Front Insert		2	11000	20
BMW	E39 5 Series 520 to 530	PFR5-522	Rear Subframe Rear Mounting Bush		2	21000	22
BMW	E39 5 Series 520 to 530	PFR5-523	Rear Subframe Rear Mounting Insert		2	11000	22
BMW	E39 5 Series 520 to 530	PFR5-524	Rear Diff Front Mounting Bush		1	6000	25
BMW	E39 5 Series 520 to 530	PFR5-525	Rear Diff Front Mounting Bush		1	6000	25
BMW	E39 5 Series 520 to 530	PFR5-526	Rear Diff Rear Mounting Bush		2	12500	26
BMW	E39 5 Series 520 to 530	PFR5-710-10	Rear Lower Arm Front Bush	10mm Bore Sleeve	2	13000	10
BMW	E39 5 Series 520 to 530	PFR5-711	Rear Lower Arm Rear Bush	14mm Bore Sleeve	2	14000	11

BMW	E39 5 Series 520 to 530	PFR5-711-12	Rear Lower Arm Rear Bush	12mm Bore Sleeve	2	14000	11
BMW	E39 5 Series 520 to 530	PFR5-712	Rear Upper Arm Inner Bush		2	15000	12
BMW	E39 5 Series 520 to 530	PFR5-713	Rear Toe Adjust Inner Bush		2	12500	13
BMW	E39 5 Series 520 to 530	PFR5-715	Rear Outer Integral Link Upper Bush		2	14000	15
BMW	E39 5 Series 520 to 530	PFR5-716	Rear Outer Integral Link Lower Bush		2	11000	16
BMW	E39 5 Series 520 to 530 Touring	PFF5-4602-23	Front Anti Roll Bar Bush 23mm	23mm	2	9500	3
BMW	E39 5 Series 520 to 530 Touring	PFF5-4602-24	Front Anti Roll Bar Bush 24mm	24mm	2	9500	3
BMW	E39 5 Series 520 to 530 Touring	PFF5-4602-25	Front Anti Roll Bar Bush 25mm	25mm	2	9500	3
BMW	E39 5 Series 520 to 530 Touring	PFF5-4602-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	9500	3
BMW	E39 5 Series 520 to 530 Touring	PFF5-503-225	Front Anti Roll Bar Mounting Bush 22.5mm	22.5mm	2	8500	3
BMW	E39 5 Series 520 to 530 Touring	PFF5-503-24	Front Anti Roll Bar Mounting Bush 24mm	24mm	2	8000	3
BMW	E39 5 Series 520 to 530 Touring	PFF5-503-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	8000	3
BMW	E39 5 Series 520 to 530 Touring	PFF5-503-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	8000	3
BMW	E39 5 Series 520 to 530 Touring	PFF5-510	Front Lower Tie Bar To Chassis Bush		2	13000	1
BMW	E39 5 Series 520 to 530 Touring	PFF5-511	Front Inner Track Control Arm Bush		2	12000	2
BMW	E39 5 Series 520 to 530 Touring	PFR5-504-13	Rear Anti Roll Bar Mounting Bush 13mm	13mm	2	7500	4
BMW	E39 5 Series 520 to 530 Touring	PFR5-504-14	Rear Anti Roll Bar Mounting Bush 14mm	14mm	2	7500	4
BMW	E39 5 Series 520 to 530 Touring	PFR5-504-15	Rear Roll Bar Mounting Bush 15mm	15mm	2	7500	4
BMW	E39 5 Series 520 to 530 Touring	PFR5-504-165	Rear Roll Bar Mounting Bush 16.5mm	16.5mm	2	7500	4
BMW	E39 5 Series 520 to 530 Touring	PFR5-524	Rear Diff Front Mounting Bush		1	6000	25
BMW	E39 5 Series 520 to 530 Touring	PFR5-525	Rear Diff Front Mounting Bush		1	6000	25
BMW	E39 5 Series 520 to 530 Touring	PFR5-526	Rear Diff Rear Mounting Bush		2	12500	26
BMW	E39 5 Series 520 to 530 Touring	PFR5-530	Rear Subframe Mounting Bush		4	52000	20
BMW	E39 5 Series 520 to 530 Touring	PFR5-531	Rear Subframe Mounting Bush Insert		4	22000	20
BMW	E39 5 Series 520 to 530 Touring	PFR5-710-10	Rear Lower Arm Front Bush	10mm Bore Sleeve	2	13000	10
BMW	E39 5 Series 520 to 530 Touring	PFR5-711	Rear Lower Arm Rear Bush	14mm Bore Sleeve	2	14000	11
BMW	E39 5 Series 520 to 530 Touring	PFR5-711-12	Rear Lower Arm Rear Bush	12mm Bore Sleeve	2	14000	11
BMW	E39 5 Series 520 to 530 Touring	PFR5-712	Rear Upper Arm Inner Bush		2	15000	12
BMW	E39 5 Series 520 to 530 Touring	PFR5-713	Rear Toe Adjust Inner Bush		2	12500	13
BMW	E39 5 Series 520 to 530 Touring	PFR5-715	Rear Outer Integral Link Upper Bush		2	14000	15
BMW	E39 5 Series 520 to 530 Touring	PFR5-716	Rear Outer Integral Link Lower Bush		2	11000	16
BMW	E39 5 Series 535 to 540 & M5	PFF5-4602-23	Front Anti Roll Bar Bush 23mm	23mm	2	9500	3
BMW	E39 5 Series 535 to 540 & M5	PFF5-4602-24	Front Anti Roll Bar Bush 24mm	24mm	2	9500	3
BMW	E39 5 Series 535 to 540 & M5	PFF5-4602-25	Front Anti Roll Bar Bush 25mm	25mm	2	9500	3
BMW	E39 5 Series 535 to 540 & M5	PFF5-4602-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	9500	3
BMW	E39 5 Series 535 to 540 & M5	PFF5-501	Front Lower Tie Bar To Chassis Bush		2	12500	1
BMW	E39 5 Series 535 to 540 & M5	PFF5-502	Front Inner Track Control Arm Bush		2	12500	2
BMW	E39 5 Series 535 to 540 & M5	PFF5-503-225	Front Anti Roll Bar Mounting Bush 22.5mm	22.5mm	2	8500	3
BMW	E39 5 Series 535 to 540 & M5	PFF5-503-24	Front Anti Roll Bar Mounting Bush 24mm	24mm	2	8000	3
BMW	E39 5 Series 535 to 540 & M5	PFF5-503-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	8000	3
BMW	E39 5 Series 535 to 540 & M5	PFF5-503-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	8000	3
BMW	E39 5 Series 535 to 540 & M5	PFR5-504-13	Rear Anti Roll Bar Mounting Bush 13mm	13mm	2	7500	4
BMW	E39 5 Series 535 to 540 & M5	PFR5-504-14	Rear Anti Roll Bar Mounting Bush 14mm	14mm	2	7500	4
BMW	E39 5 Series 535 to 540 & M5	PFR5-504-15	Rear Roll Bar Mounting Bush 15mm	15mm	2	7500	4
BMW	E39 5 Series 535 to 540 & M5	PFR5-504-165	Rear Roll Bar Mounting Bush 16.5mm	16.5mm	2	7500	4
BMW	E39 5 Series 535 to 540 & M5	PFR5-520	Rear Subframe Front Mounting Bush		2	21000	20
BMW	E39 5 Series 535 to 540 & M5	PFR5-521	Rear Subframe Mounting Front Insert		2	11000	20
BMW	E39 5 Series 535 to 540 & M5	PFR5-522	Rear Subframe Rear Mounting Bush		2	21000	22
BMW	E39 5 Series 535 to 540 & M5	PFR5-523	Rear Subframe Rear Mounting Insert		2	11000	22
BMW	E39 5 Series 535 to 540 & M5	PFR5-524	Rear Diff Front Mounting Bush		1	6000	25
BMW	E39 5 Series 535 to 540 & M5	PFR5-525	Rear Diff Front Mounting Bush		1	6000	25
BMW	E39 5 Series 535 to 540 & M5	PFR5-526	Rear Diff Rear Mounting Bush		2	12500	26
BMW	E39 5 Series 535 to 540 & M5	PFR5-710-10	Rear Lower Arm Front Bush	10mm Bore Sleeve	2	13000	10
BMW	E39 5 Series 535 to 540 & M5	PFR5-711	Rear Lower Arm Rear Bush	14mm Bore Sleeve	2	14000	11
BMW	E39 5 Series 535 to 540 & M5	PFR5-711-12	Rear Lower Arm Rear Bush	12mm Bore Sleeve	2	14000	11
BMW	E39 5 Series 535 to 540 & M5	PFR5-712	Rear Upper Arm Inner Bush		2	15000	12
BMW	E39 5 Series 535 to 540 & M5	PFR5-713	Rear Toe Adjust Inner Bush		2	12500	13
BMW	E39 5 Series 535 to 540 & M5	PFR5-715	Rear Outer Integral Link Upper Bush		2	14000	15
BMW	E39 5 Series 535 to 540 & M5	PFR5-716	Rear Outer Integral Link Lower Bush		2	11000	16

BMW	E39 5 Series 540 Touring	PFF5-4602-23	Front Anti Roll Bar Bush 23mm	23mm	2	9500	3
BMW	E39 5 Series 540 Touring	PFF5-4602-24	Front Anti Roll Bar Bush 24mm	24mm	2	9500	3
BMW	E39 5 Series 540 Touring	PFF5-4602-25	Front Anti Roll Bar Bush 25mm	25mm	2	9500	3
BMW	E39 5 Series 540 Touring	PFF5-4602-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	9500	3
BMW	E39 5 Series 540 Touring	PFF5-501	Front Lower Tie Bar To Chassis Bush		2	12500	1
BMW	E39 5 Series 540 Touring	PFF5-502	Front Inner Track Control Arm Bush		2	12500	2
BMW	E39 5 Series 540 Touring	PFF5-503-225	Front Anti Roll Bar Mounting Bush 22.5mm	22.5mm	2	8500	3
BMW	E39 5 Series 540 Touring	PFF5-503-24	Front Anti Roll Bar Mounting Bush 24mm	24mm	2	8000	3
BMW	E39 5 Series 540 Touring	PFF5-503-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	8000	3
BMW	E39 5 Series 540 Touring	PFF5-503-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	8000	3
BMW	E39 5 Series 540 Touring	PFR5-504-13	Rear Anti Roll Bar Mounting Bush 13mm	13mm	2	7500	4
BMW	E39 5 Series 540 Touring	PFR5-504-14	Rear Anti Roll Bar Mounting Bush 14mm	14mm	2	7500	4
BMW	E39 5 Series 540 Touring	PFR5-504-15	Rear Roll Bar Mounting Bush 15mm	15mm	2	7500	4
BMW	E39 5 Series 540 Touring	PFR5-504-165	Rear Roll Bar Mounting Bush 16.5mm	16.5mm	2	7500	4
BMW	E39 5 Series 540 Touring	PFR5-524	Rear Diff Front Mounting Bush		1	6000	25
BMW	E39 5 Series 540 Touring	PFR5-525	Rear Diff Front Mounting Bush		1	6000	25
BMW	E39 5 Series 540 Touring	PFR5-526	Rear Diff Rear Mounting Bush		2	12500	26
BMW	E39 5 Series 540 Touring	PFR5-530	Rear Subframe Mounting Bush		4	52000	20
BMW	E39 5 Series 540 Touring	PFR5-531	Rear Subframe Mounting Bush Insert		4	22000	20
BMW	E39 5 Series 540 Touring	PFR5-710-10	Rear Lower Arm Front Bush	10mm Bore Sleeve	2	13000	10
BMW	E39 5 Series 540 Touring	PFR5-711	Rear Lower Arm Rear Bush	14mm Bore Sleeve	2	14000	11
BMW	E39 5 Series 540 Touring	PFR5-711-12	Rear Lower Arm Rear Bush	12mm Bore Sleeve	2	14000	11
BMW	E39 5 Series 540 Touring	PFR5-712	Rear Upper Arm Inner Bush		2	15000	12
BMW	E39 5 Series 540 Touring	PFR5-713	Rear Toe Adjust Inner Bush		2	12500	13
BMW	E39 5 Series 540 Touring	PFR5-715	Rear Outer Integral Link Upper Bush		2	14000	15
BMW	E39 5 Series 540 Touring	PFR5-716	Rear Outer Integral Link Lower Bush		2	11000	16
BMW	E60 5 Series, M5	PFF5-1002	Front Lower Control Arm Inner Bush		2	12000	2
BMW	E60 5 Series, M5	PFF5-701	Front Radius Arm To Chassis Bush		2	16000	1
BMW	E60 5 Series, M5	PFR5-4609-18	Rear Anti Roll Bar Mount 18mm	18mm	2	9500	14
BMW	E60 5 Series, M5	PFR5-710	Rear Lower Arm Front Bush	12mm Bore Sleeve	2	13000	10
BMW	E60 5 Series, M5	PFR5-711	Rear Lower Arm Rear Bush	14mm Bore Sleeve	2	14000	11
BMW	E60 5 Series, M5	PFR5-712	Rear Upper Arm Inner Bush		2	15000	12
BMW	E60 5 Series, M5	PFR5-715	Rear Outer Integral Link Upper Bush		2	14000	15
BMW	E60 5 Series, M5	PFR5-716	Rear Outer Integral Link Lower Bush		2	11000	16
BMW	E60 5 Series, M5	PFR5-720	Rear Subframe Front Mounting Bush		2	23000	20
BMW	E60 5 Series, Saloon	PFF5-1002	Front Lower Control Arm Inner Bush		2	12000	2
BMW	E60 5 Series, Saloon	PFF5-701	Front Radius Arm To Chassis Bush		2	16000	1
BMW	E60 5 Series, Saloon	PFF5-703-24.6	Front Anti Roll Bar Mount 24.6mm	24.6mm	2	10000	3
BMW	E60 5 Series, Saloon	PFF5-703-25	Front Anti Roll Bar Mount 25mm	25mm	2	10000	3
BMW	E60 5 Series, Saloon	PFF5-703-25.6	Front Anti Roll Bar Mount 25.6mm	25.6mm	2	10000	3
BMW	E60 5 Series, Saloon	PFR5-4609-13.5	Rear Anti Roll Bar Mount 13.5mm	13.5mm	2	9500	14
BMW	E60 5 Series, Saloon	PFR5-4609-14	Rear Anti Roll Bar Mount 14mm	14mm	2	9500	14
BMW	E60 5 Series, Saloon	PFR5-4609-14.5	Rear Anti Roll Bar Mount 14.5mm	14.5mm	2	9500	14
BMW	E60 5 Series, Saloon	PFR5-4609-16	Rear Anti Roll Bar Mount 16mm	16mm	2	9500	14
BMW	E60 5 Series, Saloon	PFR5-4609-18	Rear Anti Roll Bar Mount 18mm	18mm	2	9500	14
BMW	E60 5 Series, Saloon	PFR5-710	Rear Lower Arm Front Bush	12mm Bore Sleeve	2	13000	10
BMW	E60 5 Series, Saloon	PFR5-711	Rear Lower Arm Rear Bush	14mm Bore Sleeve	2	14000	11
BMW	E60 5 Series, Saloon	PFR5-712	Rear Upper Arm Inner Bush		2	15000	12
BMW	E60 5 Series, Saloon	PFR5-713	Rear Toe Adjust Inner Bush		2	12500	13
BMW	E60 5 Series, Saloon	PFR5-715	Rear Outer Integral Link Upper Bush		2	14000	15
BMW	E60 5 Series, Saloon	PFR5-716	Rear Outer Integral Link Lower Bush		2	11000	16
BMW	E60 5 Series, Saloon	PFR5-720	Rear Subframe Front Mounting Bush		2	23000	20
BMW	E60 5 Series, Saloon	PFR5-721	Rear Subframe Rear Mounting Insert		2	12000	21
BMW	E60 5 Series, Saloon	PFR5-722	Rear Subframe Rear Mounting Bush		2	23000	21
BMW	E60 5 Series, Saloon	PFR5-723	Rear Subframe Front Mounting Insert		2	12000	20
BMW	E60 5 Series, Saloon	PFR5-725	Rear Diff Front Mounting Bush		2	12000	25
BMW	E60 5 Series, Saloon	PFR5-726	Rear Diff Rear Mounting Bush		1	8500	26
BMW	E61 5 Series, Touring	PFF5-1002	Front Lower Control Arm Inner Bush		2	12000	2
BMW	E61 5 Series, Touring	PFF5-701	Front Radius Arm To Chassis Bush		2	16000	1

BMW	E61 5 Series, Touring	PFF5-703-24.6	Front Anti Roll Bar Mount 24.6mm	24.6mm	2	10000	3
BMW	E61 5 Series, Touring	PFF5-703-25	Front Anti Roll Bar Mount 25mm	25mm	2	10000	3
BMW	E61 5 Series, Touring	PFF5-703-25.6	Front Anti Roll Bar Mount 25.6mm	25.6mm	2	10000	3
BMW	E61 5 Series, Touring	PFR5-4609-13.5	Rear Anti Roll Bar Mount 13.5mm	13.5mm	2	9500	14
BMW	E61 5 Series, Touring	PFR5-4609-14	Rear Anti Roll Bar Mount 14mm	14mm	2	9500	14
BMW	E61 5 Series, Touring	PFR5-4609-14.5	Rear Anti Roll Bar Mount 14.5mm	14.5mm	2	9500	14
BMW	E61 5 Series, Touring	PFR5-4609-16	Rear Anti Roll Bar Mount 16mm	16mm	2	9500	14
BMW	E61 5 Series, Touring	PFR5-4609-18	Rear Anti Roll Bar Mount 18mm	18mm	2	9500	14
BMW	E61 5 Series, Touring	PFR5-710	Rear Lower Arm Front Bush	12mm Bore Sleeve	2	13000	10
BMW	E61 5 Series, Touring	PFR5-711	Rear Lower Arm Rear Bush	14mm Bore Sleeve	2	14000	11
BMW	E61 5 Series, Touring	PFR5-712	Rear Upper Arm Inner Bush		2	15000	12
BMW	E61 5 Series, Touring	PFR5-713	Rear Toe Adjust Inner Bush		2	12500	13
BMW	E61 5 Series, Touring	PFR5-715	Rear Outer Integral Link Upper Bush		2	14000	15
BMW	E61 5 Series, Touring	PFR5-716	Rear Outer Integral Link Lower Bush		2	11000	16
BMW	E61 5 Series, Touring	PFR5-720	Rear Subframe Front Mounting Bush		2	23000	20
BMW	E61 5 Series, Touring	PFR5-721	Rear Subframe Rear Mounting Insert		2	12000	21
BMW	E61 5 Series, Touring	PFR5-722	Rear Subframe Rear Mounting Bush		2	23000	21
BMW	E61 5 Series, Touring	PFR5-723	Rear Subframe Front Mounting Insert		2	12000	20
BMW	E61 5 Series, Touring	PFR5-725	Rear Diff Front Mounting Bush		2	12000	25
BMW	E61 5 Series, Touring	PFR5-726	Rear Diff Rear Mounting Bush		1	8500	26
BMW	F10 5 Series M5	PFF5-6201	Front Radius Arm to Chassis Bush		2	22000	1
BMW	F10 5 Series M5	PFF5-6201G	Front Radius Arm to Chassis Bush Caster Offset		2	24000	1
BMW	F10, F11 5 Series	PFF5-6001	Front Radius Arm to Chassis Bush		2	20000	1
BMW	F10, F11 5 Series	PFF5-6001G	Front Radius Arm to Chassis Bush Caster Offset		2	21500	1
BMW	F10, F11 5 Series xDrive	PFF5-6101	Front Radius Arm to Chassis Bush		2	20000	1
BMW	F10, F11 5 Series xDrive	PFF5-6101G	Front Radius Arm to Chassis Bush Caster Offset		2	21500	1
BMW	E24 6 Series (1982 - 1989)	PFF5-310-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	8000	3
BMW	E24 6 Series (1982 - 1989)	PFF5-801	Front Lower Tie Bar To Chassis Bush		2	12500	1
BMW	E24 6 Series (1982 - 1989)	PFF5-802	Front Inner TCA Bush		2	12500	2
BMW	E24 6 Series (1982 - 1989)	PFR5-308-13	Rear Anti Roll Bar Mounting Bush 13mm		2	7500	7
BMW	E24 6 Series (1982 - 1989)	PFR5-308-15.5	Rear Anti Roll Bar Mounting Bush 15.5mm	15.5mm	2	7500	7
BMW	E24 6 Series (1982 - 1989)	PFR5-308-17	Rear Anti Roll Bar Mounting Bush 17mm	14mm	2	7500	7
BMW	E24 6 Series (1982 - 1989)	PFR5-308-18	Rear Anti Roll Bar Mounting Bush 18mm	18mm	2	7500	7
BMW	E24 6 Series (1982 - 1989)	PFR5-308-19	Rear Anti Roll Bar Mounting Bush 19mm	19mm	2	7500	7
BMW	E24 6 Series (1982 - 1989)	PFR5-315	Rear Anti Roll Bar Link To Arm Bush		2	7000	15
BMW	E24 6 Series (1982 - 1989)	PFR5-316	Rear Anti Roll Bar Link To Anti Roll Bar Bush		2	6500	16
BMW	E24 6 Series (1982 - 1989)	PFR5-504-13	Front Anti Roll Bar Mounting Bush 13mm	13mm	2	7500	3
BMW	E24 6 Series (1982 - 1989)	PFR5-504-14	Front Anti Roll Bar Mounting Bush 14mm	14mm	2	7500	3
BMW	E24 6 Series (1982 - 1989)	PFR5-504-15	Front Anti Roll Bar Mounting Bush 15mm	15mm	2	7500	3
BMW	E24 6 Series (1982 - 1989)	PFR5-504-16.5	Front Roll Bar Mounting Bush 16.5mm	16.5mm	2	7500	3
BMW	E24 6 Series (1982 - 1989)	PFR5-504-18	Front Anti Roll Bar Mounting Bush 18mm	18mm	2	7500	3
BMW	E24 6 Series (1982 - 1989)	PFR5-504-19	Front Anti Roll Bar Mounting Bush 19mm	19mm	2	7500	3
BMW	E24 6 Series (1982 - 1989)	PFR5-504-21	Front Anti Roll Bar Mounting Bush 21mm	21mm	2	7500	3
BMW	E24 6 Series (1982 - 1989)	PFR5-504-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	7500	3
BMW	E24 6 Series (1982 - 1989)	PFR5-606	Rear Trailing Arm Bush		4	25000	10
BMW	E24 6 Series (1982 - 1989)	PFR5-606G	Rear Trailing Arm Bush Adjustable		4	42000	10
BMW	E24 6 Series (1982 - 1989)	PFR5-807	Rear Beam Bush		2	14000	6
BMW	E63/E64 6 Series (2003 - 2010)	PFF5-701	Front Radius Arm To Chassis Bush		2	16000	1
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-4609-13.5	Rear Anti Roll Bar Mount 13.5mm	13.5mm	2	9500	14
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-4609-14.5	Rear Anti Roll Bar Mount 14.5mm	14.5mm	2	9500	14
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-4609-18	Rear Anti Roll Bar Mount 18mm	18mm	2	9500	14
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-710	Rear Lower Arm Front Bush	12mm Bore Sleeve	2	13000	10
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-711	Rear Lower Arm Rear Bush	14mm Bore Sleeve	2	14000	11
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-712	Rear Upper Arm Inner Bush		2	15000	12
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-713	Rear Toe Adjust Inner Bush		2	12500	13
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-715	Rear Outer Integral Link Upper Bush		2	14000	15
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-716	Rear Outer Integral Link Lower Bush		2	11000	16
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-720	Rear Subframe Front Mounting Bush		2	23000	20
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-721	Rear Subframe Rear Mounting Insert		2	12000	21

BMW	E63/E64 6 Series (2003 – 2010)	PFR5-722	Rear Subframe Rear Mounting Bush		2	23000	21
BMW	E63/E64 6 Series (2003 – 2010)	PFR5-723	Rear Subframe Front Mounting Insert		2	12000	20
BMW	E63/E64 6 Series (2003 – 2010)	PFR5-725	Rear Diff Front Mounting Bush		2	12000	25
BMW	E63/E64 6 Series (2003 – 2010)	PFR5-726	Rear Diff Rear Mounting Bush		1	8500	26
BMW	F06, F12, F13 6 Series	PFF5-6001	Front Radius Arm to Chassis Bush		2	20000	1
BMW	F06, F12, F13 6 Series	PFF5-6001G	Front Radius Arm to Chassis Bush Caster Offset		2	21500	1
BMW	F06, F12, F13 6 Series M6	PFF5-6201	Front Radius Arm to Chassis Bush		2	22000	1
BMW	F06, F12, F13 6 Series M6	PFF5-6201G	Front Radius Arm to Chassis Bush Caster Offset		2	24000	1
BMW	F06, F12, F13 6 Series xDrive	PFF5-6101	Front Radius Arm to Chassis Bush		2	20000	1
BMW	F06, F12, F13 6 Series xDrive	PFF5-6101G	Front Radius Arm to Chassis Bush Caster Offset		2	21500	1
BMW	E32 7 Series (1988–1994)	PFF5-310-23	Front Anti Roll Bar Mounting 23mm	23mm	2	8500	3
BMW	E32 7 Series (1988–1994)	PFF5-310-24	Front Anti Roll Bar Mounting 24mm	24mm	2	8000	3
BMW	E32 7 Series (1988–1994)	PFF5-310-25	Front Anti Roll Bar Mounting 25mm	25mm	2	8000	3
BMW	E32 7 Series (1988–1994)	PFF5-310-28	Front Anti Roll Bar Mounting 28mm	28mm	2	8000	2
BMW	E32 7 Series (1988–1994)	PFF5-601	Front Lower Tie Bar To Chassis Bush		2	13000	1
BMW	E32 7 Series (1988–1994)	PFF5-602	Front Inner TCA Bush		2	12500	2
BMW	E32 7 Series (1988–1994)	PFF5-620	Front Inner TCA Bush		2	12500	2
BMW	E32 7 Series (1988–1994)	PFR5-504-15	Rear Roll Bar Mounting Bush 15mm	15mm	2	7500	7
BMW	E32 7 Series (1988–1994)	PFR5-504-165	Rear Roll Bar Mounting Bush 16.5mm	16.5mm	2	7500	7
BMW	E32 7 Series (1988–1994)	PFR5-504-18	Rear Roll Bar Mounting Bush 18mm	18mm	2	7500	7
BMW	E32 7 Series (1988–1994)	PFR5-507	Rear Beam Mount Bush		2	15500	6
BMW	E32 7 Series (1988–1994)	PFR5-606	Rear Trailing Arm Bush		4	25000	10
BMW	E32 7 Series (1988–1994)	PFR5-606G	Rear Trailing Arm Bush Adjustable		4	42000	10
BMW	E38 7 Series (1994 – 2002)	PFF5-1001	Front Trailing Arm Rear Bush		2	12500	1
BMW	E38 7 Series (1994 – 2002)	PFF5-1002	Front Lower Control Arm Inner Bush		2	12000	2
BMW	E38 7 Series (1994 – 2002)	PFF5-503-205	Front Anti Roll Bar Mounting Bush 20.5mm	20.5mm	2	8500	3
BMW	E38 7 Series (1994 – 2002)	PFF5-503-225	Front Anti Roll Bar Mounting Bush 22.5mm	22.5mm	2	8500	3
BMW	E38 7 Series (1994 – 2002)	PFF5-503-24	Front Anti Roll Bar Mounting Bush 24mm	24mm	2	8000	3
BMW	E38 7 Series (1994 – 2002)	PFF5-503-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	8000	3
BMW	E38 7 Series (1994 – 2002)	PFF5-503-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	8000	3
BMW	E38 7 Series (1994 – 2002)	PFR5-1007-10	Rear Anti Roll Bar Mounting Bush 10mm	10mm	2	7500	7
BMW	E38 7 Series (1994 – 2002)	PFR5-524	Rear Diff Front Mounting Bush		1	6000	25
BMW	E31 8 Series (1989 – 1999)	PFF5-310-24	Front Anti Roll Bar Mounting 24mm	24mm	2	8000	2
BMW	E31 8 Series (1989 – 1999)	PFF5-310-25	Front Anti Roll Bar Mounting 25mm	25mm	2	8000	2
BMW	E31 8 Series (1989 – 1999)	PFF5-602	Front Inner TCA Bush		2	12500	1
BMW	E31 8 Series (1989 – 1999)	PFF5-902	Rear Track Rod Inner Bush		2	12500	11
BMW	E31 8 Series (1989 – 1999)	PFR5-308-15.5	Rear Anti Roll Bar Mounting Bush 15.5mm	15.5mm	2	7500	7
BMW	E53 X5 (1999–2006)	PFA100-16	PowerAlign Camber Bolt Kit (16mm)	16mm	1	4500	N/A
BMW	E53 X5 (1999–2006)	PFF5-901	Front Lower Radius Arm To Chassis Bush		2	17500	1
BMW	E53 X5 (1999–2006)	PFF5-902	Front Control Arm To Chassis Bush		2	12500	2
BMW	E53 X5 (1999–2006)	PFF5-905-29	Front Anti Roll Bar To Chassis 29mm	29mm	2	10000	3
BMW	E53 X5 (1999–2006)	PFR5-4609-22	Rear Anti Roll Bar Mounting Bush 22mm	22mm	2	9500	5
BMW	E53 X5 (1999–2006)	PFR5-4609-23.5	Rear Anti Roll Bar Mounting Bush 23.5mm	23.5mm	2	9500	5
BMW	E53 X5 (1999–2006)	PFR5-710	Rear Lower Arm Front Bush	12mm Bore Sleeve	2	13000	10
BMW	E53 X5 (1999–2006)	PFR5-711	Rear Lower Arm Rear Bush	14mm Bore Sleeve	2	14000	11
BMW	E53 X5 (1999–2006)	PFR5-715	Rear Outer Integral Link Upper Bush		2	14000	15
BMW	E53 X5 (1999–2006)	PFR5-716	Rear Outer Integral Link Lower Bush		2	11000	16
BMW	E53 X5 (1999–2006)	PFR5-908	Rear Subframe To Chassis Bush		4	79000	4
BMW	E70 X5 (2006–2013)	PFF5-1401	Front Radius Arm To Chassis Bush		2	19000	1
BMW	E70 X5 (2006–2013)	PFF5-1403-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	10000	3
BMW	E70 X5 (2006–2013)	PFF5-1404	Front Anti Roll Bar Mounting Bush		2	9000	3
BMW	E70 X5 (2006–2013)	PFR5-1413-22	Rear Anti Roll Bar Mounting Bush 22mm	22mm	2	9500	14
BMW	E70 X5 (2006–2013)	PFR5-1413-24	Rear Anti Roll Bar Mounting Bush 24mm	24mm	2	9500	14
BMW	E70 X5 (2006–2013)	PFR5-1414	Rear Anti Roll Bar Mounting Bush		2	9000	14
BMW	E70 X5 (2006–2013)	PFR5-1421	Rear Subframe Front Bush Insert		2	13000	21
BMW	E70 X5 (2006–2013)	PFR5-1423	Rear Subframe Rear Bush Insert		2	13000	23
BMW	E71 X6 (2007–)	PFF5-1401	Front Radius Arm To Chassis Bush		2	19000	1
BMW	E71 X6 (2007–)	PFF5-1403-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	10000	3
BMW	E71 X6 (2007–)	PFF5-1404	Front Anti Roll Bar Mounting Bush		2	9000	3

BMW	E71 X6 (2007-)	PFR5-1413-22	Rear Anti Roll Bar Mounting Bush 22mm	22mm	2	9500	14
BMW	E71 X6 (2007-)	PFR5-1413-24	Rear Anti Roll Bar Mounting Bush 24mm	24mm	2	9500	14
BMW	E71 X6 (2007-)	PFR5-1414	Rear Anti Roll Bar Mounting Bush		2	9000	14
BMW	E71 X6 (2007-)	PFR5-1421	Rear Subframe Front Bush Insert		2	13000	21
BMW	E71 X6 (2007-)	PFR5-1423	Rear Subframe Rear Bush Insert		2	13000	23
BMW	E83 X3 (2003-2010)	PFF5-1502	Front Control Arm To Chassis Bush		2	12500	2
BMW	E83 X3 (2003-2010)	PFF5-1503-22.5	Front Anti Roll Bar Mounting Bush 22.5mm	22.5mm	2	9500	3
BMW	E83 X3 (2003-2010)	PFF5-1503-23.5	Front Anti Roll Bar Mounting Bush 23.5mm	23.5mm	2	9500	3
BMW	E83 X3 (2003-2010)	PFF5-901	Front Lower Radius Arm To Chassis Bush		2	17500	1
BMW	E83 X3 (2003-2010)	PFR5-3608	Rear Trailing Arm Front Bush		2	13500	8
BMW	E83 X3 (2003-2010)	PFR5-4609-17.5	Rear Anti Roll Bar Mounting Bush 17.5mm	17.5mm	2	9500	5
BMW	E83 X3 (2003-2010)	PFR5-4609-18.5	Rear Anti Roll Bar Mounting Bush 18.5mm	18.5mm	2	9500	5
BMW	E83 X3 (2003-2010)	PFR5-4610	Rear Subframe Front Bush		2	18500	10
BMW	E83 X3 (2003-2010)	PFR5-4611	Rear Subframe Rear Bush		2	18500	11
BMW	E83 X3 (2003-2010)	PFR5-4613	Rear Subframe Rear Bush Insert		2	11500	11
BMW	E83 X3 (2003-2010)	PFR5-4614	Rear Subframe Front Bush Insert		2	11500	10
BMW	E83 X3 (2003-2010)	PFR5-4615G	Adjustable Rear Lower Control Arm Kit		1	31250	19
BMW	E83 X3 (2003-2010)	PFR5-4616	Rear lower Control Arm Inner Bush		2	16000	19
BMW	E83 X3 (2003-2010)	PFR5-4617	Rear Upper Arm Inner Bush		2	11000	17
BMW	E83 X3 (2003-2010)	PFR5-4618	Rear Lower Arm Outer Bush		2	12000	18
BMW	E83 X3 (2003-2010)	PFR5-4625	Rear Diff Front Bush		2	13000	25
BMW	E83 X3 (2003-2010)	PFR5-4626	Rear Diff Rear Bush		1	7750	26
BMW	E84 X1 (2008-2015)	PFF5-4602-26.5	Front Anti Roll Bar Mounting Bush 26.5mm	26.5mm	2	9500	3
BMW	E84 X1 (2008-2015)	PFR5-411	Rear Upper Control Arm To Chassis Bush		2	16500	11c
BMW	E84 X1 (2008-2015)	PFR5-411	Rear Toe Adjust Arm Inner & Outer Bush		4	33000	11a
BMW	E84 X1 (2008-2015)	PFR5-412	Rear Upper Control Arm To Hub Bush		2	17000	12a
BMW	E84 X1 (2008-2015)	PFR5-414	Rear Lower Lateral Arm To Hub Bush		2	22500	14
BMW	E84 X1 (2008-2015)	PFR5-415	Rear Lower Lateral Arm To Chassis Bush		2	14000	15
BMW	E84 X1 (2008-2015)	PFR5-416	Rear Shock Absorber Upper Mounting Bush	10mm	2	11000	16
BMW	E84 X1 (2008-2015)	PFR5-416-12	Rear Shock Absorber Upper Mounting Bush 12mm	12mm	2	11000	16
BMW	E84 X1 (2008-2015)	PFR5-425	Rear Diff Front Mounting Bush		2	14500	25
BMW	E84 X1 (2008-2015)	PFR5-426	Rear Diff Rear Mounting Bush		1	7500	26
BMW	E84 X1 (2008-2015)	PFR5-4609-11	Rear Anti Roll Bar Mounting Bush 11mm	11mm	2	9500	10
BMW	E84 X1 (2008-2015)	PFR5-4609-12	Rear Anti Roll Bar Mounting Bush 12mm	12mm	2	9500	10
BMW	E84 X1 (2008-2015)	PFR5-4609-13	Rear Anti Roll Bar Mounting Bush 13mm	13mm	2	9500	10
BMW	E84 X1 (2008-2015)	PFR5-4609-14	Rear Anti Roll Bar Mounting Bush 14mm	14mm	2	9500	10
BMW	E84 X1 (2008-2015)	PFR5-4609-15	Rear Anti Roll Bar Mounting Bush 15mm	15mm	2	9500	10
BMW	E84 X1 xDrive (2008-2015)	PFF5-5701	Front Control Arm to Chassis Bush		2	17000	2
BMW	E84 X1 xDrive (2008-2015)	PFF5-5703-26.5	Front Anti Roll Bar Mounting Bush 26.5mm	26.5mm	2	9500	3
BMW	E84 X1 xDrive (2008-2015)	PFR5-411	Rear Upper Control Arm To Chassis Bush		2	16500	11c
BMW	E84 X1 xDrive (2008-2015)	PFR5-411	Rear Toe Adjust Arm Inner & Outer Bush		4	33000	11a
BMW	E84 X1 xDrive (2008-2015)	PFR5-412	Rear Upper Control Arm To Hub Bush		2	17000	12a
BMW	E84 X1 xDrive (2008-2015)	PFR5-414	Rear Lower Lateral Arm To Hub Bush		2	22500	14
BMW	E84 X1 xDrive (2008-2015)	PFR5-415	Rear Lower Lateral Arm To Chassis Bush		2	14000	15
BMW	E84 X1 xDrive (2008-2015)	PFR5-416	Rear Shock Absorber Upper Mounting Bush	10mm	2	11000	16
BMW	E84 X1 xDrive (2008-2015)	PFR5-416-12	Rear Shock Absorber Upper Mounting Bush 12mm	12mm	2	11000	16
BMW	E84 X1 xDrive (2008-2015)	PFR5-425	Rear Diff Front Mounting Bush		2	14500	25
BMW	E84 X1 xDrive (2008-2015)	PFR5-426	Rear Diff Rear Mounting Bush		1	7500	26
BMW	E84 X1 xDrive (2008-2015)	PFR5-4609-11	Rear Anti Roll Bar Mounting Bush 11mm	11mm	2	9500	10
BMW	E84 X1 xDrive (2008-2015)	PFR5-4609-12	Rear Anti Roll Bar Mounting Bush 12mm	12mm	2	9500	10
BMW	E84 X1 xDrive (2008-2015)	PFR5-4609-13	Rear Anti Roll Bar Mounting Bush 13mm	13mm	2	9500	10
BMW	E84 X1 xDrive (2008-2015)	PFR5-4609-14	Rear Anti Roll Bar Mounting Bush 14mm	14mm	2	9500	10
BMW	E84 X1 xDrive (2008-2015)	PFR5-4609-15	Rear Anti Roll Bar Mounting Bush 15mm	15mm	2	9500	10
BMW	F15 X5 (2013-)	PFF5-1403-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	10000	3
BMW	F15 X5 (2013-)	PFF5-1404	Front Anti Roll Bar Mounting Bush		2	9000	3
BMW	F15 X5 (2013-)	PFR5-1413-24	Rear Anti Roll Bar Mounting Bush 24mm	24mm	2	9500	14
BMW	F15 X5 (2013-)	PFR5-1414	Rear Anti Roll Bar Mounting Bush		2	9000	14
BMW	F15 X5 (2013-)	PFR5-1421	Rear Subframe Front Bush Insert		2	13000	21
BMW	F15 X5 (2013-)	PFR5-1423	Rear Subframe Rear Bush Insert		2	13000	23

BMW	Z1 (1988 - 1991)	PFF5-301	Front Lower Wishbone Rear Bush		2	10500	1
BMW	Z1 (1988 - 1991)	PFF5-302-21	Front Anti Roll Bar Bush 21mm	21mm	2	7500	2
BMW	Z1 (1988 - 1991)	PFF5-303	Front Lower Wishbone Rear Bush Caster Offset		2	12500	1
BMW	Z1 (1988 - 1991)	PFF5-304	Anti Roll Bar Link Rod Bush		2	8500	3
BMW	Z1 (1988 - 1991)	PFR5-308-14	Rear Roll Bar Mounting Bush 14mm	14mm	2	7500	6
BMW	Z1 (1988 - 1991)	PFR5-4615G	Adjustable Rear Lower Control Arm Kit		1	31250	19
BMW	Z1 (1988 - 1991)	PFR5-4616	Rear lower Control Arm Inner Bush		2	16000	19
BMW	Z1 (1988 - 1991)	PFR5-4617	Rear Upper Arm Inner Bush		2	11000	17
BMW	Z1 (1988 - 1991)	PFR5-4618	Rear Lower Arm Outer Bush		2	12000	18
BMW	Z3 (1994 - 2002)	PFF5-301	Front Lower Wishbone Rear Bush		2	10500	1
BMW	Z3 (1994 - 2002)	PFF5-303	Front Lower Wishbone Rear Bush Caster Offset		2	12500	1
BMW	Z3 (1994 - 2002)	PFF5-304	Anti Roll Bar Link Rod Bush		2	8500	3
BMW	Z3 (1994 - 2002)	PFF5-310-23	Front Anti Roll Bar Mounting 23mm	23mm	2	8500	2
BMW	Z3 (1994 - 2002)	PFF5-310-24	Front Anti Roll Bar Mounting 24mm	24mm	2	8000	2
BMW	Z3 (1994 - 2002)	PFF5-310-25	Front Anti Roll Bar Mounting 25mm	25mm	2	8000	2
BMW	Z3 (1994 - 2002)	PFF5-310-26	Front Anti Roll Bar Mounting 26mm	26mm	2	8000	2
BMW	Z3 (1994 - 2002)	PFF5-310-27	Front Anti Roll Bar Mounting 27mm	27mm	2	8000	2
BMW	Z3 (1994 - 2002)	PFF5-310-28	Front Anti Roll Bar Mounting 28mm	28mm	2	8000	2
BMW	Z3 (1994 - 2002)	PFR5-300	Rear Diff Mounting Bush		1	6500	7
BMW	Z3 (1994 - 2002)	PFR5-306	Rear Trailing Arm Bush		4	25000	5
BMW	Z3 (1994 - 2002)	PFR5-306G	Rear Trailing Arm Bush Adjustable		4	34000	5
BMW	Z3 (1994 - 2002)	PFR5-311	Rear Beam Bush		2	17500	4
BMW	Z3 (1994 - 2002)	PFR5-504-14	Rear Anti Roll Bar Bush 14mm	14mm	2	7500	6
BMW	Z3 (1994 - 2002)	PFR5-504-15	Rear Roll Bar Mounting Bush 15mm	15mm	2	7500	6
BMW	Z3 (1994 - 2002)	PFR5-504-16	Rear Anti Roll Bar Bush 16mm	16mm	2	7500	6
BMW	Z3 (1994 - 2002)	PFR5-504-17	Rear Anti Roll Bar Bush 17mm	17mm	2	7500	6
BMW	Z3 (1994 - 2002)	PFR5-504-18	Rear Anti Roll Bar Bush 18mm	18mm	2	7500	6
BMW	Z3 (1994 - 2002)	PFR5-5630-10	Rear Shock Top Mount Bracket and Bush 10mm	10mm	2	18500	30
BMW	Z3 (1994 - 2002)	PFR5-5630-12	Rear Shock Top Mount Bracket and Bush 12mm	12mm	2	18500	30
BMW	Z4 E85 & E86 (2003-2009)	PFF5-4601	Front Wishbone Rear Bush	66mm	2	13000	1
BMW	Z4 E85 & E86 (2003-2009)	PFF5-4601-60	Front Wishbone Rear Bush	60mm	2	13000	1
BMW	Z4 E85 & E86 (2003-2009)	PFF5-4602-24	Front Anti Roll Bar Bush 24mm	24mm	2	9500	2
BMW	Z4 E85 & E86 (2003-2009)	PFF5-4602-25	Front Anti Roll Bar Bush 25mm	25mm	2	9500	2
BMW	Z4 E85 & E86 (2003-2009)	PFF5-4602-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	9500	2
BMW	Z4 E85 & E86 (2003-2009)	PFF5-5601	Front Wishbone Rear Bush, Aluminium Outer	66mm	2	31000	1
BMW	Z4 E85 & E86 (2003-2009)	PFF5-5601-60	Front Wishbone Rear Bush, Aluminium Outer	60mm	2	31000	1
BMW	Z4 E85 & E86 (2003-2009)	PFF5-5601G	Front Wishbone Rear Bush, Caster Offset	66mm	2	31500	1
BMW	Z4 E85 & E86 (2003-2009)	PFF5-5601G-60	Front Wishbone Rear Bush, Caster Offset	60mm	2	31500	1
BMW	Z4 E85 & E86 (2003-2009)	PFR5-3608	Rear Trailing Arm Bush		2	13500	3
BMW	Z4 E85 & E86 (2003-2009)	PFR5-4610	Rear Subframe Front Bush		2	18500	10
BMW	Z4 E85 & E86 (2003-2009)	PFR5-4611	Rear Subframe Rear Bush		2	18500	11
BMW	Z4 E85 & E86 (2003-2009)	PFR5-4613	Rear Subframe Rear Bush Insert		2	11500	11
BMW	Z4 E85 & E86 (2003-2009)	PFR5-4614	Rear Subframe Front Bush Insert		2	11500	10
BMW	Z4 E85 & E86 (2003-2009)	PFR5-4615G	Adjustable Rear Lower Control Arm Kit		1	31250	19
BMW	Z4 E85 & E86 (2003-2009)	PFR5-4616	Rear lower Control Arm Inner Bush		2	16000	19
BMW	Z4 E85 & E86 (2003-2009)	PFR5-4617	Rear Upper Arm Inner Bush		2	11000	17
BMW	Z4 E85 & E86 (2003-2009)	PFR5-4618	Rear Lower Arm Outer Bush		2	12000	18
BMW	Z4 E85 & E86 (2003-2009)	PFR5-4625	Rear Diff Front Bush		2	13000	25
BMW	Z4 E85 & E86 (2003-2009)	PFR5-4626	Rear Diff Rear Bush		1	7750	26
BMW	Z4 E85 & E86 (2003-2009)	PFR5-504-18	Rear Roll Bar Mounting Bush	18mm	2	7500	4
BMW	Z4 E85 & E86 (2003-2009)	PFR5-504-19	Rear Roll Bar Mounting Bush	19mm	2	7500	4
BMW	Z4 E85 & E86 (2003-2009)	PFR5-5630-10	Rear Shock Top Mount Bracket and Bush 10mm	10mm	2	18500	30
BMW	Z4 E85 & E86 (2003-2009)	PFR5-5630-12	Rear Shock Top Mount Bracket and Bush 12mm	12mm	2	18500	30
BMW	Z4M E85 & E86 (2006-2009)	PFF5-4602-27	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	9500	2
BMW	Z4M E85 & E86 (2006-2009)	PFF5-5601G	Front Wishbone Rear Bush, Caster Offset	66mm	2	31500	1
BMW	Z4M E85 & E86 (2006-2009)	PFR5-3608	Rear Trailing Arm Bush		2	13500	3
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4609-21.5	Rear Roll Bar Mounting Bush 21.5mm	21.5mm	2	9500	4
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4609-22.5	Rear Roll Bar Mounting Bush 22.5mm	22.5mm	2	9500	4
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4610	Rear Subframe Front Bush		2	18500	10

BMW	Z4M E85 & E86 (2006-2009)	PFR5-4611	Rear Subframe Rear Bush		2	18500	11
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4612	Rear Subframe Front Bush Insert		2	11500	10
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4613	Rear Subframe Rear Bush Insert		2	11500	11
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4615G	Adjustable Rear Lower Control Arm Kit		1	31250	19
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4616	Rear lower Control Arm Inner Bush		2	16000	19
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4617	Rear Upper Arm Inner Bush		2	11000	17
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4618	Rear Lower Arm Outer Bush		2	12000	18
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4620	Rear Diff Rear Mount		2	20000	20
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4621	Rear Diff Front Mount		1	6000	21
BMW	Z4M E85 & E86 (2006-2009)	PFR5-504-18	Rear Roll Bar Mounting Bush	18mm	2	7500	4
BMW	Z4 E89 (2009 -)	PFF5-401	Front Radius Arm To Chassis Bush		2	17000	1
BMW	Z4 E89 (2009 -)	PFF5-4602-26.5	Front Anti Roll Bar Mounting Bush 26.5mm	26.5mm	2	9500	3
BMW	Z4 E89 (2009 -)	PFR5-4610	Rear Subframe Front Bush		2	18500	10
BMW	Z4 E89 (2009 -)	PFR5-4611	Rear Subframe Rear Bush		2	18500	11
BMW	Z4 E89 (2009 -)	PFR5-4613	Rear Subframe Rear Bush Insert		2	11500	11
BMW	Z4 E89 (2009 -)	PFR5-4615G	Adjustable Rear Lower Control Arm Kit		1	31250	19
BMW	Z4 E89 (2009 -)	PFR5-4616	Rear lower Control Arm Inner Bush		2	16000	19
BMW	Z4 E89 (2009 -)	PFR5-4617	Rear Upper Arm Inner Bush		2	11000	17
BMW	Z4 E89 (2009 -)	PFR5-4618	Rear Lower Arm Outer Bush		2	12000	18
BMW	Z4 E89 (2009 -)	PFR5-504-19	Rear Roll Bar Mounting Bush	19mm	2	7500	4
BMW	1502-2002 (1962 - 1977)	PFF5-2001BLK	Front Lower Arm Inner Bush		2	12000	1
BMW	1502-2002 (1962 - 1977)	PFF5-2002BLK	Front Lower Arm Outer Bush		2	12000	2
BMW	1502-2002 (1962 - 1977)	PFF5-2003-15BLK	Anti Roll Bar Bush 15mm	15mm	2	7500	3
BMW	1502-2002 (1962 - 1977)	PFF5-2003-16BLK	Anti Roll Bar Bush 16mm	16mm	2	8000	3
BMW	1502-2002 (1962 - 1977)	PFF5-2004BLK	Anti Roll Bar Link Rod Bush		2	12500	4
BMW	1502-2002 (1962 - 1977)	PFF5-2005BLK	Tie Bar To Chassis Front Bush		2	13000	5
BMW	1502-2002 (1962 - 1977)	PFR5-2020BLK	Rear Beam Mount Bush Inserts		2	11500	20
BMW	1502-2002 (1962 - 1977)	PFR5-2021BLK	Rear Beam Mount Bush		2	17000	20
BMW	1502-2002 (1962 - 1977)	PFR5-2025BLK	Rear Diff Rear Mounting Bush		2	13500	25
BMW	1502-2002 (1962 - 1977)	PFR5-306BLK	Rear Trailing Arm Bush		4	27000	6
BMW	1502-2002 (1962 - 1977)	PFR5-306GBLK	Rear Trailing Arm Bush Adjustable		4	37000	6
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFF5-401BLK	Front Radius Arm To Chassis Bush		2	18500	1
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFF5-402BLK	Front Control Arm To Chassis Bush		2	30000	2
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFF5-4602-26.5BLK	Front Anti Roll Bar Mounting Bush 26.5mm	26.5mm	2	10500	3
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-1220BLK	Rear Subframe, Front Bush		2	33500	19
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-411BLK	Rear Upper Control Arm To Chassis Bush		2	16500	11c
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-411BLK	Rear Trailing Arm Inner & Outer Bush		4	33000	11b
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-411BLK	Rear Toe Adjust Arm Inner & Outer Bush		4	33000	11a
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-412BLK	Rear Upper Control Arm To Hub Bush		2	17000	12a
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-412BLK	Rear Upper Lateral Arm To Hub Bush		2	17000	12b
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-413BLK	Rear Upper Lateral Arm To Chassis Bush		2	24500	13
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-414BLK	Rear Lower Lateral Arm To Hub Bush		2	24500	14
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-415BLK	Rear Lower Lateral Arm To Chassis Bush		2	14000	15
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-416-12BLK	Rear Shock Absorber Upper Mounting Bush 12mm	12mm	2	12500	16
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-416BLK	Rear Shock Absorber Upper Mounting Bush	10mm	2	12500	16
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-419BLK	Rear Subframe Front Mount Insert		2	13500	19
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-420BLK	Rear Subframe Front Mounting Bush		2	31000	19
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-421BLK	Rear Subframe Rear Mounting Insert		2	13500	20
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-422BLK	Rear Subframe Rear Mounting Bush		2	26500	20
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-423BLK	Rear Subframe Rear Mounting Insert		2	13500	20
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-425BLK	Rear Diff Front Mounting Bush		2	16000	25
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-426BLK	Rear Diff Rear Mounting Bush		1	8250	26
BMW	E81, E82, E87 & E88 1 Series (2004-2013)	PFR5-4609-11BLK	Rear Anti Roll Bar Mounting Bush 11mm	11mm	2	10500	10
BMW	E82 1 Series M Coupe (2010-2012)	PFF5-1203-26.5BLK	Front Anti Roll Bar Bush 26.5mm	26.5mm	2	10000	3
BMW	E82 1 Series M Coupe (2010-2012)	PFF5-1203-28BLK	Front Anti Roll Bar Bush 28mm	28mm	2	10000	3
BMW	E82 1 Series M Coupe (2010-2012)	PFF5-401BLK	Front Radius Arm To Chassis Bush		2	18500	1
BMW	E82 1 Series M Coupe (2010-2012)	PFR5-1210-22.5BLK	Rear Anti Roll Bar Bush 22.5mm	22.5mm	2	10000	10
BMW	E82 1 Series M Coupe (2010-2012)	PFR5-1210-23.6BLK	Rear Anti Roll Bar Bush 23.6mm	23.6mm	2	10000	10
BMW	E82 1 Series M Coupe (2010-2012)	PFR5-1212BLK	Rear Upper Arm Outer Bush		4	32000	12

BMW	E82 1 Series M Coupe (2010-2012)	PFR5-1213BLK	Rear Lower Front Arm Inner Bush		2	13500	13
BMW	E82 1 Series M Coupe (2010-2012)	PFR5-1215BLK	Rear Lower Lateral Arm Inner Bush		2	21500	15
BMW	E82 1 Series M Coupe (2010-2012)	PFR5-1220BLK	Rear Subframe, Front Bush		2	33500	19
BMW	E82 1 Series M Coupe (2010-2012)	PFR5-1226BLK	Rear Diff Rear Mounting Bush		1	7250	26
BMW	E82 1 Series M Coupe (2010-2012)	PFR5-411BLK	Rear Trailing Arm Outer Bush		2	16500	11
BMW	E82 1 Series M Coupe (2010-2012)	PFR5-422BLK	Rear Subframe Rear Mounting Bush		2	26500	20
BMW	E82 1 Series M Coupe (2010-2012)	PFR5-425BLK	Rear Diff Front Mounting Bush		2	16000	25
BMW	F20, F21 1 Series	PFF5-1901BLK	Front Radius Arm To Chassis Bush		2	21000	1
BMW	F20, F21 1 Series	PFF5-1901GBLK	Front Radius Arm To Chassis Bush Caster Adjustable		2	25500	1
BMW	F20, F21 1 Series	PFF5-1902BLK	Front Control Arm To Chassis Bush		2	13500	2
BMW	F20, F21 1 Series	PFF5-1902GBLK	Front Control Arm to Chassis Bush - Camber Adjustable		2	21000	2
BMW	F20, F21 1 Series	PFF5-1903-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	10500	3
BMW	F20, F21 1 Series	PFF5-1903-25BLK	Front Anti Roll Bar Bush 25mm	25mm	2	10500	3
BMW	F20, F21 1 Series	PFR5-1913-12BLK	Rear Anti Roll Bar Bush 12mm	12mm	2	9500	13
BMW	F20, F21 1 Series	PFR5-1913-13BLK	Rear Anti Roll Bar Bush 13mm	13mm	2	9500	13
BMW	F20, F21 1 Series	PFR5-1920BLK	Rear Subframe Front Bush Insert		2	12500	20
BMW	F20, F21 1 Series	PFR5-1921BLK	Rear Subframe Rear Bush Insert		2	11500	21
BMW	F20, F21 1 Series	PFR5-1927BLK	Rear Diff Front Bush Insert		2	11000	27
BMW	F20, F21 1 Series xDrive	PFF5-1903-22.5BLK	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	10500	3
BMW	F20, F21 1 Series xDrive	PFF5-1903-23.6BLK	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	10500	3
BMW	F20, F21 1 Series xDrive	PFF5-4101BLK	Front Radius Arm To Chassis Bush		2	21000	1
BMW	F20, F21 1 Series xDrive	PFF5-4102BLK	Front Control Arm To Chassis Bush		2	15500	2
BMW	F20, F21 1 Series xDrive	PFR5-1913-12BLK	Rear Anti Roll Bar Bush 12mm	12mm	2	9500	13
BMW	F20, F21 1 Series xDrive	PFR5-1913-13BLK	Rear Anti Roll Bar Bush 13mm	13mm	2	9500	13
BMW	F20, F21 1 Series xDrive	PFR5-1920BLK	Rear Subframe Front Bush Insert		2	12500	20
BMW	F20, F21 1 Series xDrive	PFR5-1921BLK	Rear Subframe Rear Bush Insert		2	11500	21
BMW	F20, F21 1 Series xDrive	PFR5-1927BLK	Rear Diff Front Bush Insert		2	11000	27
BMW	F22, F23 2 Series	PFF5-1901BLK	Front Radius Arm To Chassis Bush		2	21000	1
BMW	F22, F23 2 Series	PFF5-1901GBLK	Front Radius Arm To Chassis Bush Caster Adjustable		2	25500	1
BMW	F22, F23 2 Series	PFF5-1902BLK	Front Control Arm To Chassis Bush		2	13500	2
BMW	F22, F23 2 Series	PFF5-1902GBLK	Front Control Arm to Chassis Bush - Camber Adjustable		2	21000	2
BMW	F22, F23 2 Series	PFF5-1903-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	10500	3
BMW	F22, F23 2 Series	PFF5-1903-25BLK	Front Anti Roll Bar Bush 25mm	25mm	2	10500	3
BMW	F22, F23 2 Series	PFR5-1913-12BLK	Rear Anti Roll Bar Bush 12mm	12mm	2	9500	13
BMW	F22, F23 2 Series	PFR5-1913-13BLK	Rear Anti Roll Bar Bush 13mm	13mm	2	9500	13
BMW	F22, F23 2 Series	PFR5-1920BLK	Rear Subframe Front Bush Insert		2	12500	20
BMW	F22, F23 2 Series	PFR5-1921BLK	Rear Subframe Rear Bush Insert		2	11500	21
BMW	F22, F23 2 Series	PFR5-1927BLK	Rear Diff Front Bush Insert		2	11000	27
BMW	F22, F23 2 Series xDrive	PFF5-1903-22.5BLK	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	10500	3
BMW	F22, F23 2 Series xDrive	PFF5-4101BLK	Front Radius Arm To Chassis Bush		2	21000	1
BMW	F22, F23 2 Series xDrive	PFF5-4102BLK	Front Control Arm To Chassis Bush		2	15500	2
BMW	F22, F23 2 Series xDrive	PFR5-1913-12BLK	Rear Anti Roll Bar Bush 12mm	12mm	2	9500	13
BMW	F22, F23 2 Series xDrive	PFR5-1913-13BLK	Rear Anti Roll Bar Bush 13mm	13mm	2	9500	13
BMW	F22, F23 2 Series xDrive	PFR5-1920BLK	Rear Subframe Front Bush Insert		2	12500	20
BMW	F22, F23 2 Series xDrive	PFR5-1921BLK	Rear Subframe Rear Bush Insert		2	11500	21
BMW	F22, F23 2 Series xDrive	PFR5-1927BLK	Rear Diff Front Bush Insert		2	11000	27
BMW	F87 2 Series M2	PFF5-1203-26.5BLK	Front Anti Roll Bar Bush 26.5mm	26.5mm	2	10000	3
BMW	F87 2 Series M2	PFF5-1203-28BLK	Front Anti Roll Bar Bush 28mm	28mm	2	10000	3
BMW	F87 2 Series M2	PFF5-4001BLK	Front Radius Arm To Chassis Bush		2	19500	1
BMW	F87 2 Series M2	PFF5-4001GBLK	Front Radius Arm To Chassis BushCaster Offset		2	21000	1
BMW	F87 2 Series M2	PFR5-4025BLK	Rear Diff Front Mounting Bush		4	51000	21
BMW	F87 2 Series M2	PFR5-4026BLK	Rear Diff Rear Mounting Bush		1	17000	22
BMW	E21 3 Series (1975 - 1978)	PFF5-1601BLK	Front Arm Inner Bush		2	12000	1
BMW	E21 3 Series (1975 - 1978)	PFF5-1603-22BLK	Front Anti Roll Bar Bush 22mm	22	2	8000	3
BMW	E21 3 Series (1975 - 1978)	PFF5-1603-23.5BLK	Front Anti Roll Bar Bush 23.5mm	23.5mm	2	8000	3
BMW	E21 3 Series (1975 - 1978)	PFF5-1702BLK	Front Arm Outer Bush		2	11500	2
BMW	E21 3 Series (1975 - 1978)	PFR5-1610-16BLK	Rear Anti Roll Bar Bush 16mm	16mm	2	8000	10
BMW	E21 3 Series (1975 - 1978)	PFR5-1611BLK	Rear Anti Roll Bar Link Rod Bush		2	11500	11
BMW	E21 3 Series (1975 - 1978)	PFR5-1620BLK	Rear Axle Carrier Mount Bush		2	15500	20

BMW	E21 3 Series (1975 - 1978)	PFR5-1625BLK	Rear Diff Mounting Bush		2	13500	25
BMW	E21 3 Series (1975 - 1978)	PFR5-306BLK	Rear Trailing Arm Bush		4	27000	5
BMW	E21 3 Series (1975 - 1978)	PFR5-306GBLK	Rear Trailing Arm Bush Adjustable		4	37000	5
BMW	E21 3 Series (1978 - 1983)	PFF5-1601BLK	Front Arm Inner Bush		2	12000	1
BMW	E21 3 Series (1978 - 1983)	PFF5-1602BLK	Front Arm Outer Bush		2	15000	2
BMW	E21 3 Series (1978 - 1983)	PFF5-1603-22BLK	Front Anti Roll Bar Bush 22mm	22	2	8000	3
BMW	E21 3 Series (1978 - 1983)	PFF5-1603-23.5BLK	Front Anti Roll Bar Bush 23.5mm	23.5mm	2	8000	3
BMW	E21 3 Series (1978 - 1983)	PFR5-1610-16BLK	Rear Anti Roll Bar Bush 16mm	16mm	2	8000	10
BMW	E21 3 Series (1978 - 1983)	PFR5-1611BLK	Rear Anti Roll Bar Link Rod Bush		2	11500	11
BMW	E21 3 Series (1978 - 1983)	PFR5-1620BLK	Rear Axle Carrier Mount Bush		2	15500	20
BMW	E21 3 Series (1978 - 1983)	PFR5-1625BLK	Rear Diff Mounting Bush		2	13500	25
BMW	E21 3 Series (1978 - 1983)	PFR5-306BLK	Rear Trailing Arm Bush		4	27000	5
BMW	E21 3 Series (1978 - 1983)	PFR5-306GBLK	Rear Trailing Arm Bush Adjustable		4	37000	5
BMW	E30 3 Series (1982 - 1991)	PFF5-301BLK	Front Lower Wishbone Rear Bush		2	11500	1
BMW	E30 3 Series (1982 - 1991)	PFF5-302-19BLK	Front Anti Roll Bar Bush 19mm	19mm	2	8500	2
BMW	E30 3 Series (1982 - 1991)	PFF5-302-20BLK	Front Anti Roll Bar Bush 20mm	20mm	2	8500	2
BMW	E30 3 Series (1982 - 1991)	PFF5-302-22BLK	Front Anti Roll Bar Bush 22mm	22mm	2	8500	2
BMW	E30 3 Series (1982 - 1991)	PFF5-303BLK	Front Lower Wishbone Rear Bush Caster Offset		2	13500	1
BMW	E30 3 Series (1982 - 1991)	PFF5-304BLK	Anti Roll Bar Link Rod Bush		2	9500	3
BMW	E30 3 Series (1982 - 1991)	PFR5-300BLK	Rear Diff Mounting Bush		1	7250	7
BMW	E30 3 Series (1982 - 1991)	PFR5-305BLK	Rear Beam Mounting Bush		2	19500	4
BMW	E30 3 Series (1982 - 1991)	PFR5-306BLK	Rear Trailing Arm Bush		4	27000	5
BMW	E30 3 Series (1982 - 1991)	PFR5-306GBLK	Rear Trailing Arm Bush Adjustable		4	37000	5
BMW	E30 3 Series (1982 - 1991)	PFR5-308-12BLK	Rear Roll Bar Mounting Bush 12mm	12mm	2	8500	6
BMW	E30 3 Series (1982 - 1991)	PFR5-308-13BLK	Rear Anti Roll Bar Mounting Bush 13mm		2	8500	6
BMW	E30 3 Series (1982 - 1991)	PFR5-308-14BLK	Rear Roll Bar Mounting Bush 14mm	14mm	2	8500	6
BMW	E30 3 Series (1982 - 1991)	PFR5-308-15.5BLK	Rear Anti Roll Bar Mounting Bush 15.5mm	15.5mm	2	8500	6
BMW	E30 3 Series (1982 - 1991)	PFR5-308-16BLK	Rear Roll Bar Mounting Bush 16mm	16mm	2	8500	6
BMW	E30 3 Series (1982 - 1991)	PFR5-308-18BLK	Rear Roll Bar Mounting Bush 18mm	18mm	2	8500	6
BMW	E30 3 Series (1982 - 1991)	PFR5-315BLK	Rear Anti Roll Bar Link To Arm Bush		2	7500	15
BMW	E30 3 Series (1982 - 1991)	PFR5-316BLK	Rear Anti Roll Bar Link To Anti Roll Bar Bush		2	7500	16
BMW	E30 3 Series (1982 - 1991)	PFR5-5630-10BLK	Rear Shock Top Mount Bracket and Bush 10mm	10mm	2	18500	30
BMW	E30 3 Series (1982 - 1991)	PFR5-5630-12BLK	Rear Shock Top Mount Bracket and Bush 12mm	12mm	2	18500	30
BMW	E36 3 Series (1990 - 1998)	PFF5-301BLK	Front Lower Wishbone Rear Bush		2	11500	1
BMW	E36 3 Series (1990 - 1998)	PFF5-303BLK	Front Lower Wishbone Rear Bush Caster Offset		2	13500	1
BMW	E36 3 Series (1990 - 1998)	PFF5-304BLK	Anti Roll Bar Link Rod Bush		2	9500	3
BMW	E36 3 Series (1990 - 1998)	PFF5-310-23BLK	Front Anti Roll Bar Mounting 23mm	23mm	2	9000	2
BMW	E36 3 Series (1990 - 1998)	PFF5-310-24BLK	Front Anti Roll Bar Mounting 24mm	24mm	2	9000	2
BMW	E36 3 Series (1990 - 1998)	PFF5-310-25BLK	Front Anti Roll Bar Mounting 25mm	25mm	2	9000	2
BMW	E36 3 Series (1990 - 1998)	PFF5-310-26BLK	Front Anti Roll Bar Mounting 26mm	26mm	2	9000	2
BMW	E36 3 Series (1990 - 1998)	PFF5-310-27BLK	Front Anti Roll Bar Mounting 27mm	27mm	2	9000	2
BMW	E36 3 Series (1990 - 1998)	PFF5-310-28BLK	Front Anti Roll Bar Mounting 28mm	28mm	2	9000	2
BMW	E36 3 Series (1990 - 1998)	PFR5-315BLK	Rear Anti Roll Bar Link To Arm Bush		2	7500	15
BMW	E36 3 Series (1990 - 1998)	PFR5-316BLK	Rear Anti Roll Bar Link To Anti Roll Bar Bush		2	7500	16
BMW	E36 3 Series (1990 - 1998)	PFR5-324BLK	Rear Diff Front Mounting Bush, M3 Evo Only		1	7750	25
BMW	E36 3 Series (1990 - 1998)	PFR5-325BLK	Rear Diff Front Mounting Bush		1	6750	25
BMW	E36 3 Series (1990 - 1998)	PFR5-326BLK	Rear Diff Rear Mounting Bush		2	21000	26
BMW	E36 3 Series (1990 - 1998)	PFR5-3606BLK	Rear Subframe Rear Mounting Bush		2	17000	7
BMW	E36 3 Series (1990 - 1998)	PFR5-3607BLK	Rear Subframe Front Mounting Bush		2	17000	6
BMW	E36 3 Series (1990 - 1998)	PFR5-3608BLK	Rear Trailing Arm Front Bush		2	13500	8
BMW	E36 3 Series (1990 - 1998)	PFR5-3616BLK	Rear Subframe Rear Mounting Bush Insert		2	13000	7
BMW	E36 3 Series (1990 - 1998)	PFR5-3617BLK	Rear Subframe Front Mounting Bush Insert		2	13000	6
BMW	E36 3 Series (1990 - 1998)	PFR5-4615G	Adjustable Rear Lower Control Arm Kit		1	31250	19
BMW	E36 3 Series (1990 - 1998)	PFR5-4616BLK	Rear Lower Control Arm Inner Bush		2	16000	19
BMW	E36 3 Series (1990 - 1998)	PFR5-4617BLK	Rear Upper Arm Inner Bush		2	11000	17
BMW	E36 3 Series (1990 - 1998)	PFR5-4618BLK	Rear Lower Arm Outer Bush		2	12000	18
BMW	E36 3 Series (1990 - 1998)	PFR5-504-15BLK	Rear Roll Bar Mounting Bush 15mm	15mm	2	8500	5
BMW	E36 3 Series (1990 - 1998)	PFR5-504-18BLK	Rear Roll Bar Mounting Bush 18mm	18mm	2	8500	5
BMW	E36 3 Series (1990 - 1998)	PFR5-504-19BLK	Rear Roll Bar Mounting Bush 19mm	19mm	2	8500	5

BMW	E36 3 Series (1990 - 1998)	PFR5-504-20BLK	Rear Roll Bar Mounting Bush 20mm	20mm	2	8500	5
BMW	E36 3 Series (1990 - 1998)	PFR5-5630-10BLK	Rear Shock Top Mount Bracket and Bush 10mm	10mm	2	18500	30
BMW	E36 3 Series (1990 - 1998)	PFR5-5630-12BLK	Rear Shock Top Mount Bracket and Bush 12mm	12mm	2	18500	30
BMW	E36 3 Series Compact (1993-2000)	PFF5-301BLK	Front Lower Wishbone Rear Bush		2	11500	1
BMW	E36 3 Series Compact (1993-2000)	PFF5-303BLK	Front Lower Wishbone Rear Bush Caster Offset		2	13500	1
BMW	E36 3 Series Compact (1993-2000)	PFF5-304BLK	Anti Roll Bar Link Rod Bush		2	9500	3
BMW	E36 3 Series Compact (1993-2000)	PFF5-310-23BLK	Front Anti Roll Bar Mounting 23mm	23mm	2	9000	2
BMW	E36 3 Series Compact (1993-2000)	PFF5-310-24BLK	Front Anti Roll Bar Mounting 24mm	24mm	2	9000	2
BMW	E36 3 Series Compact (1993-2000)	PFF5-310-25BLK	Front Anti Roll Bar Mounting 25mm	25mm	2	9000	2
BMW	E36 3 Series Compact (1993-2000)	PFF5-310-26BLK	Front Anti Roll Bar Mounting 26mm	26mm	2	9000	2
BMW	E36 3 Series Compact (1993-2000)	PFF5-310-27BLK	Front Anti Roll Bar Mounting 27mm	27mm	2	9000	2
BMW	E36 3 Series Compact (1993-2000)	PFF5-310-28BLK	Front Anti Roll Bar Mounting 28mm	28mm	2	9000	2
BMW	E36 3 Series Compact (1993-2000)	PFR5-300BLK	Rear Diff Mounting Bush		1	7250	7
BMW	E36 3 Series Compact (1993-2000)	PFR5-306BLK	Rear Trailing Arm Bush		4	27000	5
BMW	E36 3 Series Compact (1993-2000)	PFR5-306GBLK	Rear Trailing Arm Bush Adjustable		4	37000	5
BMW	E36 3 Series Compact (1993-2000)	PFR5-308-12BLK	Rear Roll Bar Mounting Bush 12mm	12mm	2	8500	6
BMW	E36 3 Series Compact (1993-2000)	PFR5-308-14BLK	Rear Roll Bar Mounting Bush 14mm	14mm	2	8500	6
BMW	E36 3 Series Compact (1993-2000)	PFR5-308-16BLK	Rear Roll Bar Mounting Bush 16mm	16mm	2	8500	6
BMW	E36 3 Series Compact (1993-2000)	PFR5-311BLK	Rear Beam Bush		2	19500	4
BMW	E36 3 Series Compact (1993-2000)	PFR5-5630-10BLK	Rear Shock Top Mount Bracket and Bush 10mm	10mm	2	18500	30
BMW	E36 3 Series Compact (1993-2000)	PFR5-5630-12BLK	Rear Shock Top Mount Bracket and Bush 12mm	12mm	2	18500	30
BMW	E46 3 Series Compact	PFF5-4601-60BLK	Front Wishbone Rear Bush	60mm	2	14500	1
BMW	E46 3 Series Compact	PFF5-4601BLK	Front Wishbone Rear Bush	66mm	2	14500	1
BMW	E46 3 Series Compact	PFF5-4602-21BLK	Front Anti Roll Bar Bush 21.5mm	21.5mm	2	10500	2
BMW	E46 3 Series Compact	PFF5-4602-23.5BLK	Front Anti Roll Bar Bush 23.5mm	23.5mm	2	10500	2
BMW	E46 3 Series Compact	PFF5-4602-23BLK	Front Anti Roll Bar Bush 23mm	23mm	2	10500	2
BMW	E46 3 Series Compact	PFF5-4602-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	10500	2
BMW	E46 3 Series Compact	PFF5-4602-26BLK	Front Anti Roll Bar Bush 26mm	26mm	2	10500	2
BMW	E46 3 Series Compact	PFF5-4602-27BLK	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	10500	2
BMW	E46 3 Series Compact	PFF5-4602-30.8BLK	Front Anti Roll Bar Bush 30.8mm	30.8mm	2	10500	2
BMW	E46 3 Series Compact	PFF5-5601-60BLK	Front Wishbone Rear Bush, Aluminium Outer	60mm	2	32500	1
BMW	E46 3 Series Compact	PFF5-5601BLK	Front Wishbone Rear Bush, Aluminium Outer	66mm	2	32500	1
BMW	E46 3 Series Compact	PFF5-5601G-60BLK	Front Wishbone Rear Bush, Caster Offset	60mm	2	33000	1
BMW	E46 3 Series Compact	PFF5-5601GBLK	Front Wishbone Rear Bush, Caster Offset	66mm	2	33000	1
BMW	E46 3 Series Compact	PFR5-3608BLK	Rear Trailing Arm Bush		2	13500	3
BMW	E46 3 Series Compact	PFR5-4610BLK	Rear Subframe Front Bush		2	20500	10
BMW	E46 3 Series Compact	PFR5-4611BLK	Rear Subframe Rear Bush		2	20500	11
BMW	E46 3 Series Compact	PFR5-4613BLK	Rear Subframe Rear Bush Insert		2	13000	11
BMW	E46 3 Series Compact	PFR5-4614BLK	Rear Subframe Front Bush Insert		2	13000	10
BMW	E46 3 Series Compact	PFR5-4615G	Adjustable Rear Lower Control Arm Kit		1	31250	19
BMW	E46 3 Series Compact	PFR5-4616BLK	Rear Lower Control Arm Inner Bush		2	16000	19
BMW	E46 3 Series Compact	PFR5-4617BLK	Rear Upper Arm Inner Bush		2	11000	17
BMW	E46 3 Series Compact	PFR5-4618BLK	Rear Lower Arm Outer Bush		2	12000	18
BMW	E46 3 Series Compact	PFR5-4625BLK	Rear Diff Front Bush		2	14500	25
BMW	E46 3 Series Compact	PFR5-4626BLK	Rear Diff Rear Bush		1	8500	26
BMW	E46 3 Series Compact	PFR5-504-15BLK	Rear Roll Bar Mounting Bush 15mm	15mm	2	8500	4
BMW	E46 3 Series Compact	PFR5-504-18BLK	Rear Roll Bar Mounting Bush 18mm	18mm	2	8500	4
BMW	E46 3 Series Compact	PFR5-504-19BLK	Rear Roll Bar Mounting Bush 19mm	19mm	2	8500	4
BMW	E46 3 Series Compact	PFR5-5630-10BLK	Rear Shock Top Mount Bracket and Bush 10mm	10mm	2	18500	30
BMW	E46 3 Series Compact	PFR5-5630-12BLK	Rear Shock Top Mount Bracket and Bush 12mm	12mm	2	18500	30
BMW	E46 3 Series inc Touring	PFF5-4601-60BLK	Front Wishbone Rear Bush	60mm	2	14500	1
BMW	E46 3 Series inc Touring	PFF5-4601BLK	Front Wishbone Rear Bush	66mm	2	14500	1
BMW	E46 3 Series inc Touring	PFF5-4602-21BLK	Front Anti Roll Bar Bush 21.5mm	21.5mm	2	10500	2
BMW	E46 3 Series inc Touring	PFF5-4602-23.5BLK	Front Anti Roll Bar Bush 23.5mm	23.5mm	2	10500	2
BMW	E46 3 Series inc Touring	PFF5-4602-23BLK	Front Anti Roll Bar Bush 23mm	23mm	2	10500	2
BMW	E46 3 Series inc Touring	PFF5-4602-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	10500	2
BMW	E46 3 Series inc Touring	PFF5-4602-26BLK	Front Anti Roll Bar Bush 26mm	26mm	2	10500	2
BMW	E46 3 Series inc Touring	PFF5-4602-27BLK	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	10500	2
BMW	E46 3 Series inc Touring	PFF5-4602-30.8BLK	Front Anti Roll Bar Bush 30.8mm	30.8mm	2	10500	2

BMW	E46 3 Series inc Touring	PFF5-5601-60BLK	Front Wishbone Rear Bush, Aluminium Outer	60mm	2	32500	1
BMW	E46 3 Series inc Touring	PFF5-5601BLK	Front Wishbone Rear Bush, Aluminium Outer	66mm	2	32500	1
BMW	E46 3 Series inc Touring	PFF5-5601G-60BLK	Front Wishbone Rear Bush, Caster Offset	60mm	2	33000	1
BMW	E46 3 Series inc Touring	PFF5-5601GBLK	Front Wishbone Rear Bush, Caster Offset	66mm	2	33000	1
BMW	E46 3 Series inc Touring	PFR5-3608BLK	Rear Trailing Arm Bush		2	13500	3
BMW	E46 3 Series inc Touring	PFR5-4610BLK	Rear Subframe Front Bush		2	20500	10
BMW	E46 3 Series inc Touring	PFR5-4611BLK	Rear Subframe Rear Bush		2	20500	11
BMW	E46 3 Series inc Touring	PFR5-4613BLK	Rear Subframe Rear Bush Insert		2	13000	11
BMW	E46 3 Series inc Touring	PFR5-4614BLK	Rear Subframe Front Bush Insert		2	13000	10
BMW	E46 3 Series inc Touring	PFR5-4615G	Adjustable Rear Lower Control Arm Kit		1	31250	19
BMW	E46 3 Series inc Touring	PFR5-4616BLK	Rear Lower Control Arm Inner Bush		2	16000	19
BMW	E46 3 Series inc Touring	PFR5-4617BLK	Rear Upper Arm Inner Bush		2	11000	17
BMW	E46 3 Series inc Touring	PFR5-4618BLK	Rear Lower Arm Outer Bush		2	12000	18
BMW	E46 3 Series inc Touring	PFR5-4625BLK	Rear Diff Front Bush		2	14500	25
BMW	E46 3 Series inc Touring	PFR5-4626BLK	Rear Diff Rear Bush		1	8500	26
BMW	E46 3 Series inc Touring	PFR5-504-15BLK	Rear Roll Bar Mounting Bush 15mm	15mm	2	8500	4
BMW	E46 3 Series inc Touring	PFR5-504-18BLK	Rear Roll Bar Mounting Bush 18mm	18mm	2	8500	4
BMW	E46 3 Series inc Touring	PFR5-504-19BLK	Rear Roll Bar Mounting Bush 19mm	19mm	2	8500	4
BMW	E46 3 Series inc Touring	PFR5-504-20BLK	Rear Roll Bar Mounting Bush 20mm	20mm	2	8500	4
BMW	E46 3 Series inc Touring	PFR5-5630-10BLK	Rear Shock Top Mount Bracket and Bush 10mm	10mm	2	18500	30
BMW	E46 3 Series inc Touring	PFR5-5630-12BLK	Rear Shock Top Mount Bracket and Bush 12mm	12mm	2	18500	30
BMW	E46 3 Series M3	PFF5-4601M3BLK	Front Wishbone Rear Bush	60mm	2	15500	1
BMW	E46 3 Series M3	PFF5-4602-26BLK	Front Anti Roll Bar Bush 26mm	26mm	2	10500	2
BMW	E46 3 Series M3	PFF5-4602-27BLK	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	10500	2
BMW	E46 3 Series M3	PFF5-4602-30.8BLK	Front Anti Roll Bar Bush 30.8mm	30.8mm	2	10500	2
BMW	E46 3 Series M3	PFF5-5601GM3BLK	Front Wishbone Rear Bush, Caster Offset	60mm	2	33000	1
BMW	E46 3 Series M3	PFF5-5601M3BLK	Front Wishbone Rear Bush, Aluminium Outer	60mm	2	32500	1
BMW	E46 3 Series M3	PFR5-3608BLK	Rear Trailing Arm Bush		2	13500	3
BMW	E46 3 Series M3	PFR5-4609-21.5BLK	Rear Roll Bar Mounting Bush 21.5mm	21.5mm	2	10500	4
BMW	E46 3 Series M3	PFR5-4609-22.5BLK	Rear Roll Bar Mounting Bush 22.5mm	22.5mm	2	10500	4
BMW	E46 3 Series M3	PFR5-4610M3BLK	Rear Subframe Front Bush		2	20500	10
BMW	E46 3 Series M3	PFR5-4611BLK	Rear Subframe Rear Bush		2	20500	11
BMW	E46 3 Series M3	PFR5-4612BLK	Rear Subframe Front Bush Insert		2	13000	10
BMW	E46 3 Series M3	PFR5-4613BLK	Rear Subframe Rear Bush Insert		2	13000	11
BMW	E46 3 Series M3	PFR5-4615G	Adjustable Rear Lower Control Arm Kit		1	31250	19
BMW	E46 3 Series M3	PFR5-4616BLK	Rear Lower Control Arm Inner Bush		2	16000	19
BMW	E46 3 Series M3	PFR5-4617BLK	Rear Upper Arm Inner Bush		2	11000	17
BMW	E46 3 Series M3	PFR5-4618BLK	Rear Lower Arm Outer Bush		2	12000	18
BMW	E46 3 Series M3	PFR5-4620BLK	Rear Diff Rear Mount		2	20000	20
BMW	E46 3 Series M3	PFR5-4621BLK	Rear Diff Front Mount		1	6000	21
BMW	E46 3 Series M3	PFR5-5630-10BLK	Rear Shock Top Mount Bracket and Bush 10mm	10mm	2	18500	30
BMW	E46 3 Series M3	PFR5-5630-12BLK	Rear Shock Top Mount Bracket and Bush 12mm	12mm	2	18500	30
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFF5-4601XIBLK	Front Wishbone Rear Bush	60mm	2	14000	1
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFF5-4602-21BLK	Front Anti Roll Bar Bush 21.5mm	21.5mm	2	10500	2
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFF5-4602-23.5BLK	Front Anti Roll Bar Bush 23.5mm	23.5mm	2	10500	2
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFF5-4602-23BLK	Front Anti Roll Bar Bush 23mm	23mm	2	10500	2
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFF5-4602-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	10500	2
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFF5-4602-26BLK	Front Anti Roll Bar Bush 26mm	26mm	2	10500	2
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFF5-4602-27BLK	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	10500	2
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFF5-4602-30.8BLK	Front Anti Roll Bar Bush 30.8mm	30.8mm	2	10500	2
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-3608BLK	Rear Trailing Arm Bush		2	13500	3
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-4610BLK	Rear Subframe Front Bush		2	20500	10
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-4611BLK	Rear Subframe Rear Bush		2	20500	11
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-4613BLK	Rear Subframe Rear Bush Insert		2	13000	11
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-4614BLK	Rear Subframe Front Bush Insert		2	13000	10
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-4615G	Adjustable Rear Lower Control Arm Kit		1	31250	19
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-4616BLK	Rear Lower Control Arm Inner Bush		2	16000	19
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-4617BLK	Rear Upper Arm Inner Bush		2	11000	17
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-4618BLK	Rear Lower Arm Outer Bush		2	12000	18

BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-4625BLK	Rear Diff Front Bush		2	14500	25
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-4626BLK	Rear Diff Rear Bush		1	8500	26
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-504-15BLK	Rear Roll Bar Mounting Bush 15mm	15mm	2	8500	4
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-504-18BLK	Rear Roll Bar Mounting Bush 18mm	18mm	2	8500	4
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-504-19BLK	Rear Roll Bar Mounting Bush 19mm	19mm	2	8500	4
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-5630-10BLK	Rear Shock Top Mount Bracket and Bush 10mm	10mm	2	18500	30
BMW	E46 3 Series Xi/XD (4 Wheel Drive)	PFR5-5630-12BLK	Rear Shock Top Mount Bracket and Bush 12mm	12mm	2	18500	30
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFF5-401BLK	Front Radius Arm To Chassis Bush		2	18500	1
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFF5-402BLK	Front Control Arm To Chassis Bush		2	30000	2
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFF5-4602-26.5BLK	Front Anti Roll Bar Mounting Bush 26.5mm	26.5mm	2	10500	3
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-1220BLK	Rear Subframe, Front Bush		2	33500	19
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-411BLK	Rear Upper Control Arm To Chassis Bush		2	16500	11c
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-411BLK	Rear Trailing Arm Inner & Outer Bush		4	33000	11b
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-411BLK	Rear Toe Adjust Arm Inner & Outer Bush		4	33000	11a
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-412BLK	Rear Upper Control Arm To Hub Bush		2	17000	12a
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-412BLK	Rear Upper Lateral Arm To Hub Bush		2	17000	12b
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-413BLK	Rear Upper Lateral Arm To Chassis Bush		2	24500	13
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-414BLK	Rear Lower Lateral Arm To Hub Bush		2	24500	14
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-415BLK	Rear Lower Lateral Arm To Chassis Bush		2	14000	15
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-416-12BLK	Rear Shock Absorber Upper Mounting Bush 12mm	12mm	2	12500	16
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-416BLK	Rear Shock Absorber Upper Mounting Bush	10mm	2	12500	16
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-419BLK	Rear Subframe Front Mount Insert		2	13500	19
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-420BLK	Rear Subframe Front Mounting Bush		2	31000	19
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-421BLK	Rear Subframe Rear Mounting Insert		2	13500	20
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-422BLK	Rear Subframe Rear Mounting Bush		2	26500	20
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-423BLK	Rear Subframe Rear Mounting Insert		2	13500	20
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-425BLK	Rear Diff Front Mounting Bush		2	16000	25
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-426BLK	Rear Diff Rear Mounting Bush		1	8250	26
BMW	E90, E91, E92 & E93 3 Series (2005-2013)	PFR5-4609-11BLK	Rear Anti Roll Bar Mounting Bush 11mm	11mm	2	10500	10
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFF5-5701BLK	Front Control Arm to Chassis Bush		2	19000	2
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFF5-5703-26.5BLK	Front Anti Roll Bar Mounting Bush 26.5mm	26.5mm	2	10500	3
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-1220BLK	Rear Subframe, Front Bush		2	33500	19
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-411BLK	Rear Upper Control Arm To Chassis Bush		2	16500	11c
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-411BLK	Rear Trailing Arm Inner & Outer Bush		4	33000	11b
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-411BLK	Rear Toe Adjust Arm Inner & Outer Bush		4	33000	11a
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-412BLK	Rear Upper Control Arm To Hub Bush		2	17000	12a
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-412BLK	Rear Upper Lateral Arm To Hub Bush		2	17000	12b
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-413BLK	Rear Upper Lateral Arm To Chassis Bush		2	24500	13
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-414BLK	Rear Lower Lateral Arm To Hub Bush		2	24500	14
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-415BLK	Rear Lower Lateral Arm To Chassis Bush		2	14000	15
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-416-12BLK	Rear Shock Absorber Upper Mounting Bush 12mm	12mm	2	12500	16
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-416BLK	Rear Shock Absorber Upper Mounting Bush	10mm	2	12500	16
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-419BLK	Rear Subframe Front Mount Insert		2	13500	19
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-420BLK	Rear Subframe Front Mounting Bush		2	31000	19
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-421BLK	Rear Subframe Rear Mounting Insert		2	13500	20
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-422BLK	Rear Subframe Rear Mounting Bush		2	26500	20
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-423BLK	Rear Subframe Rear Mounting Insert		2	13500	20
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-425BLK	Rear Diff Front Mounting Bush		2	16000	25
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-426BLK	Rear Diff Rear Mounting Bush		1	8250	26
BMW	E90, E91, E92 & E93 3 Series xDrive (2005-2013)	PFR5-4609-11BLK	Rear Anti Roll Bar Mounting Bush 11mm	11mm	2	10500	10
BMW	E90, E92 & E93 3 Series M3 (2006 -2013)	PFF5-1203-26.5BLK	Front Anti Roll Bar Bush 26.5mm	26.5mm	2	10000	3
BMW	E90, E92 & E93 3 Series M3 (2006 -2013)	PFF5-1203-28BLK	Front Anti Roll Bar Bush 28mm	28mm	2	10000	3
BMW	E90, E92 & E93 3 Series M3 (2006 -2013)	PFF5-401BLK	Front Radius Arm To Chassis Bush		2	18500	1
BMW	E90, E92 & E93 3 Series M3 (2006 -2013)	PFR5-1210-22.5BLK	Rear Anti Roll Bar Bush 22.5mm	22.5mm	2	10000	10
BMW	E90, E92 & E93 3 Series M3 (2006 -2013)	PFR5-1210-23.6BLK	Rear Anti Roll Bar Bush 23.6mm	23.6mm	2	10000	10
BMW	E90, E92 & E93 3 Series M3 (2006 -2013)	PFR5-1212BLK	Rear Upper Arm Outer Bush		4	32000	12
BMW	E90, E92 & E93 3 Series M3 (2006 -2013)	PFR5-1213BLK	Rear Lower Front Arm Inner Bush		2	13500	13
BMW	E90, E92 & E93 3 Series M3 (2006 -2013)	PFR5-1215BLK	Rear Lower Lateral Arm Inner Bush		2	21500	15
BMW	E90, E92 & E93 3 Series M3 (2006 -2013)	PFR5-1220BLK	Rear Subframe, Front Bush		2	33500	19

BMW	E90, E92 & E93 3 Series M3 (2006 -2013)	PFR5-1226BLK	Rear Diff Rear Mounting Bush		1	7250	26
BMW	E90, E92 & E93 3 Series M3 (2006 -2013)	PFR5-411BLK	Rear Trailing Arm Outer Bush		2	16500	11
BMW	E90, E92 & E93 3 Series M3 (2006 -2013)	PFR5-422BLK	Rear Subframe Rear Mounting Bush		2	26500	20
BMW	E90, E92 & E93 3 Series M3 (2006 -2013)	PFR5-425BLK	Rear Diff Front Mounting Bush		2	16000	25
BMW	F30, F31, F34 3 Series	PFF5-1901BLK	Front Radius Arm To Chassis Bush		2	21000	1
BMW	F30, F31, F34 3 Series	PFF5-1901GBLK	Front Radius Arm To Chassis Bush Caster Adjustable		2	25500	1
BMW	F30, F31, F34 3 Series	PFF5-1902BLK	Front Control Arm To Chassis Bush		2	13500	2
BMW	F30, F31, F34 3 Series	PFF5-1902GBLK	Front Control Arm to Chassis Bush - Camber Adjustable		2	21000	2
BMW	F30, F31, F34 3 Series	PFF5-1903-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	10500	3
BMW	F30, F31, F34 3 Series	PFF5-1903-25BLK	Front Anti Roll Bar Bush 25mm	25mm	2	10500	3
BMW	F30, F31, F34 3 Series	PFR5-1913-12BLK	Rear Anti Roll Bar Bush 12mm	12mm	2	9500	13
BMW	F30, F31, F34 3 Series	PFR5-1913-13BLK	Rear Anti Roll Bar Bush 13mm	13mm	2	9500	13
BMW	F30, F31, F34 3 Series	PFR5-1920BLK	Rear Subframe Front Bush Insert		2	12500	20
BMW	F30, F31, F34 3 Series	PFR5-1921BLK	Rear Subframe Rear Bush Insert		2	11500	21
BMW	F30, F31, F34 3 Series	PFR5-1927BLK	Rear Diff Front Bush Insert		2	11000	27
BMW	F30, F31, F34 3 Series xDrive	PFF5-1903-22.5BLK	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	10500	3
BMW	F30, F31, F34 3 Series xDrive	PFF5-1903-23.6BLK	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	10500	3
BMW	F30, F31, F34 3 Series xDrive	PFF5-4101BLK	Front Radius Arm To Chassis Bush		2	21000	1
BMW	F30, F31, F34 3 Series xDrive	PFF5-4102BLK	Front Control Arm To Chassis Bush		2	15500	2
BMW	F30, F31, F34 3 Series xDrive	PFR5-1913-12BLK	Rear Anti Roll Bar Bush 12mm	12mm	2	9500	13
BMW	F30, F31, F34 3 Series xDrive	PFR5-1913-13BLK	Rear Anti Roll Bar Bush 13mm	13mm	2	9500	13
BMW	F30, F31, F34 3 Series xDrive	PFR5-1920BLK	Rear Subframe Front Bush Insert		2	12500	20
BMW	F30, F31, F34 3 Series xDrive	PFR5-1921BLK	Rear Subframe Rear Bush Insert		2	11500	21
BMW	F30, F31, F34 3 Series xDrive	PFR5-1927BLK	Rear Diff Front Bush Insert		2	11000	27
BMW	F80 3 Series M3	PFF5-1203-26.5BLK	Front Anti Roll Bar Bush 26.5mm	26.5mm	2	10000	3
BMW	F80 3 Series M3	PFF5-1203-28BLK	Front Anti Roll Bar Bush 28mm	28mm	2	10000	3
BMW	F80 3 Series M3	PFF5-4001BLK	Front Radius Arm To Chassis Bush		2	19500	1
BMW	F80 3 Series M3	PFF5-4001GBLK	Front Radius Arm To Chassis BushCaster Offset		2	21000	1
BMW	F80 3 Series M3	PFR5-4025BLK	Rear Diff Front Mounting Bush		4	51000	21
BMW	F80 3 Series M3	PFR5-4026BLK	Rear Diff Rear Mounting Bush		1	17000	22
BMW	F32, F33, F36 4 Series	PFF5-1901BLK	Front Radius Arm To Chassis Bush		2	21000	1
BMW	F32, F33, F36 4 Series	PFF5-1901GBLK	Front Radius Arm To Chassis Bush Caster Adjustable		2	25500	1
BMW	F32, F33, F36 4 Series	PFF5-1902BLK	Front Control Arm To Chassis Bush		2	13500	2
BMW	F32, F33, F36 4 Series	PFF5-1902GBLK	Front Control Arm to Chassis Bush - Camber Adjustable		2	21000	2
BMW	F32, F33, F36 4 Series	PFF5-1903-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	10500	3
BMW	F32, F33, F36 4 Series	PFF5-1903-25BLK	Front Anti Roll Bar Bush 25mm	25mm	2	10500	3
BMW	F32, F33, F36 4 Series	PFR5-1913-12BLK	Rear Anti Roll Bar Bush 12mm	12mm	2	9500	13
BMW	F32, F33, F36 4 Series	PFR5-1913-13BLK	Rear Anti Roll Bar Bush 13mm	13mm	2	9500	13
BMW	F32, F33, F36 4 Series	PFR5-1920BLK	Rear Subframe Front Bush Insert		2	12500	20
BMW	F32, F33, F36 4 Series	PFR5-1921BLK	Rear Subframe Rear Bush Insert		2	11500	21
BMW	F32, F33, F36 4 Series	PFR5-1927BLK	Rear Diff Front Bush Insert		2	11000	27
BMW	F32, F33, F36 4 Series xDrive	PFF5-1903-22.5BLK	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	10500	3
BMW	F32, F33, F36 4 Series xDrive	PFF5-1903-23.6BLK	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	10500	3
BMW	F32, F33, F36 4 Series xDrive	PFF5-4101BLK	Front Radius Arm To Chassis Bush		2	21000	1
BMW	F32, F33, F36 4 Series xDrive	PFF5-4102BLK	Front Control Arm To Chassis Bush		2	15500	2
BMW	F32, F33, F36 4 Series xDrive	PFR5-1913-12BLK	Rear Anti Roll Bar Bush 12mm	12mm	2	9500	13
BMW	F32, F33, F36 4 Series xDrive	PFR5-1920BLK	Rear Subframe Front Bush Insert		2	12500	20
BMW	F32, F33, F36 4 Series xDrive	PFR5-1921BLK	Rear Subframe Rear Bush Insert		2	11500	21
BMW	F32, F33, F36 4 Series xDrive	PFR5-1927BLK	Rear Diff Front Bush Insert		2	11000	27
BMW	F82, F83 4 Series M4	PFF5-1203-26.5BLK	Front Anti Roll Bar Bush 26.5mm	26.5mm	2	10000	3
BMW	F82, F83 4 Series M4	PFF5-1203-28BLK	Front Anti Roll Bar Bush 28mm	28mm	2	10000	3
BMW	F82, F83 4 Series M4	PFF5-4001BLK	Front Radius Arm To Chassis Bush		2	19500	1
BMW	F82, F83 4 Series M4	PFF5-4001GBLK	Front Radius Arm To Chassis BushCaster Offset		2	21000	1
BMW	F82, F83 4 Series M4	PFR5-4025BLK	Rear Diff Front Mounting Bush		4	51000	21
BMW	F82, F83 4 Series M4	PFR5-4026BLK	Rear Diff Rear Mounting Bush		1	17000	22
BMW	E28 5 Series (1982 - 1988)	PFF5-310-25BLK	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	9000	3
BMW	E28 5 Series (1982 - 1988)	PFF5-801BLK	Front Lower Tie Bar To Chassis Bush		2	13500	1
BMW	E28 5 Series (1982 - 1988)	PFF5-802BLK	Front Inner TCA Bush		2	13500	2
BMW	E28 5 Series (1982 - 1988)	PFR5-308-13BLK	Rear Anti Roll Bar Mounting Bush 13mm		2	8500	7

BMW	E28 5 Series (1982 - 1988)	PFR5-308-15.5BLK	Rear Anti Roll Bar Mounting Bush 15.5mm	15.5mm	2	8500	7
BMW	E28 5 Series (1982 - 1988)	PFR5-308-18BLK	Rear Anti Roll Bar Mounting Bush 18mm	18mm	2	8500	7
BMW	E28 5 Series (1982 - 1988)	PFR5-308-19BLK	Rear Anti Roll Bar Mounting Bush 19mm	19mm	2	8500	7
BMW	E28 5 Series (1982 - 1988)	PFR5-315BLK	Rear Anti Roll Bar Link To Arm Bush		2	7500	15
BMW	E28 5 Series (1982 - 1988)	PFR5-316BLK	Rear Anti Roll Bar Link To Anti Roll Bar Bush		2	7500	16
BMW	E28 5 Series (1982 - 1988)	PFR5-504-13BLK	Front Anti Roll Bar Mounting Bush 13mm	13mm	2	8500	3
BMW	E28 5 Series (1982 - 1988)	PFR5-504-14BLK	Front Anti Roll Bar Mounting Bush 14mm	14mm	2	8500	3
BMW	E28 5 Series (1982 - 1988)	PFR5-504-15BLK	Front Anti Roll Bar Mounting Bush 15mm	15mm	2	8500	3
BMW	E28 5 Series (1982 - 1988)	PFR5-504-16.5BLK	Front Roll Bar Mounting Bush 16.5mm	16.5mm	2	8500	3
BMW	E28 5 Series (1982 - 1988)	PFR5-504-18BLK	Front Anti Roll Bar Mounting Bush 18mm	18mm	2	8500	3
BMW	E28 5 Series (1982 - 1988)	PFR5-504-19BLK	Front Anti Roll Bar Mounting Bush 19mm	19mm	2	8500	3
BMW	E28 5 Series (1982 - 1988)	PFR5-606BLK	Rear Trailing Arm Bush		4	25000	10
BMW	E28 5 Series (1982 - 1988)	PFR5-606GBLK	Rear Trailing Arm Bush Adjustable		4	42000	10
BMW	E28 5 Series (1982 - 1988)	PFR5-807BLK	Rear Beam Bush		2	15000	6
BMW	E34 5 Series (1988 - 1996)	PFF5-310-23BLK	Front Anti Roll Bar Mounting 23mm	23mm	2	9000	3
BMW	E34 5 Series (1988 - 1996)	PFF5-310-24BLK	Front Anti Roll Bar Mounting 24mm	24mm	2	9000	3
BMW	E34 5 Series (1988 - 1996)	PFF5-310-25BLK	Front Anti Roll Bar Mounting 25mm	25mm	2	9000	3
BMW	E34 5 Series (1988 - 1996)	PFF5-310-28BLK	Front Anti Roll Bar Mounting 28mm	28mm	2	9000	3
BMW	E34 5 Series (1988 - 1996)	PFF5-601BLK	Front Lower Tie Bar To Chassis Bush		2	14500	1
BMW	E34 5 Series (1988 - 1996)	PFF5-602BLK	Front Inner TCA Bush		2	13500	2
BMW	E34 5 Series (1988 - 1996)	PFF5-620BLK	Front Inner TCA Bush		2	13500	2
BMW	E34 5 Series (1988 - 1996)	PFR5-504-15BLK	Rear Roll Bar Mounting Bush 15mm	15mm	2	8500	7
BMW	E34 5 Series (1988 - 1996)	PFR5-504-16.5BLK	Rear Roll Bar Mounting Bush 16.5mm	16.5mm	2	8500	7
BMW	E34 5 Series (1988 - 1996)	PFR5-504-18BLK	Rear Roll Bar Mounting Bush 18mm	18mm	2	8500	7
BMW	E34 5 Series (1988 - 1996)	PFR5-507BLK	Rear Beam Mount Bush		2	17000	6
BMW	E34 5 Series (1988 - 1996)	PFR5-606BLK	Rear Trailing Arm Bush		4	25000	10
BMW	E34 5 Series (1988 - 1996)	PFR5-606GBLK	Rear Trailing Arm Bush Adjustable		4	42000	10
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFF5-4602-23BLK	Front Anti Roll Bar Bush 23mm	23mm	2	10500	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFF5-4602-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	10500	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFF5-4602-25BLK	Front Anti Roll Bar Bush 25mm	25mm	2	10500	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFF5-4602-27BLK	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	10500	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFF5-503-22.5BLK	Front Anti Roll Bar Mounting Bush 22.5mm	22.5mm	2	9000	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFF5-503-24BLK	Front Anti Roll Bar Mounting Bush 24mm	24mm	2	9000	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFF5-503-25BLK	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	9000	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFF5-503-27BLK	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	9000	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFF5-510BLK	Front Lower Tie Bar To Chassis Bush		2	14500	1
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFF5-511BLK	Front Inner Track Control Arm Bush		2	12000	2
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFR5-504-13BLK	Rear Anti Roll Bar Mounting Bush 13mm	13mm	2	8500	4
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFR5-504-14BLK	Rear Anti Roll Bar Mounting Bush 14mm	14mm	2	8500	4
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFR5-504-15BLK	Rear Roll Bar Mounting Bush 15mm	15mm	2	8500	4
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFR5-504-16.5BLK	Rear Roll Bar Mounting Bush 16.5mm	16.5mm	2	8500	4
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFR5-520BLK	Rear Subframe Front Mounting Bush		2	23000	20
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFR5-521BLK	Rear Subframe Mounting Front Insert		2	12000	20
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFR5-522BLK	Rear Subframe Rear Mounting Bush		2	23000	22
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFR5-523BLK	Rear Subframe Rear Mounting Insert		2	12000	22
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFR5-524BLK	Rear Diff Front Mounting Bush		1	6750	25
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFR5-525BLK	Rear Diff Front Mounting Bush		1	6750	25
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFR5-526BLK	Rear Diff Rear Mounting Bush		2	14000	26
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFR5-710-10BLK	Rear Lower Arm Front Bush	10mm Bore Sleeve	2	13000	10
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFR5-711-12BLK	Rear Lower Arm Rear Bush	12mm Bore Sleeve	2	14000	11
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFR5-711BLK	Rear Lower Arm Rear Bush	14mm Bore Sleeve	2	14000	11
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFR5-712BLK	Rear Upper Arm Inner Bush		2	15000	12
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFR5-713BLK	Rear Toe Adjust Inner Bush		2	12500	13
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFR5-715BLK	Rear Outer Integral Link Upper Bush		2	14000	15
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 To 530	PFR5-716BLK	Rear Outer Integral Link Lower Bush		2	11000	16
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFF5-4602-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	10500	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFF5-4602-25BLK	Front Anti Roll Bar Bush 25mm	25mm	2	10500	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFF5-4602-27BLK	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	10500	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFF5-503-22.5BLK	Front Anti Roll Bar Mounting Bush 22.5mm	22.5mm	2	9000	3

BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFF5-503-24BLK	Front Anti Roll Bar Mounting Bush 24mm	24mm	2	9000	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFF5-503-25BLK	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	9000	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFF5-503-27BLK	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	9000	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFF5-510BLK	Front Lower Tie Bar To Chassis Bush		2	14500	1
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFF5-511BLK	Front Inner Track Control Arm Bush		2	12000	2
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFR5-504-13BLK	Rear Anti Roll Bar Mounting Bush 13mm	13mm	2	8500	4
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFR5-504-14BLK	Rear Anti Roll Bar Mounting Bush 14mm	14mm	2	8500	4
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFR5-504-15BLK	Rear Roll Bar Mounting Bush 15mm	15mm	2	8500	4
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFR5-504-165BLK	Rear Roll Bar Mounting Bush 16.5mm	16.5mm	2	8500	4
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFR5-524BLK	Rear Diff Front Mounting Bush		1	6750	25
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFR5-525BLK	Rear Diff Front Mounting Bush		1	6750	25
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFR5-526BLK	Rear Diff Rear Mounting Bush		2	14000	26
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFR5-530BLK	Rear Subframe Mounting Bush		4	58000	20
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFR5-531BLK	Rear Subframe Mounting Bush Insert		4	24000	20
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFR5-710-10BLK	Rear Lower Arm Front Bush	10mm Bore Sleeve	2	13000	10
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFR5-711-12BLK	Rear Lower Arm Rear Bush	12mm Bore Sleeve	2	14000	11
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFR5-711BLK	Rear Lower Arm Rear Bush	14mm Bore Sleeve	2	14000	11
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFR5-712BLK	Rear Upper Arm Inner Bush		2	15000	12
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFR5-713BLK	Rear Toe Adjust Inner Bush		2	12500	13
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFR5-715BLK	Rear Outer Integral Link Upper Bush		2	14000	15
BMW	E39 5 Series (1996 - 2004)E39 5 Series 520 to 530 Touring	PFR5-716BLK	Rear Outer Integral Link Lower Bush		2	11000	16
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFF5-4602-23BLK	Front Anti Roll Bar Bush 23mm	23mm	2	10500	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFF5-4602-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	10500	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFF5-4602-25BLK	Front Anti Roll Bar Bush 25mm	25mm	2	10500	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFF5-4602-27BLK	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	10500	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFF5-501BLK	Front Lower Tie Bar To Chassis Bush		2	14000	1
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFF5-502BLK	Front Inner Track Control Arm Bush		2	12500	2
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFF5-503-225BLK	Front Anti Roll Bar Mounting Bush 22.5mm	22.5mm	2	9000	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFF5-503-24BLK	Front Anti Roll Bar Mounting Bush 24mm	24mm	2	9000	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFF5-503-25BLK	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	9000	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFF5-503-27BLK	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	9000	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFR5-504-13BLK	Rear Anti Roll Bar Mounting Bush 13mm	13mm	2	8500	4
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFR5-504-14BLK	Rear Anti Roll Bar Mounting Bush 14mm	14mm	2	8500	4
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFR5-504-15BLK	Rear Roll Bar Mounting Bush 15mm	15mm	2	8500	4
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFR5-504-165BLK	Rear Roll Bar Mounting Bush 16.5mm	16.5mm	2	8500	4
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFR5-520BLK	Rear Subframe Front Mounting Bush		2	23000	20
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFR5-521BLK	Rear Subframe Mounting Front Insert		2	12000	20
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFR5-522BLK	Rear Subframe Rear Mounting Bush		2	23000	22
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFR5-523BLK	Rear Subframe Rear Mounting Insert		2	12000	22
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFR5-524BLK	Rear Diff Front Mounting Bush		1	6750	25
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFR5-525BLK	Rear Diff Front Mounting Bush		1	6750	25
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFR5-526BLK	Rear Diff Rear Mounting Bush		2	14000	26
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFR5-710-10BLK	Rear Lower Arm Front Bush	10mm Bore Sleeve	2	13000	10
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFR5-711-12BLK	Rear Lower Arm Rear Bush	12mm Bore Sleeve	2	14000	11
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFR5-711BLK	Rear Lower Arm Rear Bush	14mm Bore Sleeve	2	14000	11
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFR5-712BLK	Rear Upper Arm Inner Bush		2	15000	12
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFR5-713BLK	Rear Toe Adjust Inner Bush		2	12500	13
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFR5-715BLK	Rear Outer Integral Link Upper Bush		2	14000	15
BMW	E39 5 Series (1996 - 2004)E39 5 Series 535 to 540 & M5	PFR5-716BLK	Rear Outer Integral Link Lower Bush		2	11000	16
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFF5-4602-23BLK	Front Anti Roll Bar Bush 23mm	23mm	2	10500	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFF5-4602-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	10500	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFF5-4602-25BLK	Front Anti Roll Bar Bush 25mm	25mm	2	10500	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFF5-4602-27BLK	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	10500	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFF5-501BLK	Front Lower Tie Bar To Chassis Bush		2	14000	1
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFF5-502BLK	Front Inner Track Control Arm Bush		2	12500	2
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFF5-503-225BLK	Front Anti Roll Bar Mounting Bush 22.5mm	22.5mm	2	9000	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFF5-503-24BLK	Front Anti Roll Bar Mounting Bush 24mm	24mm	2	9000	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFF5-503-25BLK	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	9000	3
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFF5-503-27BLK	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	9000	3

BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFR5-504-13BLK	Rear Anti Roll Bar Mounting Bush 13mm	13mm	2	8500	4
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFR5-504-14BLK	Rear Anti Roll Bar Mounting Bush 14mm	14mm	2	8500	4
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFR5-504-15BLK	Rear Roll Bar Mounting Bush 15mm	15mm	2	8500	4
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFR5-504-165BLK	Rear Roll Bar Mounting Bush 16.5mm	16.5mm	2	8500	4
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFR5-524BLK	Rear Diff Front Mounting Bush		1	6750	25
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFR5-525BLK	Rear Diff Front Mounting Bush		1	6750	25
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFR5-526BLK	Rear Diff Rear Mounting Bush		2	14000	26
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFR5-530BLK	Rear Subframe Mounting Bush		4	58000	20
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFR5-531BLK	Rear Subframe Mounting Bush Insert		4	24000	20
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFR5-710-10BLK	Rear Lower Arm Front Bush	10mm Bore Sleeve	2	13000	10
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFR5-711-12BLK	Rear Lower Arm Rear Bush	12mm Bore Sleeve	2	14000	11
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFR5-711BLK	Rear Lower Arm Rear Bush	14mm Bore Sleeve	2	14000	11
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFR5-712BLK	Rear Upper Arm Inner Bush		2	15000	12
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFR5-713BLK	Rear Toe Adjust Inner Bush		2	12500	13
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFR5-715BLK	Rear Outer Integral Link Upper Bush		2	14000	15
BMW	E39 5 Series (1996 - 2004)E39 5 Series 540 Touring	PFR5-716BLK	Rear Outer Integral Link Lower Bush		2	11000	16
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, M5	PFF5-1002BLK	Front Lower Control Arm Inner Bush		2	12000	2
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, M5	PFF5-701BLK	Front Radius Arm To Chassis Bush		2	17500	1
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, M5	PFR5-4609-18BLK	Rear Anti Roll Bar Mount 18mm	18mm	2	10500	14
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, M5	PFR5-710BLK	Rear Lower Arm Front Bush	12mm Bore Sleeve	2	13000	10
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, M5	PFR5-711BLK	Rear Lower Arm Rear Bush	14mm Bore Sleeve	2	14000	11
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, M5	PFR5-712BLK	Rear Upper Arm Inner Bush		2	15000	12
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, M5	PFR5-715BLK	Rear Outer Integral Link Upper Bush		2	14000	15
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, M5	PFR5-716BLK	Rear Outer Integral Link Lower Bush		2	11000	16
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, M5	PFR5-720BLK	Rear Subframe Front Mounting Bush		2	25000	20
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, Saloon	PFF5-1002BLK	Front Lower Control Arm Inner Bush		2	12000	2
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, Saloon	PFF5-701BLK	Front Radius Arm To Chassis Bush		2	17500	1
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, Saloon	PFF5-703-24.6BLK	Front Anti Roll Bar Mount 24.6mm	24.6mm	2	11000	3
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, Saloon	PFF5-703-25.6BLK	Front Anti Roll Bar Mount 25.6mm	25.6mm	2	11000	3
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, Saloon	PFF5-703-25BLK	Front Anti Roll Bar Mount 25mm	25mm	2	11000	3
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, Saloon	PFR5-4609-13.5BLK	Rear Anti Roll Bar Mount 13.5mm	13.5mm	2	10500	14
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, Saloon	PFR5-4609-14.5BLK	Rear Anti Roll Bar Mount 14.5mm	14.5mm	2	10500	14
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, Saloon	PFR5-4609-14BLK	Rear Anti Roll Bar Mount 14mm	14mm	2	10500	14
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, Saloon	PFR5-4609-16BLK	Rear Anti Roll Bar Mount 16mm	16mm	2	10500	14
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, Saloon	PFR5-4609-18BLK	Rear Anti Roll Bar Mount 18mm	18mm	2	10500	14
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, Saloon	PFR5-710BLK	Rear Lower Arm Front Bush	12mm Bore Sleeve	2	13000	10
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, Saloon	PFR5-711BLK	Rear Lower Arm Rear Bush	14mm Bore Sleeve	2	14000	11
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, Saloon	PFR5-712BLK	Rear Upper Arm Inner Bush		2	15000	12
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, Saloon	PFR5-713BLK	Rear Toe Adjust Inner Bush		2	12500	13
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, Saloon	PFR5-715BLK	Rear Outer Integral Link Upper Bush		2	14000	15
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, Saloon	PFR5-716BLK	Rear Outer Integral Link Lower Bush		2	11000	16
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, Saloon	PFR5-720BLK	Rear Subframe Front Mounting Bush		2	25000	20
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, Saloon	PFR5-722BLK	Rear Subframe Rear Mounting Bush		2	25000	21
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, Saloon	PFR5-725BLK	Rear Diff Front Mounting Bush		2	13000	25
BMW	E60, E61 5 Series (2003-2010)E60 5 Series, Saloon	PFR5-726BLK	Rear Diff Rear Mounting Bush		1	9250	26
BMW	E60, E61 5 Series (2003-2010)E61 5 Series, Touring	PFF5-1002BLK	Front Lower Control Arm Inner Bush		2	12000	2
BMW	E60, E61 5 Series (2003-2010)E61 5 Series, Touring	PFF5-701BLK	Front Radius Arm To Chassis Bush		2	17500	1
BMW	E60, E61 5 Series (2003-2010)E61 5 Series, Touring	PFF5-701BLK	Front Radius Arm To Chassis Bush		2	17500	1
BMW	E60, E61 5 Series (2003-2010)E61 5 Series, Touring	PFF5-703-25.6BLK	Front Anti Roll Bar Mount 25.6mm	25.6mm	2	11000	3
BMW	E60, E61 5 Series (2003-2010)E61 5 Series, Touring	PFF5-703-25BLK	Front Anti Roll Bar Mount 25mm	25mm	2	11000	3
BMW	E60, E61 5 Series (2003-2010)E61 5 Series, Touring	PFR5-4609-18BLK	Rear Anti Roll Bar Mount 18mm	18mm	2	10500	14
BMW	E60, E61 5 Series (2003-2010)E61 5 Series, Touring	PFR5-710BLK	Rear Lower Arm Front Bush	12mm Bore Sleeve	2	13000	10
BMW	E60, E61 5 Series (2003-2010)E61 5 Series, Touring	PFR5-711BLK	Rear Lower Arm Rear Bush	14mm Bore Sleeve	2	14000	11
BMW	E60, E61 5 Series (2003-2010)E61 5 Series, Touring	PFR5-712BLK	Rear Upper Arm Inner Bush		2	15000	12
BMW	E60, E61 5 Series (2003-2010)E61 5 Series, Touring	PFR5-713BLK	Rear Toe Adjust Inner Bush		2	12500	13
BMW	E60, E61 5 Series (2003-2010)E61 5 Series, Touring	PFR5-715BLK	Rear Outer Integral Link Upper Bush		2	14000	15
BMW	E60, E61 5 Series (2003-2010)E61 5 Series, Touring	PFR5-716BLK	Rear Outer Integral Link Lower Bush		2	11000	16
BMW	E60, E61 5 Series (2003-2010)E61 5 Series, Touring	PFR5-720BLK	Rear Subframe Front Mounting Bush		2	25000	20
BMW	E60, E61 5 Series (2003-2010)E61 5 Series, Touring	PFR5-722BLK	Rear Subframe Rear Mounting Bush		2	25000	21

BMW	E60, E61 5 Series (2003-2010)E61 5 Series, Touring	PFR5-725BLK	Rear Diff Front Mounting Bush		2	13000	25
BMW	E60, E61 5 Series (2003-2010)E61 5 Series, Touring	PFR5-726BLK	Rear Diff Rear Mounting Bush		1	9250	26
BMW	F10, F11 5 Series (2010 - 2016)F10 5 Series M5	PFF5-6201BLK	Front Radius Arm to Chassis Bush		2	22000	1
BMW	F10, F11 5 Series (2010 - 2016)F10 5 Series M5	PFF5-6201GBLK	Front Radius Arm to Chassis Bush Caster Offset		2	24000	1
BMW	F10, F11 5 Series (2010 - 2016)F10, F11 5 Series	PFF5-6001BLK	Front Radius Arm to Chassis Bush		2	22000	1
BMW	F10, F11 5 Series (2010 - 2016)F10, F11 5 Series	PFF5-6001GBLK	Front Radius Arm to Chassis Bush Caster Offset		2	24000	1
BMW	F10, F11 5 Series (2010 - 2016)F10, F11 5 Series xDrive	PFF5-6101BLK	Front Radius Arm to Chassis Bush		2	22000	1
BMW	F10, F11 5 Series (2010 - 2016)F10, F11 5 Series xDrive	PFF5-6101GBLK	Front Radius Arm to Chassis Bush Caster Offset		2	24000	1
BMW	E24 6 Series (1982 - 1989)	PFF5-310-25BLK	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	9000	3
BMW	E24 6 Series (1982 - 1989)	PFF5-801BLK	Front Lower Tie Bar To Chassis Bush		2	13500	1
BMW	E24 6 Series (1982 - 1989)	PFF5-802BLK	Front Inner TCA Bush		2	13500	2
BMW	E24 6 Series (1982 - 1989)	PFR5-308-13BLK	Rear Anti Roll Bar Mounting Bush 13mm		2	8500	7
BMW	E24 6 Series (1982 - 1989)	PFR5-308-15.5BLK	Rear Anti Roll Bar Mounting Bush 15.5mm	15.5mm	2	8500	7
BMW	E24 6 Series (1982 - 1989)	PFR5-308-18BLK	Rear Anti Roll Bar Mounting Bush 18mm	18mm	2	8500	7
BMW	E24 6 Series (1982 - 1989)	PFR5-308-19BLK	Rear Anti Roll Bar Mounting Bush 19mm	19mm	2	8500	7
BMW	E24 6 Series (1982 - 1989)	PFR5-315BLK	Rear Anti Roll Bar Link To Arm Bush		2	7500	15
BMW	E24 6 Series (1982 - 1989)	PFR5-316BLK	Rear Anti Roll Bar Link To Anti Roll Bar Bush		2	7500	16
BMW	E24 6 Series (1982 - 1989)	PFR5-504-13BLK	Front Anti Roll Bar Mounting Bush 13mm	13mm	2	8500	3
BMW	E24 6 Series (1982 - 1989)	PFR5-504-14BLK	Front Anti Roll Bar Mounting Bush 14mm	14mm	2	8500	3
BMW	E24 6 Series (1982 - 1989)	PFR5-504-15BLK	Front Anti Roll Bar Mounting Bush 15mm	15mm	2	8500	3
BMW	E24 6 Series (1982 - 1989)	PFR5-504-16.5BLK	Front Roll Bar Mounting Bush 16.5mm	16.5mm	2	8500	3
BMW	E24 6 Series (1982 - 1989)	PFR5-504-18BLK	Front Anti Roll Bar Mounting Bush 18mm	18mm	2	8500	3
BMW	E24 6 Series (1982 - 1989)	PFR5-504-19BLK	Front Anti Roll Bar Mounting Bush 19mm	19mm	2	8500	3
BMW	E24 6 Series (1982 - 1989)	PFR5-606BLK	Rear Trailing Arm Bush		4	25000	10
BMW	E24 6 Series (1982 - 1989)	PFR5-606GBLK	Rear Trailing Arm Bush Adjustable		4	42000	10
BMW	E24 6 Series (1982 - 1989)	PFR5-807BLK	Rear Beam Bush		2	15000	6
BMW	E63/E64 6 Series (2003 - 2010)	PFF5-701BLK	Front Radius Arm To Chassis Bush		2	17500	1
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-4609-13.5BLK	Rear Anti Roll Bar Mount 13.5mm	13.5mm	2	10500	14
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-4609-14.5BLK	Rear Anti Roll Bar Mount 14.5mm	14.5mm	2	10500	14
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-4609-18BLK	Rear Anti Roll Bar Mount 18mm	18mm	2	10500	14
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-710BLK	Rear Lower Arm Front Bush	12mm Bore Sleeve	2	13000	10
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-711BLK	Rear Lower Arm Rear Bush	14mm Bore Sleeve	2	14000	11
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-712BLK	Rear Upper Arm Inner Bush		2	15000	12
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-713BLK	Rear Toe Adjust Inner Bush		2	12500	13
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-715BLK	Rear Outer Integral Link Upper Bush		2	14000	15
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-716BLK	Rear Outer Integral Link Lower Bush		2	11000	16
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-720BLK	Rear Subframe Front Mounting Bush		2	25000	20
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-722BLK	Rear Subframe Rear Mounting Bush		2	25000	21
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-725BLK	Rear Diff Front Mounting Bush		2	13000	25
BMW	E63/E64 6 Series (2003 - 2010)	PFR5-726BLK	Rear Diff Rear Mounting Bush		1	9250	26
BMW	F06, F12, F13 6 Series (2011 -)F06, F12, F13 6 Series	PFF5-6001BLK	Front Radius Arm to Chassis Bush		2	22000	1
BMW	F06, F12, F13 6 Series (2011 -)F06, F12, F13 6 Series	PFF5-6001GBLK	Front Radius Arm to Chassis Bush Caster Offset		2	24000	1
BMW	F06, F12, F13 6 Series (2011 -)F06, F12, F13 6 Series M6	PFF5-6201BLK	Front Radius Arm to Chassis Bush		2	22000	1
BMW	F06, F12, F13 6 Series (2011 -)F06, F12, F13 6 Series M6	PFF5-6201GBLK	Front Radius Arm to Chassis Bush Caster Offset		2	24000	1
BMW	F06, F12, F13 6 Series (2011 -)F06, F12, F13 6 Series xDrive	PFF5-6101BLK	Front Radius Arm to Chassis Bush		2	22000	1
BMW	F06, F12, F13 6 Series (2011 -)F06, F12, F13 6 Series xDrive	PFF5-6101GBLK	Front Radius Arm to Chassis Bush Caster Offset		2	24000	1
BMW	E32 7 Series (1988-1994)	PFF5-310-23BLK	Front Anti Roll Bar Mounting 23mm	23mm	2	9000	3
BMW	E32 7 Series (1988-1994)	PFF5-310-24BLK	Front Anti Roll Bar Mounting 24mm	24mm	2	9000	3
BMW	E32 7 Series (1988-1994)	PFF5-310-25BLK	Front Anti Roll Bar Mounting 25mm	25mm	2	9000	3
BMW	E32 7 Series (1988-1994)	PFF5-310-28BLK	Front Anti Roll Bar Mounting 28mm	28mm	2	9000	3
BMW	E32 7 Series (1988-1994)	PFF5-601BLK	Front Lower Tie Bar To Chassis Bush		2	14500	1
BMW	E32 7 Series (1988-1994)	PFF5-602BLK	Front Inner TCA Bush		2	13500	2
BMW	E32 7 Series (1988-1994)	PFF5-620BLK	Front Inner TCA Bush		2	13500	2
BMW	E32 7 Series (1988-1994)	PFR5-504-15BLK	Rear Roll Bar Mounting Bush 15mm	15mm	2	8500	7
BMW	E32 7 Series (1988-1994)	PFR5-504-16.5BLK	Rear Roll Bar Mounting Bush 16.5mm	16.5mm	2	8500	7
BMW	E32 7 Series (1988-1994)	PFR5-504-18BLK	Rear Roll Bar Mounting Bush 18mm	18mm	2	8500	7
BMW	E32 7 Series (1988-1994)	PFR5-507BLK	Rear Beam Mount Bush		2	17000	6
BMW	E32 7 Series (1988-1994)	PFR5-606BLK	Rear Trailing Arm Bush		4	25000	10
BMW	E32 7 Series (1988-1994)	PFR5-606GBLK	Rear Trailing Arm Bush Adjustable		4	42000	10

BMW	E38 7 Series (1994 - 2002)	PFF5-1001BLK	Front Trailing Arm Rear Bush		2	13500	1
BMW	E38 7 Series (1994 - 2002)	PFF5-1002BLK	Front Lower Control Arm Inner Bush		2	12000	2
BMW	E38 7 Series (1994 - 2002)	PFF5-503-205BLK	Front Anti Roll Bar Mounting Bush 20.5mm	20.5mm	2	9000	3
BMW	E38 7 Series (1994 - 2002)	PFF5-503-225BLK	Front Anti Roll Bar Mounting Bush 22.5mm	22.5mm	2	9000	3
BMW	E38 7 Series (1994 - 2002)	PFF5-503-24BLK	Front Anti Roll Bar Mounting Bush 24mm	24mm	2	9000	3
BMW	E38 7 Series (1994 - 2002)	PFF5-503-25BLK	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	9000	3
BMW	E38 7 Series (1994 - 2002)	PFF5-503-27BLK	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	9000	3
BMW	E38 7 Series (1994 - 2002)	PFR5-524BLK	Rear Diff Front Mounting Bush		1	6750	25
BMW	E31 8 Series (1989 - 1999)	PFF5-310-24BLK	Front Anti Roll Bar Mounting 24mm	24mm	2	9000	2
BMW	E31 8 Series (1989 - 1999)	PFF5-310-25BLK	Front Anti Roll Bar Mounting 25mm	25mm	2	9000	2
BMW	E31 8 Series (1989 - 1999)	PFF5-602BLK	Front Inner TCA Bush		2	13500	1
BMW	E31 8 Series (1989 - 1999)	PFF5-902BLK	Rear Track Rod Inner Bush		2	12500	11
BMW	E31 8 Series (1989 - 1999)	PFR5-308-15.5BLK	Rear Anti Roll Bar Mounting Bush 15.5mm	15.5mm	2	8500	7
BMW	E53 X5 (1999-2006)	PFA100-16	PowerAlign Camber Bolt Kit (16mm)	16mm	1	4500	N/A
BMW	E53 X5 (1999-2006)	PFF5-901BLK	Front Lower Radius Arm To Chassis Bush		2	19500	1
BMW	E53 X5 (1999-2006)	PFF5-902BLK	Front Control Arm To Chassis Bush		2	12500	2
BMW	E53 X5 (1999-2006)	PFF5-905-29BLK	Front Anti Roll Bar To Chassis 29mm	29mm	2	11000	3
BMW	E53 X5 (1999-2006)	PFR5-4609-23.5BLK	Rear Anti Roll Bar Mounting Bush 23.5mm	23.5mm	2	10500	5
BMW	E53 X5 (1999-2006)	PFR5-710BLK	Rear Lower Arm Front Bush	12mm Bore Sleeve	2	13000	10
BMW	E53 X5 (1999-2006)	PFR5-711BLK	Rear Lower Arm Rear Bush	14mm Bore Sleeve	2	14000	11
BMW	E53 X5 (1999-2006)	PFR5-715BLK	Rear Outer Integral Link Upper Bush		2	14000	15
BMW	E53 X5 (1999-2006)	PFR5-716BLK	Rear Outer Integral Link Lower Bush		2	11000	16
BMW	E53 X5 (1999-2006)	PFR5-908	Rear Subframe To Chassis Bush		4	79000	4
BMW	E70 X5 (2006-2013)	PFF5-1401BLK	Front Radius Arm To Chassis Bush		2	21000	1
BMW	E70 X5 (2006-2013)	PFF5-1403-27BLK	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	11000	3
BMW	E70 X5 (2006-2013)	PFF5-1404BLK	Front Anti Roll Bar Mounting Bush		2	10000	3
BMW	E70 X5 (2006-2013)	PFR5-1413-22BLK	Rear Anti Roll Bar Mounting Bush 22mm	22mm	2	10500	14
BMW	E70 X5 (2006-2013)	PFR5-1413-24BLK	Rear Anti Roll Bar Mounting Bush 24mm	24mm	2	10500	14
BMW	E70 X5 (2006-2013)	PFR5-1414BLK	Rear Anti Roll Bar Mounting Bush		2	10000	14
BMW	E70 X5 (2006-2013)	PFR5-1421BLK	Rear Subframe Front Bush Insert		2	14000	21
BMW	E70 X5 (2006-2013)	PFR5-1423BLK	Rear Subframe Rear Bush Insert		2	14000	23
BMW	E71 X6 (2007-)	PFF5-1401BLK	Front Radius Arm To Chassis Bush		2	21000	1
BMW	E71 X6 (2007-)	PFF5-1403-27BLK	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	11000	3
BMW	E71 X6 (2007-)	PFF5-1404BLK	Front Anti Roll Bar Mounting Bush		2	10000	3
BMW	E71 X6 (2007-)	PFR5-1413-22BLK	Rear Anti Roll Bar Mounting Bush 22mm	22mm	2	10500	14
BMW	E71 X6 (2007-)	PFR5-1413-24BLK	Rear Anti Roll Bar Mounting Bush 24mm	24mm	2	10500	14
BMW	E71 X6 (2007-)	PFR5-1414BLK	Rear Anti Roll Bar Mounting Bush		2	10000	14
BMW	E71 X6 (2007-)	PFR5-1421BLK	Rear Subframe Front Bush Insert		2	14000	21
BMW	E71 X6 (2007-)	PFR5-1423BLK	Rear Subframe Rear Bush Insert		2	14000	23
BMW	E83 X3 (2003-2010)	PFF5-1502BLK	Front Control Arm To Chassis Bush		2	12500	2
BMW	E83 X3 (2003-2010)	PFF5-1503-22.5BLK	Front Anti Roll Bar Mounting Bush 22.5mm	22.5mm	2	10500	3
BMW	E83 X3 (2003-2010)	PFF5-1503-23.5BLK	Front Anti Roll Bar Mounting Bush 23.5mm	23.5mm	2	10500	3
BMW	E83 X3 (2003-2010)	PFF5-901BLK	Front Lower Radius Arm To Chassis Bush		2	19500	1
BMW	E83 X3 (2003-2010)	PFR5-3608BLK	Rear Trailing Arm Bush		2	13500	3
BMW	E83 X3 (2003-2010)	PFR5-4609-17.5BLK	Rear Anti Roll Bar Mounting Bush 17.5mm	17.5mm	2	10500	5
BMW	E83 X3 (2003-2010)	PFR5-4609-18.5BLK	Rear Anti Roll Bar Mounting Bush 18.5mm	18.5mm	2	10500	5
BMW	E83 X3 (2003-2010)	PFR5-4610BLK	Rear Subframe Front Bush		2	20500	10
BMW	E83 X3 (2003-2010)	PFR5-4611BLK	Rear Subframe Rear Bush		2	20500	11
BMW	E83 X3 (2003-2010)	PFR5-4613BLK	Rear Subframe Rear Bush Insert		2	13000	11
BMW	E83 X3 (2003-2010)	PFR5-4614BLK	Rear Subframe Front Bush Insert		2	13000	10
BMW	E83 X3 (2003-2010)	PFR5-4615G	Adjustable Rear Lower Control Arm Kit		1	31250	19
BMW	E83 X3 (2003-2010)	PFR5-4616BLK	Rear Lower Control Arm Inner Bush		2	16000	19
BMW	E83 X3 (2003-2010)	PFR5-4617BLK	Rear Upper Arm Inner Bush		2	11000	17
BMW	E83 X3 (2003-2010)	PFR5-4618BLK	Rear Lower Arm Outer Bush		2	12000	18
BMW	E83 X3 (2003-2010)	PFR5-4625BLK	Rear Diff Front Bush		2	14500	25
BMW	E83 X3 (2003-2010)	PFR5-4626BLK	Rear Diff Rear Bush		1	8500	26
BMW	F15 X5 (2013-)	PFF5-1403-27BLK	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	11000	3
BMW	F15 X5 (2013-)	PFF5-1404BLK	Front Anti Roll Bar Mounting Bush		2	10000	3
BMW	F15 X5 (2013-)	PFR5-1413-24BLK	Rear Anti Roll Bar Mounting Bush 24mm	24mm	2	10500	14

BMW	F15 X5 (2013-)	PFR5-1414BLK	Rear Anti Roll Bar Mounting Bush		2	10000	14
BMW	F15 X5 (2013-)	PFR5-1421BLK	Rear Subframe Front Bush Insert		2	14000	21
BMW	F15 X5 (2013-)	PFR5-1423BLK	Rear Subframe Rear Bush Insert		2	14000	23
BMW	Z1 (1988 - 1991)	PFF5-301BLK	Front Lower Wishbone Rear Bush		2	11500	1
BMW	Z1 (1988 - 1991)	PFF5-303BLK	Front Lower Wishbone Rear Bush Caster Offset		2	13500	1
BMW	Z1 (1988 - 1991)	PFF5-304BLK	Anti Roll Bar Link Rod Bush		2	9500	3
BMW	Z1 (1988 - 1991)	PFR5-308-14BLK	Rear Roll Bar Mounting Bush 14mm	14mm	2	8500	6
BMW	Z1 (1988 - 1991)	PFR5-4615G	Adjustable Rear Lower Control Arm Kit		1	31250	19
BMW	Z1 (1988 - 1991)	PFR5-4616BLK	Rear Lower Control Arm Inner Bush		2	16000	19
BMW	Z1 (1988 - 1991)	PFR5-4617BLK	Rear Upper Arm Inner Bush		2	11000	17
BMW	Z1 (1988 - 1991)	PFR5-4618BLK	Rear Lower Arm Outer Bush		2	12000	18
BMW	Z3 (1994 - 2002)	PFF5-301BLK	Front Lower Wishbone Rear Bush		2	11500	1
BMW	Z3 (1994 - 2002)	PFF5-303BLK	Front Lower Wishbone Rear Bush Caster Offset		2	13500	1
BMW	Z3 (1994 - 2002)	PFF5-304BLK	Anti Roll Bar Link Rod Bush		2	9500	3
BMW	Z3 (1994 - 2002)	PFF5-310-23BLK	Front Anti Roll Bar Mounting 23mm	23mm	2	9000	2
BMW	Z3 (1994 - 2002)	PFF5-310-24BLK	Front Anti Roll Bar Mounting 24mm	24mm	2	9000	2
BMW	Z3 (1994 - 2002)	PFF5-310-25BLK	Front Anti Roll Bar Mounting 25mm	25mm	2	9000	2
BMW	Z3 (1994 - 2002)	PFF5-310-26BLK	Front Anti Roll Bar Mounting 26mm	26mm	2	9000	2
BMW	Z3 (1994 - 2002)	PFF5-310-27BLK	Front Anti Roll Bar Mounting 27mm	27mm	2	9000	2
BMW	Z3 (1994 - 2002)	PFF5-310-28BLK	Front Anti Roll Bar Mounting 28mm	28mm	2	9000	2
BMW	Z3 (1994 - 2002)	PFR5-300BLK	Rear Diff Mounting Bush		1	7250	7
BMW	Z3 (1994 - 2002)	PFR5-306BLK	Rear Trailing Arm Bush		4	27000	5
BMW	Z3 (1994 - 2002)	PFR5-306GBLK	Rear Trailing Arm Bush Adjustable		4	37000	5
BMW	Z3 (1994 - 2002)	PFR5-311BLK	Rear Beam Bush		2	19500	4
BMW	Z3 (1994 - 2002)	PFR5-504-14BLK	Rear Anti Roll Bar Bush 14mm	14mm	2	8500	6
BMW	Z3 (1994 - 2002)	PFR5-504-15BLK	Rear Roll Bar Mounting Bush 15mm	15mm	2	8500	6
BMW	Z3 (1994 - 2002)	PFR5-504-18BLK	Rear Anti Roll Bar Bush 18mm	18mm	2	8500	6
BMW	Z3 (1994 - 2002)	PFR5-5630-10BLK	Rear Shock Top Mount Bracket and Bush 10mm	10mm	2	18500	30
BMW	Z3 (1994 - 2002)	PFR5-5630-12BLK	Rear Shock Top Mount Bracket and Bush 12mm	12mm	2	18500	30
BMW	Z4 E85 & E86 (2003-2009)	PFF5-4601-60BLK	Front Wishbone Rear Bush	60mm	2	14500	1
BMW	Z4 E85 & E86 (2003-2009)	PFF5-4601BLK	Front Wishbone Rear Bush	66mm	2	14500	1
BMW	Z4 E85 & E86 (2003-2009)	PFF5-4602-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	10500	2
BMW	Z4 E85 & E86 (2003-2009)	PFF5-4602-25BLK	Front Anti Roll Bar Bush 25mm	25mm	2	10500	2
BMW	Z4 E85 & E86 (2003-2009)	PFF5-4602-27BLK	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	10500	2
BMW	Z4 E85 & E86 (2003-2009)	PFF5-5601-60BLK	Front Wishbone Rear Bush, Aluminium Outer	60mm	2	32500	1
BMW	Z4 E85 & E86 (2003-2009)	PFF5-5601BLK	Front Wishbone Rear Bush, Aluminium Outer	66mm	2	32500	1
BMW	Z4 E85 & E86 (2003-2009)	PFF5-5601G-60BLK	Front Wishbone Rear Bush, Caster Offset	60mm	2	33000	1
BMW	Z4 E85 & E86 (2003-2009)	PFF5-5601GBLK	Front Wishbone Rear Bush, Caster Offset	66mm	2	33000	1
BMW	Z4 E85 & E86 (2003-2009)	PFR5-3608BLK	Rear Trailing Arm Bush		2	13500	3
BMW	Z4 E85 & E86 (2003-2009)	PFR5-4610BLK	Rear Subframe Front Bush		2	20500	10
BMW	Z4 E85 & E86 (2003-2009)	PFR5-4611BLK	Rear Subframe Rear Bush		2	20500	11
BMW	Z4 E85 & E86 (2003-2009)	PFR5-4613BLK	Rear Subframe Rear Bush Insert		2	13000	11
BMW	Z4 E85 & E86 (2003-2009)	PFR5-4614BLK	Rear Subframe Front Bush Insert		2	13000	10
BMW	Z4 E85 & E86 (2003-2009)	PFR5-4615G	Adjustable Rear Lower Control Arm Kit		1	31250	19
BMW	Z4 E85 & E86 (2003-2009)	PFR5-4616BLK	Rear Lower Control Arm Inner Bush		2	16000	19
BMW	Z4 E85 & E86 (2003-2009)	PFR5-4617BLK	Rear Upper Arm Inner Bush		2	11000	17
BMW	Z4 E85 & E86 (2003-2009)	PFR5-4618BLK	Rear Lower Arm Outer Bush		2	12000	18
BMW	Z4 E85 & E86 (2003-2009)	PFR5-4625BLK	Rear Diff Front Bush		2	14500	25
BMW	Z4 E85 & E86 (2003-2009)	PFR5-4626BLK	Rear Diff Rear Bush		1	8500	26
BMW	Z4 E85 & E86 (2003-2009)	PFR5-504-18BLK	Rear Roll Bar Mounting Bush	18mm	2	8500	4
BMW	Z4 E85 & E86 (2003-2009)	PFR5-504-19BLK	Rear Roll Bar Mounting Bush	19mm	2	8500	4
BMW	Z4 E85 & E86 (2003-2009)	PFR5-5630-10BLK	Rear Shock Top Mount Bracket and Bush 10mm	10mm	2	18500	30
BMW	Z4 E85 & E86 (2003-2009)	PFR5-5630-12BLK	Rear Shock Top Mount Bracket and Bush 12mm	12mm	2	18500	30
BMW	Z4M E85 & E86 (2006-2009)	PFF5-4602-27BLK	Front Anti Roll Bar Mounting Bush 27mm	27mm	2	10500	2
BMW	Z4M E85 & E86 (2006-2009)	PFF5-5601GBLK	Front Wishbone Rear Bush, Caster Offset	66mm	2	33000	1
BMW	Z4M E85 & E86 (2006-2009)	PFR5-3608BLK	Rear Trailing Arm Bush		2	13500	3
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4609-21.5BLK	Rear Roll Bar Mounting Bush 21.5mm	21.5mm	2	10500	4
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4609-22.5BLK	Rear Roll Bar Mounting Bush 22.5mm	22.5mm	2	10500	4
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4610BLK	Rear Subframe Front Bush		2	20500	10

BMW	Z4M E85 & E86 (2006-2009)	PFR5-4611BLK	Rear Subframe Rear Bush		2	20500	11
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4612BLK	Rear Subframe Front Bush Insert		2	13000	10
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4613BLK	Rear Subframe Rear Bush Insert		2	13000	11
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4615G	Adjustable Rear Lower Control Arm Kit		1	31250	19
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4616BLK	Rear Lower Control Arm Inner Bush		2	16000	19
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4617BLK	Rear Upper Arm Inner Bush		2	11000	17
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4618BLK	Rear Lower Arm Outer Bush		2	12000	18
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4620BLK	Rear Diff Rear Mount		2	20000	20
BMW	Z4M E85 & E86 (2006-2009)	PFR5-4621BLK	Rear Diff Front Mount		1	6000	21
BMW	Z4M E85 & E86 (2006-2009)	PFR5-504-18BLK	Rear Roll Bar Mounting Bush	18mm	2	8500	4
BMW	Z4 E89 (2009 -)	PFF5-401BLK	Front Radius Arm To Chassis Bush		2	18500	1
BMW	Z4 E89 (2009 -)	PFF5-4602-26.5BLK	Front Anti Roll Bar Mounting Bush 26.5mm	26.5mm	2	10500	3
BMW	Z4 E89 (2009 -)	PFR5-4610BLK	Rear Subframe Front Bush		2	20500	10
BMW	Z4 E89 (2009 -)	PFR5-4611BLK	Rear Subframe Rear Bush		2	20500	11
BMW	Z4 E89 (2009 -)	PFR5-4613BLK	Rear Subframe Rear Bush Insert		2	13000	11
BMW	Z4 E89 (2009 -)	PFR5-4615G	Adjustable Rear Lower Control Arm Kit		1	31250	19
BMW	Z4 E89 (2009 -)	PFR5-4616BLK	Rear Lower Control Arm Inner Bush		2	16000	19
BMW	Z4 E89 (2009 -)	PFR5-4617BLK	Rear Upper Arm Inner Bush		2	11000	17
BMW	Z4 E89 (2009 -)	PFR5-4618BLK	Rear Lower Arm Outer Bush		2	12000	18
BMW	Z4 E89 (2009 -)	PFR5-504-19BLK	Rear Roll Bar Mounting Bush	19mm	2	8500	4