

Make	Model	Variants	Part Number	Product Description	Bush Size	定価(税別)	SET入数	図面番号
Caterham	7 (DeDion With Watts Linkage)		PF8-901	Large Lower Wishbone Bush 1/2" Bore	1/2 bore"	17600	4	1
Caterham	7 (DeDion With Watts Linkage)		PF8-901	DeDion "A" Frame Mounting Bush		8800	2	6
Caterham	7 (DeDion With Watts Linkage)		PF8-902	Small Upper Wishbone Front Bush		9240	2	2
Caterham	7 (DeDion With Watts Linkage)		PF8-903	DeDion "A" Frame Centre Bush		3000	1	5
Caterham	7 (DeDion With Watts Linkage)		PF8-904	Large Upper Wishbone Rear Bush	3/8 bore"	8800	2	4
Caterham	7 (DeDion With Watts Linkage)		PF8-905-12.5	Front Anti Roll Bar Bush 12.5mm	12.5mm	5750	2	3
Caterham	7 (DeDion With Watts Linkage)		PF8-905-14.5	Front Anti Roll Bar Bush 14.5mm	14.5mm	5750	2	3
Caterham	7 (DeDion With Watts Linkage)		PF8-905-16	Front Anti Roll Bar Bush 16mm	16mm	5750	2	3
Caterham	7 (DeDion With Watts Linkage)		PF8-905-19	Front Anti Roll Bar Bush 19mm	19mm	5750	2	3
Caterham	7 (DeDion With Watts Linkage)		PF8-907	DeDion "A" Frame Centre Bush		5000	1	5
Caterham	7 (DeDion With Watts Linkage)		PF8-909	Rear Axle Trailing Arm Front Bush		8360	2	7
Caterham	7 (DeDion With Watts Linkage)		PF8-909	Rear Axle Trailing Arm Rear Bush		8360	2	7
Caterham	7 (DeDion Without Watts Linkage)		PF8-901	Large Lower Wishbone Bush 1/2" Bore	1/2 bore"	17600	4	1
Caterham	7 (DeDion Without Watts Linkage)		PF8-901	DeDion "A" Frame Mounting Bush		8800	2	6
Caterham	7 (DeDion Without Watts Linkage)		PF8-901	Rear Axle Link Rear Bush 1/2" Bore		8800	2	8
Caterham	7 (DeDion Without Watts Linkage)		PF8-902	Small Upper Wishbone Front Bush		9240	2	2
Caterham	7 (DeDion Without Watts Linkage)		PF8-903	DeDion "A" Frame Centre Bush		3000	1	5
Caterham	7 (DeDion Without Watts Linkage)		PF8-904	Large Upper Wishbone Rear Bush	3/8 bore"	8800	2	4
Caterham	7 (DeDion Without Watts Linkage)		PF8-905-12.5	Front Anti Roll Bar Bush 12.5mm	12.5mm	5750	2	3
Caterham	7 (DeDion Without Watts Linkage)		PF8-905-14.5	Front Anti Roll Bar Bush 14.5mm	14.5mm	5750	2	3
Caterham	7 (DeDion Without Watts Linkage)		PF8-905-16	Front Anti Roll Bar Bush 16mm	16mm	5750	2	3
Caterham	7 (DeDion Without Watts Linkage)		PF8-905-19	Front Anti Roll Bar Bush 19mm	19mm	5750	2	3
Caterham	7 (DeDion Without Watts Linkage)		PF8-907	DeDion "A" Frame Centre Bush		5000	1	5
Caterham	7 (DeDion Without Watts Linkage)		PF8-909	Rear Axle Trailing Arm Front Bush		8360	2	7
Caterham	7 CSR (Independant Rear Suspension)		PF8-901	Large Lower Wishbone Bush 1/2" Bore	1/2 bore"	17600	4	1
Caterham	7 CSR (Independant Rear Suspension)		PF8-902	Small Upper Wishbone Front Bush		9240	2	2
Caterham	7 CSR (Independant Rear Suspension)		PF8-904	Large Upper Wishbone Rear Bush	3/8 bore"	8800	2	4
Caterham	7 CSR (Independant Rear Suspension)		PF8-906	Rear Upper And Lower Wishbone Bush		13200	4	6