

Make	Model	Variants	Part Number	Product Description	Bush Size	定価(税別)	SET入数	図面番号
Fiat	128 (1970 - 1978)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Fiat	500 (2007-)		PFF16-501	Front Arm Front Bush		9240	2	1
Fiat	500 (2007-)		PFF16-502	Front Arm Rear Bush		10560	2	2
Fiat	500 (2007-)		PFF16-503-20	Front Anti Roll Bar Bush 20mm	20mm	9000	2	3
Fiat	500 (2007-)		PFF16-503-21	Front Anti Roll Bar Bush 21mm	21 mm	9000	2	3
Fiat	500 (2007-)		PFF16-520	Engine Mount Insert		4250	1	20
Fiat	500 (2007-)		PFF16-521	Engine Mount Insert, Abarth		4250	1	20
Fiat	500 (2007-)		PFR16-510	Rear Beam Mounting Bush		9680	2	10
Fiat	Cinquecento & Seicento		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Fiat	Cinquecento & Seicento		PFF16-101	Front Wishbone Front Inner Bush		7700	2	1
Fiat	Cinquecento & Seicento		PFF16-103	Front Wishbone Rear Inner Bush		6600	2	2
Fiat	Cinquecento & Seicento		PFR16-120	Rear Trailing Arm Bush		15400	4	3
Fiat	Coupe (1993-2000), Brava, Bravo, Marea (1995-2001)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Fiat	Coupe (1993-2000), Brava, Bravo, Marea (1995-2001)		PFF1-603	Front Anti Roll Bar End Link Mount To Arm Bush		4250	2	3
Fiat	Coupe (1993-2000), Brava, Bravo, Marea (1995-2001)		PFF1-801	Front Lower Wishbone Front Bush		12760	2	1
Fiat	Coupe (1993-2000), Brava, Bravo, Marea (1995-2001)		PFF1-802	Front Lower Wishbone Rear Bush		12760	2	2
Fiat	Coupe (1993-2000), Brava, Bravo, Marea (1995-2001)		PFF16-304-23	Front Anti Roll Bar To Chassis Bush 23mm	23mm	9500	2	4
Fiat	Croma (2005 - 2011)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Fiat	Croma (2005 - 2011)		PFF66-503-24	Front Anti Roll Bar Mounting Bush 24mm		8250	2	3
Fiat	Croma (2005 - 2011)		PFF66-503-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	8250	2	3
Fiat	Croma (2005 - 2011)		PFF80-1201	Front Lower Wishbone Front Bush		10340	2	1
Fiat	Croma (2005 - 2011)		PFF80-1202	Front Lower Wishbone Rear Bush		11660	2	2
Fiat	Croma (2005 - 2011)		PFF80-1220	Front Lower Engine Mount Insert		5500	1	20
Fiat	Croma (2005 - 2011)		PFF80-1220	Rear Lower Engine Mount Insert		5500	1	21
Fiat	Croma (2005 - 2011)		PFF80-1220R	Front Lower Engine Mount Insert (Diesel)		5500	1	20
Fiat	Croma (2005 - 2011)		PFF80-1220R	Rear Lower Engine Mount Insert (Diesel)		5500	1	21
Fiat	Croma (2005 - 2011)		PFF80-1221	Rear Lower Engine Mount Insert (79mm Option)	79mm wide	5500	1	21
Fiat	Croma (2005 - 2011)		PFF80-1221R	Rear Lower Engine Mount Insert Diesel (79mm Option)	79mm wide	5500	1	21
Fiat	Croma (2005 - 2011)		PFR66-519-16	Rear Anti Roll Bar Mounting Bush 16mm	16mm	8250	2	19
Fiat	Croma (2005 - 2011)		PFR66-519-17	Rear Anti Roll Bar Mounting Bush 17mm	17mm	8250	2	19
Fiat	Croma (2005 - 2011)		PFR66-519-18	Rear Anti Roll Bar Mounting Bush 18mm	18mm	8250	2	19
Fiat	Croma (2005 - 2011)		PFR66-519-19	Rear Anti Roll Bar Mounting Bush 19mm	19mm	8250	2	19
Fiat	Croma (2005 - 2011)		PFR80-1210	Rear Trailing Arm Front Bush		13860	2	10
Fiat	Croma (2005 - 2011)		PFR80-1211	Rear Upper Arm Outer Bush	47mm	23540	2	11
Fiat	Croma (2005 - 2011)		PFR80-1212	Rear Upper Arm Inner Bush		11660	2	12
Fiat	Croma (2005 - 2011)		PFR80-1213	Rear Toe Arm Inner Bush		11660	2	13
Fiat	Croma (2005 - 2011)		PFR80-1214	Rear Toe Arm Outer Bush		11660	2	14
Fiat	Croma (2005 - 2011)		PFR80-1215	Rear Lower Arm Outer Bush		9240	2	15
Fiat	Croma (2005 - 2011)		PFR80-1216	Rear Lower Arm Inner Bush		12100	2	16
Fiat	Croma (2005 - 2011)		PFR80-1217	Rear Upper Arm Outer Bush, 38mm	38mm	10120	2	11
Fiat	Multipla (1998 - 2007)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Fiat	Panda (2003-2012)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Fiat	Grande Punto (2005 - 2009)	Grande Punto	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Fiat	Grande Punto (2005 - 2009)	Grande Punto	PFF80-1101	Front Arm Front Bush		9680	2	1
Fiat	Grande Punto (2005 - 2009)	Grande Punto	PFF80-1102	Front Arm Rear Bush		27720	2	2
Fiat	Grande Punto (2005 - 2009)	Grande Punto	PFF80-1103-19	Front Anti Roll Bar Bush 19mm	19mm	8500	2	3
Fiat	Grande Punto (2005 - 2009)	Grande Punto	PFF80-1103-20	Front Anti Roll Bar Bush 20mm	20mm	8500	2	3
Fiat	Grande Punto (2005 - 2009)	Grande Punto	PFF80-1103-21	Front Anti Roll Bar Bush 21mm	21mm	8500	2	3
Fiat	Grande Punto (2005 - 2009)	Grande Punto	PFF80-1120	Lower Rear Engine Mount Insert		5000	1	20
Fiat	Grande Punto (2005 - 2009)	Grande Punto	PFR80-1110	Rear Beam Mounting Bush		13420	2	10
Fiat	Grande Punto (2005 - 2009)	Grande Punto Abarth	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Fiat	Grande Punto (2005 - 2009)	Grande Punto Abarth	PFF80-1101	Front Arm Front Bush		9680	2	1
Fiat	Grande Punto (2005 - 2009)	Grande Punto Abarth	PFF80-1102	Front Arm Rear Bush		27720	2	2
Fiat	Grande Punto (2005 - 2009)	Grande Punto Abarth	PFF80-1103-19	Front Anti Roll Bar Bush 19mm	19mm	8500	2	3
Fiat	Grande Punto (2005 - 2009)	Grande Punto Abarth	PFF80-1103-20	Front Anti Roll Bar Bush 20mm	20mm	8500	2	3
Fiat	Grande Punto (2005 - 2009)	Grande Punto Abarth	PFF80-1103-21	Front Anti Roll Bar Bush 21mm	21mm	8500	2	3
Fiat	Grande Punto (2005 - 2009)	Grande Punto Abarth	PFF80-1120	Lower Rear Engine Mount Insert		5000	1	20
Fiat	Grande Punto (2005 - 2009)	Grande Punto Abarth	PFR80-1110	Rear Beam Mounting Bush		13420	2	10
Fiat	Punto Evo (2009 onwards)	Punto Evo	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Fiat	Punto Evo (2009 onwards)	Punto Evo	PFF80-1101	Front Arm Front Bush		9680	2	1
Fiat	Punto Evo (2009 onwards)	Punto Evo	PFF80-1102	Front Arm Rear Bush		27720	2	2
Fiat	Punto Evo (2009 onwards)	Punto Evo	PFF80-1103-19	Front Anti Roll Bar Bush 19mm	19mm	8500	2	3
Fiat	Punto Evo (2009 onwards)	Punto Evo	PFF80-1103-20	Front Anti Roll Bar Bush 20mm	20mm	8500	2	3
Fiat	Punto Evo (2009 onwards)	Punto Evo	PFF80-1103-21	Front Anti Roll Bar Bush 21mm	21mm	8500	2	3
Fiat	Punto Evo (2009 onwards)	Punto Evo	PFF80-1120	Lower Rear Engine Mount Insert		5000	1	20
Fiat	Punto Evo (2009 onwards)	Punto Evo	PFR80-1110	Rear Beam Mounting Bush		13420	2	10
Fiat	Punto Evo (2009 onwards)	Punto Evo Abarth	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Fiat	Punto Evo (2009 onwards)	Punto Evo Abarth	PFF80-1101	Front Arm Front Bush		9680	2	1
Fiat	Punto Evo (2009 onwards)	Punto Evo Abarth	PFF80-1102	Front Arm Rear Bush		27720	2	2
Fiat	Punto Evo (2009 onwards)	Punto Evo Abarth	PFF80-1103-19	Front Anti Roll Bar Bush 19mm	19mm	8500	2	3
Fiat	Punto Evo (2009 onwards)	Punto Evo Abarth	PFF80-1103-20	Front Anti Roll Bar Bush 20mm	20mm	8500	2	3
Fiat	Punto Evo (2009 onwards)	Punto Evo Abarth	PFF80-1103-21	Front Anti Roll Bar Bush 21mm	21mm	8500	2	3
Fiat	Punto Evo (2009 onwards)	Punto Evo Abarth	PFF80-1120	Lower Rear Engine Mount Insert		5000	1	20
Fiat	Punto Evo (2009 onwards)	Punto Evo Abarth	PFR80-1110	Rear Beam Mounting Bush		13420	2	10
Fiat	Punto MK1 (1993 - 1999)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Fiat	Punto MK1 (1993 - 1999)		PFF16-101	Front Wishbone Inner Bush		7700	2	1

Fiat	Scudo MK1, MK2 (1995 - 2007)		PFF16-203-25	Front Anti Roll Bar To Chassis Bush 25mm		10000	2	1
Fiat	Strada 130TC		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Fiat	Strada 130TC		PFF16-401	Front Wishbone Inner Bush		7700	2	1
Fiat	Tipo (1988-1995)		PFF1-801	Front Lower Wishbone Front Bush		12760	2	1
Fiat	Tipo (1988-1995)		PFF1-802	Front Lower Wishbone Rear Bush		12760	2	2
Fiat	Ulysse (1994 - 2002)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Fiat	Ulysse (1994 - 2002)		PFF16-203-25	Front Anti Roll Bar To Chassis Bush 25mm		10000	2	1
Fiat	Uno inc Turbo		PFF16-101	Front Wishbone Front Inner Bush		7700	2	1
Fiat	Uno inc Turbo		PFF16-103	Front Wishbone Rear Inner Bush		6600	2	2
Fiat	Uno inc Turbo		PFF16-105	Front Anti Roll Bar Inner Mount	19mm	7500	2	3
Fiat	Uno inc Turbo		PFF16-106	Front Anti Roll Bar Outer Mount		6500	2	4
Fiat	Uno inc Turbo		PFR16-110	Rear Beam Mounting Bush		11220	2	5