

Make	Model	Part Number	Product Description	Bush Size	入数	SET価格	Diag Ref
Fiat	124 SPIDER (2016 on)	PFF36-601	Front Lower Arm Front Bush		2	13000	1
Fiat	124 SPIDER (2016 on)	PFF36-602	Front Lower Arm Rear Bush		2	13500	2
Fiat	124 SPIDER (2016 on)	PFF36-603-22.7	Front Anti Roll Bar Bush	22.7	2	8000	3
Fiat	124 SPIDER (2016 on)	PFF36-604	Front Upper Arm Bush		4	25000	4
Fiat	124 SPIDER (2016 on)	PFF36-605	Front Lower Arm Rear Bush Insert		2	10000	5
Fiat	124 SPIDER (2016 on)	PFR36-610-11.1	Rear Anti Roll Bar Bush	11.1	2	7500	10
Fiat	124 SPIDER (2016 on)	PFR36-630	Rear Diff Mount Insert		2	11000	30
Fiat	128 (1970 - 1978)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Fiat	500 (2007-)	PFA100-10	PowerAlign Camber Bolt Kit (10mm)	10mm	1	4250	N/A
Fiat	500 (2007-)	PFF16-501	Front Arm Front Bush		2	11000	1
Fiat	500 (2007-)	PFF16-502	Front Arm Rear Bush		2	12500	2
Fiat	500 (2007-)	PFF16-503-20	Front Anti Roll Bar Bush 20mm	20mm	2	9000	3
Fiat	500 (2007-)	PFF16-503-21	Front Anti Roll Bar Bush 21mm	21 mm	2	9000	3
Fiat	500 (2007-)	PFF16-520	Lower Engine Mount Insert		1	4500	20
Fiat	500 (2007-)	PFF16-521	Lower Engine Mount Insert, Abarth inc 595		1	4500	20
Fiat	500 (2007-)	PFF16-522	Lower Engine Mount Insert - US Models		1	4500	20
Fiat	500 (2007-)	PFF16-523	Lower Engine Mount Insert - US Models		1	4500	20
Fiat	500 (2007-)	PFR16-510	Rear Beam Mounting Bush		2	11500	10
Fiat	500 (2007-)	PFR16-515	Rear Shock Absorber Top Mounting Bush		2	8000	15
Fiat	Bravo (2007 -)	PFF16-701	Front Wishbone Front Bush 12mm	12mm	2	12000	1
Fiat	Bravo (2007 -)	PFF16-701-14	Front Wishbone Front Bush 14mm	12mm	2	12000	1
Fiat	Bravo (2007 -)	PFF16-702	Front Wishbone Rear Bush		2	13500	2
Fiat	Bravo (2007 -)	PFR16-710	Rear Beam Mounting Bush		2	16500	10
Fiat	Cinquecento (1991-1998) & Seicento (1997-2010)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Fiat	Cinquecento (1991-1998) & Seicento (1997-2010)	PFF16-101	Front Wishbone Front Inner Bush		2	9500	1
Fiat	Cinquecento (1991-1998) & Seicento (1997-2010)	PFF16-103	Front Wishbone Rear Inner Bush		2	8000	2
Fiat	Cinquecento (1991-1998) & Seicento (1997-2010)	PFR16-120	Rear Trailing Arm Bush		4	19000	3
Fiat	Coupe (1993-2000), Brava, Bravo, Marea (1995-2001)	PFA100-10	PowerAlign Camber Bolt Kit (10mm)	10mm	1	4250	N/A
Fiat	Coupe (1993-2000), Brava, Bravo, Marea (1995-2001)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Fiat	Coupe (1993-2000), Brava, Bravo, Marea (1995-2001)	PFF1-603	Front Anti Roll Bar End Link Mount To Arm Bush		2	7000	3
Fiat	Coupe (1993-2000), Brava, Bravo, Marea (1995-2001)	PFF1-801	Front Lower Wishbone Front Bush		2	15500	1
Fiat	Coupe (1993-2000), Brava, Bravo, Marea (1995-2001)	PFF1-802	Front Lower Wishbone Rear Bush		2	15500	2
Fiat	Coupe (1993-2000), Brava, Bravo, Marea (1995-2001)	PFF1-824	Upper Right Engine Mount Bush		1	5250	24
Fiat	Coupe (1993-2000), Brava, Bravo, Marea (1995-2001)	PFF16-304-23	Front Anti Roll Bar To Chassis Bush 23mm	23mm	2	9500	4
Fiat	Croma (2005 - 2011)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Fiat	Croma (2005 - 2011)	PFF66-503-24	Front Anti Roll Bar Mounting Bush 24mm		2	8500	3
Fiat	Croma (2005 - 2011)	PFF66-503-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	8500	3
Fiat	Croma (2005 - 2011)	PFF80-1201	Front Lower Wishbone Front Bush		2	12500	1
Fiat	Croma (2005 - 2011)	PFF80-1202	Front Lower Wishbone Rear Bush		2	14000	2
Fiat	Croma (2005 - 2011)	PFF80-1220	Front Lower Engine Mount Insert		1	6000	20
Fiat	Croma (2005 - 2011)	PFF80-1220	Rear Lower Engine Mount Insert		1	6000	21
Fiat	Croma (2005 - 2011)	PFF80-1220R	Front Lower Engine Mount Insert (Diesel)		1	6000	20
Fiat	Croma (2005 - 2011)	PFF80-1220R	Rear Lower Engine Mount Insert (Diesel)		1	6000	21
Fiat	Croma (2005 - 2011)	PFF80-1221	Rear Lower Engine Mount Insert (79mm Option)	79mm wide	1	5750	21
Fiat	Croma (2005 - 2011)	PFF80-1221R	Rear Lower Engine Mount Insert Diesel (79mm Option)	79mm wide	1	5750	21
Fiat	Croma (2005 - 2011)	PFR66-519-16	Rear Anti Roll Bar Mounting Bush 16mm	16mm	2	8500	19
Fiat	Croma (2005 - 2011)	PFR66-519-17	Rear Anti Roll Bar Mounting Bush 17mm	17mm	2	8500	19
Fiat	Croma (2005 - 2011)	PFR66-519-18	Rear Anti Roll Bar Mounting Bush 18mm	18mm	2	8500	19
Fiat	Croma (2005 - 2011)	PFR66-519-19	Rear Anti Roll Bar Mounting Bush 19mm	19mm	2	8500	19
Fiat	Croma (2005 - 2011)	PFR80-1210	Rear Trailing Arm Front Bush		2	17000	10
Fiat	Croma (2005 - 2011)	PFR80-1211	Rear Upper Arm Outer Bush	47mm	2	28500	11
Fiat	Croma (2005 - 2011)	PFR80-1212	Rear Upper Arm Inner Bush		2	14000	12
Fiat	Croma (2005 - 2011)	PFR80-1213	Rear Toe Arm Inner Bush		2	14000	13
Fiat	Croma (2005 - 2011)	PFR80-1214	Rear Toe Arm Outer Bush		2	14000	14
Fiat	Croma (2005 - 2011)	PFR80-1215	Rear Lower Arm Outer Bush		2	11000	15
Fiat	Croma (2005 - 2011)	PFR80-1216	Rear Lower Arm Inner Bush		2	14500	16
Fiat	Croma (2005 - 2011)	PFR80-1217	Rear Upper Arm Outer Bush, 38mm	38mm	2	12000	11
Fiat	Fiorino (2007-on)	PFF80-1101	Front Arm Front Bush		2	12000	1

Fiat	Fiorino (2007-on)	PFF80-1102	Front Arm Rear Bush		2	33500	2
Fiat	Fiorino (2007-on)	PFR80-1110	Rear Beam Mounting Bush		2	16000	10
Fiat	Linea (2006-on)	PFF80-1101	Front Arm Front Bush		2	12000	1
Fiat	Linea (2006-on)	PFF80-1102	Front Arm Rear Bush		2	33500	2
Fiat	Linea (2006-on)	PFR80-1110	Rear Beam Mounting Bush		2	16000	10
Fiat	Multipla (1998 - 2007)	PFA100-10	PowerAlign Camber Bolt Kit (10mm)	10mm	1	4250	N/A
Fiat	Multipla (1998 - 2007)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Fiat	Panda 2WD (2003-2012)	PFA100-10	PowerAlign Camber Bolt Kit (10mm)	10mm	1	4250	N/A
Fiat	Panda 2WD (2003-2012)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Fiat	Panda 2WD (2003-2012)	PFF16-501	Front Arm Front Bush		2	11000	1
Fiat	Panda 2WD (2003-2012)	PFF16-502	Front Arm Rear Bush		2	12500	2
Fiat	Panda 2WD (2003-2012)	PFF16-520	Lower Engine Mount Insert		1	4500	20
Fiat	Panda 2WD (2003-2012)	PFR16-510	Rear Beam Mounting Bush		2	11500	10
Fiat	Panda 4WD (2003-2012)	PFA100-10	PowerAlign Camber Bolt Kit (10mm)	10mm	1	4250	N/A
Fiat	Panda 4WD (2003-2012)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Fiat	Panda 4WD (2003-2012)	PFF16-501	Front Arm Front Bush		2	11000	1
Fiat	Panda 4WD (2003-2012)	PFF16-502	Front Arm Rear Bush		2	12500	2
Fiat	Panda 4WD (2003-2012)	PFF16-520	Lower Engine Mount Insert		1	4500	20
Fiat	Panda 4WD (2003-2012)	PFR16-120	Rear Trailing Arm Bush		4	19000	3
Fiat	Grande Punto (2005 - 2009)Grande Punto	PFF80-1101	Front Arm Front Bush		2	12000	1
Fiat	Grande Punto (2005 - 2009)Grande Punto	PFF80-1102	Front Arm Rear Bush		2	33500	2
Fiat	Grande Punto (2005 - 2009)Grande Punto	PFF80-1103-19	Front Anti Roll Bar Bush 19mm	19mm	2	8500	3
Fiat	Grande Punto (2005 - 2009)Grande Punto	PFF80-1103-20	Front Anti Roll Bar Bush 20mm	20mm	2	8500	3
Fiat	Grande Punto (2005 - 2009)Grande Punto	PFF80-1103-21	Front Anti Roll Bar Bush 21mm	21mm	2	8500	3
Fiat	Grande Punto (2005 - 2009)Grande Punto	PFF80-1120	Lower Rear Engine Mount Insert		1	5250	20
Fiat	Grande Punto (2005 - 2009)Grande Punto	PFR80-1110	Rear Beam Mounting Bush		2	16000	10
Fiat	Grande Punto (2005 - 2009)Grande Punto Abarth	PFF80-1101	Front Arm Front Bush		2	12000	1
Fiat	Grande Punto (2005 - 2009)Grande Punto Abarth	PFF80-1102	Front Arm Rear Bush		2	33500	2
Fiat	Grande Punto (2005 - 2009)Grande Punto Abarth	PFF80-1103-19	Front Anti Roll Bar Bush 19mm	19mm	2	8500	3
Fiat	Grande Punto (2005 - 2009)Grande Punto Abarth	PFF80-1103-20	Front Anti Roll Bar Bush 20mm	20mm	2	8500	3
Fiat	Grande Punto (2005 - 2009)Grande Punto Abarth	PFF80-1103-21	Front Anti Roll Bar Bush 21mm	21mm	2	8500	3
Fiat	Grande Punto (2005 - 2009)Grande Punto Abarth	PFF80-1120	Lower Rear Engine Mount Insert		1	5250	20
Fiat	Grande Punto (2005 - 2009)Grande Punto Abarth	PFR80-1110	Rear Beam Mounting Bush		2	16000	10
Fiat	Punto Evo (2009 onwards)Punto Evo	PFF80-1101	Front Arm Front Bush		2	12000	1
Fiat	Punto Evo (2009 onwards)Punto Evo	PFF80-1102	Front Arm Rear Bush		2	33500	2
Fiat	Punto Evo (2009 onwards)Punto Evo	PFF80-1103-19	Front Anti Roll Bar Bush 19mm	19mm	2	8500	3
Fiat	Punto Evo (2009 onwards)Punto Evo	PFF80-1103-20	Front Anti Roll Bar Bush 20mm	20mm	2	8500	3
Fiat	Punto Evo (2009 onwards)Punto Evo	PFF80-1103-21	Front Anti Roll Bar Bush 21mm	21mm	2	8500	3
Fiat	Punto Evo (2009 onwards)Punto Evo	PFF80-1120	Lower Rear Engine Mount Insert		1	5250	20
Fiat	Punto Evo (2009 onwards)Punto Evo	PFR80-1110	Rear Beam Mounting Bush		2	16000	10
Fiat	Punto Evo (2009 onwards)Punto Evo Abarth	PFF80-1101	Front Arm Front Bush		2	12000	1
Fiat	Punto Evo (2009 onwards)Punto Evo Abarth	PFF80-1102	Front Arm Rear Bush		2	33500	2
Fiat	Punto Evo (2009 onwards)Punto Evo Abarth	PFF80-1103-19	Front Anti Roll Bar Bush 19mm	19mm	2	8500	3
Fiat	Punto Evo (2009 onwards)Punto Evo Abarth	PFF80-1103-20	Front Anti Roll Bar Bush 20mm	20mm	2	8500	3
Fiat	Punto Evo (2009 onwards)Punto Evo Abarth	PFF80-1103-21	Front Anti Roll Bar Bush 21mm	21mm	2	8500	3
Fiat	Punto Evo (2009 onwards)Punto Evo Abarth	PFF80-1120	Lower Rear Engine Mount Insert		1	5250	20
Fiat	Punto Evo (2009 onwards)Punto Evo Abarth	PFR80-1110	Rear Beam Mounting Bush		2	16000	10
Fiat	Punto MK1 (1993 - 1999)	PFA100-10	PowerAlign Camber Bolt Kit (10mm)	10mm	1	4250	N/A
Fiat	Punto MK1 (1993 - 1999)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Fiat	Punto MK1 (1993 - 1999)	PFF16-101	Front Wishbone Inner Bush		2	9500	1
Fiat	Punto MK2 (1999 - 2005)	PFF16-601	Front Arm Front Bush		2	10500	1
Fiat	Punto MK2 (1999 - 2005)	PFF16-602	Front Arm Rear Bush		2	12500	2
Fiat	Punto MK2 (1999 - 2005)	PFF16-603-21	Front Anti Roll Bar To Chassis Bush 21mm	21mm	2	9000	3
Fiat	Punto MK2 (1999 - 2005)	PFF16-603-22	Front Anti Roll Bar To Chassis Bush 22mm	22mm	2	9000	3
Fiat	Punto MK2 (1999 - 2005)	PFF16-604-13	Front Anti Roll Bar To Arm Bush 13mm		2	9000	4
Fiat	Punto MK2 (1999 - 2005)	PFR16-510	Rear Beam Mounting Bush		2	11500	10
Fiat	Qubo (2008-on)	PFF80-1101	Front Arm Front Bush		2	12000	1
Fiat	Qubo (2008-on)	PFF80-1102	Front Arm Rear Bush		2	33500	2
Fiat	Qubo (2008-on)	PFR80-1110	Rear Beam Mounting Bush		2	16000	10

Fiat	Scudo MK1, MK2 (1995 – 2007)	EXH026	Universal Exhaust Mount		1	2250	
Fiat	Scudo MK1, MK2 (1995 – 2007)	PFF16-203-25	Front Anti Roll Bar To Chassis Bush 25mm	25mm	2	10000	1
Fiat	Scudo MK1, MK2 (1995 – 2007)	PFF16-204-25	Front Anti Roll Bar To Chassis Bush 25mm	25mm	2	10000	1
Fiat	Stilo (2001 – 2010)	PFF16-701	Front Wishbone Front Bush 12mm	12mm	2	12000	1
Fiat	Stilo (2001 – 2010)	PFF16-701-14	Front Wishbone Front Bush 14mm	12mm	2	12000	1
Fiat	Stilo (2001 – 2010)	PFF16-702	Front Wishbone Rear Bush		2	13500	2
Fiat	Stilo (2001 – 2010)	PFR16-710	Rear Beam Mounting Bush		2	16500	10
Fiat	Strada 130TC (1978-1988)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Fiat	Strada 130TC (1978-1988)	PFF16-401	Front Wishbone Inner Bush		2	9500	1
Fiat	Tipo (1988-1995)	PFA100-10	PowerAlign Camber Bolt Kit (10mm)	10mm	1	4250	N/A
Fiat	Tipo (1988-1995)	PFF1-801	Front Lower Wishbone Front Bush		2	15500	1
Fiat	Tipo (1988-1995)	PFF1-802	Front Lower Wishbone Rear Bush		2	15500	2
Fiat	Ulysse (1994 – 2002)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Fiat	Ulysse (1994 – 2002)	PFF16-203-25	Front Anti Roll Bar To Chassis Bush 25mm	25mm	2	10000	1
Fiat	Ulysse (1994 – 2002)	PFF16-204-25	Front Anti Roll Bar To Chassis Bush 25mm	25mm	2	10000	1
Fiat	Uno inc Turbo (1983-1995)	PFA100-10	PowerAlign Camber Bolt Kit (10mm)	10mm	1	4250	N/A
Fiat	Uno inc Turbo (1983-1995)	PFF16-101	Front Wishbone Front Inner Bush		2	9500	1
Fiat	Uno inc Turbo (1983-1995)	PFF16-103	Front Wishbone Rear Inner Bush		2	8000	2
Fiat	Uno inc Turbo (1983-1995)	PFF16-105	Front Anti Roll Bar Inner Mount	19mm	2	7500	3
Fiat	Uno inc Turbo (1983-1995)	PFF16-106	Front Anti Roll Bar Outer Mount		2	7000	4
Fiat	Uno inc Turbo (1983-1995)	PFR16-110	Rear Beam Mounting Bush		2	13500	5
Fiat	124 SPIDER (2016 on)	PFF36-601BLK	Front Lower Arm Front Bush		2	13000	1
Fiat	124 SPIDER (2016 on)	PFF36-602BLK	Front Lower Arm Rear Bush		2	13500	2
Fiat	124 SPIDER (2016 on)	PFF36-603-22.7BLK	Front Anti Roll Bar Bush	22.7	2	9000	3
Fiat	124 SPIDER (2016 on)	PFF36-604BLK	Front Upper Arm Bush		4	25000	4
Fiat	124 SPIDER (2016 on)	PFF36-605BLK	Front Lower Arm Rear Bush Insert		2	10000	5
Fiat	124 SPIDER (2016 on)	PFR36-610-11.1BLK	Rear Anti Roll Bar Bush	11.1	2	8500	10
Fiat	124 SPIDER (2016 on)	PFR36-630BLK	Rear Diff Mount Insert		2	12000	30
Fiat	128 (1970 – 1978)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Fiat	500 (2007-)	PFA100-10	PowerAlign Camber Bolt Kit (10mm)	10mm	1	4250	N/A
Fiat	500 (2007-)	PFF16-501GBLK	Front Arm Front Bush, Camber Adjust		2	26000	1
Fiat	500 (2007-)	PFF16-502GBLK	Front Arm Rear Bush, Caster Adjust		2	34000	2
Fiat	500 (2007-)	PFF16-503-20BLK	Front Anti Roll Bar Bush 20mm	20mm	2	10000	3
Fiat	500 (2007-)	PFF16-503-21BLK	Front Anti Roll Bar Bush 21mm	21 mm	2	10000	3
Fiat	500 (2007-)	PFF16-520BLK	Lower Engine Mount Insert		1	5000	20
Fiat	500 (2007-)	PFF16-521BLK	Lower Engine Mount Insert, Abarth inc 595		1	5000	20
Fiat	500 (2007-)	PFF16-522BLK	Lower Engine Mount Insert – US Models		1	5000	20
Fiat	500 (2007-)	PFF16-523BLK	Lower Engine Mount Insert – US Models		1	5000	20
Fiat	500 (2007-)	PFR16-510BLK	Rear Beam Mounting Bush		2	13000	10
Fiat	500 (2007-)	PFR16-515BLK	Rear Shock Absorber Top Mounting Bush		2	9000	15
Fiat	Bravo (2007 –)	PFF16-701-14BLK	Front Wishbone Front Bush 14mm	14mm	2	13500	1
Fiat	Bravo (2007 –)	PFF16-701BLK	Front Wishbone Front Bush 12mm	12mm	2	13500	1
Fiat	Bravo (2007 –)	PFF16-702BLK	Front Wishbone Rear Bush		2	15000	2
Fiat	Bravo (2007 –)	PFR16-710BLK	Rear Beam Mounting Bush		2	18500	10
Fiat	Cinquecento (1991-1998) & Seicento (1997-2010)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Fiat	Cinquecento (1991-1998) & Seicento (1997-2010)	PFF16-101BLK	Front Wishbone Inner Bush		2	10500	1
Fiat	Cinquecento (1991-1998) & Seicento (1997-2010)	PFF16-103BLK	Front Wishbone Rear Inner Bush		2	9000	2
Fiat	Cinquecento (1991-1998) & Seicento (1997-2010)	PFR16-120BLK	Rear Trailing Arm Bush		4	21000	3
Fiat	Coupe (1993-2000), Brava, Bravo, Marea (1995-2001)	PFA100-10	PowerAlign Camber Bolt Kit (10mm)	10mm	1	4250	N/A
Fiat	Coupe (1993-2000), Brava, Bravo, Marea (1995-2001)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Fiat	Coupe (1993-2000), Brava, Bravo, Marea (1995-2001)	PFF1-603BLK	Front Anti Roll Bar End Link Mount To Arm Bush		2	7500	3
Fiat	Coupe (1993-2000), Brava, Bravo, Marea (1995-2001)	PFF1-801BLK	Front Lower Wishbone Front Bush		2	17000	1
Fiat	Coupe (1993-2000), Brava, Bravo, Marea (1995-2001)	PFF1-802BLK	Front Lower Wishbone Rear Bush		2	17000	2
Fiat	Coupe (1993-2000), Brava, Bravo, Marea (1995-2001)	PFF16-304-23BLK	Front Anti Roll Bar To Chassis Bush 23mm	23mm	2	10500	4
Fiat	Croma (2005 – 2011)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Fiat	Croma (2005 – 2011)	PFF66-503-25BLK	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	9000	3
Fiat	Croma (2005 – 2011)	PFF80-1201BLK	Front Lower Wishbone Front Bush		2	12500	1
Fiat	Croma (2005 – 2011)	PFF80-1202BLK	Front Lower Wishbone Rear Bush		2	15500	2
Fiat	Croma (2005 – 2011)	PFF80-1220BLK	Rear Lower Engine Mount Insert		1	6500	21

Fiat	Croma (2005 – 2011)	PFF80-1220BLK	Front Lower Engine Mount Insert		1	6500	20
Fiat	Croma (2005 – 2011)	PFF80-1221BLK	Rear Lower Engine Mount Insert (79mm Option)	79mm wide	1	6500	21
Fiat	Croma (2005 – 2011)	PFR66-519-19BLK	Rear Anti Roll Bar Mounting Bush 19mm	19mm	2	9000	19
Fiat	Croma (2005 – 2011)	PFR80-1210BLK	Rear Trailing Arm Front Bush		2	18500	10
Fiat	Croma (2005 – 2011)	PFR80-1211BLK	Rear Upper Arm Outer Bush	47mm	2	28500	11
Fiat	Croma (2005 – 2011)	PFR80-1212BLK	Rear Upper Arm Inner Bush		2	14000	12
Fiat	Croma (2005 – 2011)	PFR80-1213BLK	Rear Toe Arm Inner Bush		2	14000	13
Fiat	Croma (2005 – 2011)	PFR80-1214BLK	Rear Toe Arm Outer Bush		2	14000	14
Fiat	Croma (2005 – 2011)	PFR80-1215BLK	Rear Lower Arm Outer Bush		2	12500	15
Fiat	Croma (2005 – 2011)	PFR80-1216BLK	Rear Lower Arm Inner Bush		2	16000	16
Fiat	Croma (2005 – 2011)	PFR80-1217BLK	Rear Upper Arm Outer Bush, 38mm	38mm	2	13500	11
Fiat	Panda 2WD (2003-2012)	PFA100-10	PowerAlign Camber Bolt Kit (10mm)	10mm	1	4250	N/A
Fiat	Panda 2WD (2003-2012)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Fiat	Panda 2WD (2003-2012)	PFF16-501GBLK	Front Arm Front Bush, Camber Adjust		2	26000	1
Fiat	Panda 2WD (2003-2012)	PFF16-502GBLK	Front Arm Rear Bush, Caster Adjust		2	34000	2
Fiat	Panda 2WD (2003-2012)	PFF16-520BLK	Lower Engine Mount Insert		1	5000	20
Fiat	Panda 2WD (2003-2012)	PFR16-510BLK	Rear Beam Mounting Bush		2	13000	10
Fiat	Panda 4WD (2003-2012)	PFA100-10	PowerAlign Camber Bolt Kit (10mm)	10mm	1	4250	N/A
Fiat	Panda 4WD (2003-2012)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Fiat	Panda 4WD (2003-2012)	PFF16-501GBLK	Front Arm Front Bush, Camber Adjust		2	26000	1
Fiat	Panda 4WD (2003-2012)	PFF16-502GBLK	Front Arm Rear Bush, Caster Adjust		2	34000	2
Fiat	Panda 4WD (2003-2012)	PFF16-520BLK	Lower Engine Mount Insert		1	5000	20
Fiat	Panda 4WD (2003-2012)	PFR16-120BLK	Rear Trailing Arm Bush		4	21000	3
Fiat	Grande Punto (2005 – 2009)Grande Punto	PFF80-1101BLK	Front Arm Front Bush		2	12000	1
Fiat	Grande Punto (2005 – 2009)Grande Punto	PFF80-1102BLK	Front Arm Rear Bush		2	36500	2
Fiat	Grande Punto (2005 – 2009)Grande Punto	PFF80-1103-19BLK	Front Anti Roll Bar Bush 19mm	19mm	2	9500	3
Fiat	Grande Punto (2005 – 2009)Grande Punto	PFF80-1103-20BLK	Front Anti Roll Bar Bush 20mm	20mm	2	9500	3
Fiat	Grande Punto (2005 – 2009)Grande Punto	PFF80-1103-21BLK	Front Anti Roll Bar Bush 21mm	21mm	2	9500	3
Fiat	Grande Punto (2005 – 2009)Grande Punto	PFF80-1120BLK	Lower Rear Engine Mount Insert		1	6000	20
Fiat	Grande Punto (2005 – 2009)Grande Punto	PFR80-1110BLK	Rear Beam Mounting Bush		2	18000	10
Fiat	Grande Punto (2005 – 2009)Grande Punto Abarth	PFF80-1101BLK	Front Arm Front Bush		2	12000	1
Fiat	Grande Punto (2005 – 2009)Grande Punto Abarth	PFF80-1102BLK	Front Arm Rear Bush		2	36500	2
Fiat	Grande Punto (2005 – 2009)Grande Punto Abarth	PFF80-1103-19BLK	Front Anti Roll Bar Bush 19mm	19mm	2	9500	3
Fiat	Grande Punto (2005 – 2009)Grande Punto Abarth	PFF80-1103-20BLK	Front Anti Roll Bar Bush 20mm	20mm	2	9500	3
Fiat	Grande Punto (2005 – 2009)Grande Punto Abarth	PFF80-1103-21BLK	Front Anti Roll Bar Bush 21mm	21mm	2	9500	3
Fiat	Grande Punto (2005 – 2009)Grande Punto Abarth	PFF80-1120BLK	Lower Rear Engine Mount Insert		1	6000	20
Fiat	Grande Punto (2005 – 2009)Grande Punto Abarth	PFR80-1110BLK	Rear Beam Mounting Bush		2	18000	10
Fiat	Punto Evo (2009 onwards)Punto Evo	PFF80-1101BLK	Front Arm Front Bush		2	12000	1
Fiat	Punto Evo (2009 onwards)Punto Evo	PFF80-1102BLK	Front Arm Rear Bush		2	36500	2
Fiat	Punto Evo (2009 onwards)Punto Evo	PFF80-1103-19BLK	Front Anti Roll Bar Bush 19mm	19mm	2	9500	3
Fiat	Punto Evo (2009 onwards)Punto Evo	PFF80-1103-20BLK	Front Anti Roll Bar Bush 20mm	20mm	2	9500	3
Fiat	Punto Evo (2009 onwards)Punto Evo	PFF80-1103-21BLK	Front Anti Roll Bar Bush 21mm	21mm	2	9500	3
Fiat	Punto Evo (2009 onwards)Punto Evo	PFF80-1120BLK	Lower Rear Engine Mount Insert		1	6000	20
Fiat	Punto Evo (2009 onwards)Punto Evo	PFR80-1110BLK	Rear Beam Mounting Bush		2	18000	10
Fiat	Punto Evo (2009 onwards)Punto Evo Abarth	PFF80-1101BLK	Front Arm Front Bush		2	12000	1
Fiat	Punto Evo (2009 onwards)Punto Evo Abarth	PFF80-1102BLK	Front Arm Rear Bush		2	36500	2
Fiat	Punto Evo (2009 onwards)Punto Evo Abarth	PFF80-1103-19BLK	Front Anti Roll Bar Bush 19mm	19mm	2	9500	3
Fiat	Punto Evo (2009 onwards)Punto Evo Abarth	PFF80-1103-20BLK	Front Anti Roll Bar Bush 20mm	20mm	2	9500	3
Fiat	Punto Evo (2009 onwards)Punto Evo Abarth	PFF80-1103-21BLK	Front Anti Roll Bar Bush 21mm	21mm	2	9500	3
Fiat	Punto Evo (2009 onwards)Punto Evo Abarth	PFF80-1120BLK	Lower Rear Engine Mount Insert		1	6000	20
Fiat	Punto Evo (2009 onwards)Punto Evo Abarth	PFR80-1110BLK	Rear Beam Mounting Bush		2	18000	10
Fiat	Punto MK1 (1993 – 1999)	PFA100-10	PowerAlign Camber Bolt Kit (10mm)	10mm	1	4250	N/A
Fiat	Punto MK1 (1993 – 1999)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Fiat	Punto MK1 (1993 – 1999)	PFF16-101BLK	Front Wishbone Inner Bush		2	10500	1
Fiat	Punto MK2 (1999 – 2005)	PFF16-601BLK	Front Arm Front Bush		2	12000	1
Fiat	Punto MK2 (1999 – 2005)	PFF16-602BLK	Front Arm Rear Bush		2	14000	2
Fiat	Punto MK2 (1999 – 2005)	PFF16-603-21BLK	Front Anti Roll Bar To Chassis Bush 21mm	21mm	2	10000	3
Fiat	Punto MK2 (1999 – 2005)	PFF16-603-22BLK	Front Anti Roll Bar To Chassis Bush 22mm	22mm	2	10000	3
Fiat	Punto MK2 (1999 – 2005)	PFF16-604-13BLK	Front Anti Roll Bar To Arm Bush 13mm	13mm	2	10000	4

Fiat	Punto MK2 (1999 – 2005)	PFR16-510BLK	Rear Beam Mounting Bush		2	13000	10
Fiat	Stilo (2001 – 2010)	PFF16-701-14BLK	Front Wishbone Front Bush 14mm	14mm	2	13500	1
Fiat	Stilo (2001 – 2010)	PFF16-701BLK	Front Wishbone Front Bush 12mm	12mm	2	13500	1
Fiat	Stilo (2001 – 2010)	PFF16-702BLK	Front Wishbone Rear Bush		2	15000	2
Fiat	Stilo (2001 – 2010)	PFR16-710BLK	Rear Beam Mounting Bush		2	18500	10
Fiat	Strada 130TC (1978-1988)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Fiat	Strada 130TC (1978-1988)	PFF16-401BLK	Front Wishbone Inner Bush		2	10500	1
Fiat	Tipo (1988-1995)	PFA100-10	PowerAlign Camber Bolt Kit (10mm)	10mm	1	4250	N/A
Fiat	Tipo (1988-1995)	PFF1-801BLK	Front Lower Wishbone Front Bush		2	17000	1
Fiat	Tipo (1988-1995)	PFF1-802BLK	Front Lower Wishbone Rear Bush		2	17000	2
Fiat	Uno inc Turbo (1983-1995)	PFA100-10	PowerAlign Camber Bolt Kit (10mm)	10mm	1	4250	N/A
Fiat	Uno inc Turbo (1983-1995)	PFF16-101BLK	Front Wishbone Inner Bush		2	10500	1
Fiat	Uno inc Turbo (1983-1995)	PFF16-103BLK	Front Wishbone Rear Inner Bush		2	9000	2
Fiat	Uno inc Turbo (1983-1995)	PFF16-105BLK	Front Anti Roll Bar Inner Mount	19mm	2	8500	3
Fiat	Uno inc Turbo (1983-1995)	PFF16-106BLK	Front Anti Roll Bar Outer Mount		2	7500	4
Fiat	Uno inc Turbo (1983-1995)	PFR16-110BLK	Rear Beam Mounting Bush		2	15000	5
Fiat	X1/9 (1978 – 1983)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A