

Make	Model	Variants	Part Number	Product Description	Bush Size	定価(税別)	SET入数	図面番号
Saab	9-3 (1998-2002)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Saab	9-3 (1998-2002)		PFF66-204-19	Front Anti Roll Bar Mounting 19mm	19mm	7500	2	4
Saab	9-3 (1998-2002)		PFF66-204-22	Front Anti Roll Bar Mounting 22mm	22mm	7500	2	4
Saab	9-3 (1998-2002)		PFF66-204-24	Front Anti Roll Bar Mounting 24mm	24mm	7500	2	4
Saab	9-3 (1998-2002)		PFF66-204-26	Front Anti Roll Bar Mounting 26mm	26mm	7500	2	4
Saab	9-3 (1998-2002)		PFF66-301	Front Track Control Arm Outer Bush		10120	2	1
Saab	9-3 (1998-2002)		PFF66-302	Front Track Control Arm Inner Bush		8800	2	2
Saab	9-3 (1998-2002)		PFF66-303	Front Tie Bar Rear Bush		11440	2	3
Saab	9-3 (1998-2002)		PFF66-310	Front Anti Roll Bar Drop Link Bush		4250	2	5
Saab	9-3 (1998-2002)		PFF66-411	Steering Rack Mounting Round Type		5000	1	6
Saab	9-3 (1998-2002)		PFF66-412	Steering Rack Mounting Flat Bottom		5000	1	7
Saab	9-3 (1998-2002)		PFR66-315	Rear Axle Mounting Bush		8800	2	8
Saab	9-3 (2002-on)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Saab	9-3 (2002-on)		PFF66-503-24	Front Anti Roll Bar Mounting Bush 24mm		8250	2	3
Saab	9-3 (2002-on)		PFF66-503-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	8250	2	3
Saab	9-3 (2002-on)		PFF66-521	Rear Lower Engine Mount Insert		5500	1	21
Saab	9-3 (2002-on)		PFF66-521R	Rear Lower Engine Mount Insert (Diesel)		5500	1	21
Saab	9-3 (2002-on)		PFF80-1201	Front Lower Wishbone Front Bush		10340	2	1
Saab	9-3 (2002-on)		PFF80-1202	Front Lower Wishbone Rear Bush		11660	2	2
Saab	9-3 (2002-on)		PFF80-1203-24	Front Anti Roll Bar Mounting Bush 24mm (2 Piece)		9500	2	3
Saab	9-3 (2002-on)		PFF80-1203-25	Front Anti Roll Bar Mounting Bush 25mm (2 Piece)		9500	2	3
Saab	9-3 (2002-on)		PFF80-1220	Front Lower Engine Mount Insert		5500	1	20
Saab	9-3 (2002-on)		PFF80-1220R	Front Lower Engine Mount Insert (Diesel)		5500	1	20
Saab	9-3 (2002-on)		PFF80-1221	Rear Lower Engine Mount Insert (Round Centre)		5500	1	21
Saab	9-3 (2002-on)		PFF80-1221R	Rear Lower Engine Mount Insert Diesel (Round Centre)		5500	1	21
Saab	9-3 (2002-on)		PFR66-519-17	Rear Anti Roll Bar Mounting Bush 17mm	17mm	8250	2	19
Saab	9-3 (2002-on)		PFR66-519-18	Rear Anti Roll Bar Mounting Bush 18mm	18mm	8250	2	19
Saab	9-3 (2002-on)		PFR66-519-19	Rear Anti Roll Bar Mounting Bush 19mm	19mm	8250	2	19
Saab	9-3 (2002-on)		PFR80-1210	Rear Trailing Arm Front Bush		13860	2	10
Saab	9-3 (2002-on)		PFR80-1211	Rear Upper Arm Outer Bush	47mm	23540	2	11
Saab	9-3 (2002-on)		PFR80-1212	Rear Upper Arm Inner Bush		11660	2	12
Saab	9-3 (2002-on)		PFR80-1215	Rear Lower Arm Outer Bush		9240	2	15
Saab	9-3 (2002-on)		PFR80-1216	Rear Lower Arm Inner Bush		12100	2	16
Saab	9-3 (2002-on)		PFR80-1217	Rear Upper Arm Outer Bush, 38mm	38mm	10120	2	11
Saab	9-5 (1998-2010) YS3E		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Saab	9-5 (1998-2010) YS3E		PFF66-201	Front Wishbone Rear Bush		11220	2	2
Saab	9-5 (1998-2010) YS3E		PFF66-202	Front Wishbone Front Bush		11440	2	1
Saab	9-5 (1998-2010) YS3E		PFF66-205	Front Wishbone Rear Bush		11440	2	2
Saab	9-5 (1998-2010) YS3E		PFF66-206-18	Front Anti Roll Bar Mounting Bush 18mm	18mm	7500	2	3
Saab	9-5 (1998-2010) YS3E		PFF66-206-20	Front Anti Roll Bar Mounting Bush 20mm	20mm	7500	2	3
Saab	9-5 (1998-2010) YS3E		PFF66-206-21	Front Anti Roll Bar Mounting Bush 21mm	21mm	7500	2	3
Saab	9-5 (1998-2010) YS3E		PFF66-208	Front Subframe Mounting Bush		27720	6	8
Saab	9-5 (1998-2010) YS3E		PFF66-220	Engine Torque Rod To Subframe Bush		5000	1	20
Saab	9-5 (1998-2010) YS3E		PFF66-221	Engine Torque Rod To Engine Bush, Manual Petrol		5250	1	21
Saab	9-5 (1998-2010) YS3E		PFF66-221R	Engine Torque Rod To Engine Bush, Manual Diesel		5250	1	21
Saab	9-5 (1998-2010) YS3E		PFF66-222	Engine Torque Rod To Engine Bush, Automatic Petrol		5250	1	21
Saab	9-5 (1998-2010) YS3E		PFR66-110	Rear Trailing Arm Bush		10120	2	10
Saab	9-5 (1998-2010) YS3E		PFR66-210-15	Rear Anti Roll Bar Bush 15mm	15mm	5750	2	11
Saab	9-5 (1998-2010) YS3E		PFR66-210-16	Rear Anti Roll Bar Bush 16mm	16mm	5750	2	11
Saab	9-5 (1998-2010) YS3E		PFR66-210-17	Rear Anti Roll Bar Bush 17mm	17mm	5750	2	11
Saab	9-5 (1998-2010) YS3E		PFR66-211-17	Rear Anti Roll Bar Bush 17mm	17mm	6500	2	11
Saab	90 & 99 (1975-1987)		PFF66-401	Front Wishbone Upper Arm Bush		17380	4	1
Saab	90 & 99 (1975-1987)		PFF66-402	Front Wishbone Lower Bush		18260	4	2
Saab	90 & 99 (1975-1987)		PFF66-425	Shock Absorber Top Mounting		5060	4	5
Saab	90 & 99 (1975-1987)		PFR66-410	Rear Wishbone Front Mounting Bush		8800	2	7
Saab	90 & 99 (1975-1987)		PFR66-415	Rear Beam To Wishbone Bush		8800	2	8
Saab	90 & 99 (1975-1987)		PFR66-416	Rear Axle Side To Side Location Axle Bush		4250	1	9
Saab	90 & 99 (1975-1987)		PFR66-417	Rear Axle Side To Side Location Body Bush		4250	1	10
Saab	90 & 99 (1975-1987)		PFR66-418	Rear Link Rod Rear Bush To Chassis		8800	2	12
Saab	90 & 99 (1975-1987)		PFR66-419	Rear Link Rod Front Bush To Axle		8800	2	11
Saab	90 & 99 (1975-1987)		PFR66-420	Lower Shock Mounting		10120	4	6
Saab	90 & 99 (1975-1987)		PFR66-423	Rear Wishbone Front Mounting Bush		8800	2	7
Saab	900 (1983-1993)		PFF66-401	Front Wishbone Upper Arm Bush		17380	4	1
Saab	900 (1983-1993)		PFF66-402	Front Wishbone Lower Bush		18260	4	2
Saab	900 (1983-1993)		PFF66-403	Front Anti Roll Bar Mounting	18mm	7500	2	3
Saab	900 (1983-1993)		PFF66-404	Front Anti Roll Bar To Wishbone Bush		5750	2	4
Saab	900 (1983-1993)		PFF66-405	Shock Top Mounting		10120	4	5
Saab	900 (1983-1993)		PFF66-422	Front Wishbone Upper Outer Bush		6600	2	15
Saab	900 (1983-1993)		PFF66-425	Front Lower Shock Mounting		2640	2	6
Saab	900 (1983-1993)		PFF66-430	Steering Rack Mounting		6600	2	
Saab	900 (1983-1993)		PFF66-431	Alternator Adjuster Arm Bush		2750	1	
Saab	900 (1983-1993)		PFF66-432	Alternator Mounting Bracket Bush		4500	1	
Saab	900 (1983-1993)		PFF66-433	Power Steering Mounting Bush		4000	1	
Saab	900 (1983-1993)		PFR66-410	Rear Wishbone Front Mounting Bush		8800	2	7
Saab	900 (1983-1993)		PFR66-415	Rear Beam To Wishbone Bush		8800	2	8
Saab	900 (1983-1993)		PFR66-416	Rear Axle Side To Side Location Axle Bush		4250	1	9

Saab	900 (1983-1993)		PFR66-417	Rear Axle Side To Side Location Body Bush		4250	1	10
Saab	900 (1983-1993)		PFR66-418	Rear Link Rod Rear Bush To Chassis		8800	2	12
Saab	900 (1983-1993)		PFR66-419	Rear Link Rod Front Bush To Axle		8800	2	11
Saab	900 (1983-1993)		PFR66-420	Rear Lower Shock Mounting		5060	2	14
Saab	900 (1983-1993)		PFR66-421	Rear Anti Roll Bar Outer Bush		10000	2	13
Saab	900 (1994-1998)		PFF66-204-19	Front Anti Roll Bar Mounting 19mm	19mm	7500	2	4
Saab	900 (1994-1998)		PFF66-204-22	Front Anti Roll Bar Mounting 22mm	22mm	7500	2	4
Saab	900 (1994-1998)		PFF66-204-24	Front Anti Roll Bar Mounting 24mm	24mm	7500	2	4
Saab	900 (1994-1998)		PFF66-204-26	Front Anti Roll Bar Mounting 26mm	26mm	7500	2	4
Saab	900 (1994-1998)		PFF66-301	Front Track Control Arm Outer Bush		10120	2	1
Saab	900 (1994-1998)		PFF66-302	Front Track Control Arm Inner Bush		8800	2	2
Saab	900 (1994-1998)		PFF66-303	Front Tie Bar Rear Bush		11440	2	3
Saab	900 (1994-1998)		PFF66-306	Front Track Control Arm Outer Bush	45mm	10780	2	1
Saab	900 (1994-1998)		PFF66-310	Front Anti Roll Bar Drop Link Bush		4250	2	5
Saab	900 (1994-1998)		PFF66-411	Steering Rack Mounting Round Type		5000	1	6
Saab	900 (1994-1998)		PFF66-412	Steering Rack Mounting Flat Bottom		5000	1	7
Saab	900 (1994-1998)		PFR66-315	Rear Axle Mounting Bush		8800	2	8
Saab	9000 (1985-1998)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Saab	9000 (1985-1998)		PFF66-101	Front Wishbone Rear Bush		9680	2	1
Saab	9000 (1985-1998)		PFF66-102-18	Front Anti Roll Bar Bush 18mm	18mm	7500	2	2
Saab	9000 (1985-1998)		PFF66-102-19	Front Anti Roll Bar Bush 19mm	19mm	7500	2	2
Saab	9000 (1985-1998)		PFF66-105	Front Anti Roll Bar Drop Link Bush		4250	2	5
Saab	9000 (1985-1998)		PFF66-120	Gearbox Mounting up to 94 only		5500	1	3
Saab	9000 (1985-1998)		PFF66-121	Gearbox Mounting Manual 94 on, All Years Auto		9750	1	3
Saab	9000 (1985-1998)		PFF66-125	Upper Engine Mounting Kit		10750	1	4
Saab	9000 (1985-1998)		PFR66-107-18	Rear Anti Roll Bar Bush 18mm	18mm	7500	2	6
Saab	9000 (1985-1998)		PFR66-304-19	Rear Anti Roll Bar Bush 19mm	19mm	7500	2	6
Saab	96 (1960-1979)		PFF66-401	Front Wishbone Upper Arm Bush		17380	4	1
Saab	96 (1960-1979)		PFF66-402	Front Wishbone Lower Bush		18260	4	2
Saab	96 (1960-1979)		PFF66-405	Rear Shock Top Mount		5060	2	6
Saab	96 (1960-1979)		PFF66-406-12.7	Front Anti Roll Bar Mounting Bush 12.7mm	12.7mm	7000	2	3
Saab	96 (1960-1979)		PFF66-407	Front Anti Roll Bar To Wishbone Mounting Bush		6750	2	4
Saab	96 (1960-1979)		PFF66-413	Engine Stay Mounting Bush		3250	1	13
Saab	96 (1960-1979)		PFF66-413	Gearbox Stay Mounting Bush		3250	1	14
Saab	96 (1960-1979)		PFF66-425	Shock Mounting		7700	6	5
Saab	96 (1960-1979)		PFR66-414	Rear Trailing Arm Bush		15840	4	10
Saab	99 (1970-1974)		PFF66-401	Front Wishbone Upper Arm Bush		17380	4	1
Saab	99 (1970-1974)		PFF66-402	Front Wishbone Lower Bush		18260	4	2
Saab	99 (1970-1974)		PFF66-405	Shock Absorber Bottom Mounting		10120	4	6
Saab	99 (1970-1974)		PFF66-425	Shock Absorber Top Mounting		5060	4	5
Saab	99 (1970-1974)		PFR66-423	Rear Wishbone Front Mounting Bush		8800	2	7