

Make	Model	Variants	Part Number	Product Description	Bush Size	定価(税別)	SET入数	図面番号
Vauxhall / Opel	Agila (2000-2008)		PFF73-201	Front Track Control Arm Inner Bush		8800	2	1
Vauxhall / Opel	Agila (2000-2008)		PFF73-202	Front Roll Bar Mount Bush		9250	2	2
Vauxhall / Opel	Agila (2000-2008)		PFF73-203	Front Anti Roll Bar Bush 21mm	21mm	7500	2	3
Vauxhall / Opel	Agila (2000-2008)		PFR73-205	Rear Tie Bar to Chassis Bush		8800	2	5
Vauxhall / Opel	Agila (2000-2008)		PFR73-206	Rear Tie Bar to Hub Bush		17380	4	6
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)		BS2002K	Bump Stop Kit	Front	5250	1	
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)		EXH004	Exhaust Mounts		1500	1	
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)		EXH008	Exhaust Mounts		1500	1	
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)		PFF80-301	Front Wishbone Inner Bush (front)		8140	2	1
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)		PFF80-303-18	Front Anti Roll Bar Mounting Bush 18mm	18mm	5750	2	3
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)		PFF80-303-20	Front Anti Roll Bar Mounting Bush 20mm	20mm	5750	2	3
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)		PFF80-303-22	Front Anti Roll Bar Mounting Bush 22mm	22mm	5750	2	3
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)		PFF80-304	Front Wishbone Inner Bush (rear)		8800	2	2
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)		PFF80-308	Front Roll Bar Mounting Bolt Bush		5750	2	4
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)		PFR80-312	Rear Beam Mounting Bush	49mm OD	9680	2	5
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)		BS2002K	Bump Stop Kit	Front	5250	1	
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)		EXH004	Exhaust Mounts		1500	1	
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)		EXH008	Exhaust Mounts		1500	1	
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)		PFF80-301	Front Wishbone Inner Bush (front)		8140	2	1
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)		PFF80-302	Front Wishbone Inner Bush (rear)		8140	2	2
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)		PFF80-303-18	Front Anti Roll Bar Mounting Bush 18mm	18mm	5750	2	3
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)		PFF80-303-20	Front Anti Roll Bar Mounting Bush 20mm	20mm	5750	2	3
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)		PFF80-303-22	Front Anti Roll Bar Mounting Bush 22mm	22mm	5750	2	3
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)		PFF80-308	Front Roll Bar Mounting Bolt Bush		5750	2	4
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)		PFR80-312	Rear Beam Mounting Bush	49mm OD	9680	2	5
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)		BS2002K	Bump Stop Kit	Front	5250	1	
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)		PFF80-401	Front Wishbone Inner Bush (front)		8140	2	1
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)		PFF80-402	Front Wishbone Inner Bush (rear)		8140	2	2
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)		PFF80-403-20	Front Anti Roll Bar Mount 20mm	20mm	5750	2	3
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)		PFF80-403-22	Front Anti Roll Bar Mount 22mm	22mm	5750	2	3
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)		PFF80-403-24	Front Anti Roll Bar Mount 24mm	24mm	5750	2	3
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)		PFF80-408	Front Anti Roll Bar Mounting Bolt Bushes		5750	2	4
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)		PFF80-409-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	6000	2	5
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)		PFF80-409-22	Front Anti Roll Bar Eye Bolt Bush 22mm	22mm	5750	2	5
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)		PFF80-409-24	Front Anti Roll Bar Eye Bolt Bush 24mm	24mm	6000	2	5
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)		PFR80-412	Rear Beam Mounting Bush	59.8mm OD	9680	2	7
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)		PFR80-415-15	Rear Anti Roll Bar Mount (inner) 15mm	15mm	6500	2	8
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)		PFR80-415-20	Rear Anti Roll Bar Mount (inner) 20mm	20mm	6500	2	8
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)		EXH016	Universal Exhaust Mount	A=56mm B=38mm	1500	1	
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)		PFF80-1003-18	Front Anti Roll Bar Mounting Bush 18mm	18mm	5750	2	4
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)		PFF80-1003-20	Front Anti Roll Bar Mounting Bush 20mm	20mm	5750	2	4
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)		PFF80-1321	Gearbox Mount Insert		5750	1	21
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)		PFF80-303-22	Front Anti Roll Bar Mounting Bush 22mm	22mm	5750	2	4
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)		PFF80-801	Front Wishbone Front Bush		8800	2	1
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)		PFF80-802	Front Wishbone Rear Bush		8140	2	2
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)		PFF80-810	Front Lower Engine Mount Insert Kit		5250	1	3
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)		PFF80-830	Front Subframe Bush		24420	6	30
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)		PFR80-815	Rear Beam Mounting Bush	60mm	13420	2	5
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)		EXH016	Universal Exhaust Mount	A=56mm B=38mm	1500	1	
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)		PFF80-1203-21	Front Anti Roll Bar Mounting Bush 21mm (2 Piece)	21mm	9500	2	3
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)		PFF80-1203-22	Front Anti Roll Bar Mounting Bush 22mm (2 Piece)	22mm	9500	2	3
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)		PFF80-1203-24	Front Anti Roll Bar Mounting Bush 24mm (2 Piece)		9500	2	3
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)		PFF80-1203-25	Front Anti Roll Bar Mounting Bush 25mm (2 Piece)		9500	2	3
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)		PFF80-1303-21	Front Anti Roll Bar Bush 21mm (1 Piece)	21mm	8250	2	3
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)		PFF80-1303-22	Front Anti Roll Bar Bush 22mm (1 Piece)	22mm	8250	2	3
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)		PFF80-1320	Front Lower Engine Mount Insert		5000	1	20
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)		PFF80-1321	Gearbox Mount Insert		5750	1	21
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)		PFF80-801	Front Wishbone Front Bush		8800	2	1
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)		PFF80-802	Front Wishbone Rear Bush		8140	2	2
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)		PFF80-830	Front Subframe Bush		24420	6	30
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)		PFR80-1310	Rear beam Mounting Bush		16720	2	5
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010 - )		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010 - )		PFF80-1401	Front Arm Front Bush		10120	2	1
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010 - )		PFF80-1402	Front Arm Rear Bush		11880	2	2
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010 - )		PFF80-1404	Hyper Strut To Lower Arm Front Bush		10560	2	4
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010 - )		PFF80-1420	Front Engine Mounting Insert		5750	1	20
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010 - )		PFF80-1421	Rear Engine Mounting Insert		5500	1	21
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010 - )		PFR80-1410	Rear Beam Mounting Bush		14520	2	10
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010 - )		PFR80-1411	Rear Panhard Rod Outer Bush		11000	2	11
Vauxhall / Opel	Calibra (1989-1997)		BS2002K	Bump Stop Kit	Front	5250	1	
Vauxhall / Opel	Calibra (1989-1997)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	Calibra (1989-1997)		PFF80-401	Front Wishbone Inner Bush (front)		8140	2	1
Vauxhall / Opel	Calibra (1989-1997)		PFF80-402	Front Wishbone Inner Bush (rear)		8140	2	2

Vauxhall / Opel	Calibra (1989-1997)		PFF80-403-20	Front Anti Roll Bar Mount 20mm	20mm	5750	2	3
Vauxhall / Opel	Calibra (1989-1997)		PFF80-403-22	Front Anti Roll Bar Mount 22mm	22mm	5750	2	3
Vauxhall / Opel	Calibra (1989-1997)		PFF80-403-24	Front Anti Roll Bar Mount 24mm	24mm	5750	2	3
Vauxhall / Opel	Calibra (1989-1997)		PFF80-408	Front Anti Roll Bar Mounting Bolt Bushes		5750	2	4
Vauxhall / Opel	Calibra (1989-1997)		PFF80-409-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	6000	2	5
Vauxhall / Opel	Calibra (1989-1997)		PFF80-409-22	Front Anti Roll Bar Eye Bolt Bush 22mm	22mm	5750	2	5
Vauxhall / Opel	Calibra (1989-1997)		PFF80-409-24	Front Anti Roll Bar Eye Bolt Bush 24mm	24mm	6000	2	5
Vauxhall / Opel	Calibra (1989-1997)		PFR80-415-15	Rear Anti Roll Bar Mount (inner) 15mm	15mm	6500	2	7
Vauxhall / Opel	Calibra (1989-1997)		PFR80-415-18	Rear Anti Roll Bar Mount (inner) 18mm	18mm	6500	2	7
Vauxhall / Opel	Calibra (1989-1997)		PFR80-416-14.5	Rear Anti Roll Bar Mount (Inner) 14.5mm	14.5mm	6500	2	7
Vauxhall / Opel	Calibra (1989-1997)		PFR80-440	Rear Trailing Arm Bush		8800	2	6
Vauxhall / Opel	Calibra (1989-1997)		PFR80-440MLK	Rear Trailing Arm Bush		8800	2	6
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)		BS2002K	Bump Stop Kit	Front	5250	1	
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)		PFF80-401	Front Wishbone Inner Bush (front)		8140	2	1
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)		PFF80-402	Front Wishbone Inner Bush (rear)		8140	2	2
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)		PFF80-403-20	Front Anti Roll Bar Mount 20mm	20mm	5750	2	3
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)		PFF80-403-22	Front Anti Roll Bar Mount 22mm	22mm	5750	2	3
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)		PFF80-403-24	Front Anti Roll Bar Mount 24mm	24mm	5750	2	3
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)		PFF80-408	Front Anti Roll Bar Mounting Bolt Bushes		5750	2	4
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)		PFF80-409-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	6000	2	5
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)		PFF80-409-22	Front Anti Roll Bar Eye Bolt Bush 22mm	22mm	5750	2	5
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)		PFF80-409-24	Front Anti Roll Bar Eye Bolt Bush 24mm	24mm	6000	2	5
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)		PFR80-412	Rear Beam Mounting Bush	59.8mm OD	9680	2	7
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)		PFR80-415-15	Rear Anti Roll Bar Mount (inner) 15mm	15mm	6500	2	8
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)		PFR80-415-18	Rear Anti Roll Bar Mount (Inner) 18mm	18mm	6500	2	8
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)		PFR80-415-20	Rear Anti Roll Bar Mount (inner) 20mm	20mm	6500	2	8
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear suspension, Vectra A (1989-1995)		PFF80-401	Front Wishbone Inner Bush (front)		8140	2	1
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear suspension, Vectra A (1989-1995)		PFF80-402	Front Wishbone Inner Bush (rear)		8140	2	2
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear suspension, Vectra A (1989-1995)		PFF80-403-20	Front Anti Roll Bar Mount 20mm	20mm	5750	2	3
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear suspension, Vectra A (1989-1995)		PFF80-403-22	Front Anti Roll Bar Mount 22mm	22mm	5750	2	3
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear suspension, Vectra A (1989-1995)		PFF80-403-24	Front Anti Roll Bar Mount 24mm	24mm	5750	2	3
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear suspension, Vectra A (1989-1995)		PFF80-408	Front Anti Roll Bar Mounting Bolt Bushes		5750	2	4
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear suspension, Vectra A (1989-1995)		PFF80-409-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	6000	2	5
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear suspension, Vectra A (1989-1995)		PFF80-409-22	Front Anti Roll Bar Eye Bolt Bush 22mm	22mm	5750	2	5
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear suspension, Vectra A (1989-1995)		PFF80-409-24	Front Anti Roll Bar Eye Bolt Bush 24mm	24mm	6000	2	5
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear suspension, Vectra A (1989-1995)		PFR80-415-15	Rear Anti Roll Bar Mount (inner) 15mm	15mm	6500	2	7
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear suspension, Vectra A (1989-1995)		PFR80-415-18	Rear Anti Roll Bar Mount (inner) 18mm	18mm	6500	2	7
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear suspension, Vectra A (1989-1995)		PFR80-416-14.5	Rear Anti Roll Bar Mount (Inner) 14.5mm	14.5mm	6500	2	7
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear suspension, Vectra A (1989-1995)		PFR80-440	Rear Trailing Arm Bush		8800	2	6
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear suspension, Vectra A (1989-1995)		PFR80-440MLK	Rear Trailing Arm Bush		8800	2	6
Vauxhall / Opel	Corsa A (1983-1993)		BS2002K	Bump Stop Kit	Front	5250	1	
Vauxhall / Opel	Corsa A (1983-1993)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	Corsa A (1983-1993)		PFF80-101	Front Wishbone Inner Bush (front)		8140	2	1
Vauxhall / Opel	Corsa A (1983-1993)		PFF80-102	Front Tie Bar To Chassis Bush		7700	2	2
Vauxhall / Opel	Corsa A (1983-1993)		PFF80-105-16	Front Anti Roll Bar Mount	16mm	8250	4	3
Vauxhall / Opel	Corsa A (1983-1993)		PFF80-105-20	Front Anti Roll Bar Mount	20mm	8250	4	3
Vauxhall / Opel	Corsa A (1983-1993)		PFR80-112	Rear Beam Mounting Bush		9680	2	5
Vauxhall / Opel	Corsa B (1993-2000)	Corsa B (1993-1997)	BS2002K	Bump Stop Kit	Front	5250	1	
Vauxhall / Opel	Corsa B (1993-2000)	Corsa B (1993-1997)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	Corsa B (1993-2000)	Corsa B (1993-1997)	PFF80-201	Front Wishbone Inner Bush		8140	2	1
Vauxhall / Opel	Corsa B (1993-2000)	Corsa B (1993-1997)	PFF80-203	Front Tie Bar To Chassis		8140	2	2
Vauxhall / Opel	Corsa B (1993-2000)	Corsa B (1993-1997)	PFF80-205	Front Anti Roll Bar Mounts		11500	4	3
Vauxhall / Opel	Corsa B (1993-2000)	Corsa B (1993-1997)	PFR80-112	Rear Beam Mounting Bush		9680	2	5
Vauxhall / Opel	Corsa B (1993-2000)	Corsa B (1998-2000)	BS2002K	Bump Stop Kit	Front	5250	1	
Vauxhall / Opel	Corsa B (1993-2000)	Corsa B (1998-2000)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	Corsa B (1993-2000)	Corsa B (1998-2000)	PFF80-201	Front Wishbone Inner Bush		8140	2	1
Vauxhall / Opel	Corsa B (1993-2000)	Corsa B (1998-2000)	PFF80-204	Front Tie Bar To Chassis		8140	2	2
Vauxhall / Opel	Corsa B (1993-2000)	Corsa B (1998-2000)	PFF80-205	Front Anti Roll Bar Mounts		11500	4	3
Vauxhall / Opel	Corsa B (1993-2000)	Corsa B (1998-2000)	PFR80-112	Rear Beam Mounting Bush		9680	2	5
Vauxhall / Opel	Corsa C (2000-2006)		EXH016	Universal Exhaust Mount	A=56mm B=38mm	1500	1	
Vauxhall / Opel	Corsa C (2000-2006)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	Corsa C (2000-2006)		PFF80-1001	Front Wishbone Rear Bush		11660	2	1
Vauxhall / Opel	Corsa C (2000-2006)		PFF80-1003-17	Front Anti Roll Bar Bush 17mm	17mm	5750	2	3
Vauxhall / Opel	Corsa C (2000-2006)		PFF80-1003-18	Front Anti Roll Bar Bush 18mm	18mm	5750	2	3
Vauxhall / Opel	Corsa C (2000-2006)		PFR80-1005	Rear Beam Mounting Bush		13420	2	5
Vauxhall / Opel	Corsa D	Corsa D	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	Corsa D	Corsa D	PFF80-1101	Front Arm Front Bush		9680	2	1
Vauxhall / Opel	Corsa D	Corsa D	PFF80-1102	Front Arm Rear Bush		27720	2	2
Vauxhall / Opel	Corsa D	Corsa D	PFF80-1103-19	Front Anti Roll Bar Bush 19mm	19mm	8500	2	3
Vauxhall / Opel	Corsa D	Corsa D	PFF80-1103-20	Front Anti Roll Bar Bush 20mm	20mm	8500	2	3
Vauxhall / Opel	Corsa D	Corsa D	PFF80-1103-21	Front Anti Roll Bar Bush 21mm	21mm	8500	2	3
Vauxhall / Opel	Corsa D	Corsa D	PFF80-1120	Lower Rear Engine Mount Insert		5000	1	20
Vauxhall / Opel	Corsa D	Corsa D	PFR80-1110	Rear Beam Mounting Bush		13420	2	10
Vauxhall / Opel	Corsa D	VXR	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	Corsa D	VXR	PFF80-1101	Front Arm Front Bush		9680	2	1
Vauxhall / Opel	Corsa D	VXR	PFF80-1102	Front Arm Rear Bush		27720	2	2
Vauxhall / Opel	Corsa D	VXR	PFF80-1103-19	Front Anti Roll Bar Bush 19mm	19mm	8500	2	3

Vauxhall / Opel	Corsa D	VXR	PFF80-1103-20	Front Anti Roll Bar Bush 20mm	20mm	8500	2	3
Vauxhall / Opel	Corsa D	VXR	PFF80-1103-21	Front Anti Roll Bar Bush 21mm	21mm	8500	2	3
Vauxhall / Opel	Corsa D	VXR	PFF80-1120	Lower Rear Engine Mount Insert		5000	1	20
Vauxhall / Opel	Corsa D	VXR	PFR80-1110	Rear Beam Mounting Bush		13420	2	10
Vauxhall / Opel	Manta B		PFF80-303-20	Front Anti Roll Bar Mounting Bush 20mm	20mm	5750	2	6
Vauxhall / Opel	Manta B		PFF80-303-22	Front Anti Roll Bar Mounting Bush 22mm	22mm	5750	2	6
Vauxhall / Opel	Manta B		PFF80-601	Front Upper Wishbone Bush		12320	4	1
Vauxhall / Opel	Manta B		PFF80-602	Front Lower Wishbone Front Bush		8800	2	2
Vauxhall / Opel	Manta B		PFF80-603	Front Lower Rear Bush		8800	2	3
Vauxhall / Opel	Manta B		PFF80-604	Front Subframe Rear Mounting Bush		7260	2	4
Vauxhall / Opel	Manta B		PFF80-605	Front Outer Roll Bar Mount		5750	2	5
Vauxhall / Opel	Manta B		PFR80-607	Rear Tie Bar To Chassis Bush		7260	2	7
Vauxhall / Opel	Manta B		PFR80-608	Rear Panhard Rod Mount		7260	2	8
Vauxhall / Opel	Manta B		PFR80-609-14	Rear Anti Roll Bar Bush 14mm	14mm	5750	2	9
Vauxhall / Opel	Manta B		PFR80-609-18	Rear Anti Roll Bar Mount 18mm	18mm	5750	2	9
Vauxhall / Opel	Manta B		PFR80-611	Rear Tie Bar To Axle Bushes		7260	2	11
Vauxhall / Opel	Manta B		PFR80-611	Rear Centre Prop Mount		7260	2	10
Vauxhall / Opel	Meriva (2002 - 2011)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	Nova (1983-1993)		EXH003	Universal Exhaust Mount	B=48mm	1500	1	
Vauxhall / Opel	Nova (1983-1993)		PFF80-101	Front Wishbone Inner Bush (front)		8140	2	1
Vauxhall / Opel	Nova (1983-1993)		PFF80-102	Front Tie Bar To Chassis Bush		7700	2	2
Vauxhall / Opel	Nova (1983-1993)		PFF80-105-16	Front Anti Roll Bar Mount	16mm	8250	4	3
Vauxhall / Opel	Nova (1983-1993)		PFF80-105-20	Front Anti Roll Bar Mount	20mm	8250	4	3
Vauxhall / Opel	Nova (1983-1993)		PFR80-112	Rear Beam Mounting Bush		9680	2	5
Vauxhall / Opel	Omega B 1994-2003		EXH016	Universal Exhaust Mount	A=56mm B=38mm	1500	1	
Vauxhall / Opel	Omega B 1994-2003		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	Omega B 1994-2003		PFF80-901-26	Front Anti Roll Bar To Chassis Bush 26mm	26mm	8250	2	1
Vauxhall / Opel	Omega B 1994-2003		PFF80-902	Front Wishbone Front Bush		9680	2	2
Vauxhall / Opel	Senator B (1987 - 1994)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	Signum (2003 - 2008)		EXH016	Universal Exhaust Mount	A=56mm B=38mm	1500	1	
Vauxhall / Opel	Signum (2003 - 2008)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	Signum (2003 - 2008)		PFF66-503-24	Front Anti Roll Bar Mounting Bush 24mm		8250	2	3
Vauxhall / Opel	Signum (2003 - 2008)		PFF66-503-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	8250	2	3
Vauxhall / Opel	Signum (2003 - 2008)		PFF80-1201	Front Lower Wishbone Front Bush		10340	2	1
Vauxhall / Opel	Signum (2003 - 2008)		PFF80-1202	Front Lower Wishbone Rear Bush		11660	2	2
Vauxhall / Opel	Signum (2003 - 2008)		PFF80-1203-24	Front Anti Roll Bar Mounting Bush 24mm (2 Piece)		9500	2	3
Vauxhall / Opel	Signum (2003 - 2008)		PFF80-1203-25	Front Anti Roll Bar Mounting Bush 25mm (2 Piece)		9500	2	3
Vauxhall / Opel	Signum (2003 - 2008)		PFF80-1220	Front Lower Engine Mount Insert		5500	1	20
Vauxhall / Opel	Signum (2003 - 2008)		PFF80-1220	Rear Lower Engine Mount Insert		5500	1	21
Vauxhall / Opel	Signum (2003 - 2008)		PFF80-1220R	Front Lower Engine Mount Insert (Diesel)		5500	1	20
Vauxhall / Opel	Signum (2003 - 2008)		PFF80-1220R	Rear Lower Engine Mount Insert (Diesel)		5500	1	21
Vauxhall / Opel	Signum (2003 - 2008)		PFR80-1221	Rear Lower Engine Mount Insert (79mm Option)	79mm wide	5500	1	21
Vauxhall / Opel	Signum (2003 - 2008)		PFR80-1221R	Rear Lower Engine Mount Insert Diesel (79mm Option)	79mm wide	5500	1	21
Vauxhall / Opel	Signum (2003 - 2008)		PFR66-519-17	Rear Anti Roll Bar Mounting Bush 17mm	17mm	8250	2	19
Vauxhall / Opel	Signum (2003 - 2008)		PFR66-519-18	Rear Anti Roll Bar Mounting Bush 18mm	18mm	8250	2	19
Vauxhall / Opel	Signum (2003 - 2008)		PFR66-519-19	Rear Anti Roll Bar Mounting Bush 19mm	19mm	8250	2	19
Vauxhall / Opel	Signum (2003 - 2008)		PFR80-1210	Rear Trailing Arm Front Bush		13860	2	10
Vauxhall / Opel	Signum (2003 - 2008)		PFR80-1211	Rear Upper Arm Outer Bush	47mm	23540	2	11
Vauxhall / Opel	Signum (2003 - 2008)		PFR80-1212	Rear Upper Arm Inner Bush		11660	2	12
Vauxhall / Opel	Signum (2003 - 2008)		PFR80-1213	Rear Toe Arm Inner Bush		11660	2	13
Vauxhall / Opel	Signum (2003 - 2008)		PFR80-1214	Rear Toe Arm Outer Bush		11660	2	14
Vauxhall / Opel	Signum (2003 - 2008)		PFR80-1215	Rear Lower Arm Outer Bush		9240	2	15
Vauxhall / Opel	Signum (2003 - 2008)		PFR80-1216	Rear Lower Arm Inner Bush		12100	2	16
Vauxhall / Opel	Signum (2003 - 2008)		PFR80-1217	Rear Upper Arm Outer Bush, 38mm	38mm	10120	2	11
Vauxhall / Opel	TIGRA MODELS	Tigra (1993-2001)	BS2002K	Bump Stop Kit	Front	5250	1	
Vauxhall / Opel	TIGRA MODELS	Tigra (1993-2001)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	TIGRA MODELS	Tigra (1993-2001)	PFF80-201	Front Wishbone Inner Bush		8140	2	1
Vauxhall / Opel	TIGRA MODELS	Tigra (1993-2001)	PFF80-203	Front Tie Bar To Chassis		8140	2	2
Vauxhall / Opel	TIGRA MODELS	Tigra (1993-2001)	PFF80-204	Front Tie Bar To Chassis		8140	2	2
Vauxhall / Opel	TIGRA MODELS	Tigra (1993-2001)	PFF80-205	Front Anti Roll Bar Mounts		11500	4	3
Vauxhall / Opel	TIGRA MODELS	Tigra (1993-2001)	PFR80-112	Rear Beam Mounting Bush		9680	2	5
Vauxhall / Opel	TIGRA MODELS	Tigra Twin Top (2004-)	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1500	1	
Vauxhall / Opel	TIGRA MODELS	Tigra Twin Top (2004-)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	TIGRA MODELS	Tigra Twin Top (2004-)	PFF80-1001	Front Arm Rear Bush		11660	2	1
Vauxhall / Opel	TIGRA MODELS	Tigra Twin Top (2004-)	PFF80-1003-17	Front Anti Roll Bar Mounting Bush 17mm	17mm	5750	2	3
Vauxhall / Opel	TIGRA MODELS	Tigra Twin Top (2004-)	PFF80-1003-18	Front Anti Roll Bar Mounting Bush 18mm	18mm	5750	2	3
Vauxhall / Opel	TIGRA MODELS	Tigra Twin Top (2004-)	PFR80-1005	Rear Beam Mounting Bush		13420	2	5
Vauxhall / Opel	Vectra (1997 - 2002), Vectra B (1997 - 2002)		EXH002	Exhaust Mounts		1500	1	
Vauxhall / Opel	Vectra (1997 - 2002), Vectra B (1997 - 2002)		EXH016	Universal Exhaust Mount	A=56mm B=38mm	1500	1	
Vauxhall / Opel	Vectra (1997 - 2002), Vectra B (1997 - 2002)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	Vectra (1997 - 2002), Vectra B (1997 - 2002)		PFF66-206-18	Front Anti Roll Bar Mounting Bush 18mm	18mm	7500	2	3
Vauxhall / Opel	Vectra (1997 - 2002), Vectra B (1997 - 2002)		PFF80-303-20	Front Anti Roll Bar Mounting Bush 20mm	20mm	5750	2	3
Vauxhall / Opel	Vectra (1997 - 2002), Vectra B (1997 - 2002)		PFF80-303-22	Front Anti Roll Bar Mounting Bush 22mm	22mm	5750	2	3
Vauxhall / Opel	Vectra (1997 - 2002), Vectra B (1997 - 2002)		PFF80-501	Front Lower Wishbone Front Bush		7700	2	1
Vauxhall / Opel	Vectra (1997 - 2002), Vectra B (1997 - 2002)		PFF80-502	Front Lower Wishbone Rear Bush		8140	2	2
Vauxhall / Opel	Vectra (1997 - 2002), Vectra B (1997 - 2002)		PFR66-110	Rear Trailing Arm Bush		10120	2	4
Vauxhall / Opel	Vectra (1997 - 2002), Vectra B (1997 - 2002)		PFR66-210-15	Rear Anti Roll Bar Mounting Bush 15mm	15mm	5750	2	5

Vauxhall / Opel	Vectra (1997 - 2002), Vectra B (1997 - 2002)	PFR66-210-16	Rear Anti Roll Bar Mounting Bush 16mm	16mm	5750	2	5
Vauxhall / Opel	Vectra (1997 - 2002), Vectra B (1997 - 2002)	PFR66-210-17	Rear Anti Roll Bar Mounting Bush 17mm	17mm	5750	2	5
Vauxhall / Opel	Vectra C (2002-2008)	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1500	1	
Vauxhall / Opel	Vectra C (2002-2008)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	Vectra C (2002-2008)	PFF66-503-24	Front Anti Roll Bar Mounting Bush 24mm		8250	2	3
Vauxhall / Opel	Vectra C (2002-2008)	PFF66-503-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	8250	2	3
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1201	Front Lower Wishbone Front Bush		10340	2	1
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1202	Front Lower Wishbone Rear Bush		11660	2	2
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1203-24	Front Anti Roll Bar Mounting Bush 24mm (2 Piece)		9500	2	3
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1203-25	Front Anti Roll Bar Mounting Bush 25mm (2 Piece)		9500	2	3
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1220	Front Lower Engine Mount Insert		5500	1	20
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1220	Rear Lower Engine Mount Insert		5500	1	21
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1220R	Front Lower Engine Mount Insert (Diesel)		5500	1	20
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1220R	Rear Lower Engine Mount Insert (Diesel)		5500	1	21
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1221	Rear Lower Engine Mount Insert (79mm Option)	79mm wide	5500	1	21
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1221R	Rear Lower Engine Mount Insert Diesel (79mm Option)	79mm wide	5500	1	21
Vauxhall / Opel	Vectra C (2002-2008)	PFR66-519-16	Rear Anti Roll Bar Mounting Bush 16mm	16mm	8250	2	19
Vauxhall / Opel	Vectra C (2002-2008)	PFR66-519-17	Rear Anti Roll Bar Mounting Bush 17mm	17mm	8250	2	19
Vauxhall / Opel	Vectra C (2002-2008)	PFR66-519-18	Rear Anti Roll Bar Mounting Bush 18mm	18mm	8250	2	19
Vauxhall / Opel	Vectra C (2002-2008)	PFR66-519-19	Rear Anti Roll Bar Mounting Bush 19mm	19mm	8250	2	19
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1210	Rear Trailing Arm Front Bush		13860	2	10
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1211	Rear Upper Arm Outer Bush	47mm	23540	2	11
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1212	Rear Upper Arm Inner Bush		11660	2	12
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1213	Rear Toe Arm Inner Bush		11660	2	13
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1214	Rear Toe Arm Outer Bush		11660	2	14
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1215	Rear Lower Arm Outer Bush		9240	2	15
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1216	Rear Lower Arm Inner Bush		12100	2	16
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1217	Rear Upper Arm Outer Bush, 38mm	38mm	10120	2	11
Vauxhall / Opel	VX220 (Opel Speedster)	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1500	1	
Vauxhall / Opel	VX220 (Opel Speedster)	PF34-201	Front and Rear Wishbone Bushes		48400	14	1
Vauxhall / Opel	VX220 (Opel Speedster)	PF34-202	Inner Rear Wishbone Bushes		7040	2	2
Vauxhall / Opel	VX220 (Opel Speedster)	PFF80-810	Lower Engine Mount Insert Kit		10500	2	3
Vauxhall / Opel	Zafira A (1999-2004)	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1500	1	
Vauxhall / Opel	Zafira A (1999-2004)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	Zafira A (1999-2004)	PFF80-1321	Gearbox Mount Insert		5750	1	21
Vauxhall / Opel	Zafira A (1999-2004)	PFF80-801	Front Wishbone Front Bush		8800	2	1
Vauxhall / Opel	Zafira A (1999-2004)	PFF80-802	Front Wishbone Rear Bush		8140	2	2
Vauxhall / Opel	Zafira A (1999-2004)	PFF80-810	Front Lower Engine Mount Insert Kit		5250	1	3
Vauxhall / Opel	Zafira A (1999-2004)	PFF80-830	Front Subframe Bush		24420	6	30
Vauxhall / Opel	Zafira A (1999-2004)	PFR80-815	Rear Beam Mounting Bush	60mm	13420	2	5
Vauxhall / Opel	Zafira B (2005-2011)	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1500	1	
Vauxhall / Opel	Zafira B (2005-2011)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-1203-24	Front Anti Roll Bar Mounting Bush 24mm (2 Piece)		9500	2	3
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-1203-25	Front Anti Roll Bar Mounting Bush 25mm (2 Piece)		9500	2	3
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-1320	Front Lower Engine Mount Insert		5000	1	20
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-1321	Gearbox Mount Insert		5750	1	21
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-801	Front Wishbone Front Bush		8800	2	1
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-802	Front Wishbone Rear Bush		8140	2	2
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-830	Front Subframe Bush		24420	6	30
Vauxhall / Opel	Zafira B (2005-2011)	PFR80-1310	Rear beam Mounting Bush		16720	2	5