

Make	Model	Part Number	Product Description	Bush Size	入数	SET価格	Diag Ref
Vauxhall / Opel	Adam (2012-)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Adam (2012-)	PFF80-1101	Front Arm Front Bush		2	12000	1
Vauxhall / Opel	Adam (2012-)	PFF80-1102	Front Arm Rear Bush		2	33500	2
Vauxhall / Opel	Adam (2012-)	PFF80-1103-19	Front Anti Roll Bar Bush 19mm	19mm	2	8500	3
Vauxhall / Opel	Adam (2012-)	PFF80-1103-20	Front Anti Roll Bar Bush 20mm	20mm	2	8500	3
Vauxhall / Opel	Adam (2012-)	PFF80-1103-21	Front Anti Roll Bar Bush 21mm	21mm	2	8500	3
Vauxhall / Opel	Adam (2012-)	PFF80-1120	Lower Rear Engine Mount Insert		1	5250	20
Vauxhall / Opel	Adam (2012-)	PFR80-1110	Rear Beam Mounting Bush		2	16000	10
Vauxhall / Opel	Agila (2000-2008)	PFF73-201	Front Track Control Arm Inner Bush		2	10500	1
Vauxhall / Opel	Agila (2000-2008)	PFF73-202	Front Roll Bar Mount Bush		2	9500	2
Vauxhall / Opel	Agila (2000-2008)	PFF73-203	Front Anti Roll Bar Bush 21mm	21mm	2	7500	3
Vauxhall / Opel	Agila (2000-2008)	PFR73-205	Rear Tie Bar to Chassis Bush		2	10500	5
Vauxhall / Opel	Agila (2000-2008)	PFR73-206	Rear Tie Bar to Hub Bush		4	21000	6
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	BS2002K	Bump Stop Kit	Front	1	10000	
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	EXH004	Exhaust Mounts		1	2250	
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	EXH008	Exhaust Mounts		1	2250	
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	PFF80-301	Front Wishbone Inner Bush (Front)		2	10000	1
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	PFF80-303-18	Front Anti Roll Bar Mounting Bush 18mm	18mm	2	7000	3
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	PFF80-303-19	Front Anti Roll Bar Mounting Bush 19mm	19mm	2	7000	3
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	PFF80-303-20	Front Anti Roll Bar Mounting Bush 20mm	20mm	2	7000	3
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	PFF80-303-22	Front Anti Roll Bar Mounting Bush 22mm	22mm	2	7000	3
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	PFF80-304	Front Wishbone Inner Bush (Rear)		2	10500	2
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	PFF80-308	Front Roll Bar Mounting Bolt Bush		2	9000	4
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	PFR80-312	Rear Beam Mounting Bush	49mm OD	2	12000	5
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)	BS2002K	Bump Stop Kit	Front	1	10000	
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)	EXH004	Exhaust Mounts		1	2250	
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)	EXH008	Exhaust Mounts		1	2250	
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)	PFF80-301	Front Wishbone Inner Bush (Front)		2	10000	1
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)	PFF80-302	Front Wishbone Inner Bush (Rear)		2	10000	2
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)	PFF80-303-18	Front Anti Roll Bar Mounting Bush 18mm	18mm	2	7000	3
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)	PFF80-303-19	Front Anti Roll Bar Mounting Bush 19mm	19mm	2	7000	3
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)	PFF80-303-20	Front Anti Roll Bar Mounting Bush 20mm	20mm	2	7000	3
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)	PFF80-303-22	Front Anti Roll Bar Mounting Bush 22mm	22mm	2	7000	3
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)	PFF80-308	Front Roll Bar Mounting Bolt Bush		2	9000	4
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)	PFR80-312	Rear Beam Mounting Bush	49mm OD	2	12000	5
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	BS2002K	Bump Stop Kit	Front	1	10000	
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFF80-401	Front Wishbone Inner Bush (Front)		2	10000	1
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFF80-402	Front Wishbone Inner Bush (Rear)		2	10000	2
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFF80-403-20	Front Anti Roll Bar Mount 20mm	20mm	2	7000	3
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFF80-403-22	Front Anti Roll Bar Mount 22mm	22mm	2	7000	3
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFF80-403-24	Front Anti Roll Bar Mount 24mm	24mm	2	7000	3
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFF80-408	Front Anti Roll Bar Mounting Bolt Bushes		2	7000	4
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFF80-409-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	7000	5
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFF80-409-22	Front Anti Roll Bar Eye Bolt Bush 22mm	22mm	2	7000	5
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFF80-409-24	Front Anti Roll Bar Eye Bolt Bush 24mm	24mm	2	7000	5
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFR80-412	Rear Beam Mounting Bush	59.8mm OD	2	12000	7
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFR80-415-15	Rear Anti Roll Bar Mount (inner) 15mm	15mm	2	7000	8
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFR80-415-20	Rear Anti Roll Bar Mount (inner) 20mm	20mm	2	7000	8
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1	2250	
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	EXH022	Universal Exhaust Mount		1	2250	
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFF80-1003-18	Front Anti Roll Bar Mounting Bush 18mm	18mm	2	7000	3
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFF80-1003-20	Front Anti Roll Bar Mounting Bush 20mm	20mm	2	7000	3
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFF80-1321	Gearbox Mount Insert		1	6000	21
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFF80-1322R	Upper Right Engine Mounting Insert Diesel		1	5250	22
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFF80-1323	Upper Right Engine Mounting Insert Petrol		1	5250	22
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFF80-303-22	Front Anti Roll Bar Mounting Bush 22mm	22mm	2	7000	3
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFF80-801	Front Wishbone Front Bush		2	10500	1
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFF80-802	Front Wishbone Rear Bush		2	10000	2

Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFF80-810	Front Lower Engine Mount Insert Kit		1	5500	20
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFF80-830	Front Subframe Bush		6	30000	30
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFR80-815	Rear Beam Mounting Bush	60mm	2	16000	5
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1	2250	
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	EXH022	Universal Exhaust Mount		1	2250	
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PF80K-1002	Powerflex Handling Pack		1	43500	
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1203-21	Front Anti Roll Bar Mounting Bush 21mm (2 Piece)	21mm	2	9500	3
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1203-22	Front Anti Roll Bar Mounting Bush 22mm (2 Piece)	22mm	2	9500	3
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1203-24	Front Anti Roll Bar Mounting Bush 24mm (2 Piece)		2	9500	3
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1203-25	Front Anti Roll Bar Mounting Bush 25mm (2 Piece)		2	9500	3
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1303-21	Front Anti Roll Bar Bush 21mm (1 Piece)	21mm	2	8500	3
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1303-22	Front Anti Roll Bar Bush 22mm	22mm	2	8500	3
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1320	Front Lower Engine Mount Insert Petrol		1	5250	20
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1321	Gearbox Mount Insert		1	6000	21
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1322R	Upper Right Engine Mounting Insert Diesel		1	5250	22
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1323	Upper Right Engine Mounting Insert Petrol		1	5250	22
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1324R	Front Lower Engine Mount Insert Diesel		1	5500	20
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1330	Lower Radiator Mount		2	6000	23
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-801	Front Wishbone Front Bush		2	10500	1
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-802	Front Wishbone Rear Bush		2	10000	2
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-830	Front Subframe Bush		6	30000	30
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFR80-1310	Rear beam Mounting Bush		2	20000	5
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010-2015)	EXH030	Rear Exhaust Mount		2	9000	30
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010-2015)	PF80K-1003	Powerflex Handling Pack		1	62750	
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010-2015)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010-2015)	PFF80-1401	Front Arm Front Bush		2	12000	1
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010-2015)	PFF80-1402	Front Arm Rear Bush		2	14500	2
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010-2015)	PFF80-1404	Hyper Strut To Lower Arm Front Bush		2	12500	4
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010-2015)	PFF80-1420	Front Engine Mounting Insert		1	6000	20
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010-2015)	PFF80-1421	Rear Engine Mounting Insert		1	5750	21
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010-2015)	PFR80-1410	Rear Beam Mounting Bush		2	17500	10
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010-2015)	PFR80-1411	Rear Panhard Rod Outer Bush		2	13000	11
Vauxhall / Opel	Calibra (1989-1997)	BS2002K	Bump Stop Kit	Front	1	10000	
Vauxhall / Opel	Calibra (1989-1997)	PFF80-401	Front Wishbone Inner Bush (Front)		2	10000	1
Vauxhall / Opel	Calibra (1989-1997)	PFF80-402	Front Wishbone Inner Bush (Rear)		2	10000	2
Vauxhall / Opel	Calibra (1989-1997)	PFF80-403-20	Front Anti Roll Bar Mount 20mm	20mm	2	7000	3
Vauxhall / Opel	Calibra (1989-1997)	PFF80-403-22	Front Anti Roll Bar Mount 22mm	22mm	2	7000	3
Vauxhall / Opel	Calibra (1989-1997)	PFF80-403-24	Front Anti Roll Bar Mount 24mm	24mm	2	7000	3
Vauxhall / Opel	Calibra (1989-1997)	PFF80-408	Front Anti Roll Bar Mounting Bolt Bushes		2	7000	4
Vauxhall / Opel	Calibra (1989-1997)	PFF80-409-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	7000	5
Vauxhall / Opel	Calibra (1989-1997)	PFF80-409-22	Front Anti Roll Bar Eye Bolt Bush 22mm	22mm	2	7000	5
Vauxhall / Opel	Calibra (1989-1997)	PFF80-409-24	Front Anti Roll Bar Eye Bolt Bush 24mm	24mm	2	7000	5
Vauxhall / Opel	Calibra (1989-1997)	PFR80-415-15	Rear Anti Roll Bar Mount (inner) 15mm	15mm	2	7000	7
Vauxhall / Opel	Calibra (1989-1997)	PFR80-415-18	Rear Anti Roll Bar Mount (inner) 18mm	18mm	2	7000	7
Vauxhall / Opel	Calibra (1989-1997)	PFR80-416-14.5	Rear Anti Roll Bar Mount (Inner) 14.5mm	14.5mm	2	7000	7
Vauxhall / Opel	Calibra (1989-1997)	PFR80-440	Rear Trailing Arm Bush		2	10500	6
Vauxhall / Opel	Calibra (1989-1997)	PFR80-440MLK	Rear Trailing Arm Bush		2	10500	6
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	BS2002K	Bump Stop Kit	Front	1	10000	
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFF80-401	Front Wishbone Inner Bush (Front)		2	10000	1
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFF80-402	Front Wishbone Inner Bush (Rear)		2	10000	2
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFF80-403-20	Front Anti Roll Bar Mount 20mm	20mm	2	7000	3
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFF80-403-22	Front Anti Roll Bar Mount 22mm	22mm	2	7000	3
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFF80-403-24	Front Anti Roll Bar Mount 24mm	24mm	2	7000	3
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFF80-408	Front Anti Roll Bar Mounting Bolt Bushes		2	7000	4
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFF80-409-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	7000	5
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFF80-409-22	Front Anti Roll Bar Eye Bolt Bush 22mm	22mm	2	7000	5
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFF80-409-24	Front Anti Roll Bar Eye Bolt Bush 24mm	24mm	2	7000	5
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFR80-412	Rear Beam Mounting Bush	59.8mm OD	2	12000	7

Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFR80-415-15	Rear Anti Roll Bar Mount (inner) 15mm	15mm	2	7000	8
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFR80-415-18	Rear Anti Roll Bar Mount (Inner) 18mm	18mm	2	7000	8
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFR80-415-20	Rear Anti Roll Bar Mount (inner) 20mm	20mm	2	7000	8
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFF80-401	Front Wishbone Inner Bush (Front)		2	10000	1
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFF80-402	Front Wishbone Inner Bush (Rear)		2	10000	2
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFF80-403-20	Front Anti Roll Bar Mount 20mm	20mm	2	7000	3
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFF80-403-22	Front Anti Roll Bar Mount 22mm	22mm	2	7000	3
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFF80-403-24	Front Anti Roll Bar Mount 24mm	24mm	2	7000	3
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFF80-408	Front Anti Roll Bar Mounting Bolt Bushes		2	7000	4
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFF80-409-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	7000	5
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFF80-409-22	Front Anti Roll Bar Eye Bolt Bush 22mm	22mm	2	7000	5
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFF80-409-24	Front Anti Roll Bar Eye Bolt Bush 24mm	24mm	2	7000	5
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFR80-415-15	Rear Anti Roll Bar Mount (inner) 15mm	15mm	2	7000	7
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFR80-415-18	Rear Anti Roll Bar Mount (inner) 18mm	18mm	2	7000	7
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFR80-416-14.5	Rear Anti Roll Bar Mount (Inner) 14.5mm	14.5mm	2	7000	7
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFR80-440	Rear Trailing Arm Bush		2	10500	6
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFR80-440MLK	Rear Trailing Arm Bush		2	10500	6
Vauxhall / Opel	Corsa A (1983-1993)	BS2002K	Bump Stop Kit	Front	1	10000	
Vauxhall / Opel	Corsa A (1983-1993)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Corsa A (1983-1993)	PFF80-101	Front Wishbone Inner Bush (front)		2	10000	1
Vauxhall / Opel	Corsa A (1983-1993)	PFF80-102	Front Tie Bar To Chassis Bush		2	9500	2
Vauxhall / Opel	Corsa A (1983-1993)	PFF80-105-16	Front Anti Roll Bar Mount	16mm	4	13000	3
Vauxhall / Opel	Corsa A (1983-1993)	PFF80-105-20	Front Anti Roll Bar Mount	20mm	4	13000	3
Vauxhall / Opel	Corsa A (1983-1993)	PFR80-112	Rear Beam Mounting Bush		2	12000	5
Vauxhall / Opel	Corsa B (1993-1997)	BS2002K	Bump Stop Kit	Front	1	10000	
Vauxhall / Opel	Corsa B (1993-1997)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Corsa B (1993-1997)	PFF80-201	Front Wishbone Inner Bush		2	10000	1
Vauxhall / Opel	Corsa B (1993-1997)	PFF80-203	Front Tie Bar To Chassis		2	10000	2
Vauxhall / Opel	Corsa B (1993-1997)	PFF80-205	Front Anti Roll Bar Mounts		4	13000	3
Vauxhall / Opel	Corsa B (1993-1997)	PFR80-112	Rear Beam Mounting Bush		2	12000	5
Vauxhall / Opel	Corsa B (1998-2000)	BS2002K	Bump Stop Kit	Front	1	10000	
Vauxhall / Opel	Corsa B (1998-2000)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Corsa B (1998-2000)	PFF80-201	Front Wishbone Inner Bush		2	10000	1
Vauxhall / Opel	Corsa B (1998-2000)	PFF80-204	Front Tie Bar To Chassis		2	10000	2
Vauxhall / Opel	Corsa B (1998-2000)	PFF80-205	Front Anti Roll Bar Mounts		4	13000	3
Vauxhall / Opel	Corsa B (1998-2000)	PFR80-112	Rear Beam Mounting Bush		2	12000	5
Vauxhall / Opel	Corsa C (2000-2006)	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1	2250	
Vauxhall / Opel	Corsa C (2000-2006)	EXH022	Universal Exhaust Mount		1	2250	
Vauxhall / Opel	Corsa C (2000-2006)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Corsa C (2000-2006)	PFF80-1001	Front Wishbone Rear Bush		2	14000	1
Vauxhall / Opel	Corsa C (2000-2006)	PFF80-1002	Front Wishbone Front Bush		2	12000	2
Vauxhall / Opel	Corsa C (2000-2006)	PFF80-1003-17	Front Anti Roll Bar Bush 17mm	17mm	2	7000	3
Vauxhall / Opel	Corsa C (2000-2006)	PFF80-1003-18	Front Anti Roll Bar Bush 18mm	18mm	2	7000	3
Vauxhall / Opel	Corsa C (2000-2006)	PFF80-1030	Gearbox Mount Insert		1	6750	30
Vauxhall / Opel	Corsa C (2000-2006)	PFF80-1030R	Gearbox Mount Insert (Diesel)		1	6750	30
Vauxhall / Opel	Corsa C (2000-2006)	PFF80-1031	Engine Mount Insert Right Side		1	6000	31
Vauxhall / Opel	Corsa C (2000-2006)	PFF80-1032	Rear Lower Engine Mount Rear Bush		1	6750	32
Vauxhall / Opel	Corsa C (2000-2006)	PFF80-1034	Rear Lower Engine Mount Front Bush		1	7250	34
Vauxhall / Opel	Corsa C (2000-2006)	PFF80-1035	Front Lower Engine Mount Bush		1	11500	35
Vauxhall / Opel	Corsa C (2000-2006)	PFR80-1005	Rear Beam Mounting Bush		2	16500	5
Vauxhall / Opel	Corsa D (2006-2014)Corsa D	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Corsa D (2006-2014)Corsa D	PFF80-1101	Front Arm Front Bush		2	12000	1
Vauxhall / Opel	Corsa D (2006-2014)Corsa D	PFF80-1102	Front Arm Rear Bush		2	33500	2
Vauxhall / Opel	Corsa D (2006-2014)Corsa D	PFF80-1103-19	Front Anti Roll Bar Bush 19mm	19mm	2	8500	3
Vauxhall / Opel	Corsa D (2006-2014)Corsa D	PFF80-1103-20	Front Anti Roll Bar Bush 20mm	20mm	2	8500	3
Vauxhall / Opel	Corsa D (2006-2014)Corsa D	PFF80-1103-21	Front Anti Roll Bar Bush 21mm	21mm	2	8500	3
Vauxhall / Opel	Corsa D (2006-2014)Corsa D	PFF80-1120	Lower Rear Engine Mount Insert		1	5250	20
Vauxhall / Opel	Corsa D (2006-2014)Corsa D	PFR80-1110	Rear Beam Mounting Bush		2	16000	10
Vauxhall / Opel	Corsa D (2006-2014)VXR	PF80K-1001	Powerflex Handling Pack		1	62750	

Vauxhall / Opel	Corsa D (2006-2014)VXR	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Corsa D (2006-2014)VXR	PFF80-1101	Front Arm Front Bush		2	12000	1
Vauxhall / Opel	Corsa D (2006-2014)VXR	PFF80-1102	Front Arm Rear Bush		2	33500	2
Vauxhall / Opel	Corsa D (2006-2014)VXR	PFF80-1103-19	Front Anti Roll Bar Bush 19mm	19mm	2	8500	3
Vauxhall / Opel	Corsa D (2006-2014)VXR	PFF80-1103-20	Front Anti Roll Bar Bush 20mm	20mm	2	8500	3
Vauxhall / Opel	Corsa D (2006-2014)VXR	PFF80-1103-21	Front Anti Roll Bar Bush 21mm	21mm	2	8500	3
Vauxhall / Opel	Corsa D (2006-2014)VXR	PFF80-1120	Lower Rear Engine Mount Insert		1	5250	20
Vauxhall / Opel	Corsa D (2006-2014)VXR	PFR80-1110	Rear Beam Mounting Bush		2	16000	10
Vauxhall / Opel	Manta B (1982-1988)	PFF80-303-20	Front Anti Roll Bar Mounting Bush 20mm	20mm	2	7000	6
Vauxhall / Opel	Manta B (1982-1988)	PFF80-303-22	Front Anti Roll Bar Mounting Bush 22mm	22mm	2	7000	6
Vauxhall / Opel	Manta B (1982-1988)	PFF80-601	Front Upper Wishbone Bush		4	15000	1
Vauxhall / Opel	Manta B (1982-1988)	PFF80-602	Front Lower Wishbone Front Bush		2	10500	2
Vauxhall / Opel	Manta B (1982-1988)	PFF80-603	Front Lower Rear Bush		2	10500	3
Vauxhall / Opel	Manta B (1982-1988)	PFF80-604	Front Subframe Rear Mounting Bush		2	9000	4
Vauxhall / Opel	Manta B (1982-1988)	PFF80-605	Front Outer Roll Bar Mount		2	11000	5
Vauxhall / Opel	Manta B (1982-1988)	PFR80-607	Rear Tie Bar To Chassis Bush		2	9000	7
Vauxhall / Opel	Manta B (1982-1988)	PFR80-608	Rear Panhard Rod Mount		2	9000	8
Vauxhall / Opel	Manta B (1982-1988)	PFR80-609-14	Rear Anti Roll Bar Bush 14mm	14mm	2	7000	9
Vauxhall / Opel	Manta B (1982-1988)	PFR80-609-18	Rear Anti Roll Bar Mount 18mm	18mm	2	7000	9
Vauxhall / Opel	Manta B (1982-1988)	PFR80-611	Rear Tie Bar To Axle Bushes		2	9000	11
Vauxhall / Opel	Manta B (1982-1988)	PFR80-611	Rear Centre Prop Mount		2	9000	10
Vauxhall / Opel	Meriva (2002 - 2011)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Meriva (2002 - 2011)	PFF80-1030	Gearbox Mount Insert		1	6750	30
Vauxhall / Opel	Meriva (2002 - 2011)	PFF80-1030R	Gearbox Mount Insert (Diesel)		1	6750	30
Vauxhall / Opel	Meriva (2002 - 2011)	PFF80-1031	Engine Mount Insert Right Side		1	6000	31
Vauxhall / Opel	Meriva (2002 - 2011)	PFF80-1032	Rear Lower Engine Mount Rear Bush		1	6750	32
Vauxhall / Opel	Meriva (2002 - 2011)	PFF80-1034	Rear Lower Engine Mount Front Bush		1	7250	34
Vauxhall / Opel	Meriva (2002 - 2011)	PFF80-1035	Front Lower Engine Mount Bush		1	11500	35
Vauxhall / Opel	Meriva (2002 - 2011)	PFF80-1303-21	Front Anti Roll Bar Bush 21mm (1 Piece)	21mm	2	8500	3
Vauxhall / Opel	Meriva (2002 - 2011)	PFF80-1330	Lower Radiator Mount		2	6000	23
Vauxhall / Opel	Nova (1983-1993)	EXH003	Exhaust Mount	B=48mm	1	2250	
Vauxhall / Opel	Nova (1983-1993)	PFF80-101	Front Wishbone Inner Bush (front)		2	10000	1
Vauxhall / Opel	Nova (1983-1993)	PFF80-102	Front Tie Bar To Chassis Bush		2	9500	2
Vauxhall / Opel	Nova (1983-1993)	PFF80-105-16	Front Anti Roll Bar Mount	16mm	4	13000	3
Vauxhall / Opel	Nova (1983-1993)	PFF80-105-20	Front Anti Roll Bar Mount	20mm	4	13000	3
Vauxhall / Opel	Nova (1983-1993)	PFR80-112	Rear Beam Mounting Bush		2	12000	5
Vauxhall / Opel	Omega B 1994-2003	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1	2250	
Vauxhall / Opel	Omega B 1994-2003	EXH022	Universal Exhaust Mount		1	2250	
Vauxhall / Opel	Omega B 1994-2003	PFF80-901-26	Front Anti Roll Bar To Chassis Bush 26mm	26mm	2	8500	1
Vauxhall / Opel	Omega B 1994-2003	PFF80-902	Front Wishbone Front Bush		2	12000	2
Vauxhall / Opel	Senator B (1987 - 1994)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Signum (2003 - 2008)	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1	2250	
Vauxhall / Opel	Signum (2003 - 2008)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Signum (2003 - 2008)	PFF66-503-24	Front Anti Roll Bar Mounting Bush 24mm		2	8500	3
Vauxhall / Opel	Signum (2003 - 2008)	PFF66-503-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	8500	3
Vauxhall / Opel	Signum (2003 - 2008)	PFF80-1201	Front Lower Wishbone Front Bush		2	12500	1
Vauxhall / Opel	Signum (2003 - 2008)	PFF80-1202	Front Lower Wishbone Rear Bush		2	14000	2
Vauxhall / Opel	Signum (2003 - 2008)	PFF80-1203-24	Front Anti Roll Bar Mounting Bush 24mm (2 Piece)		2	9500	3
Vauxhall / Opel	Signum (2003 - 2008)	PFF80-1203-25	Front Anti Roll Bar Mounting Bush 25mm (2 Piece)		2	9500	3
Vauxhall / Opel	Signum (2003 - 2008)	PFF80-1220	Front Lower Engine Mount Insert		1	6000	20
Vauxhall / Opel	Signum (2003 - 2008)	PFF80-1220	Rear Lower Engine Mount Insert		1	6000	21
Vauxhall / Opel	Signum (2003 - 2008)	PFF80-1220R	Front Lower Engine Mount Insert (Diesel)		1	6000	20
Vauxhall / Opel	Signum (2003 - 2008)	PFF80-1220R	Rear Lower Engine Mount Insert (Diesel)		1	6000	21
Vauxhall / Opel	Signum (2003 - 2008)	PFF80-1221	Rear Lower Engine Mount Insert (79mm Option)	79mm wide	1	5750	21
Vauxhall / Opel	Signum (2003 - 2008)	PFF80-1221R	Rear Lower Engine Mount Insert Diesel (79mm Option)	79mm wide	1	5750	21
Vauxhall / Opel	Signum (2003 - 2008)	PFR66-519-17	Rear Anti Roll Bar Mounting Bush 17mm	17mm	2	8500	19
Vauxhall / Opel	Signum (2003 - 2008)	PFR66-519-18	Rear Anti Roll Bar Mounting Bush 18mm	18mm	2	8500	19
Vauxhall / Opel	Signum (2003 - 2008)	PFR66-519-19	Rear Anti Roll Bar Mounting Bush 19mm	19mm	2	8500	19
Vauxhall / Opel	Signum (2003 - 2008)	PFR80-1210	Rear Trailing Arm Front Bush		2	17000	10

Vauxhall / Opel	Signum (2003 - 2008)	PFR80-1211	Rear Upper Arm Outer Bush	47mm	2	28500	11
Vauxhall / Opel	Signum (2003 - 2008)	PFR80-1212	Rear Upper Arm Inner Bush		2	14000	12
Vauxhall / Opel	Signum (2003 - 2008)	PFR80-1213	Rear Toe Arm Inner Bush		2	14000	13
Vauxhall / Opel	Signum (2003 - 2008)	PFR80-1214	Rear Toe Arm Outer Bush		2	14000	14
Vauxhall / Opel	Signum (2003 - 2008)	PFR80-1215	Rear Lower Arm Outer Bush		2	11000	15
Vauxhall / Opel	Signum (2003 - 2008)	PFR80-1216	Rear Lower Arm Inner Bush		2	14500	16
Vauxhall / Opel	Signum (2003 - 2008)	PFR80-1217	Rear Upper Arm Outer Bush, 38mm	38mm	2	12000	11
Vauxhall / Opel	Tigra (1993-2001)	BS2002K	Bump Stop Kit	Front	1	10000	
Vauxhall / Opel	Tigra (1993-2001)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Tigra (1993-2001)	PFF80-201	Front Wishbone Inner Bush		2	10000	1
Vauxhall / Opel	Tigra (1993-2001)	PFF80-203	Front Tie Bar To Chassis		2	10000	2
Vauxhall / Opel	Tigra (1993-2001)	PFF80-204	Front Tie Bar To Chassis		2	10000	2
Vauxhall / Opel	Tigra (1993-2001)	PFF80-205	Front Anti Roll Bar Mounts		4	13000	3
Vauxhall / Opel	Tigra (1993-2001)	PFR80-112	Rear Beam Mounting Bush		2	12000	5
Vauxhall / Opel	Tigra Twin Top (2004-)	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1	2250	
Vauxhall / Opel	Tigra Twin Top (2004-)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Tigra Twin Top (2004-)	PFF80-1001	Front Arm Rear Bush		2	14000	1
Vauxhall / Opel	Tigra Twin Top (2004-)	PFF80-1003-17	Front Anti Roll Bar Bush 17mm	17mm	2	7000	3
Vauxhall / Opel	Tigra Twin Top (2004-)	PFF80-1003-18	Front Anti Roll Bar Mounting Bush 18mm	18mm	2	7000	3
Vauxhall / Opel	Tigra Twin Top (2004-)	PFR80-1005	Rear Beam Mounting Bush		2	16500	5
Vauxhall / Opel	Vectra B (1995 - 2002)	EXH002	Exhaust Mounts		1	2250	
Vauxhall / Opel	Vectra B (1995 - 2002)	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1	2250	
Vauxhall / Opel	Vectra B (1995 - 2002)	EXH022	Universal Exhaust Mount		1	2250	
Vauxhall / Opel	Vectra B (1995 - 2002)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Vectra B (1995 - 2002)	PFF80-303-18	Front Anti Roll Bar Mounting Bush 18mm	18mm	2	7000	3
Vauxhall / Opel	Vectra B (1995 - 2002)	PFF80-303-19	Front Anti Roll Bar Mounting Bush 19mm	19mm	2	7000	3
Vauxhall / Opel	Vectra B (1995 - 2002)	PFF80-303-19.5	Front Anti Roll Bar Mounting Bush 19.5mm	19.5mm	2	7000	3
Vauxhall / Opel	Vectra B (1995 - 2002)	PFF80-303-20	Front Anti Roll Bar Mounting Bush 20mm	20mm	2	7000	3
Vauxhall / Opel	Vectra B (1995 - 2002)	PFF80-303-22	Front Anti Roll Bar Mounting Bush 22mm	22mm	2	7000	3
Vauxhall / Opel	Vectra B (1995 - 2002)	PFF80-501	Front Lower Wishbone Front Bush		2	9500	1
Vauxhall / Opel	Vectra B (1995 - 2002)	PFF80-502	Front Lower Wishbone Rear Bush		2	10000	2
Vauxhall / Opel	Vectra B (1995 - 2002)	PFR66-110	Rear Trailing Arm Bush		2	12500	4
Vauxhall / Opel	Vectra B (1995 - 2002)	PFR66-210-15	Rear Anti Roll Bar Mounting Bush 15mm	15mm	2	7000	5
Vauxhall / Opel	Vectra B (1995 - 2002)	PFR66-210-16	Rear Anti Roll Bar Mounting Bush 16mm	16mm	2	7000	5
Vauxhall / Opel	Vectra B (1995 - 2002)	PFR66-210-17	Rear Anti Roll Bar Mounting Bush 17mm	17mm	2	7000	5
Vauxhall / Opel	Vectra C (2002-2008)	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1	2250	
Vauxhall / Opel	Vectra C (2002-2008)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Vectra C (2002-2008)	PFF66-503-24	Front Anti Roll Bar Mounting Bush 24mm		2	8500	3
Vauxhall / Opel	Vectra C (2002-2008)	PFF66-503-25	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	8500	3
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1201	Front Lower Wishbone Front Bush		2	12500	1
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1202	Front Lower Wishbone Rear Bush		2	14000	2
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1203-24	Front Anti Roll Bar Mounting Bush 24mm (2 Piece)		2	9500	3
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1203-25	Front Anti Roll Bar Mounting Bush 25mm (2 Piece)		2	9500	3
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1220	Front Lower Engine Mount Insert		1	6000	20
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1220	Rear Lower Engine Mount Insert		1	6000	21
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1220R	Front Lower Engine Mount Insert (Diesel)		1	6000	20
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1220R	Rear Lower Engine Mount Insert (Diesel)		1	6000	21
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1221	Rear Lower Engine Mount Insert (79mm Option)	79mm wide	1	5750	21
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1221R	Rear Lower Engine Mount Insert Diesel (79mm Option)	79mm wide	1	5750	21
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1230	Front Subframe Front Bush		2	18500	30
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1231	Front Subframe Rear Bush		2	18500	31
Vauxhall / Opel	Vectra C (2002-2008)	PFR66-519-16	Rear Anti Roll Bar Mounting Bush 16mm	16mm	2	8500	19
Vauxhall / Opel	Vectra C (2002-2008)	PFR66-519-17	Rear Anti Roll Bar Mounting Bush 17mm	17mm	2	8500	19
Vauxhall / Opel	Vectra C (2002-2008)	PFR66-519-18	Rear Anti Roll Bar Mounting Bush 18mm	18mm	2	8500	19
Vauxhall / Opel	Vectra C (2002-2008)	PFR66-519-19	Rear Anti Roll Bar Mounting Bush 19mm	19mm	2	8500	19
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1210	Rear Trailing Arm Front Bush		2	17000	10
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1211	Rear Upper Arm Outer Bush	47mm	2	28500	11
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1212	Rear Upper Arm Inner Bush		2	14000	12
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1213	Rear Toe Arm Inner Bush		2	14000	13

Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1214	Rear Toe Arm Outer Bush		2	14000	14
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1215	Rear Lower Arm Outer Bush		2	11000	15
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1216	Rear Lower Arm Inner Bush		2	14500	16
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1217	Rear Upper Arm Outer Bush, 38mm	38mm	2	12000	11
Vauxhall / Opel	VX220 (Opel Speedster)	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1	2250	
Vauxhall / Opel	VX220 (Opel Speedster)	PF34-201	Front and Rear Wishbone Bushes		14	59500	1
Vauxhall / Opel	VX220 (Opel Speedster)	PF34-202	Inner Rear Wishbone Bushes		2	8500	2
Vauxhall / Opel	VX220 (Opel Speedster)	PFF34-203-19	Front Anti Roll Bar Bush 19mm	19mm	2	7000	3
Vauxhall / Opel	VX220 (Opel Speedster)	PFF34-203-22.2	Front Anti Roll Bar Bush 22.2mm	22.2mm	2	7000	3
Vauxhall / Opel	VX220 (Opel Speedster)	PFF34-203-25.4	Front Anti Roll Bar Bush 25.4mm	25.4mm	2	7000	3
Vauxhall / Opel	VX220 (Opel Speedster)	PFF80-810	Lower Engine Mount Insert Kit		2	11000	20
Vauxhall / Opel	Zafira A (1999-2004)	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1	2250	
Vauxhall / Opel	Zafira A (1999-2004)	EXH022	Universal Exhaust Mount		1	2250	
Vauxhall / Opel	Zafira A (1999-2004)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Zafira A (1999-2004)	PFF80-1321	Gearbox Mount Insert		1	6000	21
Vauxhall / Opel	Zafira A (1999-2004)	PFF80-1322R	Upper Right Engine Mounting Insert Diesel		1	5250	22
Vauxhall / Opel	Zafira A (1999-2004)	PFF80-1323	Upper Right Engine Mounting Insert Petrol		1	5250	22
Vauxhall / Opel	Zafira A (1999-2004)	PFF80-801	Front Wishbone Front Bush		2	10500	1
Vauxhall / Opel	Zafira A (1999-2004)	PFF80-802	Front Wishbone Rear Bush		2	10000	2
Vauxhall / Opel	Zafira A (1999-2004)	PFF80-810	Front Lower Engine Mount Insert Kit		1	5500	20
Vauxhall / Opel	Zafira A (1999-2004)	PFF80-830	Front Subframe Bush		6	30000	30
Vauxhall / Opel	Zafira A (1999-2004)	PFR80-815	Rear Beam Mounting Bush	60mm	2	16000	5
Vauxhall / Opel	Zafira B (2005-2011)	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1	2250	
Vauxhall / Opel	Zafira B (2005-2011)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-1203-24	Front Anti Roll Bar Mounting Bush 24mm (2 Piece)		2	9500	3
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-1203-25	Front Anti Roll Bar Mounting Bush 25mm (2 Piece)		2	9500	3
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-1320	Front Lower Engine Mount Insert Petrol		1	5250	20
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-1321	Gearbox Mount Insert		1	6000	21
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-1322R	Upper Right Engine Mounting Insert Diesel		1	5250	22
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-1323	Upper Right Engine Mounting Insert Petrol		1	5250	22
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-1324R	Front Lower Engine Mount Insert Diesel		1	5500	20
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-1330	Lower Radiator Mount		2	6000	23
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-801	Front Wishbone Front Bush		2	10500	1
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-802	Front Wishbone Rear Bush		2	10000	2
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-830	Front Subframe Bush		6	30000	30
Vauxhall / Opel	Zafira B (2005-2011)	PFR80-1310	Rear beam Mounting Bush		2	20000	5
Vauxhall / Opel	Adam (2012-)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Adam (2012-)	PFF80-1101BLK	Front Arm Front Bush		2	12000	1
Vauxhall / Opel	Adam (2012-)	PFF80-1102BLK	Front Arm Rear Bush		2	36500	2
Vauxhall / Opel	Adam (2012-)	PFF80-1103-19BLK	Front Anti Roll Bar Bush 19mm	19mm	2	9500	3
Vauxhall / Opel	Adam (2012-)	PFF80-1103-20BLK	Front Anti Roll Bar Bush 20mm	20mm	2	9500	3
Vauxhall / Opel	Adam (2012-)	PFF80-1103-21BLK	Front Anti Roll Bar Bush 21mm	21mm	2	9500	3
Vauxhall / Opel	Adam (2012-)	PFF80-1120BLK	Lower Rear Engine Mount Insert		1	6000	20
Vauxhall / Opel	Adam (2012-)	PFR80-1110BLK	Rear Beam Mounting Bush		2	18000	10
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	BS2002K	Bump Stop Kit	Front	1	10000	
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	EXH004	Exhaust Mounts		1	2250	
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	EXH008	Exhaust Mounts		1	2250	
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	PFF80-301BLK	Front Wishbone Inner Bush (Front)		2	11000	1
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	PFF80-303-19BLK	Front Anti Roll Bar Mounting Bush 19mm	19mm	2	8000	3
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	PFF80-303-20BLK	Front Anti Roll Bar Mounting Bush 20mm	20mm	2	7500	3
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	PFF80-303-22BLK	Front Anti Roll Bar Mounting Bush 22mm	22mm	2	7500	3
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	PFF80-304BLK	Front Wishbone Inner Bush (Rear)		2	11500	2
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	PFF80-308BLK	Front Roll Bar Mounting Bolt Bush		2	10000	4
Vauxhall / Opel	Astra MK1 - Kadett D (1980 - 1985)	PFR80-312BLK	Rear Beam Mounting Bush	49mm OD	2	13000	5
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)	BS2002K	Bump Stop Kit	Front	1	10000	
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)	EXH004	Exhaust Mounts		1	2250	
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)	EXH008	Exhaust Mounts		1	2250	
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)	PFF80-301BLK	Front Wishbone Inner Bush (Front)		2	11000	1
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)	PFF80-302BLK	Front Wishbone Inner Bush (Rear)		2	11000	2

Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)	PFF80-303-20BLK	Front Anti Roll Bar Mounting Bush 20mm	20mm	2	7500	3
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)	PFF80-303-22BLK	Front Anti Roll Bar Mounting Bush 22mm	22mm	2	7500	3
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)	PFF80-308BLK	Front Roll Bar Mounting Bolt Bush		2	10000	4
Vauxhall / Opel	Astra MK2 - Kadett E (1985-1991)	PFR80-312BLK	Rear Beam Mounting Bush	49mm OD	2	13000	5
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	BS2002K	Bump Stop Kit	Front	1	10000	
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFF80-303-19BLK	Front Anti Roll Bar Mounting Bush 19mm	19mm	2	8000	3
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFF80-401BLK	Front Wishbone Inner Bush (Front)		2	11000	1
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFF80-402BLK	Front Wishbone Inner Bush (Rear)		2	11000	2
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFF80-403-20BLK	Front Anti Roll Bar Mount 20mm	20mm	2	7500	3
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFF80-403-22BLK	Front Anti Roll Bar Mount 22mm	22mm	2	7500	3
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFF80-403-24BLK	Front Anti Roll Bar Mount 24mm	24mm	2	7500	3
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFF80-408BLK	Front Anti Roll Bar Mounting Bolt Bushes		2	8000	4
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFF80-409-22BLK	Front Anti Roll Bar Eye Bolt Bush 22mm	22mm	2	7500	5
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFF80-409-24BLK	Front Anti Roll Bar Eye Bolt Bush 24mm	24mm	2	7500	5
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFR80-412BLK	Rear Beam Mounting Bush	59.8mm OD	2	13000	7
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFR80-415-15BLK	Rear Anti Roll Bar Mount (inner) 15mm	15mm	2	7500	8
Vauxhall / Opel	Astra MK3 - Astra F (1991-1998)	PFR80-415-18BLK	Rear Anti Roll Bar Mount (inner) 18mm	18mm	2	7500	8
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1	2250	
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFF80-1003-18BLK	Front Anti Roll Bar Mounting Bush 18mm	18mm	2	7500	3
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFF80-1003-20BLK	Front Anti Roll Bar Mounting Bush 20mm	20mm	2	7500	3
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFF80-1321BLK	Gearbox Mount Insert		1	6750	21
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFF80-1322BLK	Upper Right Engine Mounting Insert Diesel		1	5750	22
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFF80-1323BLK	Upper Right Engine Mounting Insert Petrol		1	5750	22
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFF80-303-22BLK	Front Anti Roll Bar Mounting Bush 22mm	22mm	2	7500	3
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFF80-801BLK	Front Wishbone Front Bush		2	11500	1
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFF80-802BLK	Front Wishbone Rear Bush		2	11000	2
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFF80-810BLK	Front Lower Engine Mount Insert Kit		1	6000	20
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFF80-830BLK	Front Subframe Bush		6	33000	30
Vauxhall / Opel	Astra MK4 - Astra G (1998-2004)	PFR80-815BLK	Rear Beam Mounting Bush	60mm	2	18000	5
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1	2250	
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1203-21BLK	Front Anti Roll Bar Mounting Bush 21mm (2 Piece)	21mm	2	10500	3
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1203-24BLK	Front Anti Roll Bar Mounting Bush 24mm (2 Piece)		2	10500	3
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1203-25BLK	Front Anti Roll Bar Mounting Bush 25mm (2 Piece)		2	10500	3
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1303-21BLK	Front Anti Roll Bar Bush 21mm (1 Piece)	21mm	2	9000	3
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1320BLK	Front Lower Engine Mount Insert Petrol		1	6000	20
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1321BLK	Gearbox Mount Insert		1	6750	21
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1322BLK	Upper Right Engine Mounting Insert Diesel		1	5750	22
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1323BLK	Upper Right Engine Mounting Insert Petrol		1	5750	22
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1324BLK	Front Lower Engine Mount Insert Diesel		1	6000	20
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-1330BLK	Lower Radiator Mount		2	6500	23
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-801BLK	Front Wishbone Front Bush		2	11500	1
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-802BLK	Front Wishbone Rear Bush		2	11000	2
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFF80-830BLK	Front Subframe Bush		6	33000	30
Vauxhall / Opel	Astra MK5 - Astra H (2004-2010)	PFR80-1310BLK	Rear beam Mounting Bush		2	22500	5
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010-2015)	EXH030BLK	Rear Exhaust Mount		2	10000	30
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010-2015)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010-2015)	PFF80-1401BLK	Front Arm Front Bush		2	12000	1
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010-2015)	PFF80-1402BLK	Front Arm Rear Bush		2	14500	2
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010-2015)	PFF80-1404BLK	Hyper Strut To Lower Arm Front Bush		2	12500	4
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010-2015)	PFF80-1420BLK	Front Engine Mounting Insert		1	6750	20
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010-2015)	PFF80-1421BLK	Rear Engine Mounting Insert		1	6250	21
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010-2015)	PFR80-1410BLK	Rear Beam Mounting Bush		2	19000	10
Vauxhall / Opel	Astra MK6 - Astra J GTC, VXR & OPC (2010-2015)	PFR80-1411BLK	Rear Panhard Rod Outer Bush		2	13000	11
Vauxhall / Opel	Calibra (1989-1997)	BS2002K	Bump Stop Kit	Front	1	10000	
Vauxhall / Opel	Calibra (1989-1997)	PFF80-401BLK	Front Wishbone Inner Bush (Front)		2	11000	1
Vauxhall / Opel	Calibra (1989-1997)	PFF80-402BLK	Front Wishbone Inner Bush (Rear)		2	11000	2
Vauxhall / Opel	Calibra (1989-1997)	PFF80-403-20BLK	Front Anti Roll Bar Mount 20mm	20mm	2	7500	3
Vauxhall / Opel	Calibra (1989-1997)	PFF80-403-22BLK	Front Anti Roll Bar Mount 22mm	22mm	2	7500	3

Vauxhall / Opel	Calibra (1989-1997)	PFF80-403-24BLK	Front Anti Roll Bar Mount 24mm	24mm	2	7500	3
Vauxhall / Opel	Calibra (1989-1997)	PFF80-408BLK	Front Anti Roll Bar Mounting Bolt Bushes		2	8000	4
Vauxhall / Opel	Calibra (1989-1997)	PFF80-409-22BLK	Front Anti Roll Bar Eye Bolt Bush 22mm	22mm	2	7500	5
Vauxhall / Opel	Calibra (1989-1997)	PFF80-409-24BLK	Front Anti Roll Bar Eye Bolt Bush 24mm	24mm	2	7500	5
Vauxhall / Opel	Calibra (1989-1997)	PFR80-415-15BLK	Rear Anti Roll Bar Mount (inner) 15mm	15mm	2	7500	7
Vauxhall / Opel	Calibra (1989-1997)	PFR80-415-18BLK	Rear Anti Roll Bar Mount (inner) 18mm	18mm	2	7500	7
Vauxhall / Opel	Calibra (1989-1997)	PFR80-440BLK	Rear Trailing Arm Bush		2	11500	6
Vauxhall / Opel	Calibra (1989-1997)	PFR80-440MLK-BLK	Rear Trailing Arm Bush		2	10500	6
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	BS2002K	Bump Stop Kit	Front	1	10000	
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFF80-401BLK	Front Wishbone Inner Bush (Front)		2	11000	1
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFF80-402BLK	Front Wishbone Inner Bush (Rear)		2	11000	2
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFF80-403-20BLK	Front Anti Roll Bar Mount 20mm	20mm	2	7500	3
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFF80-403-22BLK	Front Anti Roll Bar Mount 22mm	22mm	2	7500	3
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFF80-403-24BLK	Front Anti Roll Bar Mount 24mm	24mm	2	7500	3
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFF80-408BLK	Front Anti Roll Bar Mounting Bolt Bushes		2	8000	4
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFF80-409-22BLK	Front Anti Roll Bar Eye Bolt Bush 22mm	22mm	2	7500	5
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFF80-409-24BLK	Front Anti Roll Bar Eye Bolt Bush 24mm	24mm	2	7500	5
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFR80-412BLK	Rear Beam Mounting Bush	59.8mm OD	2	13000	7
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFR80-415-15BLK	Rear Anti Roll Bar Mount (inner) 15mm	15mm	2	7500	8
Vauxhall / Opel	Cavalier 2WD (1989-1995), Vectra A (1989-1995)	PFR80-415-18BLK	Rear Anti Roll Bar Mount (inner) 18mm	18mm	2	7500	8
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFF80-401BLK	Front Wishbone Inner Bush (Front)		2	11000	1
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFF80-402BLK	Front Wishbone Inner Bush (Rear)		2	11000	2
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFF80-403-20BLK	Front Anti Roll Bar Mount 20mm	20mm	2	7500	3
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFF80-403-22BLK	Front Anti Roll Bar Mount 22mm	22mm	2	7500	3
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFF80-403-24BLK	Front Anti Roll Bar Mount 24mm	24mm	2	7500	3
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFF80-408BLK	Front Anti Roll Bar Mounting Bolt Bushes		2	8000	4
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFF80-409-22BLK	Front Anti Roll Bar Eye Bolt Bush 22mm	22mm	2	7500	5
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFF80-409-24BLK	Front Anti Roll Bar Eye Bolt Bush 24mm	24mm	2	7500	5
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFR80-415-15BLK	Rear Anti Roll Bar Mount (inner) 15mm	15mm	2	7500	7
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFR80-415-18BLK	Rear Anti Roll Bar Mount (inner) 18mm	18mm	2	7500	7
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFR80-440BLK	Rear Trailing Arm Bush		2	11500	6
Vauxhall / Opel	Cavalier/Calibra 4WD inc GSi with independent rear sus, Vectra A (1989-1995)	PFR80-440MLK-BLK	Rear Trailing Arm Bush		2	10500	6
Vauxhall / Opel	Corsa A (1983-1993)	BS2002K	Bump Stop Kit	Front	1	10000	
Vauxhall / Opel	Corsa A (1983-1993)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Corsa A (1983-1993)	PFF80-101BLK	Front Wishbone Inner Bush (front)		2	11000	1
Vauxhall / Opel	Corsa A (1983-1993)	PFF80-102BLK	Front Tie Bar To Chassis Bush		2	10500	2
Vauxhall / Opel	Corsa A (1983-1993)	PFF80-105-20BLK	Front Anti Roll Bar Mount	20mm	4	14000	3
Vauxhall / Opel	Corsa A (1983-1993)	PFR80-112BLK	Rear Beam Mounting Bush		2	13000	5
Vauxhall / Opel	Corsa B (1993-1997)	BS2002K	Bump Stop Kit	Front	1	10000	
Vauxhall / Opel	Corsa B (1993-1997)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Corsa B (1993-1997)	PFF80-201BLK	Front Wishbone Inner Bush		2	11000	1
Vauxhall / Opel	Corsa B (1993-1997)	PFF80-203BLK	Front Tie Bar To Chassis		2	11000	2
Vauxhall / Opel	Corsa B (1993-1997)	PFF80-205BLK	Front Anti Roll Bar Mounts		4	15000	3
Vauxhall / Opel	Corsa B (1993-1997)	PFR80-112BLK	Rear Beam Mounting Bush		2	13000	5
Vauxhall / Opel	Corsa B (1998-2000)	BS2002K	Bump Stop Kit	Front	1	10000	
Vauxhall / Opel	Corsa B (1998-2000)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Corsa B (1998-2000)	PFF80-201BLK	Front Wishbone Inner Bush		2	11000	1
Vauxhall / Opel	Corsa B (1998-2000)	PFF80-204BLK	Front Tie Bar To Chassis		2	11000	2
Vauxhall / Opel	Corsa B (1998-2000)	PFF80-205BLK	Front Anti Roll Bar Mounts		4	15000	3
Vauxhall / Opel	Corsa B (1998-2000)	PFR80-112BLK	Rear Beam Mounting Bush		2	13000	5
Vauxhall / Opel	Corsa C (2000-2006)	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1	2250	
Vauxhall / Opel	Corsa C (2000-2006)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Corsa C (2000-2006)	PFF80-1001BLK	Front Wishbone Rear Bush		2	15500	1
Vauxhall / Opel	Corsa C (2000-2006)	PFF80-1002BLK	Front Wishbone Front Bush		2	12000	2
Vauxhall / Opel	Corsa C (2000-2006)	PFF80-1003-17BLK	Front Anti Roll Bar Bush 17mm	17mm	2	7500	3
Vauxhall / Opel	Corsa C (2000-2006)	PFF80-1003-18BLK	Front Anti Roll Bar Bush 18mm	18mm	2	7500	3
Vauxhall / Opel	Corsa C (2000-2006)	PFF80-1030BLK	Gearbox Mount Insert		1	7500	30
Vauxhall / Opel	Corsa C (2000-2006)	PFF80-1031BLK	Engine Mount Insert Right Side		1	6750	31
Vauxhall / Opel	Corsa C (2000-2006)	PFF80-1032BLK	Rear Lower Engine Mount Rear Bush		1	7500	32

Vauxhall / Opel	Corsa C (2000-2006)	PFF80-1034BLK	Rear Lower Engine Mount Front Bush		1	8000	34
Vauxhall / Opel	Corsa C (2000-2006)	PFF80-1035BLK	Front Lower Engine Mount Bush		1	12500	35
Vauxhall / Opel	Corsa C (2000-2006)	PFR80-1005BLK	Rear Beam Mounting Bush		2	18000	5
Vauxhall / Opel	Corsa D (2006-2014)Corsa D	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Corsa D (2006-2014)Corsa D	PFF80-1101BLK	Front Arm Front Bush		2	12000	1
Vauxhall / Opel	Corsa D (2006-2014)Corsa D	PFF80-1102BLK	Front Arm Rear Bush		2	36500	2
Vauxhall / Opel	Corsa D (2006-2014)Corsa D	PFF80-1103-19BLK	Front Anti Roll Bar Bush 19mm	19mm	2	9500	3
Vauxhall / Opel	Corsa D (2006-2014)Corsa D	PFF80-1103-20BLK	Front Anti Roll Bar Bush 20mm	20mm	2	9500	3
Vauxhall / Opel	Corsa D (2006-2014)Corsa D	PFF80-1103-21BLK	Front Anti Roll Bar Bush 21mm	21mm	2	9500	3
Vauxhall / Opel	Corsa D (2006-2014)Corsa D	PFF80-1120BLK	Lower Rear Engine Mount Insert		1	6000	20
Vauxhall / Opel	Corsa D (2006-2014)Corsa D	PFR80-1110BLK	Rear Beam Mounting Bush		2	18000	10
Vauxhall / Opel	Corsa D (2006-2014)VXR	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Corsa D (2006-2014)VXR	PFF80-1101BLK	Front Arm Front Bush		2	12000	1
Vauxhall / Opel	Corsa D (2006-2014)VXR	PFF80-1102BLK	Front Arm Rear Bush		2	36500	2
Vauxhall / Opel	Corsa D (2006-2014)VXR	PFF80-1103-19BLK	Front Anti Roll Bar Bush 19mm	19mm	2	9500	3
Vauxhall / Opel	Corsa D (2006-2014)VXR	PFF80-1103-20BLK	Front Anti Roll Bar Bush 20mm	20mm	2	9500	3
Vauxhall / Opel	Corsa D (2006-2014)VXR	PFF80-1103-21BLK	Front Anti Roll Bar Bush 21mm	21mm	2	9500	3
Vauxhall / Opel	Corsa D (2006-2014)VXR	PFF80-1120BLK	Lower Rear Engine Mount Insert		1	6000	20
Vauxhall / Opel	Corsa D (2006-2014)VXR	PFR80-1110BLK	Rear Beam Mounting Bush		2	18000	10
Vauxhall / Opel	Manta B (1982-1988)	PFF80-303-20BLK	Front Anti Roll Bar Mounting Bush 20mm	20mm	2	7500	6
Vauxhall / Opel	Manta B (1982-1988)	PFF80-303-22BLK	Front Anti Roll Bar Mounting Bush 22mm	22mm	2	7500	6
Vauxhall / Opel	Manta B (1982-1988)	PFF80-601BLK	Front Upper Wishbone Bush		4	17000	1
Vauxhall / Opel	Manta B (1982-1988)	PFF80-602BLK	Front Lower Wishbone Front Bush		2	10500	2
Vauxhall / Opel	Manta B (1982-1988)	PFF80-603BLK	Front Lower Rear Bush		2	10500	3
Vauxhall / Opel	Manta B (1982-1988)	PFF80-604BLK	Front Subframe Rear Mounting Bush		2	9500	4
Vauxhall / Opel	Manta B (1982-1988)	PFF80-605BLK	Front Outer Roll Bar Mount		2	12000	5
Vauxhall / Opel	Manta B (1982-1988)	PFR80-607BLK	Rear Tie Bar To Chassis Bush		2	9500	7
Vauxhall / Opel	Manta B (1982-1988)	PFR80-608BLK	Rear Panhard Rod Mount		2	9500	8
Vauxhall / Opel	Manta B (1982-1988)	PFR80-609-18BLK	Rear Anti Roll Bar Mount 18mm	18mm	2	8000	9
Vauxhall / Opel	Manta B (1982-1988)	PFR80-611BLK	Rear Tie Bar To Axle Bushes		2	9500	11
Vauxhall / Opel	Manta B (1982-1988)	PFR80-611BLK	Rear Centre Prop Mount		2	9500	10
Vauxhall / Opel	Meriva (2002 - 2011)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Meriva (2002 - 2011)	PFF80-1030BLK	Gearbox Mount Insert		1	7500	30
Vauxhall / Opel	Meriva (2002 - 2011)	PFF80-1031BLK	Engine Mount Insert Right Side		1	6750	31
Vauxhall / Opel	Meriva (2002 - 2011)	PFF80-1032BLK	Rear Lower Engine Mount Rear Bush		1	7500	32
Vauxhall / Opel	Meriva (2002 - 2011)	PFF80-1034BLK	Rear Lower Engine Mount Front Bush		1	8000	34
Vauxhall / Opel	Meriva (2002 - 2011)	PFF80-1035BLK	Front Lower Engine Mount Bush		1	12500	35
Vauxhall / Opel	Meriva (2002 - 2011)	PFF80-1303-21BLK	Front Anti Roll Bar Bush 21mm (1 Piece)	21mm	2	9000	3
Vauxhall / Opel	Meriva (2002 - 2011)	PFF80-1330BLK	Lower Radiator Mount		2	6500	23
Vauxhall / Opel	Nova (1983-1993)	EXH003	Exhaust Mount	B=48mm	1	2250	
Vauxhall / Opel	Nova (1983-1993)	PFF80-101BLK	Front Wishbone Inner Bush (front)		2	11000	1
Vauxhall / Opel	Nova (1983-1993)	PFF80-102BLK	Front Tie Bar To Chassis Bush		2	10500	2
Vauxhall / Opel	Nova (1983-1993)	PFF80-105-20BLK	Front Anti Roll Bar Mount	20mm	4	14000	3
Vauxhall / Opel	Nova (1983-1993)	PFR80-112BLK	Rear Beam Mounting Bush		2	13000	5
Vauxhall / Opel	Signum (2003 - 2008)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Signum (2003 - 2008)	PFF66-503-25BLK	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	9000	3
Vauxhall / Opel	Signum (2003 - 2008)	PFF80-1201BLK	Front Lower Wishbone Front Bush		2	12500	1
Vauxhall / Opel	Signum (2003 - 2008)	PFF80-1202BLK	Front Lower Wishbone Rear Bush		2	15500	2
Vauxhall / Opel	Signum (2003 - 2008)	PFF80-1203-24BLK	Front Anti Roll Bar Mounting Bush 24mm (2 Piece)		2	10500	3
Vauxhall / Opel	Signum (2003 - 2008)	PFF80-1203-25BLK	Front Anti Roll Bar Mounting Bush 25mm (2 Piece)		2	10500	3
Vauxhall / Opel	Signum (2003 - 2008)	PFF80-1220BLK	Rear Lower Engine Mount Insert		1	6500	21
Vauxhall / Opel	Signum (2003 - 2008)	PFF80-1220BLK	Front Lower Engine Mount Insert		1	6500	20
Vauxhall / Opel	Signum (2003 - 2008)	PFF80-1221BLK	Rear Lower Engine Mount Insert (79mm Option)	79mm wide	1	6500	21
Vauxhall / Opel	Signum (2003 - 2008)	PFR66-519-19BLK	Rear Anti Roll Bar Mounting Bush 19mm	19mm	2	9000	19
Vauxhall / Opel	Signum (2003 - 2008)	PFR80-1210BLK	Rear Trailing Arm Front Bush		2	18500	10
Vauxhall / Opel	Signum (2003 - 2008)	PFR80-1211BLK	Rear Upper Arm Outer Bush	47mm	2	28500	11
Vauxhall / Opel	Signum (2003 - 2008)	PFR80-1212BLK	Rear Upper Arm Inner Bush		2	14000	12
Vauxhall / Opel	Signum (2003 - 2008)	PFR80-1213BLK	Rear Toe Arm Inner Bush		2	14000	13
Vauxhall / Opel	Signum (2003 - 2008)	PFR80-1214BLK	Rear Toe Arm Outer Bush		2	14000	14

Vauxhall / Opel	Signum (2003 - 2008)	PFR80-1215BLK	Rear Lower Arm Outer Bush		2	12500	15
Vauxhall / Opel	Signum (2003 - 2008)	PFR80-1216BLK	Rear Lower Arm Inner Bush		2	16000	16
Vauxhall / Opel	Signum (2003 - 2008)	PFR80-1217BLK	Rear Upper Arm Outer Bush, 38mm	38mm	2	13500	11
Vauxhall / Opel	Tigra (1993-2001)	BS2002K	Bump Stop Kit	Front	1	10000	
Vauxhall / Opel	Tigra (1993-2001)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Tigra (1993-2001)	PFF80-201BLK	Front Wishbone Inner Bush		2	11000	1
Vauxhall / Opel	Tigra (1993-2001)	PFF80-203BLK	Front Tie Bar To Chassis		2	11000	2
Vauxhall / Opel	Tigra (1993-2001)	PFF80-204BLK	Front Tie Bar To Chassis		2	11000	2
Vauxhall / Opel	Tigra (1993-2001)	PFF80-205BLK	Front Anti Roll Bar Mounts		4	15000	3
Vauxhall / Opel	Tigra (1993-2001)	PFR80-112BLK	Rear Beam Mounting Bush		2	13000	5
Vauxhall / Opel	Tigra Twin Top (2004-)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Tigra Twin Top (2004-)	PFF80-1001BLK	Front Arm Rear Bush		2	15500	1
Vauxhall / Opel	Tigra Twin Top (2004-)	PFF80-1003-17BLK	Front Anti Roll Bar Bush 17mm	17mm	2	7500	3
Vauxhall / Opel	Tigra Twin Top (2004-)	PFF80-1003-18BLK	Front Anti Roll Bar Mounting Bush 18mm	18mm	2	7500	3
Vauxhall / Opel	Tigra Twin Top (2004-)	PFR80-1005BLK	Rear Beam Mounting Bush		2	18000	5
Vauxhall / Opel	Vectra B (1995 - 2002)	EXH002	Exhaust Mounts		1	2250	
Vauxhall / Opel	Vectra B (1995 - 2002)	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1	2250	
Vauxhall / Opel	Vectra B (1995 - 2002)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Vectra B (1995 - 2002)	PFF80-303-18BLK	Front Anti Roll Bar Mounting Bush 18mm	18mm	2	8000	3
Vauxhall / Opel	Vectra B (1995 - 2002)	PFF80-303-19.5BLK	Front Anti Roll Bar Mounting Bush 19.5mm	19.5mm	2	8000	3
Vauxhall / Opel	Vectra B (1995 - 2002)	PFF80-303-19BLK	Front Anti Roll Bar Mounting Bush 19mm	19mm	2	8000	3
Vauxhall / Opel	Vectra B (1995 - 2002)	PFF80-303-20BLK	Front Anti Roll Bar Mounting Bush 20mm	20mm	2	7500	3
Vauxhall / Opel	Vectra B (1995 - 2002)	PFF80-303-22BLK	Front Anti Roll Bar Mounting Bush 22mm	22mm	2	7500	3
Vauxhall / Opel	Vectra B (1995 - 2002)	PFF80-501BLK	Front Lower Wishbone Front Bush		2	9500	1
Vauxhall / Opel	Vectra B (1995 - 2002)	PFF80-502BLK	Front Lower Wishbone Rear Bush		2	11000	2
Vauxhall / Opel	Vectra B (1995 - 2002)	PFR66-110BLK	Rear Trailing Arm Bush		2	13500	4
Vauxhall / Opel	Vectra B (1995 - 2002)	PFR66-210-16BLK	Rear Anti Roll Bar Mounting Bush 16mm	16mm	2	7500	5
Vauxhall / Opel	Vectra B (1995 - 2002)	PFR66-210-17BLK	Rear Anti Roll Bar Mounting Bush 17mm	17mm	2	7500	5
Vauxhall / Opel	Vectra C (2002-2008)	EXH016	Universal Exhaust Mount	A=56mm B=38mm	1	2250	
Vauxhall / Opel	Vectra C (2002-2008)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Vectra C (2002-2008)	PFF66-503-25BLK	Front Anti Roll Bar Mounting Bush 25mm	25mm	2	9000	3
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1201BLK	Front Lower Wishbone Front Bush		2	12500	1
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1202BLK	Front Lower Wishbone Rear Bush		2	15500	2
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1203-24BLK	Front Anti Roll Bar Mounting Bush 24mm (2 Piece)		2	10500	3
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1203-25BLK	Front Anti Roll Bar Mounting Bush 25mm (2 Piece)		2	10500	3
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1220BLK	Rear Lower Engine Mount Insert		1	6500	21
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1220BLK	Front Lower Engine Mount Insert		1	6500	20
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1221BLK	Rear Lower Engine Mount Insert (79mm Option)	79mm wide	1	6500	21
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1230BLK	Front Subframe Front Bush		2	20000	30
Vauxhall / Opel	Vectra C (2002-2008)	PFF80-1231BLK	Front Subframe Rear Bush		2	20000	31
Vauxhall / Opel	Vectra C (2002-2008)	PFR66-519-19BLK	Rear Anti Roll Bar Mounting Bush 19mm	19mm	2	9000	19
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1210BLK	Rear Trailing Arm Front Bush		2	18500	10
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1211BLK	Rear Upper Arm Outer Bush	47mm	2	28500	11
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1212BLK	Rear Upper Arm Inner Bush		2	14000	12
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1213BLK	Rear Toe Arm Inner Bush		2	14000	13
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1214BLK	Rear Toe Arm Outer Bush		2	14000	14
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1215BLK	Rear Lower Arm Outer Bush		2	12500	15
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1216BLK	Rear Lower Arm Inner Bush		2	16000	16
Vauxhall / Opel	Vectra C (2002-2008)	PFR80-1217BLK	Rear Upper Arm Outer Bush, 38mm	38mm	2	13500	11
Vauxhall / Opel	VX220 (Opel Speedster)	PF34-1001BLK	Front and Rear Wishbone Bush		14	70000	1
Vauxhall / Opel	VX220 (Opel Speedster)	PF34-202BLK	Inner Rear Wishbone Bushes		2	9500	2
Vauxhall / Opel	VX220 (Opel Speedster)	PFF34-203-19BLK	Front Anti Roll Bar Bush 19mm	19mm	2	7000	3
Vauxhall / Opel	VX220 (Opel Speedster)	PFF34-203-22.2BLK	Front Anti Roll Bar Bush 22.2mm	22.2mm	2	7000	3
Vauxhall / Opel	VX220 (Opel Speedster)	PFF34-203-25.4BLK	Front Anti Roll Bar Bush 25.4mm	25.4mm	2	7000	3
Vauxhall / Opel	VX220 (Opel Speedster)	PFF80-810BLK	Lower Engine Mount Insert Kit		2	12000	20
Vauxhall / Opel	VX220 (Opel Speedster)	PFR34-1002BLK	Rear Lower Wishbone Front Bush		2	11000	2
Vauxhall / Opel	Zafira A (1999-2004)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Zafira A (1999-2004)	PFF80-1321BLK	Gearbox Mount Insert		1	6750	21
Vauxhall / Opel	Zafira A (1999-2004)	PFF80-1322BLK	Upper Right Engine Mounting Insert Diesel		1	5750	22

Vauxhall / Opel	Zafira A (1999-2004)	PFF80-1323BLK	Upper Right Engine Mounting Insert Petrol		1	5750	22
Vauxhall / Opel	Zafira A (1999-2004)	PFF80-801BLK	Front Wishbone Front Bush		2	11500	1
Vauxhall / Opel	Zafira A (1999-2004)	PFF80-802BLK	Front Wishbone Rear Bush		2	11000	2
Vauxhall / Opel	Zafira A (1999-2004)	PFF80-810BLK	Front Lower Engine Mount Insert Kit		1	6000	20
Vauxhall / Opel	Zafira A (1999-2004)	PFF80-830BLK	Front Subframe Bush		6	33000	30
Vauxhall / Opel	Zafira A (1999-2004)	PFR80-815BLK	Rear Beam Mounting Bush	60mm	2	18000	5
Vauxhall / Opel	Zafira B (2005-2011)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-1203-24BLK	Front Anti Roll Bar Mounting Bush 24mm (2 Piece)		2	10500	3
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-1203-25BLK	Front Anti Roll Bar Mounting Bush 25mm (2 Piece)		2	10500	3
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-1320BLK	Front Lower Engine Mount Insert Petrol		1	6000	20
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-1321BLK	Gearbox Mount Insert		1	6750	21
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-1322BLK	Upper Right Engine Mounting Insert Diesel		1	5750	22
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-1323BLK	Upper Right Engine Mounting Insert Petrol		1	5750	22
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-1324BLK	Front Lower Engine Mount Insert Diesel		1	6000	20
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-1330BLK	Lower Radiator Mount		2	6500	23
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-801BLK	Front Wishbone Front Bush		2	11500	1
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-802BLK	Front Wishbone Rear Bush		2	11000	2
Vauxhall / Opel	Zafira B (2005-2011)	PFF80-830BLK	Front Subframe Bush		6	33000	30
Vauxhall / Opel	Zafira B (2005-2011)	PFR80-1310BLK	Rear beam Mounting Bush		2	22500	5