

Make	Model	Variants	Part Number	Product Description	Bush Size	定価(税別)	SET入数	図面番号
Volkswagen	Bora (1997-2006)	Bora 2WD (1997 - 2006)	BS2006K	Bump Stop Kit	Rear	6250	1	
Volkswagen	Bora (1997-2006)	Bora 2WD (1997 - 2006)	PFF85-201	Front Wishbone Front Bush		8580	2	1
Volkswagen	Bora (1997-2006)	Bora 2WD (1997 - 2006)	PFF85-410	Front Wishbone Rear Bush		9680	2	2
Volkswagen	Bora (1997-2006)	Bora 2WD (1997 - 2006)	PFF85-411-19	Front Anti Roll Bar Mount 19mm	19mm	7500	2	3
Volkswagen	Bora (1997-2006)	Bora 2WD (1997 - 2006)	PFF85-411-21	Front Anti Roll Bar Mount 21mm	21mm	7500	2	3
Volkswagen	Bora (1997-2006)	Bora 2WD (1997 - 2006)	PFF85-411-23	Front Anti Roll Bar Mount 23mm	23mm	7500	2	3
Volkswagen	Bora (1997-2006)	Bora 2WD (1997 - 2006)	PFF85-412	Front Anti Roll Bar Link Bush Kit		9500	2	4
Volkswagen	Bora (1997-2006)	Bora 2WD (1997 - 2006)	PFF85-414	Front Wishbone Rear Bush (Motorsport Use)		28160	2	2
Volkswagen	Bora (1997-2006)	Bora 2WD (1997 - 2006)	PFF85-416	Steering Rack Mount Bush		3000	1	7
Volkswagen	Bora (1997-2006)	Bora 2WD (1997 - 2006)	PFF85-420	Front Engine Mount Dog Bone		5000	1	8
Volkswagen	Bora (1997-2006)	Bora 2WD (1997 - 2006)	PFF85-420R	Front Engine Mount Dog Bone (Diesel)		5500	1	8
Volkswagen	Bora (1997-2006)	Bora 2WD (1997 - 2006)	PFF85-430	Front Strut Top Mount Bush		8800	2	11
Volkswagen	Bora (1997-2006)	Bora 2WD (1997 - 2006)	PFF85-505	Front Engine Mount Dog Bone Small Bush		5000	1	9
Volkswagen	Bora (1997-2006)	Bora 2WD (1997 - 2006)	PFR85-415	Rear Beam Mounting Bush		12760	2	5
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	BS2006K	Bump Stop Kit	Rear	6250	1	
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFF3-501	Front Wishbone Front Bush, Cast Arm, 45mm OD	45mm	9020	2	1
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFF3-610	Front Wishbone Rear Bush R32		9680	2	2
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFF85-410	Front Wishbone Rear Bush		9680	2	2
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFF85-411-19	Front Anti Roll Bar Bush 19mm	19mm	7500	2	3
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFF85-411-21	Front Anti Roll Bar Mount	21mm	7500	2	3
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFF85-411-21	Front Anti Roll Bar Mount 21mm	21mm	7500	2	3
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFF85-411-23	Front Anti Roll Bar Mount 23mm	23mm	7500	2	3
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFF85-412	Front Anti Roll Bar Link Bush Kit		9500	2	4
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFF85-414	Front Wishbone Rear Bush (Race Use) Fits All Models		28160	2	2
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFF85-416	Steering Rack Mount Bush		3000	1	7
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFF85-420	Front Engine Mount Dog Bone		5000	1	8
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFF85-420R	Front Engine Mount Dog Bone (Diesel)		5500	1	8
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFF85-430	Front Strut Top Mount Bush		8800	2	11
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFF85-505	Front Engine Mount Dog Bone Small Bush		5000	1	9
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFF85-505	Front Engine Mount Dog Bone Small Bush		5000	1	10
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFR3-508	Rear Wishbone Front Mounting Bush		9900	2	9
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFR3-510	Rear Wishbone Inner Bush		17820	4	5
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFR3-511-13	Rear Anti Roll Bar Mounting 13mm	13mm	7500	2	6
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFR3-511-14	Rear Anti Roll Bar Mounting 14mm	14mm	7500	2	6
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFR3-511-15	Rear Anti Roll Bar Mounting 15mm	15mm	7500	2	6
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFR3-511-16	Rear Anti Roll Bar Mounting 16mm	16mm	7500	2	6
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFR3-511-19	Rear Anti Roll Bar Mounting 19mm	19mm	7500	2	6
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFR85-425	Rear Diff Front Mounting Bush		10120	2	25
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFR85-426	Rear Diff Rear Mounting Bush		10120	2	26
Volkswagen	Bora (1997-2006)	Bora 4 Motion (1999-2005)	PFR85-427	Rear Subframe Mounting Bush		22000	4	27
Volkswagen	Corrado (1989 - 1995)		BS006	Bump Stop Front		5500	2	
Volkswagen	Corrado (1989 - 1995)		BS008	Bump Stop Rear		5500	2	
Volkswagen	Corrado (1989 - 1995)		EXH006	Exhaust Mounts		1500	1	
Volkswagen	Corrado (1989 - 1995)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Volkswagen	Corrado (1989 - 1995)		PFF85-201	Front Wishbone Front Bush		8580	2	1
Volkswagen	Corrado (1989 - 1995)		PFF85-203	Front Wishbone Rear Bush		8360	2	2
Volkswagen	Corrado (1989 - 1995)		PFF85-204	Front Wishbone Rear Bush, VR6 Models		8360	2	2
Volkswagen	Corrado (1989 - 1995)		PFF85-205	Front Anti Roll Bar Mount 18mm	18mm	7500	2	3
Volkswagen	Corrado (1989 - 1995)		PFF85-205-20	Front Anti Roll Bar Bush 20mm	20mm	7500	2	3
Volkswagen	Corrado (1989 - 1995)		PFF85-208	Front Eye Bolt Mounting Bush		6160	2	4
Volkswagen	Corrado (1989 - 1995)		PFF85-208-10	Front Eye Bolt Mounting Bush 10mm	10mm	6160	2	4
Volkswagen	Corrado (1989 - 1995)		PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	7250	2	5
Volkswagen	Corrado (1989 - 1995)		PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	7250	2	5
Volkswagen	Corrado (1989 - 1995)		PFF85-232	Power Steering Rack Mount		3000	1	9
Volkswagen	Corrado (1989 - 1995)		PFF85-233	Power Steering Rack Mount	15mm wide bracket	3000	1	9
Volkswagen	Corrado (1989 - 1995)		PFF85-239	Front Strut, Top Mount		10120	2	11
Volkswagen	Corrado (1989 - 1995)		PFF85-250	Front Subframe Mounts		6600	4	6
Volkswagen	Corrado (1989 - 1995)		PFR85-206	Rear Beam Mounting Bush		12760	2	7
Volkswagen	Corrado (1989 - 1995)		PFR85-207	Rear Beam Mounting Bush		12760	2	7
Volkswagen	Corrado (1989 - 1995)		PFR85-240	Rear Shock Top Mounting Bush		6160	2	8

Volkswagen	Eos 1F (2006-)		PFF85-501	Front Wishbone Front Bush		9240	2	1
Volkswagen	Eos 1F (2006-)		PFF85-501G	Front Wishbone Front Bush Camber Adjustable		19800	2	1
Volkswagen	Eos 1F (2006-)		PFF85-502	Front Wishbone Rear Bush		11880	2	2
Volkswagen	Eos 1F (2006-)		PFF85-502G	Front Wishbone Rear Bush Anti-Lift & Caster Adjust		24200	2	2
Volkswagen	Eos 1F (2006-)		PFF85-503-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	7500	2	3
Volkswagen	Eos 1F (2006-)		PFF85-503-23	Front Anti Roll Bar Bush 23mm	23mm	7500	2	3
Volkswagen	Eos 1F (2006-)		PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	7500	2	3
Volkswagen	Eos 1F (2006-)		PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	7500	2	3
Volkswagen	Eos 1F (2006-)		PFF85-504	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Eos 1F (2006-)		PFF85-504P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Eos 1F (2006-)		PFF85-504R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Eos 1F (2006-)		PFF85-505	Lower Engine Mount Small Bush		5000	1	5
Volkswagen	Eos 1F (2006-)		PFF85-704	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Eos 1F (2006-)		PFF85-704P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Eos 1F (2006-)		PFF85-704R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Eos 1F (2006-)		PFR85-508	Rear Tie Bar to Chassis Front Bush		8140	2	8
Volkswagen	Eos 1F (2006-)		PFR85-509	Rear Lower Spring Mount Outer		7260	2	9
Volkswagen	Eos 1F (2006-)		PFR85-510	Rear Lower Spring Mount Inner		7260	2	10
Volkswagen	Eos 1F (2006-)		PFR85-511	Rear Lower Link Outer Bush		8800	2	11
Volkswagen	Eos 1F (2006-)		PFR85-512	Rear Lower Link Inner Bush		8800	2	12
Volkswagen	Eos 1F (2006-)		PFR85-513	Rear Upper Link Outer Bush		7260	2	13
Volkswagen	Eos 1F (2006-)		PFR85-514	Rear Upper Link Inner Bush		7260	2	14
Volkswagen	Eos 1F (2006-)		PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	8250	2	15
Volkswagen	Eos 1F (2006-)		PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	8250	2	15
Volkswagen	Eos 1F (2006-)		PFR85-515-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	8250	2	15
Volkswagen	Golf MK1 (1973 - 1985)		BS2001K	Bump Stop Kit	Front	5250	1	
Volkswagen	Golf MK1 (1973 - 1985)		BS2004K	Bump Stop Kit	Rear	5250	1	
Volkswagen	Golf MK1 (1973 - 1985)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Volkswagen	Golf MK1 (1973 - 1985)		PFF85-211	Front Wishbone Inner Bush		8140	2	1
Volkswagen	Golf MK1 (1973 - 1985)		PFF85-213	Front Wishbone Rear Bush		8140	2	2
Volkswagen	Golf MK1 (1973 - 1985)		PFF85-215	Front Anti Roll Bar Outer Mount 16mm	16mm	7500	2	4
Volkswagen	Golf MK1 (1973 - 1985)		PFF85-215-22	Front Anti Roll Bar Outer Mount 22mm	22mm	7500	2	4
Volkswagen	Golf MK1 (1973 - 1985)		PFF85-216	Front Anti Roll Bar Inner Mount		7500	2	3
Volkswagen	Golf MK1 (1973 - 1985)		PFF85-229	Steering Rack Mount		3000	1	11
Volkswagen	Golf MK1 (1973 - 1985)		PFF85-230	Steering Rack Mount		3000	1	12
Volkswagen	Golf MK1 (1973 - 1985)		PFF85-235	Engine Mount Stopper Bush		4250	1	5
Volkswagen	Golf MK1 (1973 - 1985)		PFR85-220	Rear Beam Mounting Bush		9680	2	7
Volkswagen	Golf MK1 (1973 - 1985)		PFR85-225	Rear Anti Roll Bar Mount (Inner)		5750	2	8
Volkswagen	Golf MK1 (1973 - 1985)		PFR85-226	Rear Anti Roll Bar Mount (Outer) 18mm	18mm	5750	2	9
Volkswagen	Golf MK1 (1973 - 1985)		PFR85-226-20.5	Rear Anti Roll Bar Mount (Outer) 20.5mm	20.5mm	5750	2	9
Volkswagen	Golf MK1 (1973 - 1985)		PFR85-241	Rear Shock Top Mounting Bush		8800	2	20
Volkswagen	Golf MK2 (1985 - 1992)	2WD	BS006	Bump Stop Front		5500	2	
Volkswagen	Golf MK2 (1985 - 1992)	2WD	BS008	Bump Stop Rear		5500	2	
Volkswagen	Golf MK2 (1985 - 1992)	2WD	BS2001K	Bump Stop Kit	Front	5250	1	
Volkswagen	Golf MK2 (1985 - 1992)	2WD	BS2005K	Bump Stop Kit	Rear	5250	1	
Volkswagen	Golf MK2 (1985 - 1992)	2WD	EXH006	Exhaust Mounts		1500	1	
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFF85-201	Front Wishbone Front Bush		8580	2	1
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFF85-203	Front Wishbone Inner Bush		8360	2	2
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFF85-205	Front Anti Roll Bar Mount 18mm	18mm	7500	2	3
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFF85-205-20	Front Anti Roll Bar Bush 20mm	20mm	7500	2	3
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFF85-205-22	Front Anti Roll Bar Bush Eibach 22mm	22mm	7500	2	3
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFF85-208	Front Eye Bolt Mounting Bush		6160	2	4
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFF85-208-10	Front Eye Bolt Mounting Bush 10mm	10mm	6160	2	4
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	7250	2	5
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	7250	2	5
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFF85-210-22	Front Anti Roll Bar Eye Bolt Bush Eibach 22mm	22mm	7250	2	5
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFF85-231	Non Power Steering Rack Mount		5060	2	9
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFF85-232	Power Steering Rack Mount	18.5mm wide bracket	3000	1	9
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFF85-233	Power Steering Rack Mount	15mm wide bracket	3000	1	9
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFF85-244	Rear Lower Engine Mount Bush		11500	1	20
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFF85-244R	Rear Lower Engine Mount Bush, Diesel		11500	1	20
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFF85-245	Rear Lower Engine Mount Insert		5250	1	20
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFF85-245R	Rear Lower Engine Mount Insert, Diesel		5250	1	20
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFF85-250	Front Subframe Mounts		6600	4	6
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFR85-207	Rear Beam Mounting Bush		12760	2	7
Volkswagen	Golf MK2 (1985 - 1992)	2WD	PFR85-240	Rear Shock Top Mounting Bush		6160	2	8

Volkswagen	Golf MK2 (1985 – 1992)	4WD	BS006	Bump Stop Front		5500	2	
Volkswagen	Golf MK2 (1985 – 1992)	4WD	BS2001K	Bump Stop Kit	Front	5250	1	
Volkswagen	Golf MK2 (1985 – 1992)	4WD	EXH006	Exhaust Mounts		1500	1	
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFF85-201	Front Wishbone Front Bush		8580	2	1
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFF85-205	Front Anti Roll Bar Mount 18mm	18mm	7500	2	3
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFF85-205-20	Front Anti Roll Bar Mount 20mm	20mm	7500	2	3
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFF85-208	Front Eye Bolt Mounting Bush		6160	2	4
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFF85-208-10	Front Eye Bolt Mounting Bush 10mm	10mm	6160	2	4
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	7250	2	5
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	7250	2	5
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFF85-244	Rear Lower Engine Mount Bush		11500	1	20
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFF85-244R	Rear Lower Engine Mount Bush, Diesel		11500	1	20
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFF85-245	Rear Lower Engine Mount Insert		5250	1	20
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFF85-245R	Rear Lower Engine Mount Insert, Diesel		5250	1	20
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFF85-250	Front Subframe Mounts		6600	4	6
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFF85-265	Front Wish Bone Rear Bush		8140	2	2
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFR85-240	Rear Shock Top Mounting Bush		6160	2	11
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFR85-260	Rear Beam Mounting Bush		10340	2	8
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFR85-262	Rear Trailing Arm Bush		17380	4	7
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFR85-263	Rear Anti Roll Bar Inner Bush 18.5mm	18.5mm	5750	2	9
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFR85-263-20	Rear Anti Roll Bar Inner Bush 20mm	20mm	5750	2	9
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFR85-264	Rear Anti Roll Bar Outer Mount 18.5mm	18.5mm	5750	2	10
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFR85-264-20	Rear Anti Roll Bar Outer Mount 20mm	20mm	5750	2	10
Volkswagen	Golf MK2 (1985 – 1992)	4WD	PFR85-270	Rear Diff Rear Mounting Bush		7000	1	12
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	BS006	Bump Stop Front		5500	2	
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	BS2001K	Bump Stop Kit	Front	5250	1	
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	EXH006	Exhaust Mounts		1500	1	
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFF85-201	Front Wishbone Front Bush		8580	2	1
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFF85-205	Front Anti Roll Bar Mount 18mm	18mm	7500	2	3
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFF85-205-20	Front Anti Roll Bar Mount 20mm	20mm	7500	2	3
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFF85-208	Front Eye Bolt Mounting Bush		6160	2	4
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFF85-208-10	Front Eye Bolt Mounting Bush 10mm	10mm	6160	2	4
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	7250	2	5
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	7250	2	5
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFF85-244	Rear Lower Engine Mount Bush		11500	1	20
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFF85-244R	Rear Lower Engine Mount Bush, Diesel		11500	1	20
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFF85-245	Rear Lower Engine Mount Insert		5250	1	20
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFF85-245R	Rear Lower Engine Mount Insert, Diesel		5250	1	20
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFF85-250	Front Subframe Mounts		6600	4	6
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFF85-265	Front Wish Bone Rear Bush		8140	2	2
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFR85-240	Rear Shock Top Mounting Bush		6160	2	11
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFR85-260	Rear Beam Mounting Bush		10340	2	8
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFR85-262	Rear Trailing Arm Bush		17380	4	7
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFR85-263	Rear Anti Roll Bar Inner Bush 18.5mm	18.5mm	5750	2	9
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFR85-263-20	Rear Anti Roll Bar Inner Bush 20mm	20mm	5750	2	9
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFR85-264	Rear Anti Roll Bar Outer Mount 18.5mm	18.5mm	5750	2	10
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFR85-264-20	Rear Anti Roll Bar Outer Mount 20mm	20mm	5750	2	10
Volkswagen	Golf MK2 (1985 – 1992)	G60, Rallye, Country	PFR85-270	Rear Diff Rear Mounting Bush		7000	1	12
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	BS006	Bump Stop Front		5500	2	
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	BS008	Bump Stop Rear		5500	2	
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	BS2001K	Bump Stop Kit	Front	5250	1	
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	BS2005K	Bump Stop Kit	Rear	5250	1	
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	EXH006	Exhaust Mounts		1500	1	
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	PFF85-201	Front Wishbone Front Bush		8580	2	1
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	PFF85-204	Front Wishbone Rear Bush		8360	2	2
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	PFF85-205	Front Anti Roll Bar Mount 18mm	18mm	7500	2	3
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	PFF85-205-20	Front Anti Roll Bar Mount 20mm	20mm	7500	2	3
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	PFF85-208	Front Eye Bolt Mounting Bush		6160	2	4
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	PFF85-208-10	Front Eye Bolt Mounting Bush 10mm	10mm	6160	2	4
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	7250	2	5
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	7250	2	5
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	PFF85-231	Non Power Steering Rack Mount		5060	2	9
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	PFF85-232	Power Steering Rack Mount	18.5mm wide bracket	3000	1	9
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	PFF85-233	Power Steering Rack Mount	15mm wide bracket	3000	1	9
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	PFF85-239	Front Strut, Top Mount		10120	2	11
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	PFF85-250	Front Subframe Mounts		6600	4	6
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	PFR85-206	Rear Beam Mounting Bush		12760	2	7
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 2WD (1992 – 1998)	PFR85-240	Rear Shock Top Mounting Bush		6160	2	8

Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFF85-201	Front Wishbone Front Bush		8580	2	1
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFF85-204	Front Wishbone Rear Bush		8360	2	2
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFF85-205	Front Anti Roll Bar Mount 18mm	18mm	7500	2	3
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFF85-205-20	Front Anti Roll Bar Mount 20mm	20mm	7500	2	3
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFF85-208	Front Eye Bolt Mounting Bush		6160	2	4
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFF85-208-10	Front Eye Bolt Mounting Bush 10mm	10mm	6160	2	4
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	7250	2	5
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	7250	2	5
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFF85-232	Power Steering Rack Mount	18.5mm wide bracket	3000	1	9
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFF85-233	Power Steering Rack Mount	15mm wide bracket	3000	1	9
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFF85-239	Front Strut, Top Mount		10120	2	11
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFF85-250	Front Subframe Mounts		6600	4	6
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFR85-240	Rear Shock Top Mounting Bush		6160	2	17
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFR85-260	Rear Beam Mounting Bush		10340	2	15
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFR85-262	Rear Trailing Arm Bush		17380	4	12
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFR85-263	Rear Anti Roll Bar Inner Bush 18.5mm	18.5mm	5750	2	13
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFR85-263-20	Rear Anti Roll Bar Inner Bush 20mm	20mm	5750	2	13
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFR85-264	Rear Anti Roll Bar Outer Mount 18.5mm	18.5mm	5750	2	14
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFR85-264-20	Rear Anti Roll Bar Outer Mount 20mm	20mm	5750	2	14
Volkswagen	Golf Mk3 (1992 – 1998)	Golf Mk3 Syncro (1993 – 1997)	PFR85-270	Rear Diff Rear Mounting Bush		7000	1	16
Volkswagen	Golf MK4 (1997 – 2006)	2WD Typ 1J	PFF85-201	Front Wishbone Front Bush		8580	2	1
Volkswagen	Golf MK4 (1997 – 2006)	2WD Typ 1J	PFF85-410	Front Wishbone Rear Bush		9680	2	2
Volkswagen	Golf MK4 (1997 – 2006)	2WD Typ 1J	PFF85-411-19	Front Anti Roll Bar Mount 19mm	19mm	7500	2	3
Volkswagen	Golf MK4 (1997 – 2006)	2WD Typ 1J	PFF85-411-21	Front Anti Roll Bar Mount 21mm	21mm	7500	2	3
Volkswagen	Golf MK4 (1997 – 2006)	2WD Typ 1J	PFF85-411-23	Front Anti Roll Bar Mount 23mm	23mm	7500	2	3
Volkswagen	Golf MK4 (1997 – 2006)	2WD Typ 1J	PFF85-412	Front Anti Roll Bar Link Bush Kit		9500	2	4
Volkswagen	Golf MK4 (1997 – 2006)	2WD Typ 1J	PFF85-414	Front Wishbone Rear Bush (Motorsport Use)		28160	2	2
Volkswagen	Golf MK4 (1997 – 2006)	2WD Typ 1J	PFF85-416	Steering Rack Mount Bush		3000	1	7
Volkswagen	Golf MK4 (1997 – 2006)	2WD Typ 1J	PFF85-420	Front Engine Mount Dog Bone		5000	1	8
Volkswagen	Golf MK4 (1997 – 2006)	2WD Typ 1J	PFF85-420R	Front Engine Mount Dog Bone (Diesel)		5500	1	8
Volkswagen	Golf MK4 (1997 – 2006)	2WD Typ 1J	PFF85-430	Front Strut Top Mount Bush		8800	2	11
Volkswagen	Golf MK4 (1997 – 2006)	2WD Typ 1J	PFF85-505	Front Engine Mount Dog Bone Small Bush		5000	1	9
Volkswagen	Golf MK4 (1997 – 2006)	2WD Typ 1J	PFR85-415	Rear Beam Mounting Bush		12760	2	5
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFF3-501	Front Wishbone Front Bush, Cast Arm, 45mm OD	45mm	9020	2	1
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFF3-610	Front Wishbone Rear Bush R32		9680	2	2
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFF85-201	Front Wishbone Front Bush		8580	2	1
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFF85-410	Front Wishbone Rear Bush		9680	2	2
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFF85-411-19	Front Anti Roll Bar Bush 19mm	19mm	7500	2	3
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFF85-411-21	Front Anti Roll Bar Mount 21mm	21mm	7500	2	3
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFF85-411-23	Front Anti Roll Bar Mount 23mm	23mm	7500	2	3
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFF85-412	Front Anti Roll Bar Link Bush Kit		9500	2	4
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFF85-414	Front Wishbone Rear Bush (Race Use) Fits All Models		28160	2	2
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFF85-416	Steering Rack Mount Bush		3000	1	7
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFF85-420	Front Engine Mount Dog Bone		5000	1	8
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFF85-420R	Front Engine Mount Dog Bone (Diesel)		5500	1	8
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFF85-430	Front Strut Top Mount Bush		8800	2	11
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFF85-505	Front Engine Mount Dog Bone Small Bush		5000	1	10
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFR3-508	Rear Wishbone Front Mounting Bush		9900	2	9
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFR3-510	Rear Wishbone Inner Bush		17820	4	5
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFR3-511-13	Rear Anti Roll Bar Mounting 13mm	13mm	7500	2	6
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFR3-511-14	Rear Anti Roll Bar Mounting 14mm	14mm	7500	2	6
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFR3-511-15	Rear Anti Roll Bar Mounting 15mm	15mm	7500	2	6
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFR3-511-16	Rear Anti Roll Bar Mounting 16mm	16mm	7500	2	6
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFR3-511-19	Rear Anti Roll Bar Mounting 19mm	19mm	7500	2	6
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFR85-425	Rear Diff Front Mounting Bush		10120	2	25
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFR85-426	Rear Diff Rear Mounting Bush		10120	2	26
Volkswagen	Golf MK4 (1997 – 2006)	R32/4motion	PFR85-427	Rear Subframe Mounting Bush		22000	4	27

Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	BS2006K	Bump Stop Kit	Rear	6250	1	
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFF85-501	Front Wishbone Front Bush		9240	2	1
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		19800	2	1
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFF85-502	Front Wishbone Rear Bush		11880	2	2
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFF85-502G	Front Wishbone Rear Bush Anti-Lift & Caster Adjust		24200	2	2
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFF85-503-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	7500	2	3
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	7500	2	3
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	7500	2	3
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFF85-504	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFF85-504P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFF85-504R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFF85-505	Lower Engine Mount Small Bush		5000	1	5
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFF85-704	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFF85-704P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFF85-704R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFR85-508	Rear Tie Bar to Chassis Front Bush		8140	2	8
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFR85-509	Rear Lower Spring Mount Outer		7260	2	9
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFR85-510	Rear Lower Spring Mount Inner		7260	2	10
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFR85-511	Rear Lower Link Outer Bush		8800	2	11
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFR85-512	Rear Lower Link Inner Bush		8800	2	12
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFR85-513	Rear Upper Link Outer Bush		7260	2	13
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFR85-514	Rear Upper Link Inner Bush		7260	2	14
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFR85-515-18.5	Rear Anti Roll Bar Bush 18.5mm	18.5mm	8250	2	15
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFR85-515-19.6	Rear Anti Roll Bar Bush 19.6mm	19.6mm	8250	2	15
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	8250	2	15
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	8250	2	15
Volkswagen	Golf MK5 (2003 - 2009)	Golf MK5 1K	PFR85-515-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	8250	2	15
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFF85-501	Front Wishbone Front Bush		9240	2	1
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		19800	2	1
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFF85-502	Front Wishbone Rear Bush		11880	2	2
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFF85-502G	Front Wishbone Rear Bush Anti-Lift & Caster Adjust		24200	2	2
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFF85-503-23	Front Anti Roll Bar Bush 23mm	23mm	7500	2	3
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	7500	2	3
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	7500	2	3
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFF85-504	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFF85-504P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFF85-504R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFF85-505	Lower Engine Mount Small Bush		5000	1	5
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFF85-704	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFF85-704P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFF85-704R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFR85-508	Rear Tie Bar to Chassis Front Bush		8140	2	8
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFR85-509	Rear Lower Spring Mount Outer		7260	2	9
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFR85-510	Rear Lower Spring Mount Inner		7260	2	10
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFR85-511	Rear Lower Link Outer Bush		8800	2	11
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFR85-512	Rear Lower Link Inner Bush		8800	2	12
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFR85-513	Rear Upper Link Outer Bush		7260	2	13
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFR85-514	Rear Upper Link Inner Bush		7260	2	14
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	8250	2	15
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	8250	2	15
Volkswagen	Golf MK5 (2003 - 2009)	Golf Plus 5M	PFR85-515-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	8250	2	15

Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFF85-501	Front Wishbone Front Bush		9240	2	1
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		19800	2	1
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFF85-502	Front Wishbone Rear Bush		11880	2	2
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFF85-502G	Front Wishbone Rear Bush Anti-Lift & Caster Adjust		24200	2	2
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFF85-503-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	7500	2	3
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	7500	2	3
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	7500	2	3
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFF85-504	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFF85-504P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFF85-504R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFF85-505	Lower Engine Mount Small Bush		5000	1	5
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFF85-704	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFF85-704P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFF85-704R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFR85-508	Rear Tie Bar to Chassis Front Bush		8140	2	8
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFR85-509	Rear Lower Spring Mount Outer		7260	2	9
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFR85-510	Rear Lower Spring Mount Inner		7260	2	10
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFR85-511	Rear Lower Link Outer Bush		8800	2	11
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFR85-512	Rear Lower Link Inner Bush		8800	2	12
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFR85-513	Rear Upper Link Outer Bush		7260	2	13
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFR85-514	Rear Upper Link Inner Bush		7260	2	14
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFR85-515-18.5	Rear Anti Roll Bar Bush 18.5mm	18.5mm	8250	2	15
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFR85-515-19.6	Rear Anti Roll Bar Bush 19.6mm	19.6mm	8250	2	15
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	8250	2	15
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	8250	2	15
Volkswagen	Golf MK5 (2003 - 2009)	GTI & R32	PFR85-515-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	8250	2	15
Volkswagen	Golf MK6 5K (2009-2011)		PFF85-501	Front Wishbone Front Bush		9240	2	1
Volkswagen	Golf MK6 5K (2009-2011)		PFF85-501G	Front Wishbone Front Bush Camber Adjustable		19800	2	1
Volkswagen	Golf MK6 5K (2009-2011)		PFF85-502	Front Wishbone Rear Bush		11880	2	2
Volkswagen	Golf MK6 5K (2009-2011)		PFF85-502G	Front Wishbone Rear Bush Anti-Lift & Caster Adjust		24200	2	2
Volkswagen	Golf MK6 5K (2009-2011)		PFF85-503-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	7500	2	3
Volkswagen	Golf MK6 5K (2009-2011)		PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	7500	2	3
Volkswagen	Golf MK6 5K (2009-2011)		PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	7500	2	3
Volkswagen	Golf MK6 5K (2009-2011)		PFF85-504	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Golf MK6 5K (2009-2011)		PFF85-504P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Golf MK6 5K (2009-2011)		PFF85-504R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Golf MK6 5K (2009-2011)		PFF85-505	Lower Engine Mount Small Bush		5000	1	5
Volkswagen	Golf MK6 5K (2009-2011)		PFF85-704	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Golf MK6 5K (2009-2011)		PFF85-704P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Golf MK6 5K (2009-2011)		PFF85-704R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Golf MK6 5K (2009-2011)		PFR85-508	Rear Tie Bar to Chassis Front Bush		8140	2	8
Volkswagen	Golf MK6 5K (2009-2011)		PFR85-509	Rear Lower Spring Mount Outer		7260	2	9
Volkswagen	Golf MK6 5K (2009-2011)		PFR85-510	Rear Lower Spring Mount Inner		7260	2	10
Volkswagen	Golf MK6 5K (2009-2011)		PFR85-511	Rear Lower Link Outer Bush		8800	2	11
Volkswagen	Golf MK6 5K (2009-2011)		PFR85-512	Rear Lower Link Inner Bush		8800	2	12
Volkswagen	Golf MK6 5K (2009-2011)		PFR85-513	Rear Upper Link Outer Bush		7260	2	13
Volkswagen	Golf MK6 5K (2009-2011)		PFR85-514	Rear Upper Link Inner Bush		7260	2	14
Volkswagen	Golf MK6 5K (2009-2011)		PFR85-515-18.5	Rear Anti Roll Bar Bush 18.5mm	18.5mm	8250	2	15
Volkswagen	Golf MK6 5K (2009-2011)		PFR85-515-19.6	Rear Anti Roll Bar Bush 19.6mm	19.6mm	8250	2	15
Volkswagen	Golf MK6 5K (2009-2011)		PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	8250	2	15
Volkswagen	Golf MK6 5K (2009-2011)		PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	8250	2	15
Volkswagen	Golf MK6 5K (2009-2011)		PFR85-515-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	8250	2	15
Volkswagen	Iltis (1978 - 1988)		PFR85-1020 KIT2	Mounting Bush Kit Of 2		13250	1	22
Volkswagen	Iltis (1978 - 1988)		PFR85-1020 KIT2	Mounting Bush Kit Of 2		13250	1	22
Volkswagen	Iltis (1978 - 1988)		PFR85-1020 KIT3	Diff Mounting Bush Kit Of 3		20000	1	21

Volkswagen	Jetta MK1 (1979 - 1984)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Volkswagen	Jetta MK1 (1979 - 1984)	PFF85-211	Front Wishbone Inner Bush		8140	2	1
Volkswagen	Jetta MK1 (1979 - 1984)	PFF85-213	Front Wishbone Rear Bush		8140	2	2
Volkswagen	Jetta MK1 (1979 - 1984)	PFF85-215	Front Anti Roll Bar Outer Mount 16mm	16mm	7500	2	4
Volkswagen	Jetta MK1 (1979 - 1984)	PFF85-215-22	Front Anti Roll Bar Outer Mount 22mm	22mm	7500	2	4
Volkswagen	Jetta MK1 (1979 - 1984)	PFF85-216	Front Anti Roll Bar Inner Mount		7500	2	3
Volkswagen	Jetta MK1 (1979 - 1984)	PFF85-229	Steering Rack Mount		3000	1	11
Volkswagen	Jetta MK1 (1979 - 1984)	PFF85-230	Steering Rack Mount		3000	1	12
Volkswagen	Jetta MK1 (1979 - 1984)	PFF85-235	Engine Mount Stopper Bush		4250	1	5
Volkswagen	Jetta MK1 (1979 - 1984)	PFR85-220	Rear Beam Mounting Bush		9680	2	7
Volkswagen	Jetta MK1 (1979 - 1984)	PFR85-225	Rear Anti Roll Bar Mount (Inner)		5750	2	8
Volkswagen	Jetta MK1 (1979 - 1984)	PFR85-226	Rear Anti Roll Bar Mount (Outer) 18mm	18mm	5750	2	9
Volkswagen	Jetta MK1 (1979 - 1984)	PFR85-226-20.5	Rear Anti Roll Bar Mount (Outer) 20.5mm	20.5mm	5750	2	9
Volkswagen	Jetta MK1 (1979 - 1984)	PFR85-241	Rear Shock Top Mounting Bush		8800	2	20
Volkswagen	Jetta MK2 (1985 - 1992)	BS006	Bump Stop Front		5500	2	
Volkswagen	Jetta MK2 (1985 - 1992)	BS008	Bump Stop Rear		5500	2	
Volkswagen	Jetta MK2 (1985 - 1992)	BS2001K	Bump Stop Kit	Front	5250	1	
Volkswagen	Jetta MK2 (1985 - 1992)	BS2005K	Bump Stop Kit	Rear	5250	1	
Volkswagen	Jetta MK2 (1985 - 1992)	EXH006	Exhaust Mounts		1500	1	
Volkswagen	Jetta MK2 (1985 - 1992)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Volkswagen	Jetta MK2 (1985 - 1992)	PFF85-201	Front Wishbone Front Bush		8580	2	1
Volkswagen	Jetta MK2 (1985 - 1992)	PFF85-203	Front Wishbone Inner Bush (Rear)		8360	2	2
Volkswagen	Jetta MK2 (1985 - 1992)	PFF85-205	Front Anti Roll Bar Mount 18mm	18mm	7500	2	3
Volkswagen	Jetta MK2 (1985 - 1992)	PFF85-205-20	Front Anti Roll Bar Bush 20mm	20mm	7500	2	3
Volkswagen	Jetta MK2 (1985 - 1992)	PFF85-208	Front Eye Bolt Mounting Bush		6160	2	4
Volkswagen	Jetta MK2 (1985 - 1992)	PFF85-208-10	Front Eye Bolt Mounting Bush 10mm	10mm	6160	2	4
Volkswagen	Jetta MK2 (1985 - 1992)	PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	7250	2	5
Volkswagen	Jetta MK2 (1985 - 1992)	PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	7250	2	5
Volkswagen	Jetta MK2 (1985 - 1992)	PFF85-231	Non Power Steering Rack Mount		5060	2	9
Volkswagen	Jetta MK2 (1985 - 1992)	PFF85-232	Power Steering Rack Mount	18.5mm wide bracket	3000	1	9
Volkswagen	Jetta MK2 (1985 - 1992)	PFF85-233	Power Steering Rack Mount	15mm wide bracket	3000	1	9
Volkswagen	Jetta MK2 (1985 - 1992)	PFF85-244	Rear Lower Engine Mount Bush		11500	1	20
Volkswagen	Jetta MK2 (1985 - 1992)	PFF85-244R	Rear Lower Engine Mount Bush, Diesel		11500	1	20
Volkswagen	Jetta MK2 (1985 - 1992)	PFF85-245	Rear Lower Engine Mount Insert		5250	1	20
Volkswagen	Jetta MK2 (1985 - 1992)	PFF85-245R	Rear Lower Engine Mount Insert, Diesel		5250	1	20
Volkswagen	Jetta MK2 (1985 - 1992)	PFF85-250	Front Subframe Mounts		6600	4	6
Volkswagen	Jetta MK2 (1985 - 1992)	PFR85-207	Rear Beam Mounting Bush		12760	2	7
Volkswagen	Jetta MK2 (1985 - 1992)	PFR85-240	Rear Shock Top Mounting Bush		6160	2	8
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFF85-501	Front Wishbone Front Bush		9240	2	1
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		19800	2	1
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFF85-502	Front Wishbone Rear Bush		11880	2	2
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFF85-502G	Front Wishbone Rear Bush Anti-Lift & Caster Adjust		24200	2	2
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFF85-503-19.6	Front Anti Roll Bar Bush 19.6mm	19.6mm	7500	2	3
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFF85-503-20	Front Anti Roll Bar Bush 20mm	20mm	7500	2	3
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFF85-503-20.7	Front Anti Roll Bar Bush 20.7mm	20.7mm	7500	2	3
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFF85-503-21.7	Front Anti Roll Bar Bush 21.7mm	21.7mm	7500	2	3
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFF85-503-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	7500	2	3
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFF85-503-23	Front Anti Roll Bar Bush 23mm	23mm	7500	2	3
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	7500	2	3
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	7500	2	3
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFF85-504	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFF85-504P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFF85-504R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFF85-505	Lower Engine Mount Small Bush		5000	1	5
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFF85-704	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFF85-704P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFF85-704R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFR85-508	Rear Tie Bar to Chassis Front Bush		8140	2	8
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFR85-509	Rear Lower Spring Mount Outer		7260	2	9
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFR85-510	Rear Lower Spring Mount Inner		7260	2	10
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFR85-511	Rear Lower Link Outer Bush		8800	2	11
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFR85-512	Rear Lower Link Inner Bush		8800	2	12
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFR85-513	Rear Upper Link Outer Bush		7260	2	13
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFR85-514	Rear Upper Link Inner Bush		7260	2	14
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFR85-515-18	Rear Anti Roll Bar Bush 18mm	18mm	8250	2	15
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFR85-515-18.5	Rear Anti Roll Bar Bush 18.5mm	18.5mm	8250	2	15
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFR85-515-19	Rear Anti Roll Bar Bush 19mm	19mm	8250	2	15
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFR85-515-19.6	Rear Anti Roll Bar Bush 19.6mm	19.6mm	8250	2	15
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFR85-515-20	Rear Anti Roll Bar Bush 20mm	20mm	8250	2	15
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	8250	2	15
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005年「翼」系·010)	PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	8250	2	15

Volkswagen	Lupo (1999 – 2006)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Volkswagen	Lupo (1999 – 2006)		PFF85-208-10	Front Eye Bolt Mounting Bush 10mm (M8 nut)	M10	6160	2	4
Volkswagen	Lupo (1999 – 2006)		PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	7250	2	5
Volkswagen	Lupo (1999 – 2006)		PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	7250	2	5
Volkswagen	Lupo (1999 – 2006)		PFF85-401	Front Wishbone Inner Bush (front)		7700	2	1
Volkswagen	Lupo (1999 – 2006)		PFF85-402	Front Wishbone Rear Bush		8800	2	2
Volkswagen	Lupo (1999 – 2006)		PFF85-403-18	Front Anti Roll Bar Bush 18mm	18mm	8000	2	3
Volkswagen	Lupo (1999 – 2006)		PFF85-403-20	Front Anti Roll Bar Bush 20mm	20mm	8000	2	3
Volkswagen	Lupo (1999 – 2006)		PFF85-403-22	Front Anti Roll Bar Bush 22mm	22mm	8000	2	3
Volkswagen	Lupo (1999 – 2006)		PFF85-920	Lower Engine Mount Large Bush		8250	1	6
Volkswagen	Lupo (1999 – 2006)		PFR85-615	Rear Beam Mounting Bush	58mm	12320	2	7
Volkswagen	New Beetle & Cabrio 2WD (1998-)		BS2006K	Bump Stop Kit	Rear	6250	1	
Volkswagen	New Beetle & Cabrio 2WD (1998-)		PFF85-201	Front Wishbone Front Bush		8580	2	1
Volkswagen	New Beetle & Cabrio 2WD (1998-)		PFF85-410	Front Wishbone Rear Bush		9680	2	2
Volkswagen	New Beetle & Cabrio 2WD (1998-)		PFF85-411-21	Front Anti Roll Bar Mount 21mm	21mm	7500	2	3
Volkswagen	New Beetle & Cabrio 2WD (1998-)		PFF85-411-23	Front Anti Roll Bar Mount 23mm	23mm	7500	2	3
Volkswagen	New Beetle & Cabrio 2WD (1998-)		PFF85-412	Front Anti Roll Bar Link Bush Kit		9500	2	4
Volkswagen	New Beetle & Cabrio 2WD (1998-)		PFF85-414	Front Wishbone Rear Bush (Race Use)		28160	2	2
Volkswagen	New Beetle & Cabrio 2WD (1998-)		PFF85-416	Steering Rack Mount Bush		3000	1	7
Volkswagen	New Beetle & Cabrio 2WD (1998-)		PFF85-420	Front Engine Mount Dog Bone		5000	1	8
Volkswagen	New Beetle & Cabrio 2WD (1998-)		PFF85-420R	Front Engine Mount Dog Bone (Diesel)		5500	1	8
Volkswagen	New Beetle & Cabrio 2WD (1998-)		PFF85-430	Front Strut Top Mount Bush		8800	2	11
Volkswagen	New Beetle & Cabrio 2WD (1998-)		PFF85-505	Front Engine Mount Dog Bone Small Bush		5000	1	9
Volkswagen	New Beetle & Cabrio 2WD (1998-)		PFR85-415	Rear Beam Mounting Bush		12760	2	5
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		BS2006K	Bump Stop Kit	Rear	6250	1	
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFF85-201	Front Wishbone Front Bush		8580	2	1
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFF85-410	Front Wishbone Rear Bush		9680	2	2
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFF85-411-21	Front Anti Roll Bar Mount 21mm	21mm	7500	2	3
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFF85-411-23	Front Anti Roll Bar Mount 23mm	23mm	7500	2	3
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFF85-412	Front Anti Roll Bar Link Bush Kit		9500	2	4
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFF85-414	Front Wishbone Rear Bush (Race Use)		28160	2	2
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFF85-416	Steering Rack Mount Bush		3000	1	7
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFF85-420	Front Engine Mount Dog Bone		5000	1	8
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFF85-420R	Front Engine Mount Dog Bone (Diesel)		5500	1	8
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFF85-430	Front Strut Top Mount Bush		8800	2	11
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFF85-505	Front Engine Mount Dog Bone Small Bush		5000	1	10
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFR3-508	Rear Wishbone Front Mounting Bush		9900	2	9
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFR3-510	Rear Wishbone Inner Bush		17820	4	5
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFR3-511-13	Rear Anti Roll Bar Mounting 13mm	13mm	7500	2	6
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFR3-511-14	Rear Anti Roll Bar Mounting 14mm	14mm	7500	2	6
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFR3-511-15	Rear Anti Roll Bar Mounting 15mm	15mm	7500	2	6
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFR3-511-16	Rear Anti Roll Bar Mounting 16mm	16mm	7500	2	6
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFR3-511-19	Rear Anti Roll Bar Mounting 19mm	19mm	7500	2	6
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFR85-425	Rear Diff Front Mounting Bush		10120	2	25
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFR85-426	Rear Diff Rear Mounting Bush		10120	2	26
Volkswagen	New Beetle & Cabrio 4Motion (1998-)		PFR85-427	Rear Subframe Mounting Bush		22000	4	27
Volkswagen	Passat (1988 – 1996)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Volkswagen	Passat (1988 – 1996)		PFF85-244	Rear Lower Engine Mount Bush		11500	1	20
Volkswagen	Passat (1988 – 1996)		PFF85-244R	Rear Lower Engine Mount Bush, Diesel		11500	1	20
Volkswagen	Passat (1988 – 1996)		PFF85-245	Rear Lower Engine Mount Insert		5250	1	20
Volkswagen	Passat (1988 – 1996)		PFF85-245R	Rear Lower Engine Mount Insert, Diesel		5250	1	20
Volkswagen	Passat (B5) 1996 – 2005	4 Motion (1996 – 2005)	PFF3-201	Front Lower Shock Mount		12540	2	1
Volkswagen	Passat (B5) 1996 – 2005	4 Motion (1996 – 2005)	PFF3-202	Front Tie Bar Inner Bush		18480	2	2
Volkswagen	Passat (B5) 1996 – 2005	4 Motion (1996 – 2005)	PFF3-203	Front Upper Arm To Chassis Bush		15400	4	3
Volkswagen	Passat (B5) 1996 – 2005	4 Motion (1996 – 2005)	PFF3-204-25	Front Anti Roll Bar Bush 25mm	25mm	7500	2	4
Volkswagen	Passat (B5) 1996 – 2005	4 Motion (1996 – 2005)	PFF3-204-27	Front Anti Roll Bar Bush 27mm	27mm	7500	2	4
Volkswagen	Passat (B5) 1996 – 2005	4 Motion (1996 – 2005)	PFF3-204-29	Front Anti Roll Bar Bush 29mm	29mm	7500	2	4
Volkswagen	Passat (B5) 1996 – 2005	4 Motion (1996 – 2005)	PFF3-211	Front Lower Arm Inner Bush		11220	2	11
Volkswagen	Passat (B5) 1996 – 2005	4 Motion (1996 – 2005)	PFF3-213	Front Anti Roll Bar Link Bush		17500	4	5
Volkswagen	Passat (B5) 1996 – 2005	4 Motion Estate (1996 – 2005)	PFF3-201	Front Lower Shock Mount		12540	2	1
Volkswagen	Passat (B5) 1996 – 2005	4 Motion Estate (1996 – 2005)	PFF3-202	Front Tie Bar Inner Bush		18480	2	2
Volkswagen	Passat (B5) 1996 – 2005	4 Motion Estate (1996 – 2005)	PFF3-203	Front Upper Arm To Chassis Bush		15400	4	3
Volkswagen	Passat (B5) 1996 – 2005	4 Motion Estate (1996 – 2005)	PFF3-204-25	Front Anti Roll Bar Bush 25mm	25mm	7500	2	4
Volkswagen	Passat (B5) 1996 – 2005	4 Motion Estate (1996 – 2005)	PFF3-204-27	Front Anti Roll Bar Bush 27mm	27mm	7500	2	4
Volkswagen	Passat (B5) 1996 – 2005	4 Motion Estate (1996 – 2005)	PFF3-204-29	Front Anti Roll Bar Bush 29mm	29mm	7500	2	4
Volkswagen	Passat (B5) 1996 – 2005	4 Motion Estate (1996 – 2005)	PFF3-211	Front Lower Arm Inner Bush		11220	2	11
Volkswagen	Passat (B5) 1996 – 2005	4 Motion Estate (1996 – 2005)	PFF3-213	Front Anti Roll Bar Link Bush		17500	4	5

Volkswagen	Passat (B5) 1996 – 2005	Estate (1996-2005)	BS2007K	Bump Stop Kit	Rear	8750	1	
Volkswagen	Passat (B5) 1996 – 2005	Estate (1996-2005)	PFF3-201	Front Lower Shock Mount		12540	2	1
Volkswagen	Passat (B5) 1996 – 2005	Estate (1996-2005)	PFF3-202	Front Tie Bar Inner Bush		18480	2	2
Volkswagen	Passat (B5) 1996 – 2005	Estate (1996-2005)	PFF3-203	Front Upper Arm To Chassis Bush		15400	4	3
Volkswagen	Passat (B5) 1996 – 2005	Estate (1996-2005)	PFF3-204-25	Front Anti Roll Bar Bush 25mm	25mm	7500	2	4
Volkswagen	Passat (B5) 1996 – 2005	Estate (1996-2005)	PFF3-204-27	Front Anti Roll Bar Bush 27mm	27mm	7500	2	4
Volkswagen	Passat (B5) 1996 – 2005	Estate (1996-2005)	PFF3-204-29	Front Anti Roll Bar Bush 29mm	29mm	7500	2	4
Volkswagen	Passat (B5) 1996 – 2005	Estate (1996-2005)	PFF3-211	Front Lower Arm Inner Bush		11220	2	11
Volkswagen	Passat (B5) 1996 – 2005	Estate (1996-2005)	PFF3-213	Front Anti Roll Bar Link Bush		17500	4	5
Volkswagen	Passat (B5) 1996 – 2005	Saloon (1996 – 2005)	BS2007K	Bump Stop Kit	Rear	8750	1	
Volkswagen	Passat (B5) 1996 – 2005	Saloon (1996 – 2005)	PFF3-201	Front Lower Shock Mount		12540	2	1
Volkswagen	Passat (B5) 1996 – 2005	Saloon (1996 – 2005)	PFF3-202	Front Tie Bar Inner Bush		18480	2	2
Volkswagen	Passat (B5) 1996 – 2005	Saloon (1996 – 2005)	PFF3-203	Front Upper Arm To Chassis Bush		15400	4	3
Volkswagen	Passat (B5) 1996 – 2005	Saloon (1996 – 2005)	PFF3-204-25	Front Anti Roll Bar Bush 25mm	25mm	7500	2	4
Volkswagen	Passat (B5) 1996 – 2005	Saloon (1996 – 2005)	PFF3-204-27	Front Anti Roll Bar Bush 27mm	27mm	7500	2	4
Volkswagen	Passat (B5) 1996 – 2005	Saloon (1996 – 2005)	PFF3-204-29	Front Anti Roll Bar Bush 29mm	29mm	7500	2	4
Volkswagen	Passat (B5) 1996 – 2005	Saloon (1996 – 2005)	PFF3-211	Front Lower Arm Inner Bush		11220	2	11
Volkswagen	Passat (B5) 1996 – 2005	Saloon (1996 – 2005)	PFF3-213	Front Anti Roll Bar Link Bush		17500	4	5
Volkswagen	Passat B6 Typ3C (2006-)		PFF85-501	Front Wishbone Front Bush		9240	2	1
Volkswagen	Passat B6 Typ3C (2006-)		PFF85-501G	Front Wishbone Front Bush Camber Adjustable		19800	2	1
Volkswagen	Passat B6 Typ3C (2006-)		PFF85-502	Front Wishbone Rear Bush		11880	2	2
Volkswagen	Passat B6 Typ3C (2006-)		PFF85-503-19.6	Front Anti Roll Bar Bush 19.6mm	19.6mm	7500	2	3
Volkswagen	Passat B6 Typ3C (2006-)		PFF85-503-20	Front Anti Roll Bar Bush 20mm	20mm	7500	2	3
Volkswagen	Passat B6 Typ3C (2006-)		PFF85-503-20.7	Front Anti Roll Bar Bush 20.7mm	20.7mm	7500	2	3
Volkswagen	Passat B6 Typ3C (2006-)		PFF85-503-21.7	Front Anti Roll Bar Bush 21.7mm	21.7mm	7500	2	3
Volkswagen	Passat B6 Typ3C (2006-)		PFF85-503-22	Front Anti Roll Bar Bush 22mm	22mm	7500	2	3
Volkswagen	Passat B6 Typ3C (2006-)		PFF85-503-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	7500	2	3
Volkswagen	Passat B6 Typ3C (2006-)		PFF85-503-23	Front Anti Roll Bar Bush 23mm	23mm	7500	2	3
Volkswagen	Passat B6 Typ3C (2006-)		PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	7500	2	3
Volkswagen	Passat B6 Typ3C (2006-)		PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	7500	2	3
Volkswagen	Passat B6 Typ3C (2006-)		PFF85-504	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Passat B6 Typ3C (2006-)		PFF85-504P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Passat B6 Typ3C (2006-)		PFF85-504R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Passat B6 Typ3C (2006-)		PFF85-505	Lower Engine Mount Small Bush		5000	1	5
Volkswagen	Passat B6 Typ3C (2006-)		PFF85-704	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Passat B6 Typ3C (2006-)		PFF85-704P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Passat B6 Typ3C (2006-)		PFF85-704R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Passat B6 Typ3C (2006-)		PFR85-508	Rear Tie Bar to Chassis Front Bush		8140	2	8
Volkswagen	Passat B6 Typ3C (2006-)		PFR85-509	Rear Lower Spring Mount Outer		7260	2	9
Volkswagen	Passat B6 Typ3C (2006-)		PFR85-510	Rear Lower Spring Mount Inner		7260	2	10
Volkswagen	Passat B6 Typ3C (2006-)		PFR85-511	Rear Lower Link Outer Bush		8800	2	11
Volkswagen	Passat B6 Typ3C (2006-)		PFR85-512	Rear Lower Link Inner Bush		8800	2	12
Volkswagen	Passat B6 Typ3C (2006-)		PFR85-513	Rear Upper Link Outer Bush		7260	2	13
Volkswagen	Passat B6 Typ3C (2006-)		PFR85-514	Rear Upper Link Inner Bush		7260	2	14
Volkswagen	Passat B6 Typ3C (2006-)		PFR85-515-18	Rear Anti Roll Bar Bush 18mm	18mm	8250	2	15
Volkswagen	Passat B6 Typ3C (2006-)		PFR85-515-18.5	Rear Anti Roll Bar Bush 18.5mm	18.5mm	8250	2	15
Volkswagen	Passat B6 Typ3C (2006-)		PFR85-515-19.6	Rear Anti Roll Bar Bush 19.6mm	19.6mm	8250	2	15
Volkswagen	Passat B6 Typ3C (2006-)		PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	8250	2	15
Volkswagen	Passat B6 Typ3C (2006-)		PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	8250	2	15
Volkswagen	Passat B6 Typ3C (2006-)		PFR85-515-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	8250	2	15

Volkswagen	Passat CC 35 (2009-)		PFF85-501	Front Wishbone Front Bush		9240	2	1
Volkswagen	Passat CC 35 (2009-)		PFF85-501G	Front Wishbone Front Bush Camber Adjustable		19800	2	1
Volkswagen	Passat CC 35 (2009-)		PFF85-502	Front Wishbone Rear Bush		11880	2	2
Volkswagen	Passat CC 35 (2009-)		PFF85-503-19.6	Front Anti Roll Bar Bush 19.6mm	19.6mm	7500	2	3
Volkswagen	Passat CC 35 (2009-)		PFF85-503-20	Front Anti Roll Bar Bush 20mm	20mm	7500	2	3
Volkswagen	Passat CC 35 (2009-)		PFF85-503-20.7	Front Anti Roll Bar Bush 20.7mm	20.7mm	7500	2	3
Volkswagen	Passat CC 35 (2009-)		PFF85-503-21.7	Front Anti Roll Bar Bush 21.7mm	21.7mm	7500	2	3
Volkswagen	Passat CC 35 (2009-)		PFF85-503-22	Front Anti Roll Bar Bush 22mm	22mm	7500	2	3
Volkswagen	Passat CC 35 (2009-)		PFF85-503-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	7500	2	3
Volkswagen	Passat CC 35 (2009-)		PFF85-503-23	Front Anti Roll Bar Bush 23mm	23mm	7500	2	3
Volkswagen	Passat CC 35 (2009-)		PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	7500	2	3
Volkswagen	Passat CC 35 (2009-)		PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	7500	2	3
Volkswagen	Passat CC 35 (2009-)		PFF85-504	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Passat CC 35 (2009-)		PFF85-504P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Passat CC 35 (2009-)		PFF85-504R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Passat CC 35 (2009-)		PFF85-505	Lower Engine Mount Small Bush		5000	1	5
Volkswagen	Passat CC 35 (2009-)		PFF85-704	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Passat CC 35 (2009-)		PFF85-704P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Passat CC 35 (2009-)		PFF85-704R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Passat CC 35 (2009-)		PFR85-508	Rear Tie Bar to Chassis Front Bush		8140	2	8
Volkswagen	Passat CC 35 (2009-)		PFR85-509	Rear Lower Spring Mount Outer		7260	2	9
Volkswagen	Passat CC 35 (2009-)		PFR85-510	Rear Lower Spring Mount Inner		7260	2	10
Volkswagen	Passat CC 35 (2009-)		PFR85-511	Rear Lower Link Outer Bush		8800	2	11
Volkswagen	Passat CC 35 (2009-)		PFR85-512	Rear Lower Link Inner Bush		8800	2	12
Volkswagen	Passat CC 35 (2009-)		PFR85-513	Rear Upper Link Outer Bush		7260	2	13
Volkswagen	Passat CC 35 (2009-)		PFR85-514	Rear Upper Link Inner Bush		7260	2	14
Volkswagen	Passat CC 35 (2009-)		PFR85-515-18	Rear Anti Roll Bar Bush 18mm	18mm	8250	2	15
Volkswagen	Passat CC 35 (2009-)		PFR85-515-18.5	Rear Anti Roll Bar Bush 18.5mm	18.5mm	8250	2	15
Volkswagen	Passat CC 35 (2009-)		PFR85-515-19.6	Rear Anti Roll Bar Bush 19.6mm	19.6mm	8250	2	15
Volkswagen	Passat CC 35 (2009-)		PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	8250	2	15
Volkswagen	Passat CC 35 (2009-)		PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	8250	2	15
Volkswagen	Passat CC 35 (2009-)		PFR85-515-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	8250	2	15
Volkswagen	Phaeton (2002-2009)		PFF3-213-12	Front Anti Roll Bar Link Bush	12mm	16500	4	5
Volkswagen	Polo (1975 - 1994)		EXH006	Exhaust Mounts		1500	1	
Volkswagen	Polo (1975 - 1994)		PFF85-101	Front Wishbone Outer Bush		7700	2	1
Volkswagen	Polo (1975 - 1994)		PFF85-103	Front Wishbone Inner Bush		6600	2	2
Volkswagen	Polo (1975 - 1994)		PFF85-105	Front Anti Roll Bar Mount 18mm	18mm	7500	2	3
Volkswagen	Polo 6N (1995 - 2002)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Volkswagen	Polo 6N (1995 - 2002)		PFF85-208-10	Front Eye Bolt Mounting Bush 10mm (M8 nut)	10mm	6160	2	4
Volkswagen	Polo 6N (1995 - 2002)		PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	7250	2	5
Volkswagen	Polo 6N (1995 - 2002)		PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20/22mm	7250	2	5
Volkswagen	Polo 6N (1995 - 2002)		PFF85-401	Front Wishbone Inner Bush (front)		7700	2	1
Volkswagen	Polo 6N (1995 - 2002)		PFF85-402	Front Wishbone Inner Bush (rear)		8800	2	2
Volkswagen	Polo 6N (1995 - 2002)		PFF85-403-18	Front Anti Roll Bar Bush 18mm	18mm	8000	2	3
Volkswagen	Polo 6N (1995 - 2002)		PFF85-403-20	Front Anti Roll Bar Bush 20mm	20mm	8000	2	3
Volkswagen	Polo 6N (1995 - 2002)		PFF85-403-22	Front Anti Roll Bar Bush 22mm	22mm	8000	2	3
Volkswagen	Polo 6N (1995 - 2002)		PFF85-920	Lower Engine Mount Large Bush		8250	1	6
Volkswagen	Polo 6N (1995 - 2002)		PFR85-240	Rear Shock Top Mounting Bush		6160	2	8
Volkswagen	Polo 6N (1995 - 2002)		PFR85-615	Rear Beam Mounting Bush	58mm	12320	2	7
Volkswagen	Polo 6N (1995 - 2002)		PFR85-915	Rear Beam Mounting Bush	71.5mm	12320	2	7
Volkswagen	Polo 6R (2009-)		BS2006K	Bump Stop Kit	Rear	6250	1	
Volkswagen	Polo 6R (2009-)		PFF85-1202	Front Arm Rear Bush		10340	2	2
Volkswagen	Polo 6R (2009-)		PFF85-201	Front Wishbone Front Bush		8580	2	1
Volkswagen	Polo 6R (2009-)		PFF85-430	Front Strut Top Mount Bush		8800	2	11
Volkswagen	Polo 6R (2009-)		PFF85-603-18	Front Anti Roll Bar Bush 17.5mm	17.5mm	7500	2	3
Volkswagen	Polo 6R (2009-)		PFF85-603-19	Front Anti Roll Bar Bush 19mm	19mm	7500	2	3
Volkswagen	Polo 6R (2009-)		PFF85-603-20	Front Anti Roll Bar Bush 20mm		7500	2	3
Volkswagen	Polo 6R (2009-)		PFF85-620	Lower Engine Mount Large Bush		7250	1	20
Volkswagen	Polo 6R (2009-)		PFF85-620P	Lower Engine Mount Large Bush (Track Use)		7250	1	20
Volkswagen	Polo 6R (2009-)		PFF85-620R	Lower Engine Mount Large Bush (Diesel)		7250	1	20
Volkswagen	Polo 6R (2009-)		PFR85-415	Rear Beam Mounting Bush		12760	2	4
Volkswagen	Polo 9N/9N3 (2002 - 2008)		PFF85-201	Front Wishbone Front Bush		8580	2	1
Volkswagen	Polo 9N/9N3 (2002 - 2008)		PFF85-602	Front Wishbone Rear Bush		12100	2	2
Volkswagen	Polo 9N/9N3 (2002 - 2008)		PFF85-603-16	Front Anti Roll Bar Bush 16mm	16mm	7500	2	3
Volkswagen	Polo 9N/9N3 (2002 - 2008)		PFF85-603-18	Front Anti Roll Bar Bush 17.5mm	17.5mm	7500	2	3
Volkswagen	Polo 9N/9N3 (2002 - 2008)		PFF85-603-19	Front Anti Roll Bar Bush 19mm	19mm	7500	2	3
Volkswagen	Polo 9N/9N3 (2002 - 2008)		PFF85-603-20	Front Anti Roll Bar Bush 20mm		7500	2	3
Volkswagen	Polo 9N/9N3 (2002 - 2008)		PFF85-620	Lower Engine Mount Large Bush		7250	1	20
Volkswagen	Polo 9N/9N3 (2002 - 2008)		PFF85-620P	Lower Engine Mount Large Bush (Track Use)		7250	1	20
Volkswagen	Polo 9N/9N3 (2002 - 2008)		PFF85-620R	Lower Engine Mount Large Bush (Diesel)		7250	1	20
Volkswagen	Polo 9N/9N3 (2002 - 2008)		PFR85-415	Rear Beam Mounting Bush		12760	2	4

Volkswagen	Scirocco (1973 - 1992)		BS2001K	Bump Stop Kit	Front	5250	1	
Volkswagen	Scirocco (1973 - 1992)		BS2004K	Bump Stop Kit	Rear	5250	1	
Volkswagen	Scirocco (1973 - 1992)		PFF85-211	Front Wishbone Inner Bush		8140	2	1
Volkswagen	Scirocco (1973 - 1992)		PFF85-213	Front Wishbone Rear Bush		8140	2	2
Volkswagen	Scirocco (1973 - 1992)		PFF85-215	Front Anti Roll Bar Outer Mount 16mm	16mm	7500	2	4
Volkswagen	Scirocco (1973 - 1992)		PFF85-215-22	Front Anti Roll Bar Outer Mount 22mm	22mm	7500	2	4
Volkswagen	Scirocco (1973 - 1992)		PFF85-216	Front Anti Roll Bar Inner Mount		7500	2	3
Volkswagen	Scirocco (1973 - 1992)		PFF85-229	Steering Rack Mount		3000	1	11
Volkswagen	Scirocco (1973 - 1992)		PFF85-230	Steering Rack Mount		3000	1	12
Volkswagen	Scirocco (1973 - 1992)		PFF85-235	Engine Mount Stopper Bush		4250	1	5
Volkswagen	Scirocco (1973 - 1992)		PFR85-220	Rear Beam Mounting Bush		9680	2	7
Volkswagen	Scirocco (1973 - 1992)		PFR85-225	Rear Anti Roll Bar Mount (Inner)		5750	2	8
Volkswagen	Scirocco (1973 - 1992)		PFR85-226	Rear Anti Roll Bar Mount (Outer) 18mm	18mm	5750	2	9
Volkswagen	Scirocco (1973 - 1992)		PFR85-226-20.5	Rear Anti Roll Bar Mount (Outer) 20.5mm	20.5mm	5750	2	9
Volkswagen	Scirocco (1973 - 1992)		PFR85-241	Rear Shock Top Mounting Bush		8800	2	20
Volkswagen	Scirocco Mk3 (2008-)		PFF85-501	Front Wishbone Front Bush		9240	2	1
Volkswagen	Scirocco Mk3 (2008-)		PFF85-501G	Front Wishbone Front Bush Camber Adjustable		19800	2	1
Volkswagen	Scirocco Mk3 (2008-)		PFF85-502	Front Wishbone Rear Bush		11880	2	2
Volkswagen	Scirocco Mk3 (2008-)		PFF85-502G	Front Wishbone Rear Bush Anti-Lift & Caster Adjust		24200	2	2
Volkswagen	Scirocco Mk3 (2008-)		PFF85-503-22	Front Anti Roll Bar Bush 22mm	22mm	7500	2	3
Volkswagen	Scirocco Mk3 (2008-)		PFF85-503-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	7500	2	3
Volkswagen	Scirocco Mk3 (2008-)		PFF85-503-23	Front Anti Roll Bar Bush 23mm	23mm	7500	2	3
Volkswagen	Scirocco Mk3 (2008-)		PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	7500	2	3
Volkswagen	Scirocco Mk3 (2008-)		PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	7500	2	3
Volkswagen	Scirocco Mk3 (2008-)		PFF85-504	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Scirocco Mk3 (2008-)		PFF85-504P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Scirocco Mk3 (2008-)		PFF85-504R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Scirocco Mk3 (2008-)		PFF85-505	Lower Engine Mount Small Bush		5000	1	5
Volkswagen	Scirocco Mk3 (2008-)		PFF85-704	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Scirocco Mk3 (2008-)		PFF85-704P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Scirocco Mk3 (2008-)		PFF85-704R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Scirocco Mk3 (2008-)		PFR85-508	Rear Tie Bar to Chassis Front Bush		8140	2	8
Volkswagen	Scirocco Mk3 (2008-)		PFR85-509	Rear Lower Spring Mount Outer		7260	2	9
Volkswagen	Scirocco Mk3 (2008-)		PFR85-510	Rear Lower Spring Mount Inner		7260	2	10
Volkswagen	Scirocco Mk3 (2008-)		PFR85-511	Rear Lower Link Outer Bush		8800	2	11
Volkswagen	Scirocco Mk3 (2008-)		PFR85-512	Rear Lower Link Inner Bush		8800	2	12
Volkswagen	Scirocco Mk3 (2008-)		PFR85-513	Rear Upper Link Outer Bush		7260	2	13
Volkswagen	Scirocco Mk3 (2008-)		PFR85-514	Rear Upper Link Inner Bush		7260	2	14
Volkswagen	Scirocco Mk3 (2008-)		PFR85-515-18.5	Rear Anti Roll Bar Bush 18.5mm	18.5mm	8250	2	15
Volkswagen	Scirocco Mk3 (2008-)		PFR85-515-19.6	Rear Anti Roll Bar Bush 19.6mm	19.6mm	8250	2	15
Volkswagen	Scirocco Mk3 (2008-)		PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	8250	2	15
Volkswagen	Scirocco Mk3 (2008-)		PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	8250	2	15
Volkswagen	Scirocco Mk3 (2008-)		PFR85-515-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	8250	2	15

Volkswagen	T4 Transporter (1990 – 2003)		PFF85-1101	Front Lower Arm Front Bush, upto 1996		9680	2	1
Volkswagen	T4 Transporter (1990 – 2003)		PFF85-1102	Front Lower Arm Rear Bush		13200	2	2
Volkswagen	T4 Transporter (1990 – 2003)		PFF85-1103-23	Anti Roll Bar Mount Bush 23mm	23mm	8000	2	3
Volkswagen	T4 Transporter (1990 – 2003)		PFF85-1103-27	Anti Roll Bar Mount Bush 27mm	27mm	8000	2	3
Volkswagen	T4 Transporter (1990 – 2003)		PFF85-1104-23	Anti Roll Bar Mount Bush 23mm	23mm	8000	2	3
Volkswagen	T4 Transporter (1990 – 2003)		PFF85-1105	Front Upper Arm Front Bush		9680	2	5
Volkswagen	T4 Transporter (1990 – 2003)		PFF85-1106	Front Upper Arm Rear Bush		9680	2	6
Volkswagen	T4 Transporter (1990 – 2003)		PFF85-1107	23mm Anti Roll Bar To Link Rod Bush	23mm	6500	2	7
Volkswagen	T4 Transporter (1990 – 2003)		PFF85-1108	Front Anti Roll Bar Link Rod To Arm Bush		9500	2	8
Volkswagen	T4 Transporter (1990 – 2003)		PFF85-1120-10	Front Steering Rack Mount Bush 10mm Bolt	10mm bolt	11440	4	20
Volkswagen	T4 Transporter (1990 – 2003)		PFF85-1120-8	Front Steering Rack Mount Bush 8mm Bolt	8mm bolt	11440	4	20
Volkswagen	T4 Transporter (1990 – 2003)		PFF85-1131	Front Lower Arm Front Bush, from 1997		9680	2	1
Volkswagen	T4 Transporter (1990 – 2003)		PFR85-1020 KIT3	Diff Mounting Bush Kit Of 3		20000	1	21
Volkswagen	T4 Transporter (1990 – 2003)		PFR85-1110	Rear Trailing Arm Inner Bush To Chassis		9680	2	10
Volkswagen	T4 Transporter (1990 – 2003)		PFR85-1111	Rear Trailing Arm Outer Bush To Chassis		9680	2	11
Volkswagen	T4 Transporter (1990 – 2003)		PFR85-1112-20	Rear Anti Roll Bar Bush 20mm	20mm	14000	4	12
Volkswagen	T4 Transporter (1990 – 2003)		PFR85-1112-26	Rear Anti Roll Bar Bush 26mm	26mm	14000	4	12
Volkswagen	T4 Transporter (1990 – 2003)		PFR85-1112-28	Rear Anti Roll Bar Bush 28mm	28mm	14000	4	12
Volkswagen	T5 Transporter (2003 –)		PFA100-14	PowerAlign Camber Bolt Kit (14mm)	14mm	4250	1	
Volkswagen	T5 Transporter (2003 –)		PFF85-1301	Front Arm Front Bush		10120	2	1
Volkswagen	T5 Transporter (2003 –)		PFF85-1301G	Front Arm Front Bush, Camber Adjustable		16280	2	1
Volkswagen	T5 Transporter (2003 –)		PFF85-1302	Front Arm Rear Bush		11440	2	2
Volkswagen	T5 Transporter (2003 –)		PFF85-1302G	Front Arm Rear Bush, Caster Adjustable		17600	2	2
Volkswagen	T5 Transporter (2003 –)		PFF85-1303-22	Front Anti Roll Bar Bush 22mm	22mm	8250	2	3
Volkswagen	T5 Transporter (2003 –)		PFF85-1303-23	Front Anti Roll Bar Bush 23mm	23mm	8250	2	3
Volkswagen	T5 Transporter (2003 –)		PFF85-1303-25	Front Anti Roll Bar Bush 25mm	25mm	8250	2	3
Volkswagen	T5 Transporter (2003 –)		PFR85-1310	Rear Arm Outer Bush		11440	2	10
Volkswagen	T5 Transporter (2003 –)		PFR85-1310G	Rear Arm Outer Bush, Adjustable		19360	2	10
Volkswagen	T5 Transporter (2003 –)		PFR85-1311	Rear Arm Inner Bush		13200	2	11
Volkswagen	T5 Transporter (2003 –)		PFR85-1311G	Rear Arm Inner Bush, Adjustable		22440	2	11
Volkswagen	T5 Transporter (2003 –)		PFR85-1312-22	Rear Anti Roll Bar Bush to Chassis 22mm	22mm	8250	2	12
Volkswagen	T5 Transporter (2003 –)		PFR85-1312-24	Rear Anti Roll Bar Bush to Chassis 24mm	24mm	8250	2	12
Volkswagen	T5 Transporter (2003 –)		PFR85-1312-28	Rear Anti Roll Bar Bush to Chassis 28mm	28mm	8250	2	12
Volkswagen	T5 Transporter (2003 –)		PFR85-1313-22	Rear Anti Roll Bar Bush to Arm 22mm	22mm	8250	2	13
Volkswagen	T5 Transporter (2003 –)		PFR85-1313-24	Rear Anti Roll Bar Bush to Arm 24mm	24mm	8250	2	13
Volkswagen	T5 Transporter (2003 –)		PFR85-1313-28	Rear Anti Roll Bar Bush to Arm 28mm	28mm	8250	2	13
Volkswagen	Tiguan 5N (2007-)		PFF85-501	Front Wishbone Front Bush		9240	2	1
Volkswagen	Tiguan 5N (2007-)		PFF85-501G	Front Wishbone Front Bush Camber Adjustable		19800	2	1
Volkswagen	Tiguan 5N (2007-)		PFF85-502	Front Wishbone Rear Bush		11880	2	2
Volkswagen	Tiguan 5N (2007-)		PFF85-503-23	Front Anti Roll Bar Bush 23mm	23mm	7500	2	3
Volkswagen	Tiguan 5N (2007-)		PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	7500	2	3
Volkswagen	Tiguan 5N (2007-)		PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	7500	2	3
Volkswagen	Tiguan 5N (2007-)		PFF85-504	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Tiguan 5N (2007-)		PFF85-504P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Tiguan 5N (2007-)		PFF85-504R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Tiguan 5N (2007-)		PFF85-505	Lower Engine Mount Small Bush		5000	1	5
Volkswagen	Tiguan 5N (2007-)		PFF85-704	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Tiguan 5N (2007-)		PFF85-704P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Tiguan 5N (2007-)		PFF85-704R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Tiguan 5N (2007-)		PFR85-508	Rear Tie Bar to Chassis Front Bush		8140	2	8
Volkswagen	Tiguan 5N (2007-)		PFR85-509	Rear Lower Spring Mount Outer		7260	2	9
Volkswagen	Tiguan 5N (2007-)		PFR85-510	Rear Lower Spring Mount Inner		7260	2	10
Volkswagen	Tiguan 5N (2007-)		PFR85-511	Rear Lower Link Outer Bush		8800	2	11
Volkswagen	Tiguan 5N (2007-)		PFR85-512	Rear Lower Link Inner Bush		8800	2	12
Volkswagen	Tiguan 5N (2007-)		PFR85-513	Rear Upper Link Outer Bush		7260	2	13
Volkswagen	Tiguan 5N (2007-)		PFR85-514	Rear Upper Link Inner Bush		7260	2	14
Volkswagen	Tiguan 5N (2007-)		PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	8250	2	15
Volkswagen	Tiguan 5N (2007-)		PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	8250	2	15
Volkswagen	Tiguan 5N (2007-)		PFR85-515-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	8250	2	15

Volkswagen	Touran 1T (2003-)		PFF85-501	Front Wishbone Front Bush		9240	2	1
Volkswagen	Touran 1T (2003-)		PFF85-501G	Front Wishbone Front Bush Camber Adjustable		19800	2	1
Volkswagen	Touran 1T (2003-)		PFF85-502	Front Wishbone Rear Bush		11880	2	2
Volkswagen	Touran 1T (2003-)		PFF85-502G	Front Wishbone Rear Bush Anti-Lift & Caster Adjust		24200	2	2
Volkswagen	Touran 1T (2003-)		PFF85-503-23	Front Anti Roll Bar Bush 23mm	23mm	7500	2	3
Volkswagen	Touran 1T (2003-)		PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	7500	2	3
Volkswagen	Touran 1T (2003-)		PFF85-504	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Touran 1T (2003-)		PFF85-504P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Touran 1T (2003-)		PFF85-504R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Touran 1T (2003-)		PFF85-505	Lower Engine Mount Small Bush		5000	1	5
Volkswagen	Touran 1T (2003-)		PFF85-704	Lower Engine Mount Insert (Large)		5500	1	4
Volkswagen	Touran 1T (2003-)		PFF85-704P	Lower Engine Mount Insert (Large) Track Use		5500	1	4
Volkswagen	Touran 1T (2003-)		PFF85-704R	Lower Engine Mount Insert (Large) Diesel		5500	1	4
Volkswagen	Touran 1T (2003-)		PFR85-508	Rear Tie Bar to Chassis Front Bush		8140	2	8
Volkswagen	Touran 1T (2003-)		PFR85-509	Rear Lower Spring Mount Outer		7260	2	9
Volkswagen	Touran 1T (2003-)		PFR85-510	Rear Lower Spring Mount Inner		7260	2	10
Volkswagen	Touran 1T (2003-)		PFR85-511	Rear Lower Link Outer Bush		8800	2	11
Volkswagen	Touran 1T (2003-)		PFR85-512	Rear Lower Link Inner Bush		8800	2	12
Volkswagen	Touran 1T (2003-)		PFR85-513	Rear Upper Link Outer Bush		7260	2	13
Volkswagen	Touran 1T (2003-)		PFR85-514	Rear Upper Link Inner Bush		7260	2	14
Volkswagen	Touran 1T (2003-)		PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	8250	2	15
Volkswagen	Touran 1T (2003-)		PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	8250	2	15
Volkswagen	Touran 1T (2003-)		PFR85-515-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	8250	2	15
Volkswagen	Vento (1992 - 1998)		BS006	Bump Stop Front		5500	2	
Volkswagen	Vento (1992 - 1998)		BS008	Bump Stop Rear		5500	2	
Volkswagen	Vento (1992 - 1998)		BS2005K	Bump Stop Kit	Rear	5250	1	
Volkswagen	Vento (1992 - 1998)		EXH006	Exhaust Mounts		1500	1	
Volkswagen	Vento (1992 - 1998)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Volkswagen	Vento (1992 - 1998)		PFF85-201	Front Wishbone Front Bush		8580	2	1
Volkswagen	Vento (1992 - 1998)		PFF85-204	Front Wishbone Inner Bush (rear)		8360	2	2
Volkswagen	Vento (1992 - 1998)		PFF85-205	Front Anti Roll Bar Mount 18mm	18mm	7500	2	3
Volkswagen	Vento (1992 - 1998)		PFF85-205-20	Front Anti Roll Bar Bush 20mm	20mm	7500	2	3
Volkswagen	Vento (1992 - 1998)		PFF85-208	Front Eye Bolt Mounting Bush		6160	2	4
Volkswagen	Vento (1992 - 1998)		PFF85-208-10	Front Eye Bolt Mounting Bush 10mm	10mm	6160	2	4
Volkswagen	Vento (1992 - 1998)		PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	7250	2	5
Volkswagen	Vento (1992 - 1998)		PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	7250	2	5
Volkswagen	Vento (1992 - 1998)		PFF85-231	Non Power Steering Rack Mount		5060	2	9
Volkswagen	Vento (1992 - 1998)		PFF85-232	Power Steering Rack Mount	18.5mm wide bracket	3000	1	9
Volkswagen	Vento (1992 - 1998)		PFF85-233	Power Steering Rack Mount	15mm wide bracket	3000	1	9
Volkswagen	Vento (1992 - 1998)		PFF85-239	Front Strut, Top Mount		10120	2	11
Volkswagen	Vento (1992 - 1998)		PFF85-250	Front Subframe Mounts		6600	4	6
Volkswagen	Vento (1992 - 1998)		PFR85-206	Rear Beam Mounting Bush		12760	2	7
Volkswagen	Vento (1992 - 1998)		PFR85-240	Rear Shock Top Mounting Bush		6160	2	8