

Make	Model	Part Number	Product Description	Bush Size	入数	SET価格	Diag Ref
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-201	Front Wishbone Front Bush	30mm	2	10500	1
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-410	Front Wishbone Rear Bush		2	12000	2
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-410PA	Front Wishbone Rear Bush		2	11000	2
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-411-19	Front Anti Roll Bar Mount 19mm	19mm	2	7500	3
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-411-21	Front Anti Roll Bar Mount 21mm	21mm	2	7500	3
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-411-23	Front Anti Roll Bar Mount 23mm	23mm	2	7500	3
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-412	Front Anti Roll Bar Link Bush Kit		2	10000	4
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-414	Front Wishbone Rear Bush (Motorsport Use)		2	34000	2
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-416	Steering Rack Mount Bush		1	3250	7
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-420	Front Engine Mount Dog Bone		1	5250	8
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-420R	Front Engine Mount Dog Bone (Diesel)		1	6000	8
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-424	Front Subframe Rear Bush		2	13500	24
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-430	Front Strut Top Mount Bush		2	10500	11
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-431	Front Strut Top Mount Bush -10mm	-10mm	2	12000	11
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-505	Front Engine Mount Dog Bone Small Bush		1	5250	9
Volkswagen	Bora 2WD (1997 - 2006)	PFR85-415	Rear Beam Mounting Bush, 72.5mm	72.5mm	2	15500	5
Volkswagen	Bora 2WD (1997 - 2006)	PFR85-610	Rear Beam Mounting Bush, 69mm	69mm	2	15500	5
Volkswagen	Bora 4 Motion (1999-2005)	PFF3-501	Front Wishbone Front Bush, Cast Arm, 45mm OD	45mm	2	11000	1
Volkswagen	Bora 4 Motion (1999-2005)	PFF3-610	Front Wishbone Rear Bush R32		2	12000	2
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-410	Front Wishbone Rear Bush		2	12000	2
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-410PA	Front Wishbone Rear Bush		2	11000	2
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-411-19	Front Anti Roll Bar Bush 19mm	19mm	2	7500	3
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-411-21	Front Anti Roll Bar Mount	21mm	2	7500	3
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-411-21	Front Anti Roll Bar Mount 21mm	21mm	2	7500	3
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-411-23	Front Anti Roll Bar Mount 23mm	23mm	2	7500	3
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-412	Front Anti Roll Bar Link Bush Kit		2	10000	4
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-414	Front Wishbone Rear Bush (Race Use) Fits All Models		2	34000	2
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-416	Steering Rack Mount Bush		1	3250	7
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-420	Front Engine Mount Dog Bone		1	5250	8
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-420R	Front Engine Mount Dog Bone (Diesel)		1	6000	8
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-424	Front Subframe Rear Bush		2	13500	24
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-430	Front Strut Top Mount Bush		2	10500	11
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-431	Front Strut Top Mount Bush -10mm	-10mm	2	12000	11
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-505	Front Engine Mount Dog Bone Small Bush		1	5250	10
Volkswagen	Bora 4 Motion (1999-2005)	PFR3-508	Rear Trailing Arm Front Bush		2	12000	9
Volkswagen	Bora 4 Motion (1999-2005)	PFR3-508G	Rear Trailing Arm Front Bush Toe Adjust		2	14500	9
Volkswagen	Bora 4 Motion (1999-2005)	PFR3-510	Rear Arm Inner Bush		4	22000	5
Volkswagen	Bora 4 Motion (1999-2005)	PFR3-510G	Rear Arm Inner Bush Camber Adjustable		4	40000	5
Volkswagen	Bora 4 Motion (1999-2005)	PFR3-511-13	Rear Anti Roll Bar Mounting 13mm	13mm	2	7500	6
Volkswagen	Bora 4 Motion (1999-2005)	PFR3-511-14	Rear Anti Roll Bar Mounting 14mm	14mm	2	7500	6
Volkswagen	Bora 4 Motion (1999-2005)	PFR3-511-15	Rear Anti Roll Bar Mounting 15mm	15mm	2	7500	6
Volkswagen	Bora 4 Motion (1999-2005)	PFR3-511-16	Rear Anti Roll Bar Mounting 16mm	16mm	2	7500	6
Volkswagen	Bora 4 Motion (1999-2005)	PFR3-511-19	Rear Anti Roll Bar Mounting 19mm	19mm	2	7500	6
Volkswagen	Bora 4 Motion (1999-2005)	PFR85-425	Rear Diff Front Mounting Bush		2	12000	25
Volkswagen	Bora 4 Motion (1999-2005)	PFR85-426	Rear Diff Rear Mounting Bush		2	12000	26
Volkswagen	Bora 4 Motion (1999-2005)	PFR85-427	Rear Subframe Mounting Bush		4	26000	27
Volkswagen	Bora (2005-2010)	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Bora (2005-2010)	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Bora (2005-2010)	PFF85-502	Front Wishbone Rear Bush		2	14500	2
Volkswagen	Bora (2005-2010)	PFF85-502G	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	29000	2
Volkswagen	Bora (2005-2010)	PFF85-503-19.6	Front Anti Roll Bar Bush 19.6mm	19.6mm	2	7500	3
Volkswagen	Bora (2005-2010)	PFF85-503-20	Front Anti Roll Bar Bush 20mm	20mm	2	7500	3
Volkswagen	Bora (2005-2010)	PFF85-503-20.7	Front Anti Roll Bar Bush 20.7mm	20.7mm	2	7500	3
Volkswagen	Bora (2005-2010)	PFF85-503-21.7	Front Anti Roll Bar Bush 21.7mm	21.7mm	2	7500	3
Volkswagen	Bora (2005-2010)	PFF85-503-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	7500	3
Volkswagen	Bora (2005-2010)	PFF85-503-23	Front Anti Roll Bar Bush 23mm	23mm	2	7500	3
Volkswagen	Bora (2005-2010)	PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	7500	3
Volkswagen	Bora (2005-2010)	PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	2	7500	3

Volkswagen	Bora (2005-2010)	PFF85-504	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Bora (2005-2010)	PFF85-504P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Bora (2005-2010)	PFF85-504R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Bora (2005-2010)	PFF85-505	Lower Engine Mount Small Bush		1	5250	5
Volkswagen	Bora (2005-2010)	PFF85-704	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Bora (2005-2010)	PFF85-704P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Bora (2005-2010)	PFF85-704R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Bora (2005-2010)	PFR85-508	Rear Tie Bar to Chassis Front Bush		2	10000	8
Volkswagen	Bora (2005-2010)	PFR85-509	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Bora (2005-2010)	PFR85-510	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Bora (2005-2010)	PFR85-511	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Bora (2005-2010)	PFR85-512	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Bora (2005-2010)	PFR85-513	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Bora (2005-2010)	PFR85-514	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Bora (2005-2010)	PFR85-515-18	Rear Anti Roll Bar Bush 18mm	18mm	2	8500	15
Volkswagen	Bora (2005-2010)	PFR85-515-18.5	Rear Anti Roll Bar Bush 18.5mm	18.5mm	2	8500	15
Volkswagen	Bora (2005-2010)	PFR85-515-19	Rear Anti Roll Bar Bush 19mm	19mm	2	8500	15
Volkswagen	Bora (2005-2010)	PFR85-515-19.6	Rear Anti Roll Bar Bush 19.6mm	19.6mm	2	8500	15
Volkswagen	Bora (2005-2010)	PFR85-515-20	Rear Anti Roll Bar Bush 20mm	20mm	2	8500	15
Volkswagen	Bora (2005-2010)	PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	8500	15
Volkswagen	Bora (2005-2010)	PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	8500	15
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFF85-211	Front Wishbone Inner Bush		2	10000	1
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFF85-213	Front Wishbone Rear Bush		2	10000	2
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFF85-215	Front Anti Roll Bar Outer Mount 16mm	16mm	2	7500	4
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFF85-215-22	Front Anti Roll Bar Outer Mount 22mm	22mm	2	7500	4
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFF85-216	Front Anti Roll Bar Inner Mount		2	7500	3
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFF85-229	Steering Rack Mount		1	3250	11
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFF85-230	Steering Rack Mount		1	3250	12
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFF85-235	Engine Mount Stopper Bush		1	4500	5
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFR85-310	Rear Leaf Spring Bush		6	33000	10
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFR85-315	Rear Leaf Spring Anti Clatter Bush		4	12000	15
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFR85-316	Rear Bump Stop		2	11000	16
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-201	Front Wishbone Front Bush	30mm	2	10500	1
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-204	Front Wishbone Rear Bush		2	10500	2
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-205	Front Anti Roll Bar Bush 18mm	18mm	2	9000	3
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-205-20	Front Anti Roll Bar Bush 20mm	20mm	2	9000	3
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-208	Front Eye Bolt Mounting Bush		2	7500	4
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-208-10	Front Eye Bolt Mounting Bush 10mm	10mm	2	7500	4
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	7500	5
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	7500	5
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-231	Non Power Steering Rack Mount		2	6500	9
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-232	Power Steering Rack Mount	18.5mm wide bracket	1	3250	9
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-233	Power Steering Rack Mount	15mm wide bracket	1	3250	9
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-239	Front Strut, Top Mount		2	12000	11
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-250	Front Cross Member Mounting Bush		4	11000	6
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-280	Front Lower Engine Mounting Bush & Inserts		1	9000	20
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFR85-1410	Rear Leaf Spring Bush		6	36000	10
Volkswagen	Caddy MK3 Typ 2K (2004 - 06/2010)	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Caddy MK3 Typ 2K (2004 - 06/2010)	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Caddy MK3 Typ 2K (2004 - 06/2010)	PFF85-502	Front Wishbone Rear Bush		2	14500	2
Volkswagen	Caddy MK3 Typ 2K (2004 - 06/2010)	PFF85-502G	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	29000	2
Volkswagen	Caddy MK3 Typ 2K (2004 - 06/2010)	PFF85-503-20	Front Anti Roll Bar Bush 20mm	20mm	2	7500	3
Volkswagen	Caddy MK3 Typ 2K (2004 - 06/2010)	PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	7500	3
Volkswagen	Caddy MK3 Typ 2K (2004 - 06/2010)	PFF85-504	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Caddy MK3 Typ 2K (2004 - 06/2010)	PFF85-504P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Caddy MK3 Typ 2K (2004 - 06/2010)	PFF85-504R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Caddy MK3 Typ 2K (2004 - 06/2010)	PFF85-505	Lower Engine Mount Small Bush		1	5250	5
Volkswagen	Caddy MK3 Typ 2K (2004 - 06/2010)	PFF85-530	Transmission Mount Insert		1	7250	30

Volkswagen	Caddy MK3 Typ 2K (2004 – 06/2010)	PFF85-704	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Caddy MK3 Typ 2K (2004 – 06/2010)	PFF85-704P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Caddy MK3 Typ 2K (2004 – 06/2010)	PFF85-704R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Caddy MK3 Typ 2K (2004 – 06/2010)	PFR85-1410-4	Rear Leaf Spring Bush		4	24000	10
Volkswagen	Caddy MK3 Typ 2K (2004 – 06/2010)	PFR85-1510	Rear Leaf Spring Chassis Shackle Bush		2	12500	11
Volkswagen	Caddy MK3 Typ 2K (2004 – 06/2010)	PFR85-1513-20	Rear Anti Roll Bar Mounting Bush 20mm	20mm	2	7500	12
Volkswagen	Caddy MK3 Typ 2K (2004 – 06/2010)	PFR85-1513-22	Rear Anti Roll Bar Mounting Bush 22mm	22mm	2	7500	12
Volkswagen	Caddy MK4 (06/2010 – )	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Caddy MK4 (06/2010 – )	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Caddy MK4 (06/2010 – )	PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	7500	3
Volkswagen	Caddy MK4 (06/2010 – )	PFF85-704	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Caddy MK4 (06/2010 – )	PFF85-704P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Caddy MK4 (06/2010 – )	PFF85-704R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Caddy MK4 (06/2010 – )	PFF85-802	Front Wishbone Rear Bush		2	21000	2
Volkswagen	Caddy MK4 (06/2010 – )	PFR85-1410-4	Rear Leaf Spring Bush		4	24000	10
Volkswagen	Caddy MK4 (06/2010 – )	PFR85-1510	Rear Leaf Spring Chassis Shackle Bush		2	12500	11
Volkswagen	Caddy MK4 (06/2010 – )	PFR85-1513-22	Rear Anti Roll Bar Mounting Bush 22mm	22mm	2	7500	12
Volkswagen	Corrado (1989 – 1995)	BS006	Bump Stop Front		2	6500	
Volkswagen	Corrado (1989 – 1995)	BS008	Bump Stop Rear		2	6500	
Volkswagen	Corrado (1989 – 1995)	EXH006	Exhaust Mounts		1	2250	
Volkswagen	Corrado (1989 – 1995)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Corrado (1989 – 1995)	PFF85-201	Front Wishbone Front Bush	30mm	2	10500	1
Volkswagen	Corrado (1989 – 1995)	PFF85-203	Front Wishbone Rear Bush		2	10500	2
Volkswagen	Corrado (1989 – 1995)	PFF85-205	Front Anti Roll Bar Mount 18mm	18mm	2	9000	3
Volkswagen	Corrado (1989 – 1995)	PFF85-205-20	Front Anti Roll Bar Bush 20mm	20mm	2	9000	3
Volkswagen	Corrado (1989 – 1995)	PFF85-205-22	Front Anti Roll Bar Bush Eibach 22mm	22mm	2	9000	3
Volkswagen	Corrado (1989 – 1995)	PFF85-208	Front Eye Bolt Mounting Bush		2	7500	4
Volkswagen	Corrado (1989 – 1995)	PFF85-208-10	Front Eye Bolt Mounting Bush 10mm	10mm	2	7500	4
Volkswagen	Corrado (1989 – 1995)	PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	7500	5
Volkswagen	Corrado (1989 – 1995)	PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	7500	5
Volkswagen	Corrado (1989 – 1995)	PFF85-232	Power Steering Rack Mount		1	3250	9
Volkswagen	Corrado (1989 – 1995)	PFF85-233	Power Steering Rack Mount	15mm wide bracket	1	3250	9
Volkswagen	Corrado (1989 – 1995)	PFF85-239	Front Strut, Top Mount		2	12000	11
Volkswagen	Corrado (1989 – 1995)	PFF85-250	Front Cross Member Mounting Bush		4	11000	6
Volkswagen	Corrado (1989 – 1995)	PFR85-207	Rear Beam Mounting Bush		2	15500	7
Volkswagen	Corrado (1989 – 1995)	PFR85-212	Rear Anti-Roll Bar To Beam Bush Eibach		2	9000	12
Volkswagen	Corrado (1989 – 1995)	PFR85-225-25	Rear Anti Roll Bar Bush Eibach 25mm	25mm	2	9000	25
Volkswagen	Corrado (1989 – 1995)	PFR85-240	Rear Shock Top Mounting Bush		2	7500	8
Volkswagen	Corrado VR6	BS006	Bump Stop Front		2	6500	
Volkswagen	Corrado VR6	BS008	Bump Stop Rear		2	6500	
Volkswagen	Corrado VR6	EXH006	Exhaust Mounts		1	2250	
Volkswagen	Corrado VR6	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Corrado VR6	PFF85-201	Front Wishbone Front Bush	30mm	2	10500	1
Volkswagen	Corrado VR6	PFF85-204	Front Wishbone Rear Bush, VR6 Models		2	10500	2
Volkswagen	Corrado VR6	PFF85-205	Front Anti Roll Bar Mount 18mm	18mm	2	9000	3
Volkswagen	Corrado VR6	PFF85-205-20	Front Anti Roll Bar Bush 20mm	20mm	2	9000	3
Volkswagen	Corrado VR6	PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	7500	5
Volkswagen	Corrado VR6	PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	7500	5
Volkswagen	Corrado VR6	PFF85-232	Power Steering Rack Mount		1	3250	9
Volkswagen	Corrado VR6	PFF85-233	Power Steering Rack Mount	15mm wide bracket	1	3250	9
Volkswagen	Corrado VR6	PFF85-239	Front Strut, Top Mount		2	12000	11
Volkswagen	Corrado VR6	PFF85-250	Front Cross Member Mounting Bush		4	11000	6
Volkswagen	Corrado VR6	PFF85-280	Front Lower Engine Mounting Bush & Inserts		1	9000	20
Volkswagen	Corrado VR6	PFR85-206	Rear Beam Mounting Bush		2	15500	7
Volkswagen	Corrado VR6	PFR85-240	Rear Shock Top Mounting Bush		2	7500	8
Volkswagen	Eos 1F (2006-)	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Eos 1F (2006-)	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Eos 1F (2006-)	PFF85-502	Front Wishbone Rear Bush		2	14500	2
Volkswagen	Eos 1F (2006-)	PFF85-502G	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	29000	2

Volkswagen	Eos 1F (2006-)	PFF85-503-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	7500	3
Volkswagen	Eos 1F (2006-)	PFF85-503-23	Front Anti Roll Bar Bush 23mm	23mm	2	7500	3
Volkswagen	Eos 1F (2006-)	PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	7500	3
Volkswagen	Eos 1F (2006-)	PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	2	7500	3
Volkswagen	Eos 1F (2006-)	PFF85-504	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Eos 1F (2006-)	PFF85-504P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Eos 1F (2006-)	PFF85-504R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Eos 1F (2006-)	PFF85-505	Lower Engine Mount Small Bush		1	5250	5
Volkswagen	Eos 1F (2006-)	PFF85-531	Upper Engine Mount Insert		1	7250	31
Volkswagen	Eos 1F (2006-)	PFF85-532	Upper Engine Mount Insert		1	7250	31
Volkswagen	Eos 1F (2006-)	PFF85-704	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Eos 1F (2006-)	PFF85-704P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Eos 1F (2006-)	PFF85-704R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Eos 1F (2006-)	PFR85-508	Rear Tie Bar to Chassis Front Bush		2	10000	8
Volkswagen	Eos 1F (2006-)	PFR85-509	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Eos 1F (2006-)	PFR85-510	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Eos 1F (2006-)	PFR85-511	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Eos 1F (2006-)	PFR85-512	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Eos 1F (2006-)	PFR85-513	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Eos 1F (2006-)	PFR85-514	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Eos 1F (2006-)	PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	8500	15
Volkswagen	Eos 1F (2006-)	PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	8500	15
Volkswagen	Eos 1F (2006-)	PFR85-515-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	8500	15
Volkswagen	Fox	PFF85-201	Front Wishbone Front Bush	30mm	2	10500	1
Volkswagen	Fox	PFF85-602	Front Wishbone Rear Bush		2	15000	2
Volkswagen	Fox	PFF85-603-16	Front Anti Roll Bar Bush 16mm	16mm	2	7500	3
Volkswagen	Fox	PFF85-603-18	Front Anti Roll Bar Bush 18mm	18mm	2	7500	3
Volkswagen	Fox	PFF85-603-19	Front Anti Roll Bar Bush 19mm	19mm	2	7500	3
Volkswagen	Fox	PFF85-603-20	Front Anti Roll Bar Bush 20mm		2	7500	3
Volkswagen	Fox	PFF85-620	Lower Engine Mount Large Bush		1	7500	20
Volkswagen	Fox	PFF85-620P	Lower Engine Mount Large Bush (Track Use)		1	7500	20
Volkswagen	Fox	PFF85-620R	Lower Engine Mount Large Bush (Diesel)		1	7500	20
Volkswagen	Fox	PFR85-415	Rear Beam Mounting Bush, 72.5mm	72.5mm	2	15500	4
Volkswagen	Fox	PFR85-610	Rear Beam Mounting Bush, 69mm	69mm	2	15500	4
Volkswagen	Golf MK1 (1973 - 1985)	BS2001K	Bump Stop Kit	Front	1	9250	
Volkswagen	Golf MK1 (1973 - 1985)	BS2004K	Bump Stop Kit	Rear	1	9750	
Volkswagen	Golf MK1 (1973 - 1985)	PF85K-1001	Powerflex Handling Pack		1	34250	
Volkswagen	Golf MK1 (1973 - 1985)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Golf MK1 (1973 - 1985)	PFF85-211	Front Wishbone Inner Bush		2	10000	1
Volkswagen	Golf MK1 (1973 - 1985)	PFF85-213	Front Wishbone Rear Bush		2	10000	2
Volkswagen	Golf MK1 (1973 - 1985)	PFF85-215	Front Anti Roll Bar Outer Mount 16mm	16mm	2	7500	4
Volkswagen	Golf MK1 (1973 - 1985)	PFF85-215-22	Front Anti Roll Bar Outer Mount 22mm	22mm	2	7500	4
Volkswagen	Golf MK1 (1973 - 1985)	PFF85-216	Front Anti Roll Bar Inner Mount		2	7500	3
Volkswagen	Golf MK1 (1973 - 1985)	PFF85-229	Steering Rack Mount		1	3250	11
Volkswagen	Golf MK1 (1973 - 1985)	PFF85-230	Steering Rack Mount		1	3250	12
Volkswagen	Golf MK1 (1973 - 1985)	PFF85-235	Engine Mount Stopper Bush		1	4500	5
Volkswagen	Golf MK1 (1973 - 1985)	PFR85-220	Rear Beam Mounting Bush		2	12000	7
Volkswagen	Golf MK1 (1973 - 1985)	PFR85-225	Rear Anti Roll Bar Mount (Inner)	19.5mm	2	9000	8
Volkswagen	Golf MK1 (1973 - 1985)	PFR85-226	Rear Anti Roll Bar Mount (Outer) 18mm	18mm	2	7000	9
Volkswagen	Golf MK1 (1973 - 1985)	PFR85-226-20.5	Rear Anti Roll Bar Mount (Outer) 20.5mm	20.5mm	2	7000	9
Volkswagen	Golf MK1 (1973 - 1985)	PFR85-241	Rear Shock Top Mounting Bush		2	10500	20
Volkswagen	Golf MK2 (1985 - 1992)2WD	BS006	Bump Stop Front		2	6500	
Volkswagen	Golf MK2 (1985 - 1992)2WD	BS008	Bump Stop Rear		2	6500	
Volkswagen	Golf MK2 (1985 - 1992)2WD	BS2001K	Bump Stop Kit	Front	1	9250	
Volkswagen	Golf MK2 (1985 - 1992)2WD	EXH006	Exhaust Mounts		1	2250	
Volkswagen	Golf MK2 (1985 - 1992)2WD	PF85K-1002	Powerflex Handling Pack		1	52750	
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFF85-201	Front Wishbone Front Bush	30mm	2	10500	1
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFF85-203	Front Wishbone Inner Bush		2	10500	2

Volkswagen	Golf MK2 (1985 – 1992)2WD	PFF85-205	Front Anti Roll Bar Mount 18mm	18mm	2	9000	3
Volkswagen	Golf MK2 (1985 – 1992)2WD	PFF85-205-20	Front Anti Roll Bar Bush 20mm	20mm	2	9000	3
Volkswagen	Golf MK2 (1985 – 1992)2WD	PFF85-205-22	Front Anti Roll Bar Bush Eibach 22mm	22mm	2	9000	3
Volkswagen	Golf MK2 (1985 – 1992)2WD	PFF85-208	Front Eye Bolt Mounting Bush		2	7500	4
Volkswagen	Golf MK2 (1985 – 1992)2WD	PFF85-208-10	Front Eye Bolt Mounting Bush 10mm	10mm	2	7500	4
Volkswagen	Golf MK2 (1985 – 1992)2WD	PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	7500	5
Volkswagen	Golf MK2 (1985 – 1992)2WD	PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	7500	5
Volkswagen	Golf MK2 (1985 – 1992)2WD	PFF85-210-22	Front Anti Roll Bar Eye Bolt Bush Eibach 22mm	22mm	2	7500	5
Volkswagen	Golf MK2 (1985 – 1992)2WD	PFF85-231	Non Power Steering Rack Mount		2	6500	9
Volkswagen	Golf MK2 (1985 – 1992)2WD	PFF85-232	Power Steering Rack Mount	18.5mm wide bracket	1	3250	9
Volkswagen	Golf MK2 (1985 – 1992)2WD	PFF85-233	Power Steering Rack Mount	15mm wide bracket	1	3250	9
Volkswagen	Golf MK2 (1985 – 1992)2WD	PFF85-244	Rear Lower Engine Mount Bush		1	12000	20
Volkswagen	Golf MK2 (1985 – 1992)2WD	PFF85-244R	Rear Lower Engine Mount Bush, Diesel		1	12000	20
Volkswagen	Golf MK2 (1985 – 1992)2WD	PFF85-245	Rear Lower Engine Mount Insert		1	5500	20
Volkswagen	Golf MK2 (1985 – 1992)2WD	PFF85-245R	Rear Lower Engine Mount Insert, Diesel		1	5500	20
Volkswagen	Golf MK2 (1985 – 1992)2WD	PFF85-250	Front Cross Member Mounting Bush		4	11000	6
Volkswagen	Golf MK2 (1985 – 1992)2WD	PFR85-207	Rear Beam Mounting Bush		2	15500	7
Volkswagen	Golf MK2 (1985 – 1992)2WD	PFR85-212	Rear Anti-Roll Bar To Beam Bush Eibach		2	9000	12
Volkswagen	Golf MK2 (1985 – 1992)2WD	PFR85-225-25	Rear Anti Roll Bar Bush Eibach 25mm	25mm	2	9000	25
Volkswagen	Golf MK2 (1985 – 1992)2WD	PFR85-240	Rear Shock Top Mounting Bush		2	7500	8
Volkswagen	Golf MK2 (1985 – 1992)4WD	BS006	Bump Stop Front		2	6500	
Volkswagen	Golf MK2 (1985 – 1992)4WD	BS2001K	Bump Stop Kit	Front	1	9250	
Volkswagen	Golf MK2 (1985 – 1992)4WD	EXH006	Exhaust Mounts		1	2250	
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-201	Front Wishbone Front Bush		2	10500	1
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-205	Front Anti Roll Bar Mount 18mm	18mm	2	9000	3
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-205-20	Front Anti Roll Bar Mount 20mm	20mm	2	9000	3
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-208	Front Eye Bolt Mounting Bush		2	7500	4
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-208-10	Front Eye Bolt Mounting Bush 10mm	10mm	2	7500	4
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	7500	5
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	7500	5
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-244	Rear Lower Engine Mount Bush		1	12000	20
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-244R	Rear Lower Engine Mount Bush, Diesel		1	12000	20
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-245	Rear Lower Engine Mount Insert		1	5500	20
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-245R	Rear Lower Engine Mount Insert, Diesel		1	5500	20
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-250	Front Cross Member Mounting Bush		4	11000	6
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-265	Front Wish Bone Rear Bush		2	10000	2
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFR85-240	Rear Shock Top Mounting Bush		2	7500	11
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFR85-260	Rear Beam Mounting Bush		2	12500	8
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFR85-262	Rear Trailing Arm Bush		4	21000	7
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFR85-263	Rear Anti Roll Bar Inner Bush 18.5mm	18.5mm	2	6500	9
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFR85-263-20	Rear Anti Roll Bar Inner Bush 20mm	20mm	2	6500	9
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFR85-264	Rear Anti Roll Bar Outer Mount 18.5mm	18.5mm	2	7000	10
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFR85-264-20	Rear Anti Roll Bar Outer Mount 20mm	20mm	2	7000	10
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFR85-270	Rear Diff Rear Mounting Bush		1	7500	12
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	BS006	Bump Stop Front		2	6500	
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	BS2001K	Bump Stop Kit	Front	1	9250	
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	EXH006	Exhaust Mounts		1	2250	
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-201	Front Wishbone Front Bush		2	10500	1
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-205	Front Anti Roll Bar Mount 18mm	18mm	2	9000	3
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-205-20	Front Anti Roll Bar Mount 20mm	20mm	2	9000	3
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-208	Front Eye Bolt Mounting Bush		2	7500	4
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-208-10	Front Eye Bolt Mounting Bush 10mm	10mm	2	7500	4
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	7500	5
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	7500	5
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-244	Rear Lower Engine Mount Bush		1	12000	20
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-244R	Rear Lower Engine Mount Bush, Diesel		1	12000	20
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-245	Rear Lower Engine Mount Insert		1	5500	20

Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-245R	Rear Lower Engine Mount Insert, Diesel		1	5500	20
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-250	Front Cross Member Mounting Bush		4	11000	6
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-265	Front Wish Bone Rear Bush		2	10000	2
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFR85-240	Rear Shock Top Mounting Bush		2	7500	11
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFR85-260	Rear Beam Mounting Bush		2	12500	8
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFR85-262	Rear Trailing Arm Bush		4	21000	7
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFR85-263	Rear Anti Roll Bar Inner Bush 18.5mm	18.5mm	2	6500	9
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFR85-263-20	Rear Anti Roll Bar Inner Bush 20mm	20mm	2	6500	9
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFR85-264	Rear Anti Roll Bar Outer Mount 18.5mm	18.5mm	2	7000	10
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFR85-264-20	Rear Anti Roll Bar Outer Mount 20mm	20mm	2	7000	10
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFR85-270	Rear Diff Rear Mounting Bush		1	7500	12
Volkswagen	Golf MK3 2WD (1992 – 1998)	BS006	Bump Stop Front		2	6500	
Volkswagen	Golf MK3 2WD (1992 – 1998)	BS008	Bump Stop Rear		2	6500	
Volkswagen	Golf MK3 2WD (1992 – 1998)	BS2001K	Bump Stop Kit	Front	1	9250	
Volkswagen	Golf MK3 2WD (1992 – 1998)	EXH006	Exhaust Mounts		1	2250	
Volkswagen	Golf MK3 2WD (1992 – 1998)	PF85K-1003	Powerflex Handling Pack		1	52750	
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-201	Front Wishbone Front Bush	30mm	2	10500	1
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-204	Front Wishbone Rear Bush		2	10500	2
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-205	Front Anti Roll Bar Mount 18mm	18mm	2	9000	3
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-205-20	Front Anti Roll Bar Mount 20mm	20mm	2	9000	3
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-205-22	Front Anti Roll Bar Bush Eibach 22mm	22mm	2	9000	3
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-208	Front Eye Bolt Mounting Bush		2	7500	4
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-208-10	Front Eye Bolt Mounting Bush 10mm	10mm	2	7500	4
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	7500	5
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	7500	5
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-231	Non Power Steering Rack Mount		2	6500	9
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-232	Power Steering Rack Mount	18.5mm wide bracket	1	3250	9
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-233	Power Steering Rack Mount	15mm wide bracket	1	3250	9
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-239	Front Strut, Top Mount		2	12000	11
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-250	Front Cross Member Mounting Bush		4	11000	6
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-280	Front Lower Engine Mounting Bush & Inserts		1	9000	20
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFR85-206	Rear Beam Mounting Bush		2	15500	7
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFR85-212	Rear Anti-Roll Bar To Beam Bush Eibach		2	9000	12
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFR85-225-25	Rear Anti Roll Bar Bush Eibach 25mm	25mm	2	9000	25
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFR85-240	Rear Shock Top Mounting Bush		2	7500	8
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFF85-201	Front Wishbone Front Bush	30mm	2	10500	1
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFF85-204	Front Wishbone Rear Bush		2	10500	2
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFF85-205	Front Anti Roll Bar Mount 18mm	18mm	2	9000	3
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFF85-205-20	Front Anti Roll Bar Mount 20mm	20mm	2	9000	3
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFF85-208	Front Eye Bolt Mounting Bush		2	7500	4
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFF85-208-10	Front Eye Bolt Mounting Bush 10mm	10mm	2	7500	4
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	7500	5
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	7500	5
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFF85-232	Power Steering Rack Mount	18.5mm wide bracket	1	3250	9
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFF85-233	Power Steering Rack Mount	15mm wide bracket	1	3250	9
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFF85-239	Front Strut, Top Mount		2	12000	11
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFF85-250	Front Cross Member Mounting Bush		4	11000	6
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFF85-280	Front Lower Engine Mounting Bush & Inserts		1	9000	20
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFR85-240	Rear Shock Top Mounting Bush		2	7500	17
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFR85-260	Rear Beam Mounting Bush		2	12500	15
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFR85-262	Rear Trailing Arm Bush		4	21000	12
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFR85-263	Rear Anti Roll Bar Inner Bush 18.5mm	18.5mm	2	6500	13
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFR85-263-20	Rear Anti Roll Bar Inner Bush 20mm	20mm	2	6500	13
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFR85-264	Rear Anti Roll Bar Outer Mount 18.5mm	18.5mm	2	7000	14
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFR85-264-20	Rear Anti Roll Bar Outer Mount 20mm	20mm	2	7000	14
Volkswagen	Golf Mk3 4WD Syncro (1993 – 1997)	PFR85-270	Rear Diff Rear Mounting Bush		1	7500	16
Volkswagen	Golf Mk4 2WD Typ 1J	PF85K-1004	Powerflex Handling Pack		1	45500	



Volkswagen	Golf Mk4 2WD Typ 1J	PFF85-201	Front Wishbone Front Bush	30mm	2	10500	1
Volkswagen	Golf Mk4 2WD Typ 1J	PFF85-410	Front Wishbone Rear Bush		2	12000	2
Volkswagen	Golf Mk4 2WD Typ 1J	PFF85-411-19	Front Anti Roll Bar Mount 19mm	19mm	2	7500	3
Volkswagen	Golf Mk4 2WD Typ 1J	PFF85-411-21	Front Anti Roll Bar Mount 21mm	21mm	2	7500	3
Volkswagen	Golf Mk4 2WD Typ 1J	PFF85-411-23	Front Anti Roll Bar Mount 23mm	23mm	2	7500	3
Volkswagen	Golf Mk4 2WD Typ 1J	PFF85-412	Front Anti Roll Bar Link Bush Kit		2	10000	4
Volkswagen	Golf Mk4 2WD Typ 1J	PFF85-414	Front Wishbone Rear Bush (Motorsport Use)		2	34000	2
Volkswagen	Golf Mk4 2WD Typ 1J	PFF85-416	Steering Rack Mount Bush		1	3250	7
Volkswagen	Golf Mk4 2WD Typ 1J	PFF85-420	Front Engine Mount Dog Bone		1	5250	8
Volkswagen	Golf Mk4 2WD Typ 1J	PFF85-420R	Front Engine Mount Dog Bone (Diesel)		1	6000	8
Volkswagen	Golf Mk4 2WD Typ 1J	PFF85-424	Front Subframe Rear Bush		2	13500	24
Volkswagen	Golf Mk4 2WD Typ 1J	PFF85-430	Front Strut Top Mount Bush		2	10500	11
Volkswagen	Golf Mk4 2WD Typ 1J	PFF85-431	Front Strut Top Mount Bush -10mm	-10mm	2	12000	11
Volkswagen	Golf Mk4 2WD Typ 1J	PFF85-505	Front Engine Mount Dog Bone Small Bush		1	5250	9
Volkswagen	Golf Mk4 2WD Typ 1J	PFR85-415	Rear Beam Mounting Bush, 72.5mm	72.5mm	2	15500	5
Volkswagen	Golf Mk4 2WD Typ 1J	PFR85-610	Rear Beam Mounting Bush, 69mm	69mm	2	15500	5
Volkswagen	Golf Mk4 R32/4Motion	PF3K-1002	Powerflex Handling Pack (Petrol Only)		1	42750	
Volkswagen	Golf Mk4 R32/4Motion	PFF3-501	Front Wishbone Front Bush, Cast Arm, 45mm OD	45mm	2	11000	1
Volkswagen	Golf Mk4 R32/4Motion	PFF3-610	Front Wishbone Rear Bush R32		2	12000	2
Volkswagen	Golf Mk4 R32/4Motion	PFF85-201	Front Wishbone Front Bush	30mm	2	10500	1
Volkswagen	Golf Mk4 R32/4Motion	PFF85-410	Front Wishbone Rear Bush		2	12000	2
Volkswagen	Golf Mk4 R32/4Motion	PFF85-410PA	Front Wishbone Rear Bush		2	11000	2
Volkswagen	Golf Mk4 R32/4Motion	PFF85-411-19	Front Anti Roll Bar Bush 19mm	19mm	2	7500	3
Volkswagen	Golf Mk4 R32/4Motion	PFF85-411-21	Front Anti Roll Bar Mount 21mm	21mm	2	7500	3
Volkswagen	Golf Mk4 R32/4Motion	PFF85-411-23	Front Anti Roll Bar Mount 23mm	23mm	2	7500	3
Volkswagen	Golf Mk4 R32/4Motion	PFF85-412	Front Anti Roll Bar Link Bush Kit		2	10000	4
Volkswagen	Golf Mk4 R32/4Motion	PFF85-414	Front Wishbone Rear Bush (Race Use) Fits All Models		2	34000	2
Volkswagen	Golf Mk4 R32/4Motion	PFF85-416	Steering Rack Mount Bush		1	3250	7
Volkswagen	Golf Mk4 R32/4Motion	PFF85-420	Front Engine Mount Dog Bone		1	5250	8
Volkswagen	Golf Mk4 R32/4Motion	PFF85-420R	Front Engine Mount Dog Bone (Diesel)		1	6000	8
Volkswagen	Golf Mk4 R32/4Motion	PFF85-424	Front Subframe Rear Bush		2	13500	24
Volkswagen	Golf Mk4 R32/4Motion	PFF85-430	Front Strut Top Mount Bush		2	10500	11
Volkswagen	Golf Mk4 R32/4Motion	PFF85-431	Front Strut Top Mount Bush -10mm	-10mm	2	12000	11
Volkswagen	Golf Mk4 R32/4Motion	PFF85-505	Front Engine Mount Dog Bone Small Bush		1	5250	10
Volkswagen	Golf Mk4 R32/4Motion	PFR3-508	Rear Trailing Arm Front Bush		2	12000	9
Volkswagen	Golf Mk4 R32/4Motion	PFR3-508G	Rear Trailing Arm Front Bush Toe Adjust		2	14500	9
Volkswagen	Golf Mk4 R32/4Motion	PFR3-510	Rear Arm Inner Bush		4	22000	5
Volkswagen	Golf Mk4 R32/4Motion	PFR3-510G	Rear Arm Inner Bush Camber Adjustable		4	40000	5
Volkswagen	Golf Mk4 R32/4Motion	PFR3-511-13	Rear Anti Roll Bar Mounting 13mm	13mm	2	7500	6
Volkswagen	Golf Mk4 R32/4Motion	PFR3-511-14	Rear Anti Roll Bar Mounting 14mm	14mm	2	7500	6
Volkswagen	Golf Mk4 R32/4Motion	PFR3-511-15	Rear Anti Roll Bar Mounting 15mm	15mm	2	7500	6
Volkswagen	Golf Mk4 R32/4Motion	PFR3-511-16	Rear Anti Roll Bar Mounting 16mm	16mm	2	7500	6
Volkswagen	Golf Mk4 R32/4Motion	PFR3-511-19	Rear Anti Roll Bar Mounting 19mm	19mm	2	7500	6
Volkswagen	Golf Mk4 R32/4Motion	PFR85-425	Rear Diff Front Mounting Bush		2	12000	25
Volkswagen	Golf Mk4 R32/4Motion	PFR85-426	Rear Diff Rear Mounting Bush		2	12000	26
Volkswagen	Golf Mk4 R32/4Motion	PFR85-427	Rear Subframe Mounting Bush		4	26000	27
Volkswagen	Golf MK5 1K	PF85K-1005	Powerflex Handling Pack (-2008 Petrol Only)		1	43750	
Volkswagen	Golf MK5 1K	PF85K-1006	Powerflex Handling Pack (2008- Petrol Only)		1	43750	
Volkswagen	Golf MK5 1K	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Golf MK5 1K	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Golf MK5 1K	PFF85-502	Front Wishbone Rear Bush		2	14500	2
Volkswagen	Golf MK5 1K	PFF85-502G	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	29000	2
Volkswagen	Golf MK5 1K	PFF85-503-21.7	Front Anti Roll Bar Bush 21.7mm	21.7mm	2	7500	3
Volkswagen	Golf MK5 1K	PFF85-503-22	Front Anti Roll Bar Bush 22mm	22mm	2	7500	3
Volkswagen	Golf MK5 1K	PFF85-503-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	7500	3
Volkswagen	Golf MK5 1K	PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	7500	3
Volkswagen	Golf MK5 1K	PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	2	7500	3
Volkswagen	Golf MK5 1K	PFF85-504	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Golf MK5 1K	PFF85-504P	Lower Engine Mount Insert (Large) Track Use		1	5750	4

Volkswagen	Golf MK5 1K	PFF85-504R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Golf MK5 1K	PFF85-505	Lower Engine Mount Small Bush		1	5250	5
Volkswagen	Golf MK5 1K	PFF85-530	Transmission Mount Insert		1	7250	30
Volkswagen	Golf MK5 1K	PFF85-531	Upper Engine Mount Insert		1	7250	31
Volkswagen	Golf MK5 1K	PFF85-532	Upper Engine Mount Insert		1	7250	31
Volkswagen	Golf MK5 1K	PFF85-704	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Golf MK5 1K	PFF85-704P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Golf MK5 1K	PFF85-704R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Golf MK5 1K	PFR85-508	Rear Tie Bar to Chassis Front Bush		2	10000	8
Volkswagen	Golf MK5 1K	PFR85-509	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Golf MK5 1K	PFR85-510	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Golf MK5 1K	PFR85-511	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Golf MK5 1K	PFR85-512	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Golf MK5 1K	PFR85-513	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Golf MK5 1K	PFR85-514	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Golf MK5 1K	PFR85-515-18.5	Rear Anti Roll Bar Bush 18.5mm	18.5mm	2	8500	15
Volkswagen	Golf MK5 1K	PFR85-515-19.6	Rear Anti Roll Bar Bush 19.6mm	19.6mm	2	8500	15
Volkswagen	Golf MK5 1K	PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	8500	15
Volkswagen	Golf MK5 1K	PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	8500	15
Volkswagen	Golf MK5 1K	PFR85-515-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	8500	15
Volkswagen	Golf MK5 1K	PFR85-524	Rear Diff Front Mounting Bush		1	7250	24
Volkswagen	Golf MK5 1K	PFR85-525	Rear Diff Rear Mounting Bush		2	13000	25
Volkswagen	Golf MK5 1K	PFR85-527	Rear Subframe Front Mounting Bush		2	19500	27
Volkswagen	Golf MK5 1K	PFR85-528	Rear Subframe Rear Mounting Bush		2	19500	28
Volkswagen	Golf Mk5 GTI & R32	PF85K-1005	Powerflex Handling Pack (-2008 Petrol Only)		1	43750	
Volkswagen	Golf Mk5 GTI & R32	PF85K-1006	Powerflex Handling Pack (2008- Petrol Only)		1	43750	
Volkswagen	Golf Mk5 GTI & R32	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Golf Mk5 GTI & R32	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Golf Mk5 GTI & R32	PFF85-502	Front Wishbone Rear Bush		2	14500	2
Volkswagen	Golf Mk5 GTI & R32	PFF85-502G	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	29000	2
Volkswagen	Golf Mk5 GTI & R32	PFF85-503-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	7500	3
Volkswagen	Golf Mk5 GTI & R32	PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	7500	3
Volkswagen	Golf Mk5 GTI & R32	PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	2	7500	3
Volkswagen	Golf Mk5 GTI & R32	PFF85-504	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Golf Mk5 GTI & R32	PFF85-504P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Golf Mk5 GTI & R32	PFF85-504R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Golf Mk5 GTI & R32	PFF85-505	Lower Engine Mount Small Bush		1	5250	5
Volkswagen	Golf Mk5 GTI & R32	PFF85-530	Transmission Mount Insert		1	7250	30
Volkswagen	Golf Mk5 GTI & R32	PFF85-531	Upper Engine Mount Insert		1	7250	31
Volkswagen	Golf Mk5 GTI & R32	PFF85-532	Upper Engine Mount Insert		1	7250	31
Volkswagen	Golf Mk5 GTI & R32	PFF85-704	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Golf Mk5 GTI & R32	PFF85-704P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Golf Mk5 GTI & R32	PFF85-704R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Golf Mk5 GTI & R32	PFR85-508	Rear Tie Bar to Chassis Front Bush		2	10000	8
Volkswagen	Golf Mk5 GTI & R32	PFR85-509	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Golf Mk5 GTI & R32	PFR85-510	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Golf Mk5 GTI & R32	PFR85-511	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Golf Mk5 GTI & R32	PFR85-512	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Golf Mk5 GTI & R32	PFR85-513	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Golf Mk5 GTI & R32	PFR85-514	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Golf Mk5 GTI & R32	PFR85-515-18.5	Rear Anti Roll Bar Bush 18.5mm	18.5mm	2	8500	15
Volkswagen	Golf Mk5 GTI & R32	PFR85-515-19.6	Rear Anti Roll Bar Bush 19.6mm	19.6mm	2	8500	15
Volkswagen	Golf Mk5 GTI & R32	PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	8500	15
Volkswagen	Golf Mk5 GTI & R32	PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	8500	15
Volkswagen	Golf Mk5 GTI & R32	PFR85-515-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	8500	15
Volkswagen	Golf Mk5 GTI & R32	PFR85-524	Rear Diff Front Mounting Bush		1	7250	24
Volkswagen	Golf Mk5 GTI & R32	PFR85-525	Rear Diff Rear Mounting Bush		2	13000	25
Volkswagen	Golf Mk5 GTI & R32	PFR85-527	Rear Subframe Front Mounting Bush		2	19500	27
Volkswagen	Golf Mk5 GTI & R32	PFR85-528	Rear Subframe Rear Mounting Bush		2	19500	28



Volkswagen	Golf Plus 5M	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Golf Plus 5M	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Golf Plus 5M	PFF85-502	Front Wishbone Rear Bush		2	14500	2
Volkswagen	Golf Plus 5M	PFF85-502G	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	29000	2
Volkswagen	Golf Plus 5M	PFF85-503-21.7	Front Anti Roll Bar Bush 21.7mm	21.7mm	2	7500	3
Volkswagen	Golf Plus 5M	PFF85-503-22	Front Anti Roll Bar Bush 22mm	22mm	2	7500	3
Volkswagen	Golf Plus 5M	PFF85-503-23	Front Anti Roll Bar Bush 23mm	23mm	2	7500	3
Volkswagen	Golf Plus 5M	PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	7500	3
Volkswagen	Golf Plus 5M	PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	2	7500	3
Volkswagen	Golf Plus 5M	PFF85-504	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Golf Plus 5M	PFF85-504P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Golf Plus 5M	PFF85-504R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Golf Plus 5M	PFF85-505	Lower Engine Mount Small Bush		1	5250	5
Volkswagen	Golf Plus 5M	PFF85-530	Transmission Mount Insert		1	7250	30
Volkswagen	Golf Plus 5M	PFF85-704	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Golf Plus 5M	PFF85-704P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Golf Plus 5M	PFF85-704R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Golf Plus 5M	PFR85-508	Rear Tie Bar to Chassis Front Bush		2	10000	8
Volkswagen	Golf Plus 5M	PFR85-509	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Golf Plus 5M	PFR85-510	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Golf Plus 5M	PFR85-511	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Golf Plus 5M	PFR85-512	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Golf Plus 5M	PFR85-513	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Golf Plus 5M	PFR85-514	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Golf Plus 5M	PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	8500	15
Volkswagen	Golf Plus 5M	PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	8500	15
Volkswagen	Golf Plus 5M	PFR85-515-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	8500	15
Volkswagen	Golf Plus 5M	PFR85-524	Rear Diff Front Mounting Bush		1	7250	24
Volkswagen	Golf Plus 5M	PFR85-525	Rear Diff Rear Mounting Bush		2	13000	25
Volkswagen	Golf Plus 5M	PFR85-527	Rear Subframe Front Mounting Bush		2	19500	27
Volkswagen	Golf Plus 5M	PFR85-528	Rear Subframe Rear Mounting Bush		2	19500	28
Volkswagen	Golf MK6 5K (2009-2012)	PF85K-1005	Powerflex Handling Pack (-2008 Petrol Only)		1	43750	
Volkswagen	Golf MK6 5K (2009-2012)	PF85K-1006	Powerflex Handling Pack (2008- Petrol Only)		1	43750	
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-502	Front Wishbone Rear Bush		2	14500	2
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-502G	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	29000	2
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-503-21.7	Front Anti Roll Bar Bush 21.7mm	21.7mm	2	7500	3
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-503-22	Front Anti Roll Bar Bush 22mm	22mm	2	7500	3
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-503-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	7500	3
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	7500	3
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	2	7500	3
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-504	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-504P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-504R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-505	Lower Engine Mount Small Bush		1	5250	5
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-530	Transmission Mount Insert		1	7250	30
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-531	Upper Engine Mount Insert		1	7250	31
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-532	Upper Engine Mount Insert		1	7250	31
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-704	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-704P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-704R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-508	Rear Tie Bar to Chassis Front Bush		2	10000	8
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-509	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-510	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-511	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-512	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-513	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-514	Rear Upper Link Inner Bush		2	9000	14

Volkswagen	Golf MK6 5K (2009-2012)	PFR85-515-18.5	Rear Anti Roll Bar Bush 18.5mm	18.5mm	2	8500	15
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-515-19.6	Rear Anti Roll Bar Bush 19.6mm	19.6mm	2	8500	15
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	8500	15
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	8500	15
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-515-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	8500	15
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-524	Rear Diff Front Mounting Bush		1	7250	24
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-525	Rear Diff Rear Mounting Bush		2	13000	25
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-527	Rear Subframe Front Mounting Bush		2	19500	27
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-528	Rear Subframe Rear Mounting Bush		2	19500	28
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PF85K-1007	Powerflex Handling Pack ( 2012 - )		1	51000	
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PF85K-1008	Powerflex Handling Pack ( 2012 - )		1	51000	
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFF85-802	Front Wishbone Rear Bush		2	21000	2
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFF85-803-21.7	Front Anti Roll Bar Bush 21.7mm	21.7mm	2	8000	3
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFF85-803-23.2	Front Anti Roll Bar Bush 23.2mm	23.2mm	2	8000	3
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFF85-803-24	Front Anti Roll Bar Bush 24mm	24mm	2	8000	3
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFF85-803-25	Front Anti Roll Bar Bush 25mm	25mm	2	8000	3
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFF85-830	Lower Engine Mount Insert (Large)		1	7500	30
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFF85-830P	Lower Engine Mount Insert (Large) Track Use		1	7500	30
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFF85-830R	Lower Engine Mount Insert (Large) Diesel		1	7500	30
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFF85-831	Front Lower Engine Mount Hybrid Bush (Large)		1	11750	30
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFF85-832	Lower Engine Mount (Large) Insert		1	7500	30
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFF85-832P	Lower Engine Mount (Large) Insert Track Use		1	7500	30
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFF85-832R	Lower Engine Mount (Large) Insert Diesel		1	7500	30
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFF85-833	Front Lower Engine Mount Hybrid Bush (Large)		1	11750	30
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFR85-513	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFR85-514	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFR85-811	Rear Tie Bar Outer Bush		2	14000	11
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFR85-812	Rear Tie Bar Inner Bush		2	14000	12
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFR85-815-18.5	Rear Anti Roll Bar Bush 18.5mm	18.5mm	2	8000	15
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFR85-815-19.6	Rear Anti Roll Bar Bush 19.6mm	19.6mm	2	8000	15
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFR85-815-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	8000	15
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFR85-815-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	8000	15
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFR85-816	Rear Trailing Arm Bush		2	15500	16
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFR85-817	Rear Lower Arm Outer Bush		2	12500	17
Volkswagen	Golf MK7 5G 2WD 122PS plus Multi-link	PFR85-818	Rear Lower Arm Inner Bush		2	14000	18
Volkswagen	Golf MK7 5G 2WD upto 122PS Rear Beam	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Golf MK7 5G 2WD upto 122PS Rear Beam	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Golf MK7 5G 2WD upto 122PS Rear Beam	PFF85-802	Front Wishbone Rear Bush		2	21000	2
Volkswagen	Golf MK7 5G 2WD upto 122PS Rear Beam	PFF85-803-21.7	Front Anti Roll Bar Bush 21.7mm	21.7mm	2	8000	3
Volkswagen	Golf MK7 5G 2WD upto 122PS Rear Beam	PFF85-803-23.2	Front Anti Roll Bar Bush 23.2mm	23.2mm	2	8000	3
Volkswagen	Golf MK7 5G 2WD upto 122PS Rear Beam	PFF85-803-24	Front Anti Roll Bar Bush 24mm	24mm	2	8000	3
Volkswagen	Golf MK7 5G 2WD upto 122PS Rear Beam	PFF85-803-25	Front Anti Roll Bar Bush 25mm	25mm	2	8000	3
Volkswagen	Golf MK7 5G 2WD upto 122PS Rear Beam	PFF85-830	Lower Engine Mount Insert (Large)		1	7500	30
Volkswagen	Golf MK7 5G 2WD upto 122PS Rear Beam	PFF85-830P	Lower Engine Mount Insert (Large) Track Use		1	7500	30
Volkswagen	Golf MK7 5G 2WD upto 122PS Rear Beam	PFF85-830R	Lower Engine Mount Insert (Large) Diesel		1	7500	30
Volkswagen	Golf MK7 5G 2WD upto 122PS Rear Beam	PFF85-831	Front Lower Engine Mount Hybrid Bush (Large)		1	11750	30
Volkswagen	Golf MK7 5G 2WD upto 122PS Rear Beam	PFF85-832	Lower Engine Mount (Large) Insert		1	7500	30
Volkswagen	Golf MK7 5G 2WD upto 122PS Rear Beam	PFF85-832P	Lower Engine Mount (Large) Insert Track Use		1	7500	30
Volkswagen	Golf MK7 5G 2WD upto 122PS Rear Beam	PFF85-832R	Lower Engine Mount (Large) Insert Diesel		1	7500	30
Volkswagen	Golf MK7 5G 2WD upto 122PS Rear Beam	PFF85-833	Front Lower Engine Mount Hybrid Bush (Large)		1	11750	30
Volkswagen	Golf MK7 5G 2WD upto 122PS Rear Beam	PFR85-810	Rear Beam Mounting Bush		2	16500	10
Volkswagen	Golf MK7 5G 4WD	PF85K-1007	Powerflex Handling Pack ( 2012 - )		1	51000	
Volkswagen	Golf MK7 5G 4WD	PF85K-1008	Powerflex Handling Pack ( 2012 - )		1	51000	
Volkswagen	Golf MK7 5G 4WD	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Golf MK7 5G 4WD	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Golf MK7 5G 4WD	PFF85-802	Front Wishbone Rear Bush		2	21000	2
Volkswagen	Golf MK7 5G 4WD	PFF85-803-21.7	Front Anti Roll Bar Bush 21.7mm	21.7mm	2	8000	3

Volkswagen	Golf MK7 5G 4WD	PFF85-803-23.2	Front Anti Roll Bar Bush 23.2mm	23.2mm	2	8000	3
Volkswagen	Golf MK7 5G 4WD	PFF85-803-24	Front Anti Roll Bar Bush 24mm	24mm	2	8000	3
Volkswagen	Golf MK7 5G 4WD	PFF85-803-25	Front Anti Roll Bar Bush 25mm	25mm	2	8000	3
Volkswagen	Golf MK7 5G 4WD	PFF85-830	Lower Engine Mount Insert (Large)		1	7500	30
Volkswagen	Golf MK7 5G 4WD	PFF85-830P	Lower Engine Mount Insert (Large) Track Use		1	7500	30
Volkswagen	Golf MK7 5G 4WD	PFF85-830R	Lower Engine Mount Insert (Large) Diesel		1	7500	30
Volkswagen	Golf MK7 5G 4WD	PFF85-831	Front Lower Engine Mount Hybrid Bush (Large)		1	11750	30
Volkswagen	Golf MK7 5G 4WD	PFF85-832	Lower Engine Mount (Large) Insert		1	7500	30
Volkswagen	Golf MK7 5G 4WD	PFF85-832P	Lower Engine Mount (Large) Insert Track Use		1	7500	30
Volkswagen	Golf MK7 5G 4WD	PFF85-832R	Lower Engine Mount (Large) Insert Diesel		1	7500	30
Volkswagen	Golf MK7 5G 4WD	PFF85-833	Front Lower Engine Mount Hybrid Bush (Large)		1	11750	30
Volkswagen	Golf MK7 5G 4WD	PFR85-513	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Golf MK7 5G 4WD	PFR85-514	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Golf MK7 5G 4WD	PFR85-524	Rear Diff Front Mounting Bush		1	7250	24
Volkswagen	Golf MK7 5G 4WD	PFR85-525	Rear Diff Rear Mounting Bush		2	13000	25
Volkswagen	Golf MK7 5G 4WD	PFR85-811	Rear Tie Bar Outer Bush		2	14000	11
Volkswagen	Golf MK7 5G 4WD	PFR85-812	Rear Tie Bar Inner Bush		2	14000	12
Volkswagen	Golf MK7 5G 4WD	PFR85-815-18.5	Rear Anti Roll Bar Bush 18.5mm	18.5mm	2	8000	15
Volkswagen	Golf MK7 5G 4WD	PFR85-815-19.6	Rear Anti Roll Bar Bush 19.6mm	19.6mm	2	8000	15
Volkswagen	Golf MK7 5G 4WD	PFR85-815-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	8000	15
Volkswagen	Golf MK7 5G 4WD	PFR85-815-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	8000	15
Volkswagen	Golf MK7 5G 4WD	PFR85-816	Rear Trailing Arm Bush		2	15500	16
Volkswagen	Golf MK7 5G 4WD	PFR85-817	Rear Lower Arm Outer Bush		2	12500	17
Volkswagen	Golf MK7 5G 4WD	PFR85-818	Rear Lower Arm Inner Bush		2	14000	18
Volkswagen	Iltis (1978 - 1988)	PFR85-1020 KIT2	Mounting Bush Kit Of 2		1	14000	22
Volkswagen	Iltis (1978 - 1988)	PFR85-1020 KIT2	Mounting Bush Kit Of 2		1	14000	22
Volkswagen	Iltis (1978 - 1988)	PFR85-1020 KIT3	Diff Mounting Bush Kit Of 3		1	20750	21
Volkswagen	Jetta (2011 - ON)	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Jetta (2011 - ON)	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Jetta (2011 - ON)	PFF85-802	Front Wishbone Rear Bush		2	21000	2
Volkswagen	Jetta (2011 - ON)	PFR85-817	Rear Lower Arm Outer Bush		2	12500	17
Volkswagen	Jetta MK1 (1979-1984)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Jetta MK1 (1979-1984)	PFF85-211	Front Wishbone Inner Bush		2	10000	1
Volkswagen	Jetta MK1 (1979-1984)	PFF85-213	Front Wishbone Rear Bush		2	10000	2
Volkswagen	Jetta MK1 (1979-1984)	PFF85-215	Front Anti Roll Bar Outer Mount 16mm	16mm	2	7500	4
Volkswagen	Jetta MK1 (1979-1984)	PFF85-215-22	Front Anti Roll Bar Outer Mount 22mm	22mm	2	7500	4
Volkswagen	Jetta MK1 (1979-1984)	PFF85-216	Front Anti Roll Bar Inner Mount		2	7500	3
Volkswagen	Jetta MK1 (1979-1984)	PFF85-229	Steering Rack Mount		1	3250	11
Volkswagen	Jetta MK1 (1979-1984)	PFF85-230	Steering Rack Mount		1	3250	12
Volkswagen	Jetta MK1 (1979-1984)	PFF85-235	Engine Mount Stopper Bush		1	4500	5
Volkswagen	Jetta MK1 (1979-1984)	PFR85-220	Rear Beam Mounting Bush		2	12000	7
Volkswagen	Jetta MK1 (1979-1984)	PFR85-225	Rear Anti Roll Bar Mount (Inner)	19.5mm	2	9000	8
Volkswagen	Jetta MK1 (1979-1984)	PFR85-226	Rear Anti Roll Bar Mount (Outer) 18mm	18mm	2	7000	9
Volkswagen	Jetta MK1 (1979-1984)	PFR85-226-20.5	Rear Anti Roll Bar Mount (Outer) 20.5mm	20.5mm	2	7000	9
Volkswagen	Jetta MK1 (1979-1984)	PFR85-241	Rear Shock Top Mounting Bush		2	10500	20
Volkswagen	Jetta MK2 (1985-1992)	BS006	Bump Stop Front		2	6500	
Volkswagen	Jetta MK2 (1985-1992)	BS008	Bump Stop Rear		2	6500	
Volkswagen	Jetta MK2 (1985-1992)	BS2001K	Bump Stop Kit	Front	1	9250	
Volkswagen	Jetta MK2 (1985-1992)	EXH006	Exhaust Mounts		1	2250	
Volkswagen	Jetta MK2 (1985-1992)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Jetta MK2 (1985-1992)	PFF85-201	Front Wishbone Front Bush	30mm	2	10500	1
Volkswagen	Jetta MK2 (1985-1992)	PFF85-203	Front Wishbone Inner Bush (Rear)		2	10500	2
Volkswagen	Jetta MK2 (1985-1992)	PFF85-205	Front Anti Roll Bar Mount 18mm	18mm	2	9000	3
Volkswagen	Jetta MK2 (1985-1992)	PFF85-205-20	Front Anti Roll Bar Bush 20mm	20mm	2	9000	3
Volkswagen	Jetta MK2 (1985-1992)	PFF85-205-22	Front Anti Roll Bar Bush Eibach 22mm	22mm	2	9000	3
Volkswagen	Jetta MK2 (1985-1992)	PFF85-208	Front Eye Bolt Mounting Bush		2	7500	4
Volkswagen	Jetta MK2 (1985-1992)	PFF85-208-10	Front Eye Bolt Mounting Bush 10mm	10mm	2	7500	4
Volkswagen	Jetta MK2 (1985-1992)	PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	7500	5
Volkswagen	Jetta MK2 (1985-1992)	PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	7500	5

Volkswagen	Jetta MK2 (1985-1992)	PFF85-231	Non Power Steering Rack Mount		2	6500	9
Volkswagen	Jetta MK2 (1985-1992)	PFF85-232	Power Steering Rack Mount	18.5mm wide bracket	1	3250	9
Volkswagen	Jetta MK2 (1985-1992)	PFF85-233	Power Steering Rack Mount	15mm wide bracket	1	3250	9
Volkswagen	Jetta MK2 (1985-1992)	PFF85-244	Rear Lower Engine Mount Bush		1	12000	20
Volkswagen	Jetta MK2 (1985-1992)	PFF85-244R	Rear Lower Engine Mount Bush, Diesel		1	12000	20
Volkswagen	Jetta MK2 (1985-1992)	PFF85-245	Rear Lower Engine Mount Insert		1	5500	20
Volkswagen	Jetta MK2 (1985-1992)	PFF85-245R	Rear Lower Engine Mount Insert, Diesel		1	5500	20
Volkswagen	Jetta MK2 (1985-1992)	PFF85-250	Front Cross Member Mounting Bush		4	11000	6
Volkswagen	Jetta MK2 (1985-1992)	PFR85-207	Rear Beam Mounting Bush		2	15500	7
Volkswagen	Jetta MK2 (1985-1992)	PFR85-212	Rear Anti-Roll Bar To Beam Bush Eibach		2	9000	12
Volkswagen	Jetta MK2 (1985-1992)	PFR85-225-25	Rear Anti Roll Bar Bush Eibach 25mm	25mm	2	9000	25
Volkswagen	Jetta MK2 (1985-1992)	PFR85-240	Rear Shock Top Mounting Bush		2	7500	8
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-502	Front Wishbone Rear Bush		2	14500	2
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-502G	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	29000	2
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-503-19.6	Front Anti Roll Bar Bush 19.6mm	19.6mm	2	7500	3
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-503-20	Front Anti Roll Bar Bush 20mm	20mm	2	7500	3
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-503-20.7	Front Anti Roll Bar Bush 20.7mm	20.7mm	2	7500	3
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-503-21.7	Front Anti Roll Bar Bush 21.7mm	21.7mm	2	7500	3
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-503-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	7500	3
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-503-23	Front Anti Roll Bar Bush 23mm	23mm	2	7500	3
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	7500	3
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	2	7500	3
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-504	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-504P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-504R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-505	Lower Engine Mount Small Bush		1	5250	5
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-530	Transmission Mount Insert		1	7250	30
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-531	Upper Engine Mount Insert		1	7250	31
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-532	Upper Engine Mount Insert		1	7250	31
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-704	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-704P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-704R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-508	Rear Tie Bar to Chassis Front Bush		2	10000	8
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-509	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-510	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-511	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-512	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-513	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-514	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-515-18	Rear Anti Roll Bar Bush 18mm	18mm	2	8500	15
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-515-18.5	Rear Anti Roll Bar Bush 18.5mm	18.5mm	2	8500	15
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-515-19	Rear Anti Roll Bar Bush 19mm	19mm	2	8500	15
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-515-19.6	Rear Anti Roll Bar Bush 19.6mm	19.6mm	2	8500	15
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-515-20	Rear Anti Roll Bar Bush 20mm	20mm	2	8500	15
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	8500	15
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	8500	15
Volkswagen	Lupo (1999 - 2006)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Lupo (1999 - 2006)	PFF85-208-10	Front Eye Bolt Mounting Bush 10mm (M8 nut)	M10	2	7500	4
Volkswagen	Lupo (1999 - 2006)	PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	7500	5
Volkswagen	Lupo (1999 - 2006)	PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	7500	5
Volkswagen	Lupo (1999 - 2006)	PFF85-401	Front Wishbone Inner Bush (front)		2	9500	1
Volkswagen	Lupo (1999 - 2006)	PFF85-402	Front Wishbone Rear Bush		2	10500	2
Volkswagen	Lupo (1999 - 2006)	PFF85-403-18	Front Anti Roll Bar Bush 18mm	18mm	2	8000	3
Volkswagen	Lupo (1999 - 2006)	PFF85-403-20	Front Anti Roll Bar Bush 20mm	20mm	2	8000	3
Volkswagen	Lupo (1999 - 2006)	PFF85-403-22	Front Anti Roll Bar Bush 22mm	22mm	2	8000	3
Volkswagen	Lupo (1999 - 2006)	PFF85-431	Front Strut Top Mount Bush -10mm	-10mm	2	12000	11
Volkswagen	Lupo (1999 - 2006)	PFF85-920	Lower Engine Mount Large Bush		1	8750	6

Volkswagen	Lupo (1999 - 2006)	PFF85-921	Lower Engine Mount Large Bush		1	7500	6
Volkswagen	Lupo (1999 - 2006)	PFR85-615	Rear Beam Mounting Bush	58mm	2	15000	7
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-201	Front Wishbone Front Bush	30mm	2	10500	1
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-410	Front Wishbone Rear Bush		2	12000	2
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-410PA	Front Wishbone Rear Bush		2	11000	2
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-411-21	Front Anti Roll Bar Mount 21mm	21mm	2	7500	3
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-411-23	Front Anti Roll Bar Mount 23mm	23mm	2	7500	3
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-412	Front Anti Roll Bar Link Bush Kit		2	10000	4
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-414	Front Wishbone Rear Bush (Race Use)		2	34000	2
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-416	Steering Rack Mount Bush		1	3250	7
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-420	Front Engine Mount Dog Bone		1	5250	8
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-420R	Front Engine Mount Dog Bone (Diesel)		1	6000	8
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-424	Front Subframe Rear Bush		2	13500	24
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-430	Front Strut Top Mount Bush		2	10500	11
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-431	Front Strut Top Mount Bush -10mm	-10mm	2	12000	11
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-505	Front Engine Mount Dog Bone Small Bush		1	5250	9
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFR85-415	Rear Beam Mounting Bush, 72.5mm	72.5mm	2	15500	5
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFR85-610	Rear Beam Mounting Bush, 69mm	69mm	2	15500	5
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-201	Front Wishbone Front Bush	30mm	2	10500	1
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-410	Front Wishbone Rear Bush		2	12000	2
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-410PA	Front Wishbone Rear Bush		2	11000	2
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-411-21	Front Anti Roll Bar Mount 21mm	21mm	2	7500	3
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-411-23	Front Anti Roll Bar Mount 23mm	23mm	2	7500	3
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-412	Front Anti Roll Bar Link Bush Kit		2	10000	4
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-414	Front Wishbone Rear Bush (Race Use)		2	34000	2
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-416	Steering Rack Mount Bush		1	3250	7
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-420	Front Engine Mount Dog Bone		1	5250	8
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-420R	Front Engine Mount Dog Bone (Diesel)		1	6000	8
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-424	Front Subframe Rear Bush		2	13500	24
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-430	Front Strut Top Mount Bush		2	10500	11
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-431	Front Strut Top Mount Bush -10mm	-10mm	2	12000	11
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-505	Front Engine Mount Dog Bone Small Bush		1	5250	10
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR3-508	Rear Trailing Arm Front Bush		2	12000	9
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR3-508G	Rear Trailing Arm Front Bush Toe Adjust		2	14500	9
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR3-510	Rear Arm Inner Bush		4	22000	5
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR3-510G	Rear Arm Inner Bush Camber Adjustable		4	40000	5
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR3-511-13	Rear Anti Roll Bar Mounting 13mm	13mm	2	7500	6
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR3-511-14	Rear Anti Roll Bar Mounting 14mm	14mm	2	7500	6
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR3-511-15	Rear Anti Roll Bar Mounting 15mm	15mm	2	7500	6
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR3-511-16	Rear Anti Roll Bar Mounting 16mm	16mm	2	7500	6
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR3-511-19	Rear Anti Roll Bar Mounting 19mm	19mm	2	7500	6
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR85-425	Rear Diff Front Mounting Bush		2	12000	25
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR85-426	Rear Diff Rear Mounting Bush		2	12000	26
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR85-427	Rear Subframe Mounting Bush		4	26000	27
Volkswagen	Passat (1988 - 1996)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Passat (1988 - 1996)	PFF85-244	Rear Lower Engine Mount Bush		1	12000	20
Volkswagen	Passat (1988 - 1996)	PFF85-244R	Rear Lower Engine Mount Bush, Diesel		1	12000	20
Volkswagen	Passat (1988 - 1996)	PFF85-245	Rear Lower Engine Mount Insert		1	5500	20
Volkswagen	Passat (1988 - 1996)	PFF85-245R	Rear Lower Engine Mount Insert, Diesel		1	5500	20
Volkswagen	Passat (1988 - 1996)	PFF85-280	Front Lower Engine Mounting Bush & Inserts		1	9000	20
Volkswagen	Passat B5 (1996 - 2005)4 Motion (1996 - 2005)	PFF3-201	Front Lower Shock Mount		2	15000	1
Volkswagen	Passat B5 (1996 - 2005)4 Motion (1996 - 2005)	PFF3-202	Front Tie Bar Inner Bush		2	22500	2
Volkswagen	Passat B5 (1996 - 2005)4 Motion (1996 - 2005)	PFF3-203	Front Upper Arm To Chassis Bush		4	19000	3
Volkswagen	Passat B5 (1996 - 2005)4 Motion (1996 - 2005)	PFF3-203G	Front Upper Arm To Chassis Bush Camber Adjustable		4	37000	3
Volkswagen	Passat B5 (1996 - 2005)4 Motion (1996 - 2005)	PFF3-204-27	Front Anti Roll Bar Bush 27mm	27mm	2	7500	4
Volkswagen	Passat B5 (1996 - 2005)4 Motion (1996 - 2005)	PFF3-204-29	Front Anti Roll Bar Bush 29mm	29mm	2	7500	4
Volkswagen	Passat B5 (1996 - 2005)4 Motion (1996 - 2005)	PFF3-211	Front Lower Arm Inner Bush		2	13500	11
Volkswagen	Passat B5 (1996 - 2005)4 Motion (1996 - 2005)	PFF3-213	Front Anti Roll Bar Link Bush		4	19000	5
Volkswagen	Passat B5 (1996 - 2005)4 Motion (1996 - 2005)	PFF3-220	Engine Snub Nose Mount		1	5250	16

Volkswagen	Passat B5 (1996 - 2005)4 Motion Estate (1996 - 2005)	PFF3-201	Front Lower Shock Mount		2	15000	1
Volkswagen	Passat B5 (1996 - 2005)4 Motion Estate (1996 - 2005)	PFF3-202	Front Tie Bar Inner Bush		2	22500	2
Volkswagen	Passat B5 (1996 - 2005)4 Motion Estate (1996 - 2005)	PFF3-203	Front Upper Arm To Chassis Bush		4	19000	3
Volkswagen	Passat B5 (1996 - 2005)4 Motion Estate (1996 - 2005)	PFF3-203G	Front Upper Arm To Chassis Bush Camber Adjustable		4	37000	3
Volkswagen	Passat B5 (1996 - 2005)4 Motion Estate (1996 - 2005)	PFF3-204-27	Front Anti Roll Bar Bush 27mm	27mm	2	7500	4
Volkswagen	Passat B5 (1996 - 2005)4 Motion Estate (1996 - 2005)	PFF3-204-29	Front Anti Roll Bar Bush 29mm	29mm	2	7500	4
Volkswagen	Passat B5 (1996 - 2005)4 Motion Estate (1996 - 2005)	PFF3-211	Front Lower Arm Inner Bush		2	13500	11
Volkswagen	Passat B5 (1996 - 2005)4 Motion Estate (1996 - 2005)	PFF3-213	Front Anti Roll Bar Link Bush		4	19000	5
Volkswagen	Passat B5 (1996 - 2005)4 Motion Estate (1996 - 2005)	PFF3-220	Engine Snub Nose Mount		1	5250	16
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	BS2007K	Bump Stop Kit	Rear	1	16000	
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	PFF3-201	Front Lower Shock Mount		2	15000	1
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	PFF3-202	Front Tie Bar Inner Bush		2	22500	2
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	PFF3-203	Front Upper Arm To Chassis Bush		4	19000	3
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	PFF3-203G	Front Upper Arm To Chassis Bush Camber Adjustable		4	37000	3
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	PFF3-204-27	Front Anti Roll Bar Bush 27mm	27mm	2	7500	4
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	PFF3-204-29	Front Anti Roll Bar Bush 29mm	29mm	2	7500	4
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	PFF3-211	Front Lower Arm Inner Bush		2	13500	11
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	PFF3-213	Front Anti Roll Bar Link Bush		4	19000	5
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	PFF3-220	Engine Snub Nose Mount		1	5250	16
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	PFR3-215	Rear Beam Mount Bush		2	18500	15
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	BS2007K	Bump Stop Kit	Rear	1	16000	
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	PFF3-201	Front Lower Shock Mount		2	15000	1
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	PFF3-202	Front Tie Bar Inner Bush		2	22500	2
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	PFF3-203	Front Upper Arm To Chassis Bush		4	19000	3
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	PFF3-203G	Front Upper Arm To Chassis Bush Camber Adjustable		4	37000	3
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	PFF3-204-26.5	Front Anti Roll Bar Bush 26.5mm		2	7500	4
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	PFF3-204-27	Front Anti Roll Bar Bush 27mm	27mm	2	7500	4
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	PFF3-204-29	Front Anti Roll Bar Bush 29mm	29mm	2	7500	4
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	PFF3-211	Front Lower Arm Inner Bush		2	13500	11
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	PFF3-213	Front Anti Roll Bar Link Bush		4	19000	5
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	PFF3-220	Engine Snub Nose Mount		1	5250	16
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	PFR3-215	Rear Beam Mount Bush		2	18500	15
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-502	Front Wishbone Rear Bush		2	14500	2
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-502G-5	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	29000	2
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-503-19.6	Front Anti Roll Bar Bush 19.6mm	19.6mm	2	7500	3
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-503-20	Front Anti Roll Bar Bush 20mm	20mm	2	7500	3
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-503-20.7	Front Anti Roll Bar Bush 20.7mm	20.7mm	2	7500	3
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-503-21.7	Front Anti Roll Bar Bush 21.7mm	21.7mm	2	7500	3
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-503-22	Front Anti Roll Bar Bush 22mm	22mm	2	7500	3
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-503-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	7500	3
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-503-23	Front Anti Roll Bar Bush 23mm	23mm	2	7500	3
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	7500	3
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	2	7500	3
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-504	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-504P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-504R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-505	Lower Engine Mount Small Bush		1	5250	5
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-531	Upper Engine Mount Insert		1	7250	31
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-532	Upper Engine Mount Insert		1	7250	31
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-704	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-704P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-704R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-508	Rear Tie Bar to Chassis Front Bush		2	10000	8
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-509	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-510	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-511	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-512	Rear Lower Link Inner Bush		2	10500	12



Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-513	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-514	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-515-18	Rear Anti Roll Bar Bush 18mm	18mm	2	8500	15
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-515-18.5	Rear Anti Roll Bar Bush 18.5mm	18.5mm	2	8500	15
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-515-19.6	Rear Anti Roll Bar Bush 19.6mm	19.6mm	2	8500	15
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	8500	15
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	8500	15
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-515-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	8500	15
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-527	Rear Subframe Front Mounting Bush		2	19500	27
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-528	Rear Subframe Rear Mounting Bush		2	19500	28
Volkswagen	Passat B8 (2015 on)	PF85K-1007	Powerflex Handling Pack ( 2012 - )		1	51000	
Volkswagen	Passat B8 (2015 on)	PF85K-1008	Powerflex Handling Pack ( 2012 - )		1	51000	
Volkswagen	Passat B8 (2015 on)	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Passat B8 (2015 on)	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Passat B8 (2015 on)	PFF85-802	Front Wishbone Rear Bush		2	21000	2
Volkswagen	Passat B8 (2015 on)	PFF85-830	Lower Engine Mount Insert (Large)		1	7500	30
Volkswagen	Passat B8 (2015 on)	PFF85-830P	Lower Engine Mount Insert (Large) Track Use		1	7500	30
Volkswagen	Passat B8 (2015 on)	PFF85-830R	Lower Engine Mount Insert (Large) Diesel		1	7500	30
Volkswagen	Passat B8 (2015 on)	PFF85-831	Front Lower Engine Mount Hybrid Bush (Large)		1	11750	30
Volkswagen	Passat B8 (2015 on)	PFF85-832	Lower Engine Mount (Large) Insert		1	7500	30
Volkswagen	Passat B8 (2015 on)	PFF85-832P	Lower Engine Mount (Large) Insert Track Use		1	7500	30
Volkswagen	Passat B8 (2015 on)	PFF85-832R	Lower Engine Mount (Large) Insert Diesel		1	7500	30
Volkswagen	Passat B8 (2015 on)	PFF85-833	Front Lower Engine Mount Hybrid Bush (Large)		1	11750	30
Volkswagen	Passat B8 (2015 on)	PFR85-513	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Passat B8 (2015 on)	PFR85-514	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Passat B8 (2015 on)	PFR85-524	Rear Diff Front Mounting Bush		1	7250	24
Volkswagen	Passat B8 (2015 on)	PFR85-525	Rear Diff Rear Mounting Bush		2	13000	25
Volkswagen	Passat B8 (2015 on)	PFR85-811	Rear Tie Bar Outer Bush		2	14000	11
Volkswagen	Passat B8 (2015 on)	PFR85-812	Rear Tie Bar Inner Bush		2	14000	12
Volkswagen	Passat B8 (2015 on)	PFR85-815-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	8000	15
Volkswagen	Passat B8 (2015 on)	PFR85-815-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	8000	15
Volkswagen	Passat B8 (2015 on)	PFR85-816	Rear Trailing Arm Bush		2	15500	16
Volkswagen	Passat B8 (2015 on)	PFR85-817	Rear Lower Arm Outer Bush		2	12500	17
Volkswagen	Passat CC 35 (2008-2012)	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Passat CC 35 (2008-2012)	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Passat CC 35 (2008-2012)	PFF85-502	Front Wishbone Rear Bush		2	14500	2
Volkswagen	Passat CC 35 (2008-2012)	PFF85-502G-5	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	29000	2
Volkswagen	Passat CC 35 (2008-2012)	PFF85-503-19.6	Front Anti Roll Bar Bush 19.6mm	19.6mm	2	7500	3
Volkswagen	Passat CC 35 (2008-2012)	PFF85-503-20	Front Anti Roll Bar Bush 20mm	20mm	2	7500	3
Volkswagen	Passat CC 35 (2008-2012)	PFF85-503-20.7	Front Anti Roll Bar Bush 20.7mm	20.7mm	2	7500	3
Volkswagen	Passat CC 35 (2008-2012)	PFF85-503-21.7	Front Anti Roll Bar Bush 21.7mm	21.7mm	2	7500	3
Volkswagen	Passat CC 35 (2008-2012)	PFF85-503-22	Front Anti Roll Bar Bush 22mm	22mm	2	7500	3
Volkswagen	Passat CC 35 (2008-2012)	PFF85-503-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	7500	3
Volkswagen	Passat CC 35 (2008-2012)	PFF85-503-23	Front Anti Roll Bar Bush 23mm	23mm	2	7500	3
Volkswagen	Passat CC 35 (2008-2012)	PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	7500	3
Volkswagen	Passat CC 35 (2008-2012)	PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	2	7500	3
Volkswagen	Passat CC 35 (2008-2012)	PFF85-504	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Passat CC 35 (2008-2012)	PFF85-504P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Passat CC 35 (2008-2012)	PFF85-504R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Passat CC 35 (2008-2012)	PFF85-505	Lower Engine Mount Small Bush		1	5250	5
Volkswagen	Passat CC 35 (2008-2012)	PFF85-704	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Passat CC 35 (2008-2012)	PFF85-704P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Passat CC 35 (2008-2012)	PFF85-704R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Passat CC 35 (2008-2012)	PFR85-508	Rear Tie Bar to Chassis Front Bush		2	10000	8
Volkswagen	Passat CC 35 (2008-2012)	PFR85-509	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Passat CC 35 (2008-2012)	PFR85-510	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Passat CC 35 (2008-2012)	PFR85-511	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Passat CC 35 (2008-2012)	PFR85-512	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Passat CC 35 (2008-2012)	PFR85-513	Rear Upper Link Outer Bush		2	9000	13

Volkswagen	Passat CC 35 (2008-2012)	PFR85-514	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Passat CC 35 (2008-2012)	PFR85-515-18	Rear Anti Roll Bar Bush 18mm	18mm	2	8500	15
Volkswagen	Passat CC 35 (2008-2012)	PFR85-515-18.5	Rear Anti Roll Bar Bush 18.5mm	18.5mm	2	8500	15
Volkswagen	Passat CC 35 (2008-2012)	PFR85-515-19.6	Rear Anti Roll Bar Bush 19.6mm	19.6mm	2	8500	15
Volkswagen	Passat CC 35 (2008-2012)	PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	8500	15
Volkswagen	Passat CC 35 (2008-2012)	PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	8500	15
Volkswagen	Passat CC 35 (2008-2012)	PFR85-515-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	8500	15
Volkswagen	Passat CC 35 (2008-2012)	PFR85-527	Rear Subframe Front Mounting Bush		2	19500	27
Volkswagen	Passat CC 35 (2008-2012)	PFR85-528	Rear Subframe Rear Mounting Bush		2	19500	28
Volkswagen	Phaeton (2002-2009)	PFF3-213-12	Front Anti Roll Bar Link Bush	12mm	4	18000	5
Volkswagen	Polo (1975 - 1994)	EXH006	Exhaust Mounts		1	2250	
Volkswagen	Polo (1975 - 1994)	PFF85-101	Front Wishbone Outer Bush		2	9500	1
Volkswagen	Polo (1975 - 1994)	PFF85-103	Front Wishbone Inner Bush		2	8000	2
Volkswagen	Polo (1975 - 1994)	PFF85-105	Front Anti Roll Bar Mount 18mm	18mm	2	7500	3
Volkswagen	Polo 6N (1995 - 2002)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Polo 6N (1995 - 2002)	PFF85-208-10	Front Eye Bolt Mounting Bush 10mm (M8 nut)	10mm	2	7500	4
Volkswagen	Polo 6N (1995 - 2002)	PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	7500	5
Volkswagen	Polo 6N (1995 - 2002)	PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20/22mm	2	7500	5
Volkswagen	Polo 6N (1995 - 2002)	PFF85-401	Front Wishbone Inner Bush (front)		2	9500	1
Volkswagen	Polo 6N (1995 - 2002)	PFF85-402	Front Wishbone Inner Bush (rear)		2	10500	2
Volkswagen	Polo 6N (1995 - 2002)	PFF85-403-18	Front Anti Roll Bar Bush 18mm	18mm	2	8000	3
Volkswagen	Polo 6N (1995 - 2002)	PFF85-403-20	Front Anti Roll Bar Bush 20mm	20mm	2	8000	3
Volkswagen	Polo 6N (1995 - 2002)	PFF85-403-22	Front Anti Roll Bar Bush 22mm	22mm	2	8000	3
Volkswagen	Polo 6N (1995 - 2002)	PFF85-920	Lower Engine Mount Large Bush		1	8750	6
Volkswagen	Polo 6N (1995 - 2002)	PFR85-240	Rear Shock Top Mounting Bush		2	7500	8
Volkswagen	Polo 6N (1995 - 2002)	PFR85-615	Rear Beam Mounting Bush	58mm	2	15000	7
Volkswagen	Polo 6N (1995 - 2002)	PFR85-915	Rear Beam Mounting Bush	71.5mm	2	15000	7
Volkswagen	Polo 6R/6C (2009 - 2017)	PFF85-1202	Front Arm Rear Bush		2	12500	2
Volkswagen	Polo 6R/6C (2009 - 2017)	PFF85-201	Front Wishbone Front Bush	30mm	2	10500	1
Volkswagen	Polo 6R/6C (2009 - 2017)	PFF85-430	Front Strut Top Mount Bush		2	10500	11
Volkswagen	Polo 6R/6C (2009 - 2017)	PFF85-431	Front Strut Top Mount Bush -10mm	-10mm	2	12000	11
Volkswagen	Polo 6R/6C (2009 - 2017)	PFF85-603-18	Front Anti Roll Bar Bush 18mm	18mm	2	7500	3
Volkswagen	Polo 6R/6C (2009 - 2017)	PFF85-603-19	Front Anti Roll Bar Bush 19mm	19mm	2	7500	3
Volkswagen	Polo 6R/6C (2009 - 2017)	PFF85-603-20	Front Anti Roll Bar Bush 20mm		2	7500	3
Volkswagen	Polo 6R/6C (2009 - 2017)	PFF85-620	Lower Engine Mount Large Bush		1	7500	20
Volkswagen	Polo 6R/6C (2009 - 2017)	PFF85-620P	Lower Engine Mount Large Bush (Track Use)		1	7500	20
Volkswagen	Polo 6R/6C (2009 - 2017)	PFF85-620R	Lower Engine Mount Large Bush (Diesel)		1	7500	20
Volkswagen	Polo 6R/6C (2009 - 2017)	PFR85-415	Rear Beam Mounting Bush, 72.5mm	72.5mm	2	15500	4
Volkswagen	Polo 6R/6C (2009 - 2017)	PFR85-610	Rear Beam Mounting Bush, 69mm	69mm	2	15500	4
Volkswagen	Polo 9N/9N3 (2002 - 2008)	PFF85-201	Front Wishbone Front Bush	30mm	2	10500	1
Volkswagen	Polo 9N/9N3 (2002 - 2008)	PFF85-602	Front Wishbone Rear Bush		2	15000	2
Volkswagen	Polo 9N/9N3 (2002 - 2008)	PFF85-603-16	Front Anti Roll Bar Bush 16mm	16mm	2	7500	3
Volkswagen	Polo 9N/9N3 (2002 - 2008)	PFF85-603-18	Front Anti Roll Bar Bush 18mm	18mm	2	7500	3
Volkswagen	Polo 9N/9N3 (2002 - 2008)	PFF85-603-19	Front Anti Roll Bar Bush 19mm	19mm	2	7500	3
Volkswagen	Polo 9N/9N3 (2002 - 2008)	PFF85-603-20	Front Anti Roll Bar Bush 20mm		2	7500	3
Volkswagen	Polo 9N/9N3 (2002 - 2008)	PFF85-620	Lower Engine Mount Large Bush		1	7500	20
Volkswagen	Polo 9N/9N3 (2002 - 2008)	PFF85-620P	Lower Engine Mount Large Bush (Track Use)		1	7500	20
Volkswagen	Polo 9N/9N3 (2002 - 2008)	PFF85-620R	Lower Engine Mount Large Bush (Diesel)		1	7500	20
Volkswagen	Polo 9N/9N3 (2002 - 2008)	PFR85-415	Rear Beam Mounting Bush, 72.5mm	72.5mm	2	15500	4
Volkswagen	Polo 9N/9N3 (2002 - 2008)	PFR85-610	Rear Beam Mounting Bush, 69mm	69mm	2	15500	4
Volkswagen	Scirocco (1973 - 1992)	BS2001K	Bump Stop Kit	Front	1	9250	
Volkswagen	Scirocco (1973 - 1992)	BS2004K	Bump Stop Kit	Rear	1	9750	
Volkswagen	Scirocco (1973 - 1992)	PFF85-211	Front Wishbone Inner Bush		2	10000	1
Volkswagen	Scirocco (1973 - 1992)	PFF85-213	Front Wishbone Rear Bush		2	10000	2
Volkswagen	Scirocco (1973 - 1992)	PFF85-215	Front Anti Roll Bar Outer Mount 16mm	16mm	2	7500	4
Volkswagen	Scirocco (1973 - 1992)	PFF85-215-22	Front Anti Roll Bar Outer Mount 22mm	22mm	2	7500	4
Volkswagen	Scirocco (1973 - 1992)	PFF85-216	Front Anti Roll Bar Inner Mount		2	7500	3
Volkswagen	Scirocco (1973 - 1992)	PFF85-229	Steering Rack Mount		1	3250	11
Volkswagen	Scirocco (1973 - 1992)	PFF85-230	Steering Rack Mount		1	3250	12

Volkswagen	Scirocco (1973 - 1992)	PFF85-235	Engine Mount Stopper Bush		1	4500	5
Volkswagen	Scirocco (1973 - 1992)	PFR85-220	Rear Beam Mounting Bush		2	12000	7
Volkswagen	Scirocco (1973 - 1992)	PFR85-225	Rear Anti Roll Bar Mount (Inner)	19.5mm	2	9000	8
Volkswagen	Scirocco (1973 - 1992)	PFR85-226	Rear Anti Roll Bar Mount (Outer) 18mm	18mm	2	7000	9
Volkswagen	Scirocco (1973 - 1992)	PFR85-226-20.5	Rear Anti Roll Bar Mount (Outer) 20.5mm	20.5mm	2	7000	9
Volkswagen	Scirocco (1973 - 1992)	PFR85-241	Rear Shock Top Mounting Bush		2	10500	20
Volkswagen	Scirocco Mk3 (2008-)	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Scirocco Mk3 (2008-)	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Scirocco Mk3 (2008-)	PFF85-502	Front Wishbone Rear Bush		2	14500	2
Volkswagen	Scirocco Mk3 (2008-)	PFF85-502G	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	29000	2
Volkswagen	Scirocco Mk3 (2008-)	PFF85-503-22	Front Anti Roll Bar Bush 22mm	22mm	2	7500	3
Volkswagen	Scirocco Mk3 (2008-)	PFF85-503-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	7500	3
Volkswagen	Scirocco Mk3 (2008-)	PFF85-503-23	Front Anti Roll Bar Bush 23mm	23mm	2	7500	3
Volkswagen	Scirocco Mk3 (2008-)	PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	7500	3
Volkswagen	Scirocco Mk3 (2008-)	PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	2	7500	3
Volkswagen	Scirocco Mk3 (2008-)	PFF85-504	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Scirocco Mk3 (2008-)	PFF85-504P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Scirocco Mk3 (2008-)	PFF85-504R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Scirocco Mk3 (2008-)	PFF85-505	Lower Engine Mount Small Bush		1	5250	5
Volkswagen	Scirocco Mk3 (2008-)	PFF85-530	Transmission Mount Insert		1	7250	30
Volkswagen	Scirocco Mk3 (2008-)	PFF85-704	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Scirocco Mk3 (2008-)	PFF85-704P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Scirocco Mk3 (2008-)	PFF85-704R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Scirocco Mk3 (2008-)	PFR85-508	Rear Tie Bar to Chassis Front Bush		2	10000	8
Volkswagen	Scirocco Mk3 (2008-)	PFR85-509	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Scirocco Mk3 (2008-)	PFR85-510	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Scirocco Mk3 (2008-)	PFR85-511	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Scirocco Mk3 (2008-)	PFR85-512	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Scirocco Mk3 (2008-)	PFR85-513	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Scirocco Mk3 (2008-)	PFR85-514	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Scirocco Mk3 (2008-)	PFR85-515-18.5	Rear Anti Roll Bar Bush 18.5mm	18.5mm	2	8500	15
Volkswagen	Scirocco Mk3 (2008-)	PFR85-515-19.6	Rear Anti Roll Bar Bush 19.6mm	19.6mm	2	8500	15
Volkswagen	Scirocco Mk3 (2008-)	PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	8500	15
Volkswagen	Scirocco Mk3 (2008-)	PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	8500	15
Volkswagen	Scirocco Mk3 (2008-)	PFR85-515-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	8500	15
Volkswagen	Tiguan (2016 - )	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Tiguan (2016 - )	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Tiguan (2016 - )	PFF85-802	Front Wishbone Rear Bush		2	21000	2
Volkswagen	Tiguan (2016 - )	PFF85-803-25	Front Anti Roll Bar Bush 25mm	25mm	2	8000	3
Volkswagen	Tiguan (2016 - )	PFF85-830	Lower Engine Mount Insert (Large)		1	7500	30
Volkswagen	Tiguan (2016 - )	PFF85-830P	Lower Engine Mount Insert (Large) Track Use		1	7500	30
Volkswagen	Tiguan (2016 - )	PFF85-830R	Lower Engine Mount Insert (Large) Diesel		1	7500	30
Volkswagen	Tiguan (2016 - )	PFF85-831	Front Lower Engine Mount Hybrid Bush (Large)		1	11750	30
Volkswagen	Tiguan (2016 - )	PFF85-832	Lower Engine Mount (Large) Insert		1	7500	30
Volkswagen	Tiguan (2016 - )	PFF85-832P	Lower Engine Mount (Large) Insert Track Use		1	7500	30
Volkswagen	Tiguan (2016 - )	PFF85-832R	Lower Engine Mount (Large) Insert Diesel		1	7500	30
Volkswagen	Tiguan (2016 - )	PFF85-833	Front Lower Engine Mount Hybrid Bush (Large)		1	11750	30
Volkswagen	Tiguan (2016 - )	PFR85-513	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Tiguan (2016 - )	PFR85-514	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Tiguan (2016 - )	PFR85-815-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	8000	15
Volkswagen	Tiguan (2016 - )	PFR85-816	Rear Trailing Arm Bush		2	15500	16
Volkswagen	Tiguan (2016 - )	PFR85-817	Rear Lower Arm Outer Bush		2	12500	17
Volkswagen	Tiguan (2016 - )	PFR85-818	Rear Lower Arm Inner Bush		2	14000	18
Volkswagen	Tiguan 5N (2007-)	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Tiguan 5N (2007-)	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Tiguan 5N (2007-)	PFF85-502	Front Wishbone Rear Bush		2	14500	2
Volkswagen	Tiguan 5N (2007-)	PFF85-502G-5	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	29000	2
Volkswagen	Tiguan 5N (2007-)	PFF85-503-23	Front Anti Roll Bar Bush 23mm	23mm	2	7500	3
Volkswagen	Tiguan 5N (2007-)	PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	7500	3

Volkswagen	Tiguan 5N (2007-)	PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	2	7500	3
Volkswagen	Tiguan 5N (2007-)	PFF85-504	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Tiguan 5N (2007-)	PFF85-504P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Tiguan 5N (2007-)	PFF85-504R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Tiguan 5N (2007-)	PFF85-505	Lower Engine Mount Small Bush		1	5250	5
Volkswagen	Tiguan 5N (2007-)	PFF85-704	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Tiguan 5N (2007-)	PFF85-704P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Tiguan 5N (2007-)	PFF85-704R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Tiguan 5N (2007-)	PFR85-508	Rear Tie Bar to Chassis Front Bush		2	10000	8
Volkswagen	Tiguan 5N (2007-)	PFR85-509	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Tiguan 5N (2007-)	PFR85-510	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Tiguan 5N (2007-)	PFR85-511	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Tiguan 5N (2007-)	PFR85-512	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Tiguan 5N (2007-)	PFR85-513	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Tiguan 5N (2007-)	PFR85-514	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Tiguan 5N (2007-)	PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	8500	15
Volkswagen	Tiguan 5N (2007-)	PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	8500	15
Volkswagen	Tiguan 5N (2007-)	PFR85-515-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	8500	15
Volkswagen	Tiguan 5N (2007-)	PFR85-527	Rear Subframe Front Mounting Bush		2	19500	27
Volkswagen	Tiguan 5N (2007-)	PFR85-528	Rear Subframe Rear Mounting Bush		2	19500	28
Volkswagen	Touareg (2002 - 2010)	PFF85-1601	Front Lower Wishbone Front Bush		2	11500	1
Volkswagen	Touareg (2002 - 2010)	PFF85-1602	Front Lower Wishbone Rear Bush	72.05mm	2	14000	2
Volkswagen	Touareg (2002 - 2010)	PFF85-1604	Front Upper Wishbone Bush		4	22000	4
Volkswagen	Touareg (2002 - 2010)	PFF85-1702	Front Lower Wishbone Rear Bush	60.05mm	2	12500	2
Volkswagen	Touareg (2011 - )	PFF85-1601	Front Lower Wishbone Front Bush		2	11500	1
Volkswagen	Touareg (2011 - )	PFF85-1602	Front Lower Wishbone Rear Bush	72.05mm	2	14000	2
Volkswagen	Touareg (2011 - )	PFF85-1604	Front Upper Wishbone Bush		4	22000	4
Volkswagen	Touran (2017 - )	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Touran (2017 - )	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Touran (2017 - )	PFF85-802	Front Wishbone Rear Bush		2	21000	2
Volkswagen	Touran (2017 - )	PFF85-803-25	Front Anti Roll Bar Bush 25mm	25mm	2	8000	3
Volkswagen	Touran (2017 - )	PFF85-830	Lower Engine Mount Insert (Large)		1	7500	30
Volkswagen	Touran (2017 - )	PFF85-830P	Lower Engine Mount Insert (Large) Track Use		1	7500	30
Volkswagen	Touran (2017 - )	PFF85-830R	Lower Engine Mount Insert (Large) Diesel		1	7500	30
Volkswagen	Touran (2017 - )	PFF85-831	Front Lower Engine Mount Hybrid Bush (Large)		1	11750	30
Volkswagen	Touran (2017 - )	PFF85-832	Lower Engine Mount (Large) Insert		1	7500	30
Volkswagen	Touran (2017 - )	PFF85-832P	Lower Engine Mount (Large) Insert Track Use		1	7500	30
Volkswagen	Touran (2017 - )	PFF85-832R	Lower Engine Mount (Large) Insert Diesel		1	7500	30
Volkswagen	Touran (2017 - )	PFF85-833	Front Lower Engine Mount Hybrid Bush (Large)		1	11750	30
Volkswagen	Touran (2017 - )	PFR85-513	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Touran (2017 - )	PFR85-514	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Touran (2017 - )	PFR85-815-19.6	Rear Anti Roll Bar Bush 19.6mm	19.6mm	2	8000	15
Volkswagen	Touran (2017 - )	PFR85-815-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	8000	15
Volkswagen	Touran (2017 - )	PFR85-816	Rear Trailing Arm Bush		2	15500	16
Volkswagen	Touran (2017 - )	PFR85-817	Rear Lower Arm Outer Bush		2	12500	17
Volkswagen	Touran (2017 - )	PFR85-818	Rear Lower Arm Inner Bush		2	14000	18
Volkswagen	Touran 1T (2003-)	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Touran 1T (2003-)	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Touran 1T (2003-)	PFF85-502	Front Wishbone Rear Bush		2	14500	2
Volkswagen	Touran 1T (2003-)	PFF85-502G	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	29000	2
Volkswagen	Touran 1T (2003-)	PFF85-503-23	Front Anti Roll Bar Bush 23mm	23mm	2	7500	3
Volkswagen	Touran 1T (2003-)	PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	2	7500	3
Volkswagen	Touran 1T (2003-)	PFF85-504	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Touran 1T (2003-)	PFF85-504P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Touran 1T (2003-)	PFF85-504R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Touran 1T (2003-)	PFF85-505	Lower Engine Mount Small Bush		1	5250	5
Volkswagen	Touran 1T (2003-)	PFF85-530	Transmission Mount Insert		1	7250	30
Volkswagen	Touran 1T (2003-)	PFF85-531	Upper Engine Mount Insert		1	7250	31
Volkswagen	Touran 1T (2003-)	PFF85-532	Upper Engine Mount Insert		1	7250	31

Volkswagen	Touran 1T (2003-)	PFF85-704	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Touran 1T (2003-)	PFF85-704P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Touran 1T (2003-)	PFF85-704R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Touran 1T (2003-)	PFR85-508	Rear Tie Bar to Chassis Front Bush		2	10000	8
Volkswagen	Touran 1T (2003-)	PFR85-509	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Touran 1T (2003-)	PFR85-510	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Touran 1T (2003-)	PFR85-511	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Touran 1T (2003-)	PFR85-512	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Touran 1T (2003-)	PFR85-513	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Touran 1T (2003-)	PFR85-514	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Touran 1T (2003-)	PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	8500	15
Volkswagen	Touran 1T (2003-)	PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	8500	15
Volkswagen	Touran 1T (2003-)	PFR85-515-21.7	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	8500	15
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Automatic	PFF85-1001	Front Lower TCA Inner Bush		2	10000	1
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Automatic	PFF85-1002	Anti Roll Bar Mount Bush		2	7500	2
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Automatic	PFF85-1003	Front Steering Rack Mount Bush		4	9000	3
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Automatic	PFF85-1004	Front Anti Roll Bar To Chassis Bush 21mm	21mm	2	7500	4
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Automatic	PFF85-1004-19	Front Anti Roll Bar To Chassis Bush 19mm	19mm	2	7500	4
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Automatic	PFF85-1005	Front Anti Roll Bar To Chassis Bush 21mm	21mm	2	7500	4
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Automatic	PFF85-1005-23	Front Anti Roll Bar To Chassis Bush 23mm	23mm	2	7500	4
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Automatic	PFF85-1006	Front Arm-Upper Inner Bush		4	42000	6
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Automatic	PFF85-1007	Front Radius Rod Bush		2	22500	7
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Automatic	PFF85-1008-19	Front Endlink Eyelet Bush 19mm	19mm	2	7000	8
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Automatic	PFF85-1008-21	Front Endlink Eyelet Bush 21mm	21mm	2	7000	8
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Automatic	PFF85-1008-23	Front Endlink Eyelet Bush 23mm	23mm	2	7000	8
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Automatic	PFR85-1011	Rear Trailing Arm To Chassis Bush		4	26000	11
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Automatic	PFR85-1016	Gearbox Mounting Bush		1	9250	15
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Manual	PFF85-1001	Front Lower TCA Inner Bush		2	10000	1
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Manual	PFF85-1002	Anti Roll Bar Mount Bush		2	7500	2
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Manual	PFF85-1003	Front Steering Rack Mount Bush		4	9000	3
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Manual	PFF85-1004	Front Anti Roll Bar To Chassis Bush 21mm	21mm	2	7500	4
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Manual	PFF85-1004-19	Front Anti Roll Bar To Chassis Bush 19mm	19mm	2	7500	4
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Manual	PFF85-1005	Front Anti Roll Bar To Chassis Bush 21mm	21mm	2	7500	4
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Manual	PFF85-1005-23	Front Anti Roll Bar To Chassis Bush 23mm	23mm	2	7500	4
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Manual	PFF85-1006	Front Arm-Upper Inner Bush		4	42000	6
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Manual	PFF85-1007	Front Radius Rod Bush		2	22500	7
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Manual	PFF85-1008-19	Front Endlink Eyelet Bush 19mm	19mm	2	7000	8
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Manual	PFF85-1008-21	Front Endlink Eyelet Bush 21mm	21mm	2	7000	8
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Manual	PFF85-1008-23	Front Endlink Eyelet Bush 23mm	23mm	2	7000	8
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Manual	PFR85-1011	Rear Trailing Arm To Chassis Bush		4	26000	11
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models1.6, 1.9, 2.0 Manual	PFR85-1015	Gearbox Mounting Bush		1	7500	15
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models2.1 Model	PFF85-1001	Front Lower TCA Inner Bush		2	10000	1
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models2.1 Model	PFF85-1002	Anti Roll Bar Mount Bush		2	7500	2
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models2.1 Model	PFF85-1003	Front Steering Rack Mount Bush		4	9000	3
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models2.1 Model	PFF85-1004	Front Anti Roll Bar To Chassis Bush 21mm	21mm	2	7500	4
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models2.1 Model	PFF85-1004-19	Front Anti Roll Bar To Chassis Bush 19mm	19mm	2	7500	4
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models2.1 Model	PFF85-1005	Front Anti Roll Bar To Chassis Bush 21mm	21mm	2	7500	4
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models2.1 Model	PFF85-1005-23	Front Anti Roll Bar To Chassis Bush 23mm	23mm	2	7500	4
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models2.1 Model	PFF85-1006	Front Arm-Upper Inner Bush		4	42000	6
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models2.1 Model	PFF85-1007	Front Radius Rod Bush		2	22500	7
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models2.1 Model	PFF85-1008-19	Front Endlink Eyelet Bush 19mm	19mm	2	7000	8
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models2.1 Model	PFF85-1008-21	Front Endlink Eyelet Bush 21mm	21mm	2	7000	8
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models2.1 Model	PFF85-1008-23	Front Endlink Eyelet Bush 23mm	23mm	2	7000	8
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models2.1 Model	PFR85-1011	Rear Trailing Arm To Chassis Bush		4	26000	11
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Petrol Models2.1 Model	PFR85-1016	Gearbox Mounting Bush		1	9250	15
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Diesel Models	PFF85-1001	Front Lower TCA Inner Bush		2	10000	1
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Diesel Models	PFF85-1002	Anti Roll Bar Mount Bush		2	7500	2
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Diesel Models	PFF85-1003	Front Steering Rack Mount Bush		4	9000	3
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Diesel Models	PFF85-1004	Front Anti Roll Bar To Chassis Bush 21mm	21mm	2	7500	4

Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Diesel Models	PFF85-1004-19	Front Anti Roll Bar To Chassis Bush 19mm	19mm	2	7500	4
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Diesel Models	PFF85-1005	Front Anti Roll Bar To Chassis Bush 21mm	21mm	2	7500	4
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Diesel Models	PFF85-1005-23	Front Anti Roll Bar To Chassis Bush 23mm	23mm	2	7500	4
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Diesel Models	PFF85-1006	Front Arm-Upper Inner Bush		4	42000	6
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Diesel Models	PFF85-1007	Front Radius Rod Bush		2	22500	7
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Diesel Models	PFF85-1008-19	Front Endlink Eyelet Bush 19mm	19mm	2	7000	8
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Diesel Models	PFF85-1008-21	Front Endlink Eyelet Bush 21mm	21mm	2	7000	8
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Diesel Models	PFF85-1008-23	Front Endlink Eyelet Bush 23mm	23mm	2	7000	8
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Diesel Models	PFR85-1011	Rear Trailing Arm To Chassis Bush		4	26000	11
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Diesel Models	PFR85-1016	Gearbox Mounting Bush		1	9250	15
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Syncro	PFF85-1001	Front Lower TCA Inner Bush		2	10000	1
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Syncro	PFF85-1002	Anti Roll Bar Mount Bush		2	7500	2
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Syncro	PFF85-1003	Front Steering Rack Mount Bush		4	9000	3
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Syncro	PFF85-1004	Front Anti Roll Bar To Chassis Bush 21mm	21mm	2	7500	4
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Syncro	PFF85-1004-19	Front Anti Roll Bar To Chassis Bush 19mm	19mm	2	7500	4
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Syncro	PFF85-1005	Front Anti Roll Bar To Chassis Bush 21mm	21mm	2	7500	4
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Syncro	PFF85-1005-23	Front Anti Roll Bar To Chassis Bush 23mm	23mm	2	7500	4
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Syncro	PFF85-1006	Front Arm-Upper Inner Bush		4	42000	6
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Syncro	PFF85-1008-19	Front Endlink Eyelet Bush 19mm	19mm	2	7000	8
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Syncro	PFF85-1008-21	Front Endlink Eyelet Bush 21mm	21mm	2	7000	8
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Syncro	PFF85-1008-23	Front Endlink Eyelet Bush 23mm	23mm	2	7000	8
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Syncro	PFF85-1009	Front Radius Rod Bush		2	22500	7
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Syncro	PFR85-1011	Rear Trailing Arm To Chassis Bush		4	26000	11
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Syncro	PFR85-1020 KIT2	Mounting Bush Kit Of 2		1	14000	22
Volkswagen	T25/T3 Type 2 All Models (1979 - 1992)Syncro	PFR85-1020 KIT3	Diff Mounting Bush Kit Of 3		1	20750	21
Volkswagen	T4 Transporter (1990 - 2003)	PFF85-1101	Front Lower Arm Front Bush, upto 1996		2	12000	1
Volkswagen	T4 Transporter (1990 - 2003)	PFF85-1102	Front Lower Arm Rear Bush		2	16000	2
Volkswagen	T4 Transporter (1990 - 2003)	PFF85-1103-23	Anti Roll Bar Mount Bush 23mm	23mm	2	8000	3
Volkswagen	T4 Transporter (1990 - 2003)	PFF85-1103-27	Anti Roll Bar Mount Bush 27mm	27mm	2	8000	3
Volkswagen	T4 Transporter (1990 - 2003)	PFF85-1104-23	Anti Roll Bar Mount Bush 23mm	23mm	2	8000	3
Volkswagen	T4 Transporter (1990 - 2003)	PFF85-1105	Front Upper Arm Front Bush		2	12000	5
Volkswagen	T4 Transporter (1990 - 2003)	PFF85-1106	Front Upper Arm Rear Bush		2	12000	6
Volkswagen	T4 Transporter (1990 - 2003)	PFF85-1107	23mm Anti Roll Bar To Link Rod Bush	23mm	2	7000	7
Volkswagen	T4 Transporter (1990 - 2003)	PFF85-1108	Front Anti Roll Bar Link Rod To Arm Bush		2	10000	8
Volkswagen	T4 Transporter (1990 - 2003)	PFF85-1120-10	Front Steering Rack Mount Bush 10mm Bolt	10mm bolt	4	14000	20
Volkswagen	T4 Transporter (1990 - 2003)	PFF85-1120-8	Front Steering Rack Mount Bush 8mm Bolt	8mm bolt	4	14000	20
Volkswagen	T4 Transporter (1990 - 2003)	PFF85-1131	Front Lower Arm Front Bush, from 1997		2	12000	1
Volkswagen	T4 Transporter (1990 - 2003)	PFR85-1020 KIT3	Diff Mounting Bush Kit Of 3		1	20750	21
Volkswagen	T4 Transporter (1990 - 2003)	PFR85-1110	Rear Trailing Arm Inner Bush To Chassis		2	12000	10
Volkswagen	T4 Transporter (1990 - 2003)	PFR85-1111	Rear Trailing Arm Outer Bush To Chassis		2	12000	11
Volkswagen	T4 Transporter (1990 - 2003)	PFR85-1112-20	Rear Anti Roll Bar Bush 20mm	20mm	4	14000	12
Volkswagen	T4 Transporter (1990 - 2003)	PFR85-1112-26	Rear Anti Roll Bar Bush 26mm	26mm	4	14000	12
Volkswagen	T4 Transporter (1990 - 2003)	PFR85-1112-28	Rear Anti Roll Bar Bush 28mm	28mm	4	14000	12
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFA100-14	PowerAlign Camber Bolt Kit (14mm)	14mm	1	4250	N/A
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFF85-1301	Front Arm Front Bush		2	12000	1
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFF85-1301G	Front Arm Front Bush, Camber Adjustable		2	19500	1
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFF85-1302	Front Arm Rear Bush		2	13500	2
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFF85-1302G	Front Arm Rear Bush, Caster Adjustable		2	21000	2
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFF85-1303-22	Front Anti Roll Bar Bush 22mm	22mm	2	8500	3
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFF85-1303-23	Front Anti Roll Bar Bush 23mm	23mm	2	8500	3
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFF85-1303-25	Front Anti Roll Bar Bush 25mm	25mm	2	8500	3
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFR85-1310	Rear Arm Outer Bush		2	13500	10
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFR85-1310G	Rear Arm Outer Bush, Adjustable		2	23000	10
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFR85-1311	Rear Arm Inner Bush		2	16000	11
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFR85-1311G	Rear Arm Inner Bush, Adjustable		2	26500	11
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFR85-1312-22	Rear Anti Roll Bar Bush to Chassis 22mm	22mm	2	8500	12
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFR85-1312-24	Rear Anti Roll Bar Bush to Chassis 24mm	24mm	2	8500	12
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFR85-1312-28	Rear Anti Roll Bar Bush to Chassis 28mm	28mm	2	8500	12
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFR85-1313-22	Rear Anti Roll Bar Bush to Arm 22mm	22mm	2	8500	13



Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFR85-1313-24	Rear Anti Roll Bar Bush to Arm 24mm	24mm	2	8500	13
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFR85-1313-28	Rear Anti Roll Bar Bush to Arm 28mm	28mm	2	8500	13
Volkswagen	T6 Transporter (2015 - )	PFF85-1301	Front Arm Front Bush		2	12000	1
Volkswagen	T6 Transporter (2015 - )	PFF85-1301G	Front Arm Front Bush, Camber Adjustable		2	19500	1
Volkswagen	T6 Transporter (2015 - )	PFF85-1302	Front Arm Rear Bush		2	13500	2
Volkswagen	T6 Transporter (2015 - )	PFF85-1302G	Front Arm Rear Bush, Caster Adjustable		2	21000	2
Volkswagen	T6 Transporter (2015 - )	PFF85-1303-22	Front Anti Roll Bar Bush 22mm	22mm	2	8500	3
Volkswagen	T6 Transporter (2015 - )	PFF85-1303-23	Front Anti Roll Bar Bush 23mm	23mm	2	8500	3
Volkswagen	T6 Transporter (2015 - )	PFF85-1303-25	Front Anti Roll Bar Bush 25mm	25mm	2	8500	3
Volkswagen	T6 Transporter (2015 - )	PFR85-1310	Rear Arm Outer Bush		2	13500	10
Volkswagen	T6 Transporter (2015 - )	PFR85-1310G	Rear Arm Outer Bush, Adjustable		2	23000	10
Volkswagen	T6 Transporter (2015 - )	PFR85-1311	Rear Arm Inner Bush		2	16000	11
Volkswagen	T6 Transporter (2015 - )	PFR85-1311G	Rear Arm Inner Bush, Adjustable		2	26500	11
Volkswagen	T6 Transporter (2015 - )	PFR85-1312-22	Rear Anti Roll Bar Bush to Chassis 22mm	22mm	2	8500	12
Volkswagen	T6 Transporter (2015 - )	PFR85-1312-24	Rear Anti Roll Bar Bush to Chassis 24mm	24mm	2	8500	12
Volkswagen	T6 Transporter (2015 - )	PFR85-1312-28	Rear Anti Roll Bar Bush to Chassis 28mm	28mm	2	8500	12
Volkswagen	T6 Transporter (2015 - )	PFR85-1313-22	Rear Anti Roll Bar Bush to Arm 22mm	22mm	2	8500	13
Volkswagen	T6 Transporter (2015 - )	PFR85-1313-24	Rear Anti Roll Bar Bush to Arm 24mm	24mm	2	8500	13
Volkswagen	T6 Transporter (2015 - )	PFR85-1313-28	Rear Anti Roll Bar Bush to Arm 28mm	28mm	2	8500	13
Volkswagen	Vento (1992 - 1998)	BS006	Bump Stop Front		2	6500	
Volkswagen	Vento (1992 - 1998)	BS008	Bump Stop Rear		2	6500	
Volkswagen	Vento (1992 - 1998)	EXH006	Exhaust Mounts		1	2250	
Volkswagen	Vento (1992 - 1998)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Vento (1992 - 1998)	PFF85-201	Front Wishbone Front Bush	30mm	2	10500	1
Volkswagen	Vento (1992 - 1998)	PFF85-204	Front Wishbone Inner Bush (rear)		2	10500	2
Volkswagen	Vento (1992 - 1998)	PFF85-205	Front Anti Roll Bar Mount 18mm	18mm	2	9000	3
Volkswagen	Vento (1992 - 1998)	PFF85-205-20	Front Anti Roll Bar Bush 20mm	20mm	2	9000	3
Volkswagen	Vento (1992 - 1998)	PFF85-208	Front Eye Bolt Mounting Bush		2	7500	4
Volkswagen	Vento (1992 - 1998)	PFF85-208-10	Front Eye Bolt Mounting Bush 10mm	10mm	2	7500	4
Volkswagen	Vento (1992 - 1998)	PFF85-209	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	7500	5
Volkswagen	Vento (1992 - 1998)	PFF85-209-20	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	7500	5
Volkswagen	Vento (1992 - 1998)	PFF85-231	Non Power Steering Rack Mount		2	6500	9
Volkswagen	Vento (1992 - 1998)	PFF85-232	Power Steering Rack Mount	18.5mm wide bracket	1	3250	9
Volkswagen	Vento (1992 - 1998)	PFF85-233	Power Steering Rack Mount	15mm wide bracket	1	3250	9
Volkswagen	Vento (1992 - 1998)	PFF85-239	Front Strut, Top Mount		2	12000	11
Volkswagen	Vento (1992 - 1998)	PFF85-250	Front Cross Member Mounting Bush		4	11000	6
Volkswagen	Vento (1992 - 1998)	PFF85-280	Front Lower Engine Mounting Bush & Inserts		1	9000	20
Volkswagen	Vento (1992 - 1998)	PFR85-206	Rear Beam Mounting Bush		2	15500	7
Volkswagen	Vento (1992 - 1998)	PFR85-240	Rear Shock Top Mounting Bush		2	7500	8
Volkswagen	Vento (2005 - 2010)	PFF85-501	Front Wishbone Front Bush		2	11000	1
Volkswagen	Vento (2005 - 2010)	PFF85-501G	Front Wishbone Front Bush Camber Adjustable		2	23500	1
Volkswagen	Vento (2005 - 2010)	PFF85-502	Front Wishbone Rear Bush		2	14500	2
Volkswagen	Vento (2005 - 2010)	PFF85-502G	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	29000	2
Volkswagen	Vento (2005 - 2010)	PFF85-503-19.6	Front Anti Roll Bar Bush 19.6mm	19.6mm	2	7500	3
Volkswagen	Vento (2005 - 2010)	PFF85-503-20	Front Anti Roll Bar Bush 20mm	20mm	2	7500	3
Volkswagen	Vento (2005 - 2010)	PFF85-503-20.7	Front Anti Roll Bar Bush 20.7mm	20.7mm	2	7500	3
Volkswagen	Vento (2005 - 2010)	PFF85-503-21.7	Front Anti Roll Bar Bush 21.7mm	21.7mm	2	7500	3
Volkswagen	Vento (2005 - 2010)	PFF85-503-22.5	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	7500	3
Volkswagen	Vento (2005 - 2010)	PFF85-503-23	Front Anti Roll Bar Bush 23mm	23mm	2	7500	3
Volkswagen	Vento (2005 - 2010)	PFF85-503-23.6	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	7500	3
Volkswagen	Vento (2005 - 2010)	PFF85-503-24	Front Anti Roll Bar Bush 24mm	24mm	2	7500	3
Volkswagen	Vento (2005 - 2010)	PFF85-504	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Vento (2005 - 2010)	PFF85-504P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Vento (2005 - 2010)	PFF85-504R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Vento (2005 - 2010)	PFF85-505	Lower Engine Mount Small Bush		1	5250	5
Volkswagen	Vento (2005 - 2010)	PFF85-704	Lower Engine Mount Insert (Large)		1	5750	4
Volkswagen	Vento (2005 - 2010)	PFF85-704P	Lower Engine Mount Insert (Large) Track Use		1	5750	4
Volkswagen	Vento (2005 - 2010)	PFF85-704R	Lower Engine Mount Insert (Large) Diesel		1	5750	4
Volkswagen	Vento (2005 - 2010)	PFR85-508	Rear Tie Bar to Chassis Front Bush		2	10000	8

Volkswagen	Vento (2005 - 2010)	PFR85-509	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Vento (2005 - 2010)	PFR85-510	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Vento (2005 - 2010)	PFR85-511	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Vento (2005 - 2010)	PFR85-512	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Vento (2005 - 2010)	PFR85-513	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Vento (2005 - 2010)	PFR85-514	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Vento (2005 - 2010)	PFR85-515-18	Rear Anti Roll Bar Bush 18mm	18mm	2	8500	15
Volkswagen	Vento (2005 - 2010)	PFR85-515-18.5	Rear Anti Roll Bar Bush 18.5mm	18.5mm	2	8500	15
Volkswagen	Vento (2005 - 2010)	PFR85-515-19	Rear Anti Roll Bar Bush 19mm	19mm	2	8500	15
Volkswagen	Vento (2005 - 2010)	PFR85-515-19.6	Rear Anti Roll Bar Bush 19.6mm	19.6mm	2	8500	15
Volkswagen	Vento (2005 - 2010)	PFR85-515-20	Rear Anti Roll Bar Bush 20mm	20mm	2	8500	15
Volkswagen	Vento (2005 - 2010)	PFR85-515-20.5	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	8500	15
Volkswagen	Vento (2005 - 2010)	PFR85-515-20.7	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	8500	15
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-201BLK	Front Wishbone Front Bush	30mm	2	11500	1
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-410BLK	Front Wishbone Rear Bush		2	13000	2
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-410PABLK	Front Wishbone Rear Bush		2	12000	
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-411-19BLK	Front Anti Roll Bar Mount 19mm	19mm	2	8500	3
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-411-21BLK	Front Anti Roll Bar Mount 21mm	21mm	2	8500	3
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-411-23BLK	Front Anti Roll Bar Mount 23mm	23mm	2	8500	3
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-412BLK	Front Anti Roll Bar Link Bush Kit		2	11000	4
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-414BLK	Front Wishbone Rear Bush (Motorsport Use)		2	34000	2
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-416BLK	Steering Rack Mount Bush		1	3500	7
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-420BLK	Front Engine Mount Dog Bone		1	5750	8
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-424BLK	Front Subframe Rear Bush		2	13500	24
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-430BLK	Front Strut Top Mount Bush		2	12000	11
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-431BLK	Front Strut Top Mount Bush -10mm	-10mm	2	13500	11
Volkswagen	Bora 2WD (1997 - 2006)	PFF85-505BLK	Front Engine Mount Dog Bone Small Bush		1	6000	9
Volkswagen	Bora 2WD (1997 - 2006)	PFR85-415BLK	Rear Beam Mounting Bush, 72.5mm	72.5mm	2	17000	5
Volkswagen	Bora 2WD (1997 - 2006)	PFR85-610BLK	Rear Beam Mounting Bush, 69mm	69mm	2	17000	5
Volkswagen	Bora 4 Motion (1999-2005)	PFF3-501BLK	Front Wishbone Front Bush, Cast Arm, 45mm OD	45mm	2	12000	1
Volkswagen	Bora 4 Motion (1999-2005)	PFF3-610BLK	Front Wishbone Rear Bush R32		2	13000	2
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-201BLK	Front Wishbone Front Bush	30mm	2	11500	1
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-201BLK	Front Wishbone Front Bush	30mm	2	11500	1
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-410BLK	Front Wishbone Rear Bush		2	13000	2
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-410PABLK	Front Wishbone Rear Bush		2	12000	
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-411-19BLK	Front Anti Roll Bar Bush 19mm	19mm	2	8500	3
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-411-21BLK	Front Anti Roll Bar Mount 21mm	21mm	2	8500	3
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-411-21BLK	Front Anti Roll Bar Mount	21mm	2	8500	3
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-411-23BLK	Front Anti Roll Bar Mount 23mm	23mm	2	8500	3
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-411-23BLK	Front Anti Roll Bar Mount	23mm	2	8500	3
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-412BLK	Front Anti Roll Bar Link Bush Kit		2	11000	4
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-414BLK	Front Wishbone Rear Bush (Race Use) Fits All Models		2	34000	2
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-414BLK	Front Wishbone Rear Bush (Motorsport Use)		2	34000	2
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-416BLK	Steering Rack Mount Bush		1	3500	7
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-420BLK	Front Engine Mount Dog Bone		1	5750	8
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-424BLK	Front Subframe Rear Bush		2	13500	24
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-430BLK	Front Strut Top Mount Bush		2	12000	11
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-431BLK	Front Strut Top Mount Bush -10mm	-10mm	2	13500	11
Volkswagen	Bora 4 Motion (1999-2005)	PFF85-505BLK	Front Engine Mount Dog Bone Small Bush		1	6000	10
Volkswagen	Bora 4 Motion (1999-2005)	PFR3-508BLK	Rear Trailing Arm Front Bush		2	13500	9
Volkswagen	Bora 4 Motion (1999-2005)	PFR3-510BLK	Rear Arm Inner Bush		4	24000	5
Volkswagen	Bora 4 Motion (1999-2005)	PFR3-510GBLK	Rear Arm Inner Bush Camber Adjustable		4	44000	5
Volkswagen	Bora 4 Motion (1999-2005)	PFR3-511-14BLK	Rear Anti Roll Bar Mounting 14mm	14mm	2	8500	6
Volkswagen	Bora 4 Motion (1999-2005)	PFR3-511-15BLK	Rear Anti Roll Bar Mounting 15mm	15mm	2	8500	6
Volkswagen	Bora 4 Motion (1999-2005)	PFR3-511-16BLK	Rear Anti Roll Bar Mounting 16mm	16mm	2	8500	6
Volkswagen	Bora 4 Motion (1999-2005)	PFR3-511-19BLK	Rear Anti Roll Bar Mounting 19mm	19mm	2	8500	6
Volkswagen	Bora 4 Motion (1999-2005)	PFR85-425BLK	Rear Diff Front Mounting Bush		2	13500	25
Volkswagen	Bora 4 Motion (1999-2005)	PFR85-426BLK	Rear Diff Rear Mounting Bush		2	13500	26
Volkswagen	Bora 4 Motion (1999-2005)	PFR85-427BLK	Rear Subframe Mounting Bush		4	29000	27

Volkswagen	Bora (2005-2010)	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	Bora (2005-2010)	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	Bora (2005-2010)	PFF85-502BLK	Front Wishbone Rear Bush		2	15500	2
Volkswagen	Bora (2005-2010)	PFF85-502GBLK	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	31500	2
Volkswagen	Bora (2005-2010)	PFF85-503-22.5BLK	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	8500	3
Volkswagen	Bora (2005-2010)	PFF85-503-23.6BLK	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	8500	3
Volkswagen	Bora (2005-2010)	PFF85-503-23BLK	Front Anti Roll Bar Bush 23mm	23mm	2	8500	3
Volkswagen	Bora (2005-2010)	PFF85-503-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	8500	3
Volkswagen	Bora (2005-2010)	PFF85-504BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Bora (2005-2010)	PFF85-505BLK	Lower Engine Mount Small Bush		1	6000	5
Volkswagen	Bora (2005-2010)	PFF85-704BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Bora (2005-2010)	PFR85-508BLK	Rear Tie Bar to Chassis Front Bush		2	11000	8
Volkswagen	Bora (2005-2010)	PFR85-509BLK	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Bora (2005-2010)	PFR85-510BLK	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Bora (2005-2010)	PFR85-511BLK	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Bora (2005-2010)	PFR85-512BLK	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Bora (2005-2010)	PFR85-513BLK	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Bora (2005-2010)	PFR85-514BLK	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Bora (2005-2010)	PFR85-515-20.5BLK	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	9000	15
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFF85-211BLK	Front Wishbone Inner Bush		2	11000	1
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFF85-213BLK	Front Wishbone Rear Bush		2	11000	2
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFF85-215-22BLK	Front Anti Roll Bar Outer Mount 22mm	22mm	2	8500	4
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFF85-215BLK	Front Anti Roll Bar Outer Mount 16mm	16mm	2	8500	4
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFF85-216BLK	Front Anti Roll Bar Inner Mount		2	8500	3
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFF85-229BLK	Steering Rack Mount		1	3500	11
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFF85-230BLK	Steering Rack Mount		1	3500	12
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFF85-235BLK	Engine Mount Stopper Bush		1	4750	5
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFR85-310BLK	Rear Leaf Spring Bush		6	36000	10
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFR85-315BLK	Rear Leaf Spring Anti Clatter Bush		4	13000	15
Volkswagen	Caddy Mk1 Typ 14 (1985-1996)	PFR85-316BLK	Rear Bump Stop		2	12000	16
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-201BLK	Front Wishbone Front Bush	30mm	2	11500	1
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-204BLK	Front Wishbone Rear Bush		2	11500	2
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-205-20BLK	Front Anti Roll Bar Bush 20mm	20mm	2	10000	3
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-205BLK	Front Anti Roll Bar Mount 18mm	18mm	2	10000	3
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-208-10BLK	Front Eye Bolt Mounting Bush 10mm	10mm	2	8000	4
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-208BLK	Front Eye Bolt Mounting Bush		2	8000	4
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-209-20BLK	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	8000	5
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-209BLK	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	8000	5
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-231BLK	Non Power Steering Rack Mount		2	7000	9
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-232BLK	Power Steering Rack Mount	18.5mm wide bracket	1	3500	9
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-233BLK	Power Steering Rack Mount	15mm wide bracket	1	3500	9
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-239BLK	Front Strut, Top Mount		2	13500	11
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-250BLK	Front Cross Member Mounting Bush		4	12000	6
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFF85-280BLK	Front Lower Engine Mounting Bush & Inserts		1	10000	20
Volkswagen	Caddy Mk2 Typ 9K (1997-2003)	PFR85-1410BLK	Rear Leaf Spring Bush		6	39000	10
Volkswagen	Caddy MK3 TYP 2K (2004 - 06/2010)	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	Caddy MK3 TYP 2K (2004 - 06/2010)	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	Caddy MK3 TYP 2K (2004 - 06/2010)	PFF85-502BLK	Front Wishbone Rear Bush		2	15500	2
Volkswagen	Caddy MK3 TYP 2K (2004 - 06/2010)	PFF85-502GBLK	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	31500	2
Volkswagen	Caddy MK3 TYP 2K (2004 - 06/2010)	PFF85-503-23.6BLK	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	8500	3
Volkswagen	Caddy MK3 TYP 2K (2004 - 06/2010)	PFF85-504BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Caddy MK3 TYP 2K (2004 - 06/2010)	PFF85-505BLK	Lower Engine Mount Small Bush		1	6000	5
Volkswagen	Caddy MK3 TYP 2K (2004 - 06/2010)	PFF85-530BLK	Transmission Mount Insert		1	8000	30
Volkswagen	Caddy MK3 TYP 2K (2004 - 06/2010)	PFF85-704BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Caddy MK3 TYP 2K (2004 - 06/2010)	PFR85-1410-4BLK	Rear Leaf Spring Bush		4	26000	10
Volkswagen	Caddy MK3 TYP 2K (2004 - 06/2010)	PFR85-1510BLK	Rear Leaf Spring Chassis Shackle Bush		2	14000	11
Volkswagen	Caddy MK3 TYP 2K (2004 - 06/2010)	PFR85-1513-20BLK	Rear Anti Roll Bar Mounting Bush 20mm	20mm	2	8500	12
Volkswagen	Caddy MK3 TYP 2K (2004 - 06/2010)	PFR85-1513-22BLK	Rear Anti Roll Bar Mounting Bush 22mm	22mm	2	8500	12

Volkswagen	Caddy MK4 (06/2010 - )	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	Caddy MK4 (06/2010 - )	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	Caddy MK4 (06/2010 - )	PFF85-503-23.6BLK	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	8500	3
Volkswagen	Caddy MK4 (06/2010 - )	PFF85-704BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Caddy MK4 (06/2010 - )	PFF85-802GBLK	Front Wishbone Rear Bush, Caster Adjustable		2	33500	2
Volkswagen	Caddy MK4 (06/2010 - )	PFR85-1410-4BLK	Rear Leaf Spring Bush		4	26000	10
Volkswagen	Caddy MK4 (06/2010 - )	PFR85-1510BLK	Rear Leaf Spring Chassis Shackle Bush		2	14000	11
Volkswagen	Caddy MK4 (06/2010 - )	PFR85-1513-22BLK	Rear Anti Roll Bar Mounting Bush 22mm	22mm	2	8500	12
Volkswagen	Corrado (1989 - 1995)	BS006	Bump Stop, VW Front	54mm x 59mm x 19	2	6500	
Volkswagen	Corrado (1989 - 1995)	BS008	Bump Stop, VW Rear	60mm x 58mm x 10	2	6500	
Volkswagen	Corrado (1989 - 1995)	EXH006	Exhaust Mounts		1	2250	
Volkswagen	Corrado (1989 - 1995)	PFF85-201BLK	Front Wishbone Front Bush	30mm	2	11500	1
Volkswagen	Corrado (1989 - 1995)	PFF85-203BLK	Front Wishbone Inner Bush (Rear)		2	11500	2
Volkswagen	Corrado (1989 - 1995)	PFF85-205-20BLK	Front Anti Roll Bar Bush 20mm	20mm	2	10000	3
Volkswagen	Corrado (1989 - 1995)	PFF85-205-22BLK	Front Anti Roll Bar Bush Eibach 22mm	22mm	2	10000	3
Volkswagen	Corrado (1989 - 1995)	PFF85-205BLK	Front Anti Roll Bar Mount 18mm	18mm	2	10000	3
Volkswagen	Corrado (1989 - 1995)	PFF85-208-10BLK	Front Eye Bolt Mounting Bush 10mm	10mm	2	8000	4
Volkswagen	Corrado (1989 - 1995)	PFF85-208BLK	Front Eye Bolt Mounting Bush		2	8000	4
Volkswagen	Corrado (1989 - 1995)	PFF85-209-20BLK	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	8000	5
Volkswagen	Corrado (1989 - 1995)	PFF85-209BLK	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	8000	5
Volkswagen	Corrado (1989 - 1995)	PFF85-232BLK	Power Steering Rack Mount	18.5mm wide bracket	1	3500	9
Volkswagen	Corrado (1989 - 1995)	PFF85-233BLK	Power Steering Rack Mount	15mm wide bracket	1	3500	9
Volkswagen	Corrado (1989 - 1995)	PFF85-239BLK	Front Strut, Top Mount		2	13500	11
Volkswagen	Corrado (1989 - 1995)	PFF85-250BLK	Front Cross Member Mounting Bush		4	12000	6
Volkswagen	Corrado (1989 - 1995)	PFR85-206BLK	Rear Beam Mounting Bush		2	17000	7
Volkswagen	Corrado (1989 - 1995)	PFR85-207BLK	Rear Beam Mounting Bush		2	17000	7
Volkswagen	Corrado (1989 - 1995)	PFR85-212BLK	Rear Anti-Roll Bar To Beam Bush Eibach		2	10000	12
Volkswagen	Corrado (1989 - 1995)	PFR85-225-25BLK	Rear Anti Roll Bar Bush Eibach 25mm	25mm	2	10000	25
Volkswagen	Corrado (1989 - 1995)	PFR85-240BLK	Rear Shock Top Mounting Bush		2	8000	8
Volkswagen	Corrado VR6	BS006	Bump Stop, VW Front	54mm x 59mm x 19	2	6500	
Volkswagen	Corrado VR6	BS008	Bump Stop, VW Rear	60mm x 58mm x 10	2	6500	
Volkswagen	Corrado VR6	EXH006	Exhaust Mounts		1	2250	
Volkswagen	Corrado VR6	PFF85-201BLK	Front Wishbone Front Bush	30mm	2	11500	1
Volkswagen	Corrado VR6	PFF85-204BLK	Front Wishbone Rear Bush		2	11500	2
Volkswagen	Corrado VR6	PFF85-205-20BLK	Front Anti Roll Bar Bush 20mm	20mm	2	10000	3
Volkswagen	Corrado VR6	PFF85-205BLK	Front Anti Roll Bar Mount 18mm	18mm	2	10000	3
Volkswagen	Corrado VR6	PFF85-209-20BLK	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	8000	5
Volkswagen	Corrado VR6	PFF85-209BLK	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	8000	5
Volkswagen	Corrado VR6	PFF85-232BLK	Power Steering Rack Mount	18.5mm wide bracket	1	3500	9
Volkswagen	Corrado VR6	PFF85-233BLK	Power Steering Rack Mount	15mm wide bracket	1	3500	9
Volkswagen	Corrado VR6	PFF85-239BLK	Front Strut, Top Mount		2	13500	11
Volkswagen	Corrado VR6	PFF85-250BLK	Front Cross Member Mounting Bush		4	12000	6
Volkswagen	Corrado VR6	PFF85-280BLK	Front Lower Engine Mounting Bush & Inserts		1	10000	20
Volkswagen	Corrado VR6	PFR85-206BLK	Rear Beam Mounting Bush		2	17000	7
Volkswagen	Corrado VR6	PFR85-240BLK	Rear Shock Top Mounting Bush		2	8000	8
Volkswagen	Eos 1F (2006-)	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	Eos 1F (2006-)	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	Eos 1F (2006-)	PFF85-502BLK	Front Wishbone Rear Bush		2	15500	2
Volkswagen	Eos 1F (2006-)	PFF85-502GBLK	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	31500	2
Volkswagen	Eos 1F (2006-)	PFF85-503-22.5BLK	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	8500	3
Volkswagen	Eos 1F (2006-)	PFF85-503-23.6BLK	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	8500	3
Volkswagen	Eos 1F (2006-)	PFF85-503-23BLK	Front Anti Roll Bar Bush 23mm	23mm	2	8500	3
Volkswagen	Eos 1F (2006-)	PFF85-503-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	8500	3
Volkswagen	Eos 1F (2006-)	PFF85-504BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Eos 1F (2006-)	PFF85-505BLK	Lower Engine Mount Small Bush		1	6000	5
Volkswagen	Eos 1F (2006-)	PFF85-531BLK	Upper Engine Mount Insert		1	8000	31
Volkswagen	Eos 1F (2006-)	PFF85-532BLK	Upper Engine Mount Insert		1	8000	31
Volkswagen	Eos 1F (2006-)	PFF85-704BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Eos 1F (2006-)	PFR85-508BLK	Rear Tie Bar to Chassis Front Bush		2	11000	8

Volkswagen	Eos 1F (2006-)	PFR85-509BLK	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Eos 1F (2006-)	PFR85-510BLK	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Eos 1F (2006-)	PFR85-511BLK	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Eos 1F (2006-)	PFR85-512BLK	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Eos 1F (2006-)	PFR85-513BLK	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Eos 1F (2006-)	PFR85-514BLK	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Eos 1F (2006-)	PFR85-515-20.5BLK	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	9000	15
Volkswagen	Eos 1F (2006-)	PFR85-515-20.7BLK	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	9000	15
Volkswagen	Eos 1F (2006-)	PFR85-515-21.7BLK	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	9000	15
Volkswagen	Fox	PFF85-201BLK	Front Wishbone Front Bush		2	11500	1
Volkswagen	Fox	PFF85-602BLK	Front Wishbone Rear Bush		2	16500	2
Volkswagen	Fox	PFF85-603-18BLK	Front Anti Roll Bar Bush 18mm	18mm	2	8500	3
Volkswagen	Fox	PFF85-603-19BLK	Front Anti Roll Bar Bush 19mm	19mm	2	8500	3
Volkswagen	Fox	PFF85-603-20BLK	Front Anti Roll Bar Bush 20mm		2	8500	3
Volkswagen	Fox	PFF85-620BLK	Lower Engine Mount Large Bush		1	8250	20
Volkswagen	Fox	PFR85-415BLK	Rear Beam Mounting Bush, 72.5mm	72.5mm	2	17000	4
Volkswagen	Fox	PFR85-610BLK	Rear Beam Mounting Bush, 69mm	69mm	2	17000	4
Volkswagen	Golf MK1 (1973 - 1985)	BS2001K	Bump Stop Kit	Front	1	9250	
Volkswagen	Golf MK1 (1973 - 1985)	BS2004K	Bump Stop Kit	Rear	1	9750	
Volkswagen	Golf MK1 (1973 - 1985)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Golf MK1 (1973 - 1985)	PFF85-211BLK	Front Wishbone Inner Bush		2	11000	1
Volkswagen	Golf MK1 (1973 - 1985)	PFF85-213BLK	Front Wishbone Rear Bush		2	11000	2
Volkswagen	Golf MK1 (1973 - 1985)	PFF85-215-22BLK	Front Anti Roll Bar Outer Mount 22mm	22mm	2	8500	4
Volkswagen	Golf MK1 (1973 - 1985)	PFF85-215BLK	Front Anti Roll Bar Outer Mount 16mm	16mm	2	8500	4
Volkswagen	Golf MK1 (1973 - 1985)	PFF85-216BLK	Front Anti Roll Bar Inner Mount		2	8500	3
Volkswagen	Golf MK1 (1973 - 1985)	PFF85-229BLK	Steering Rack Mount		1	3500	11
Volkswagen	Golf MK1 (1973 - 1985)	PFF85-230BLK	Steering Rack Mount		1	3500	12
Volkswagen	Golf MK1 (1973 - 1985)	PFF85-235BLK	Engine Mount Stopper Bush		1	4750	5
Volkswagen	Golf MK1 (1973 - 1985)	PFR85-220BLK	Rear Beam Mounting Bush		2	13000	7
Volkswagen	Golf MK1 (1973 - 1985)	PFR85-225BLK	Rear Anti Roll Bar Mount (Inner)	19.5mm	2	10000	8
Volkswagen	Golf MK1 (1973 - 1985)	PFR85-226-20.5BLK	Rear Anti Roll Bar Mount (Outer) 20.5mm	20.5mm	2	8000	9
Volkswagen	Golf MK1 (1973 - 1985)	PFR85-241BLK	Rear Shock Top Mounting Bush		2	11500	20
Volkswagen	Golf MK2 (1985 - 1992)2WD	BS006	Bump Stop, VW Front	54mm x 59mm x 19	2	6500	
Volkswagen	Golf MK2 (1985 - 1992)2WD	BS008	Bump Stop, VW Rear	60mm x 58mm x 10	2	6500	
Volkswagen	Golf MK2 (1985 - 1992)2WD	BS2001K	Bump Stop Kit	Front	1	9250	
Volkswagen	Golf MK2 (1985 - 1992)2WD	EXH006	Exhaust Mounts		1	2250	
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFF85-201BLK	Front Wishbone Front Bush	30mm	2	11500	1
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFF85-203BLK	Front Wishbone Inner Bush (Rear)		2	11500	2
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFF85-205-20BLK	Front Anti Roll Bar Bush 20mm	20mm	2	10000	3
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFF85-205-22BLK	Front Anti Roll Bar Bush Eibach 22mm	22mm	2	10000	3
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFF85-205BLK	Front Anti Roll Bar Mount 18mm	18mm	2	10000	3
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFF85-208-10BLK	Front Eye Bolt Mounting Bush 10mm	10mm	2	8000	4
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFF85-208BLK	Front Eye Bolt Mounting Bush		2	8000	4
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFF85-209-20BLK	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	8000	5
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFF85-209BLK	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	8000	5
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFF85-210-22BLK	Front Anti Roll Bar Eye Bolt Bush Eibach 22mm	22mm	2	8000	5
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFF85-231BLK	Non Power Steering Rack Mount		2	7000	9
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFF85-232BLK	Power Steering Rack Mount	18.5mm wide bracket	1	3500	9
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFF85-233BLK	Power Steering Rack Mount	15mm wide bracket	1	3500	9
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFF85-244BLK	Rear Lower Engine Mount Bush		1	13250	20
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFF85-245BLK	Rear Lower Engine Mount Insert		1	6250	20
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFF85-250BLK	Front Cross Member Mounting Bush		4	12000	6
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFR85-207BLK	Rear Beam Mounting Bush		2	17000	7
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFR85-212BLK	Rear Anti-Roll Bar To Beam Bush Eibach		2	10000	12
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFR85-225-25BLK	Rear Anti Roll Bar Bush Eibach 25mm	25mm	2	10000	25
Volkswagen	Golf MK2 (1985 - 1992)2WD	PFR85-240BLK	Rear Shock Top Mounting Bush		2	8000	8
Volkswagen	Golf MK2 (1985 - 1992)4WD	BS006	Bump Stop, VW Front	54mm x 59mm x 19	2	6500	
Volkswagen	Golf MK2 (1985 - 1992)4WD	BS2001K	Bump Stop Kit	Front	1	9250	

Volkswagen	Golf MK2 (1985 – 1992)4WD	EXH006	Exhaust Mounts		1	2250	
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-201BLK	Front Wishbone Front Bush	30mm	2	11500	1
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-205-20BLK	Front Anti Roll Bar Mount 20mm	20mm	2	10000	3
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-205BLK	Front Anti Roll Bar Mount 18mm	18mm	2	10000	3
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-208-10BLK	Front Eye Bolt Mounting Bush 10mm	10mm	2	8000	4
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-208BLK	Front Eye Bolt Mounting Bush		2	8000	4
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-209-20BLK	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	8000	5
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-209BLK	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	8000	5
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-244BLK	Rear Lower Engine Mount Bush		1	13250	20
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-245BLK	Rear Lower Engine Mount Insert		1	6250	20
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFF85-250BLK	Front Cross Member Mounting Bush		4	12000	6
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFR85-240BLK	Rear Shock Top Mounting Bush		2	8000	11
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFR85-260BLK	Rear Beam Mounting Bush		2	13500	8
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFR85-262BLK	Rear Trailing Arm Bush		4	23000	7
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFR85-263-20BLK	Rear Anti Roll Bar Inner Bush 20mm	20mm	2	7500	9
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFR85-263-20BLK	Rear Anti Roll Bar Inner Bush 20mm	20mm	2	7500	9
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFR85-263BLK	Rear Anti Roll Bar Inner Bush 18.5mm	18.5mm	2	7500	9
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFR85-263BLK	Rear Anti Roll Bar Inner Bush 18.5mm	18.5mm	2	7500	9
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFR85-264-20BLK	Rear Anti Roll Bar Outer Mount 20mm	20mm	2	7500	10
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFR85-264BLK	Rear Anti Roll Bar Outer Mount 18.5mm	18.5mm	2	7500	10
Volkswagen	Golf MK2 (1985 – 1992)4WD	PFR85-270BLK	Rear Diff Rear Mounting Bush		1	7500	12
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	BS006	Bump Stop, VW Front	54mm x 59mm x 19	2	6500	
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	BS2001K	Bump Stop Kit	Front	1	9250	
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	EXH006	Exhaust Mounts		1	2250	
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-201BLK	Front Wishbone Front Bush	30mm	2	11500	1
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-205-20BLK	Front Anti Roll Bar Mount 20mm	20mm	2	10000	3
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-205BLK	Front Anti Roll Bar Mount 18mm	18mm	2	10000	3
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-208-10BLK	Front Eye Bolt Mounting Bush 10mm	10mm	2	8000	4
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-208BLK	Front Eye Bolt Mounting Bush		2	8000	4
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-209-20BLK	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	8000	5
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-209BLK	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	8000	5
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-244BLK	Rear Lower Engine Mount Bush		1	13250	20
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-245BLK	Rear Lower Engine Mount Insert		1	6250	20
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFF85-250BLK	Front Cross Member Mounting Bush		4	12000	6
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFR85-240BLK	Rear Shock Top Mounting Bush		2	8000	11
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFR85-260BLK	Rear Beam Mounting Bush		2	13500	8
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFR85-262BLK	Rear Trailing Arm Bush		4	23000	7
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFR85-262BLK	Rear Trailing Arm Bush		4	23000	7
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFR85-263-20BLK	Rear Anti Roll Bar Inner Bush 20mm	20mm	2	7500	9
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFR85-263BLK	Rear Anti Roll Bar Inner Bush 18.5mm	18.5mm	2	7500	9
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFR85-264-20BLK	Rear Anti Roll Bar Outer Mount 20mm	20mm	2	7500	10
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFR85-264BLK	Rear Anti Roll Bar Outer Mount 18.5mm	18.5mm	2	7500	10
Volkswagen	Golf MK2 (1985 – 1992)G60, Rallye, Country	PFR85-270BLK	Rear Diff Rear Mounting Bush		1	7500	12
Volkswagen	Golf MK3 2WD (1992 – 1998)	BS006	Bump Stop, VW Front	54mm x 59mm x 19	2	6500	
Volkswagen	Golf MK3 2WD (1992 – 1998)	BS008	Bump Stop, VW Rear	60mm x 58mm x 10	2	6500	
Volkswagen	Golf MK3 2WD (1992 – 1998)	BS2001K	Bump Stop Kit	Front	1	9250	
Volkswagen	Golf MK3 2WD (1992 – 1998)	EXH006	Exhaust Mounts		1	2250	
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-201BLK	Front Wishbone Front Bush	30mm	2	11500	1
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-204BLK	Front Wishbone Rear Bush		2	11500	2
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-205-20BLK	Front Anti Roll Bar Mount 20mm	20mm	2	10000	3
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-205-22BLK	Front Anti Roll Bar Bush Eibach 22mm	22mm	2	10000	3
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-205BLK	Front Anti Roll Bar Mount 18mm	18mm	2	10000	3
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-208-10BLK	Front Eye Bolt Mounting Bush 10mm	10mm	2	8000	4
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-208BLK	Front Eye Bolt Mounting Bush		2	8000	4
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-209-20BLK	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	8000	5
Volkswagen	Golf MK3 2WD (1992 – 1998)	PFF85-209BLK	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	8000	5



Volkswagen	Golf MK3 2WD (1992 - 1998)	PFF85-231BLK	Non Power Steering Rack Mount		2	7000	9
Volkswagen	Golf MK3 2WD (1992 - 1998)	PFF85-232BLK	Power Steering Rack Mount	18.5mm wide bracket	1	3500	9
Volkswagen	Golf MK3 2WD (1992 - 1998)	PFF85-233BLK	Power Steering Rack Mount	15mm wide bracket	1	3500	9
Volkswagen	Golf MK3 2WD (1992 - 1998)	PFF85-239BLK	Front Strut, Top Mount		2	13500	11
Volkswagen	Golf MK3 2WD (1992 - 1998)	PFF85-250BLK	Front Cross Member Mounting Bush		4	12000	6
Volkswagen	Golf MK3 2WD (1992 - 1998)	PFF85-280BLK	Front Lower Engine Mounting Bush & Inserts		1	10000	20
Volkswagen	Golf MK3 2WD (1992 - 1998)	PFR85-206BLK	Rear Beam Mounting Bush		2	17000	7
Volkswagen	Golf MK3 2WD (1992 - 1998)	PFR85-212BLK	Rear Anti-Roll Bar To Beam Bush Eibach		2	10000	12
Volkswagen	Golf MK3 2WD (1992 - 1998)	PFR85-225-25BLK	Rear Anti Roll Bar Bush Eibach 25mm	25mm	2	10000	25
Volkswagen	Golf MK3 2WD (1992 - 1998)	PFR85-240BLK	Rear Shock Top Mounting Bush		2	8000	8
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFF85-201BLK	Front Wishbone Front Bush	30mm	2	11500	1
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFF85-204BLK	Front Wishbone Rear Bush		2	11500	2
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFF85-205-20BLK	Front Anti Roll Bar Mount 20mm	20mm	2	10000	3
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFF85-205BLK	Front Anti Roll Bar Mount 18mm	18mm	2	10000	3
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFF85-208-10BLK	Front Eye Bolt Mounting Bush 10mm	10mm	2	8000	4
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFF85-208BLK	Front Eye Bolt Mounting Bush		2	8000	4
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFF85-209-20BLK	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	8000	5
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFF85-209BLK	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	8000	5
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFF85-232BLK	Power Steering Rack Mount	18.5mm wide bracket	1	3500	9
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFF85-233BLK	Power Steering Rack Mount	15mm wide bracket	1	3500	9
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFF85-239BLK	Front Strut, Top Mount		2	13500	11
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFF85-250BLK	Front Cross Member Mounting Bush		4	12000	6
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFF85-280BLK	Front Lower Engine Mounting Bush & Inserts		1	10000	20
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFR85-240BLK	Rear Shock Top Mounting Bush		2	8000	17
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFR85-260BLK	Rear Beam Mounting Bush		2	13500	15
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFR85-262BLK	Rear Trailing Arm Bush		4	23000	12
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFR85-263-20BLK	Rear Anti Roll Bar Inner Bush 20mm	20mm	2	7500	13
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFR85-263BLK	Rear Anti Roll Bar Inner Bush 18.5mm	18.5mm	2	7500	13
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFR85-264-20BLK	Rear Anti Roll Bar Outer Mount 20mm	20mm	2	7500	14
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFR85-264BLK	Rear Anti Roll Bar Outer Mount 18.5mm	18.5mm	2	7500	14
Volkswagen	Golf Mk3 4WD Syncro (1993 - 1997)	PFR85-270BLK	Rear Diff Rear Mounting Bush		1	7500	16
Volkswagen	Golf MK4 (1997 - 2004)2WD Typ 1J	PFF85-201BLK	Front Wishbone Front Bush	30mm	2	11500	1
Volkswagen	Golf MK4 (1997 - 2004)2WD Typ 1J	PFF85-410BLK	Front Wishbone Rear Bush		2	13000	2
Volkswagen	Golf MK4 (1997 - 2004)2WD Typ 1J	PFF85-410PABLK	Front Wishbone Rear Bush		2	12000	
Volkswagen	Golf MK4 (1997 - 2004)2WD Typ 1J	PFF85-411-19BLK	Front Anti Roll Bar Mount 19mm	19mm	2	8500	3
Volkswagen	Golf MK4 (1997 - 2004)2WD Typ 1J	PFF85-411-21BLK	Front Anti Roll Bar Mount 21mm	21mm	2	8500	3
Volkswagen	Golf MK4 (1997 - 2004)2WD Typ 1J	PFF85-411-23BLK	Front Anti Roll Bar Mount 23mm	23mm	2	8500	3
Volkswagen	Golf MK4 (1997 - 2004)2WD Typ 1J	PFF85-412BLK	Front Anti Roll Bar Link Bush Kit		2	11000	4
Volkswagen	Golf MK4 (1997 - 2004)2WD Typ 1J	PFF85-414BLK	Front Wishbone Rear Bush (Motorsport Use)		2	34000	2
Volkswagen	Golf MK4 (1997 - 2004)2WD Typ 1J	PFF85-416BLK	Steering Rack Mount Bush		1	3500	7
Volkswagen	Golf MK4 (1997 - 2004)2WD Typ 1J	PFF85-420BLK	Front Engine Mount Dog Bone		1	5750	8
Volkswagen	Golf MK4 (1997 - 2004)2WD Typ 1J	PFF85-424BLK	Front Subframe Rear Bush		2	13500	24
Volkswagen	Golf MK4 (1997 - 2004)2WD Typ 1J	PFF85-430BLK	Front Strut Top Mount Bush		2	12000	11
Volkswagen	Golf MK4 (1997 - 2004)2WD Typ 1J	PFF85-431BLK	Front Strut Top Mount Bush -10mm	-10mm	2	13500	11
Volkswagen	Golf MK4 (1997 - 2004)2WD Typ 1J	PFF85-505BLK	Front Engine Mount Dog Bone Small Bush		1	6000	9
Volkswagen	Golf MK4 (1997 - 2004)2WD Typ 1J	PFR85-415BLK	Rear Beam Mounting Bush, 72.5mm	72.5mm	2	17000	5
Volkswagen	Golf MK4 (1997 - 2004)2WD Typ 1J	PFR85-610BLK	Rear Beam Mounting Bush, 69mm	69mm	2	17000	5
Volkswagen	Golf MK4 (1997 - 2004)R32/4motion	PFF3-501BLK	Front Wishbone Front Bush, Cast Arm, 45mm OD	45mm	2	12000	1
Volkswagen	Golf MK4 (1997 - 2004)R32/4motion	PFF3-610BLK	Front Wishbone Rear Bush R32		2	13000	2
Volkswagen	Golf MK4 (1997 - 2004)R32/4motion	PFF85-201BLK	Front Wishbone Front Bush	30mm	2	11500	1
Volkswagen	Golf MK4 (1997 - 2004)R32/4motion	PFF85-410BLK	Front Wishbone Rear Bush		2	13000	2
Volkswagen	Golf MK4 (1997 - 2004)R32/4motion	PFF85-410PABLK	Front Wishbone Rear Bush		2	12000	
Volkswagen	Golf MK4 (1997 - 2004)R32/4motion	PFF85-411-19BLK	Front Anti Roll Bar Bush 19mm	19mm	2	8500	3
Volkswagen	Golf MK4 (1997 - 2004)R32/4motion	PFF85-411-21BLK	Front Anti Roll Bar Mount 21mm	21mm	2	8500	3
Volkswagen	Golf MK4 (1997 - 2004)R32/4motion	PFF85-411-23BLK	Front Anti Roll Bar Mount 23mm	23mm	2	8500	3
Volkswagen	Golf MK4 (1997 - 2004)R32/4motion	PFF85-412BLK	Front Anti Roll Bar Link Bush Kit		2	11000	4
Volkswagen	Golf MK4 (1997 - 2004)R32/4motion	PFF85-414BLK	Front Wishbone Rear Bush (Race Use) Fits All Models		2	34000	2
Volkswagen	Golf MK4 (1997 - 2004)R32/4motion	PFF85-416BLK	Steering Rack Mount Bush		1	3500	7

Volkswagen	Golf MK4 (1997 – 2004)R32/4motion	PFF85-420BLK	Front Engine Mount Dog Bone		1	5750	8
Volkswagen	Golf MK4 (1997 – 2004)R32/4motion	PFF85-424BLK	Front Subframe Rear Bush		2	13500	24
Volkswagen	Golf MK4 (1997 – 2004)R32/4motion	PFF85-430BLK	Front Strut Top Mount Bush		2	12000	11
Volkswagen	Golf MK4 (1997 – 2004)R32/4motion	PFF85-431BLK	Front Strut Top Mount Bush -10mm	-10mm	2	13500	11
Volkswagen	Golf MK4 (1997 – 2004)R32/4motion	PFF85-505BLK	Front Engine Mount Dog Bone Small Bush		1	6000	10
Volkswagen	Golf MK4 (1997 – 2004)R32/4motion	PFR3-508BLK	Rear Trailing Arm Front Bush		2	13500	9
Volkswagen	Golf MK4 (1997 – 2004)R32/4motion	PFR3-508GBLK	Rear Trailing Arm Front Bush Toe Adjust		2	17000	9
Volkswagen	Golf MK4 (1997 – 2004)R32/4motion	PFR3-510BLK	Rear Arm Inner Bush		4	24000	5
Volkswagen	Golf MK4 (1997 – 2004)R32/4motion	PFR3-510GBLK	Rear Arm Inner Bush Camber Adjustable		4	44000	5
Volkswagen	Golf MK4 (1997 – 2004)R32/4motion	PFR3-511-14BLK	Rear Anti Roll Bar Mounting 14mm	14mm	2	8500	6
Volkswagen	Golf MK4 (1997 – 2004)R32/4motion	PFR3-511-15BLK	Rear Anti Roll Bar Mounting 15mm	15mm	2	8500	6
Volkswagen	Golf MK4 (1997 – 2004)R32/4motion	PFR3-511-16BLK	Rear Anti Roll Bar Mounting 16mm	16mm	2	8500	6
Volkswagen	Golf MK4 (1997 – 2004)R32/4motion	PFR3-511-19BLK	Rear Anti Roll Bar Mounting 19mm	19mm	2	8500	6
Volkswagen	Golf MK4 (1997 – 2004)R32/4motion	PFR85-425BLK	Rear Diff Front Mounting Bush		2	13500	25
Volkswagen	Golf MK4 (1997 – 2004)R32/4motion	PFR85-426BLK	Rear Diff Rear Mounting Bush		2	13500	26
Volkswagen	Golf MK4 (1997 – 2004)R32/4motion	PFR85-427BLK	Rear Subframe Mounting Bush		4	29000	27
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFF85-502BLK	Front Wishbone Rear Bush		2	15500	2
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFF85-502GBLK	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	31500	2
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFF85-503-22.5BLK	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	8500	3
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFF85-503-23.6BLK	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	8500	3
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFF85-503-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	8500	3
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFF85-504BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFF85-505BLK	Lower Engine Mount Small Bush		1	6000	5
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFF85-530BLK	Transmission Mount Insert		1	8000	30
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFF85-531BLK	Upper Engine Mount Insert		1	8000	31
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFF85-532BLK	Upper Engine Mount Insert		1	8000	31
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFF85-704BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFR85-508BLK	Rear Tie Bar to Chassis Front Bush		2	11000	8
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFR85-509BLK	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFR85-510BLK	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFR85-511BLK	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFR85-512BLK	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFR85-513BLK	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFR85-514BLK	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFR85-515-20.5BLK	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	9000	15
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFR85-515-20.7BLK	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	9000	15
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFR85-515-21.7BLK	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	9000	15
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFR85-524BLK	Rear Diff Front Mounting Bush		1	7750	24
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFR85-525BLK	Rear Diff Rear Mounting Bush		2	14500	25
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFR85-527BLK	Rear Subframe Front Mounting Bush		2	19500	27
Volkswagen	Golf MK5 (2003 – 2009)Golf MK5 1K	PFR85-528BLK	Rear Subframe Rear Mounting Bush		2	19500	28
Volkswagen	Golf MK5 (2003 – 2009)Golf Mk5 GTI & R32	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	Golf MK5 (2003 – 2009)Golf Mk5 GTI & R32	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	Golf MK5 (2003 – 2009)Golf Mk5 GTI & R32	PFF85-502BLK	Front Wishbone Rear Bush		2	15500	2
Volkswagen	Golf MK5 (2003 – 2009)Golf Mk5 GTI & R32	PFF85-502GBLK	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	31500	2
Volkswagen	Golf MK5 (2003 – 2009)Golf Mk5 GTI & R32	PFF85-503-22.5BLK	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	8500	3
Volkswagen	Golf MK5 (2003 – 2009)Golf Mk5 GTI & R32	PFF85-503-23.6BLK	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	8500	3
Volkswagen	Golf MK5 (2003 – 2009)Golf Mk5 GTI & R32	PFF85-503-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	8500	3
Volkswagen	Golf MK5 (2003 – 2009)Golf Mk5 GTI & R32	PFF85-504BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Golf MK5 (2003 – 2009)Golf Mk5 GTI & R32	PFF85-505BLK	Lower Engine Mount Small Bush		1	6000	5
Volkswagen	Golf MK5 (2003 – 2009)Golf Mk5 GTI & R32	PFF85-530BLK	Transmission Mount Insert		1	8000	30
Volkswagen	Golf MK5 (2003 – 2009)Golf Mk5 GTI & R32	PFF85-531BLK	Upper Engine Mount Insert		1	8000	31
Volkswagen	Golf MK5 (2003 – 2009)Golf Mk5 GTI & R32	PFF85-532BLK	Upper Engine Mount Insert		1	8000	31
Volkswagen	Golf MK5 (2003 – 2009)Golf Mk5 GTI & R32	PFF85-704BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Golf MK5 (2003 – 2009)Golf Mk5 GTI & R32	PFR85-508BLK	Rear Tie Bar to Chassis Front Bush		2	11000	8
Volkswagen	Golf MK5 (2003 – 2009)Golf Mk5 GTI & R32	PFR85-509BLK	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Golf MK5 (2003 – 2009)Golf Mk5 GTI & R32	PFR85-510BLK	Rear Lower Spring Mount Inner		2	9000	10

Volkswagen	Golf MK5 (2003 - 2009)Golf Mk5 GTI & R32	PFR85-511BLK	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Golf MK5 (2003 - 2009)Golf Mk5 GTI & R32	PFR85-512BLK	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Golf MK5 (2003 - 2009)Golf Mk5 GTI & R32	PFR85-513BLK	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Golf MK5 (2003 - 2009)Golf Mk5 GTI & R32	PFR85-514BLK	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Golf MK5 (2003 - 2009)Golf Mk5 GTI & R32	PFR85-515-20.5BLK	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	9000	15
Volkswagen	Golf MK5 (2003 - 2009)Golf Mk5 GTI & R32	PFR85-515-20.7BLK	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	9000	15
Volkswagen	Golf MK5 (2003 - 2009)Golf Mk5 GTI & R32	PFR85-515-21.7BLK	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	9000	15
Volkswagen	Golf MK5 (2003 - 2009)Golf Mk5 GTI & R32	PFR85-524BLK	Rear Diff Front Mounting Bush		1	7750	24
Volkswagen	Golf MK5 (2003 - 2009)Golf Mk5 GTI & R32	PFR85-525BLK	Rear Diff Rear Mounting Bush		2	14500	25
Volkswagen	Golf MK5 (2003 - 2009)Golf Mk5 GTI & R32	PFR85-527BLK	Rear Subframe Front Mounting Bush		2	19500	27
Volkswagen	Golf MK5 (2003 - 2009)Golf Mk5 GTI & R32	PFR85-528BLK	Rear Subframe Rear Mounting Bush		2	19500	28
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFF85-502BLK	Front Wishbone Rear Bush		2	15500	2
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFF85-502GBLK	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	31500	2
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFF85-503-23.6BLK	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	8500	3
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFF85-503-23BLK	Front Anti Roll Bar Bush 23mm	23mm	2	8500	3
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFF85-503-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	8500	3
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFF85-504BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFF85-505BLK	Lower Engine Mount Small Bush		1	6000	5
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFF85-530BLK	Transmission Mount Insert		1	8000	30
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFF85-704BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFR85-508BLK	Rear Tie Bar to Chassis Front Bush		2	11000	8
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFR85-509BLK	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFR85-510BLK	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFR85-511BLK	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFR85-512BLK	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFR85-513BLK	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFR85-514BLK	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFR85-515-20.5BLK	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	9000	15
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFR85-515-20.7BLK	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	9000	15
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFR85-515-21.7BLK	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	9000	15
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFR85-524BLK	Rear Diff Front Mounting Bush		1	7750	24
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFR85-525BLK	Rear Diff Rear Mounting Bush		2	14500	25
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFR85-527BLK	Rear Subframe Front Mounting Bush		2	19500	27
Volkswagen	Golf MK5 (2003 - 2009)Golf Plus 5M	PFR85-528BLK	Rear Subframe Rear Mounting Bush		2	19500	28
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-502BLK	Front Wishbone Rear Bush		2	15500	2
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-502GBLK	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	31500	2
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-503-22.5BLK	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	8500	3
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-503-23.6BLK	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	8500	3
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-503-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	8500	3
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-504BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-505BLK	Lower Engine Mount Small Bush		1	6000	5
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-530BLK	Transmission Mount Insert		1	8000	30
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-531BLK	Upper Engine Mount Insert		1	8000	31
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-532BLK	Upper Engine Mount Insert		1	8000	31
Volkswagen	Golf MK6 5K (2009-2012)	PFF85-704BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-508BLK	Rear Tie Bar to Chassis Front Bush		2	11000	8
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-509BLK	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-510BLK	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-511BLK	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-512BLK	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-513BLK	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-514BLK	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-515-20.5BLK	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	9000	15
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-515-20.7BLK	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	9000	15
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-515-21.7BLK	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	9000	15

Volkswagen	Golf MK6 5K (2009-2012)	PFR85-524BLK	Rear Diff Front Mounting Bush		1	7750	24
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-525BLK	Rear Diff Rear Mounting Bush		2	14500	25
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-527BLK	Rear Subframe Front Mounting Bush		2	19500	27
Volkswagen	Golf MK6 5K (2009-2012)	PFR85-528BLK	Rear Subframe Rear Mounting Bush		2	19500	28
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFF85-802GBLK	Front Wishbone Rear Bush, Caster Adjustable		2	33500	2
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFF85-803-21.7BLK	Front Anti Roll Bar Bush 21.7mm	21.7mm	2	9000	3
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFF85-803-23.2BLK	Front Anti Roll Bar Bush 23.2mm	23.2mm	2	9000	3
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFF85-803-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	9000	3
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFF85-803-25BLK	Front Anti Roll Bar Bush 25mm	25mm	2	9000	3
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFF85-830BLK	Lower Engine Mount Insert (Large)		1	8250	30
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFF85-831BLK	Front Lower Engine Mount Hybrid Bush (Large)		1	12750	30
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFF85-832BLK	Lower Engine Mount (Large) Insert		1	8250	30
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFF85-833BLK	Front Lower Engine Mount Hybrid Bush (Large)		1	12750	30
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFR85-513BLK	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFR85-514BLK	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFR85-811BLK	Rear Tie Bar Outer Bush		2	15500	11
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFR85-812BLK	Rear Tie Bar Inner Bush		2	15500	12
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFR85-815-18.5BLK	Rear Anti Roll Bar Bush 18.5mm	18.5mm	2	9000	15
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFR85-815-19.6BLK	Rear Anti Roll Bar Bush 19.6mm	19.6mm	2	9000	15
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFR85-815-20.7BLK	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	9000	15
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFR85-815-21.7BLK	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	9000	15
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFR85-816BLK	Rear Trailing Arm Bush		2	17000	16
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFR85-817BLK	Rear Lower Arm Outer Bush		2	14000	17
Volkswagen	GOLF MK7 5G 2WD 122PS plus Multi-link	PFR85-818BLK	Rear Lower Arm Inner Bush		2	15500	18
Volkswagen	GOLF MK7 5G 2WD up to 122 PS Rear Beam	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	GOLF MK7 5G 2WD up to 122 PS Rear Beam	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	GOLF MK7 5G 2WD up to 122 PS Rear Beam	PFF85-802GBLK	Front Wishbone Rear Bush, Caster Adjustable		2	33500	2
Volkswagen	GOLF MK7 5G 2WD up to 122 PS Rear Beam	PFF85-803-21.7BLK	Front Anti Roll Bar Bush 21.7mm	21.7mm	2	9000	3
Volkswagen	GOLF MK7 5G 2WD up to 122 PS Rear Beam	PFF85-803-23.2BLK	Front Anti Roll Bar Bush 23.2mm	23.2mm	2	9000	3
Volkswagen	GOLF MK7 5G 2WD up to 122 PS Rear Beam	PFF85-803-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	9000	3
Volkswagen	GOLF MK7 5G 2WD up to 122 PS Rear Beam	PFF85-803-25BLK	Front Anti Roll Bar Bush 25mm	25mm	2	9000	3
Volkswagen	GOLF MK7 5G 2WD up to 122 PS Rear Beam	PFF85-830BLK	Lower Engine Mount Insert (Large)		1	8250	30
Volkswagen	GOLF MK7 5G 2WD up to 122 PS Rear Beam	PFF85-831BLK	Front Lower Engine Mount Hybrid Bush (Large)		1	12750	30
Volkswagen	GOLF MK7 5G 2WD up to 122 PS Rear Beam	PFF85-832BLK	Lower Engine Mount (Large) Insert		1	8250	30
Volkswagen	GOLF MK7 5G 2WD up to 122 PS Rear Beam	PFF85-833BLK	Front Lower Engine Mount Hybrid Bush (Large)		1	12750	30
Volkswagen	GOLF MK7 5G 2WD up to 122 PS Rear Beam	PFR85-810BLK	Rear Beam Mounting Bush		2	18500	10
Volkswagen	GOLF MK7 5G 4WD	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	GOLF MK7 5G 4WD	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	GOLF MK7 5G 4WD	PFF85-802GBLK	Front Wishbone Rear Bush, Caster Adjustable		2	33500	2
Volkswagen	GOLF MK7 5G 4WD	PFF85-803-21.7BLK	Front Anti Roll Bar Bush 21.7mm	21.7mm	2	9000	3
Volkswagen	GOLF MK7 5G 4WD	PFF85-803-23.2BLK	Front Anti Roll Bar Bush 23.2mm	23.2mm	2	9000	3
Volkswagen	GOLF MK7 5G 4WD	PFF85-803-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	9000	3
Volkswagen	GOLF MK7 5G 4WD	PFF85-803-25BLK	Front Anti Roll Bar Bush 25mm	25mm	2	9000	3
Volkswagen	GOLF MK7 5G 4WD	PFF85-830BLK	Lower Engine Mount Insert (Large)		1	8250	30
Volkswagen	GOLF MK7 5G 4WD	PFF85-831BLK	Front Lower Engine Mount Hybrid Bush (Large)		1	12750	30
Volkswagen	GOLF MK7 5G 4WD	PFF85-832BLK	Lower Engine Mount (Large) Insert		1	8250	30
Volkswagen	GOLF MK7 5G 4WD	PFF85-833BLK	Front Lower Engine Mount Hybrid Bush (Large)		1	12750	30
Volkswagen	GOLF MK7 5G 4WD	PFR85-513BLK	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	GOLF MK7 5G 4WD	PFR85-514BLK	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	GOLF MK7 5G 4WD	PFR85-524BLK	Rear Diff Front Mounting Bush		1	7750	24
Volkswagen	GOLF MK7 5G 4WD	PFR85-525BLK	Rear Diff Rear Mounting Bush		2	14500	25
Volkswagen	GOLF MK7 5G 4WD	PFR85-811BLK	Rear Tie Bar Outer Bush		2	15500	11
Volkswagen	GOLF MK7 5G 4WD	PFR85-812BLK	Rear Tie Bar Inner Bush		2	15500	12
Volkswagen	GOLF MK7 5G 4WD	PFR85-815-18.5BLK	Rear Anti Roll Bar Bush 18.5mm	18.5mm	2	9000	15
Volkswagen	GOLF MK7 5G 4WD	PFR85-815-19.6BLK	Rear Anti Roll Bar Bush 19.6mm	19.6mm	2	9000	15
Volkswagen	GOLF MK7 5G 4WD	PFR85-815-20.7BLK	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	9000	15
Volkswagen	GOLF MK7 5G 4WD	PFR85-815-21.7BLK	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	9000	15

Volkswagen	GOLF MK7 5G 4WD	PFR85-816BLK	Rear Trailing Arm Bush		2	17000	16
Volkswagen	GOLF MK7 5G 4WD	PFR85-817BLK	Rear Lower Arm Outer Bush		2	14000	17
Volkswagen	GOLF MK7 5G 4WD	PFR85-818BLK	Rear Lower Arm Inner Bush		2	15500	18
Volkswagen	Jetta (2011 - ON)	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	Jetta (2011 - ON)	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	Jetta (2011 - ON)	PFF85-802GBLK	Front Wishbone Rear Bush, Caster Adjustable		2	33500	2
Volkswagen	Jetta (2011 - ON)	PFR85-817BLK	Rear Lower Arm Outer Bush		2	14000	17
Volkswagen	Jetta MK1 (1979-1984)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Jetta MK1 (1979-1984)	PFF85-211BLK	Front Wishbone Inner Bush		2	11000	1
Volkswagen	Jetta MK1 (1979-1984)	PFF85-213BLK	Front Wishbone Rear Bush		2	11000	2
Volkswagen	Jetta MK1 (1979-1984)	PFF85-215-22BLK	Front Anti Roll Bar Outer Mount 22mm	22mm	2	8500	4
Volkswagen	Jetta MK1 (1979-1984)	PFF85-215BLK	Front Anti Roll Bar Outer Mount 16mm	16mm	2	8500	4
Volkswagen	Jetta MK1 (1979-1984)	PFF85-216BLK	Front Anti Roll Bar Inner Mount		2	8500	3
Volkswagen	Jetta MK1 (1979-1984)	PFF85-229BLK	Steering Rack Mount		1	3500	11
Volkswagen	Jetta MK1 (1979-1984)	PFF85-230BLK	Steering Rack Mount		1	3500	12
Volkswagen	Jetta MK1 (1979-1984)	PFF85-235BLK	Engine Mount Stopper Bush		1	4750	5
Volkswagen	Jetta MK1 (1979-1984)	PFR85-220BLK	Rear Beam Mounting Bush		2	13000	7
Volkswagen	Jetta MK1 (1979-1984)	PFR85-226-20.5BLK	Rear Anti Roll Bar Mount (Outer) 20.5mm	20.5mm	2	8000	9
Volkswagen	Jetta MK1 (1979-1984)	PFR85-241BLK	Rear Shock Top Mounting Bush		2	11500	20
Volkswagen	Jetta MK2 (1985-1992)	BS006	Bump Stop, VW Front	54mm x 59mm x 19	2	6500	
Volkswagen	Jetta MK2 (1985-1992)	BS008	Bump Stop, VW Rear	60mm x 58mm x 10	2	6500	
Volkswagen	Jetta MK2 (1985-1992)	BS2001K	Bump Stop Kit	Front	1	9250	
Volkswagen	Jetta MK2 (1985-1992)	EXH006	Exhaust Mounts		1	2250	
Volkswagen	Jetta MK2 (1985-1992)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Jetta MK2 (1985-1992)	PFF85-201BLK	Front Wishbone Front Bush	30mm	2	11500	1
Volkswagen	Jetta MK2 (1985-1992)	PFF85-203BLK	Front Wishbone Inner Bush (Rear)		2	11500	2
Volkswagen	Jetta MK2 (1985-1992)	PFF85-205-20BLK	Front Anti Roll Bar Bush 20mm	20mm	2	10000	3
Volkswagen	Jetta MK2 (1985-1992)	PFF85-205-22BLK	Front Anti Roll Bar Bush Eibach 22mm	22mm	2	10000	3
Volkswagen	Jetta MK2 (1985-1992)	PFF85-205BLK	Front Anti Roll Bar Mount 18mm	18mm	2	10000	3
Volkswagen	Jetta MK2 (1985-1992)	PFF85-208-10BLK	Front Eye Bolt Mounting Bush 10mm	10mm	2	8000	4
Volkswagen	Jetta MK2 (1985-1992)	PFF85-208BLK	Front Eye Bolt Mounting Bush		2	8000	4
Volkswagen	Jetta MK2 (1985-1992)	PFF85-209-20BLK	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	8000	5
Volkswagen	Jetta MK2 (1985-1992)	PFF85-209BLK	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	8000	5
Volkswagen	Jetta MK2 (1985-1992)	PFF85-231BLK	Non Power Steering Rack Mount		2	7000	9
Volkswagen	Jetta MK2 (1985-1992)	PFF85-232BLK	Power Steering Rack Mount	18.5mm wide bracket	1	3500	9
Volkswagen	Jetta MK2 (1985-1992)	PFF85-233BLK	Power Steering Rack Mount	15mm wide bracket	1	3500	9
Volkswagen	Jetta MK2 (1985-1992)	PFF85-244BLK	Rear Lower Engine Mount Bush		1	13250	20
Volkswagen	Jetta MK2 (1985-1992)	PFF85-245BLK	Rear Lower Engine Mount Insert		1	6250	20
Volkswagen	Jetta MK2 (1985-1992)	PFF85-250BLK	Front Cross Member Mounting Bush		4	12000	6
Volkswagen	Jetta MK2 (1985-1992)	PFR85-207BLK	Rear Beam Mounting Bush		2	17000	7
Volkswagen	Jetta MK2 (1985-1992)	PFR85-212BLK	Rear Anti-Roll Bar To Beam Bush Eibach		2	10000	12
Volkswagen	Jetta MK2 (1985-1992)	PFR85-225-25BLK	Rear Anti Roll Bar Bush Eibach 25mm	25mm	2	10000	25
Volkswagen	Jetta MK2 (1985-1992)	PFR85-240BLK	Rear Shock Top Mounting Bush		2	8000	8
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-502BLK	Front Wishbone Rear Bush		2	15500	2
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-502GBLK	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	31500	2
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-503-22.5BLK	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	8500	3
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-503-23.6BLK	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	8500	3
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-503-23BLK	Front Anti Roll Bar Bush 23mm	23mm	2	8500	3
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-503-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	8500	3
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-504BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-505BLK	Lower Engine Mount Small Bush		1	6000	5
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-530BLK	Transmission Mount Insert		1	8000	30
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-531BLK	Upper Engine Mount Insert		1	8000	31
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-532BLK	Upper Engine Mount Insert		1	8000	31
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFF85-704BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-508BLK	Rear Tie Bar to Chassis Front Bush		2	11000	8
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-509BLK	Rear Lower Spring Mount Outer		2	9000	9

Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-510BLK	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-511BLK	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-512BLK	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-513BLK	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-514BLK	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Jetta, Bora, Vento Mk5 1K (2005-2010)	PFR85-515-20.5BLK	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	9000	15
Volkswagen	Lupo (1999 - 2006)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Lupo (1999 - 2006)	PFF85-208-10BLK	Front Eye Bolt Mounting Bush 10mm (M8 nut)	M10	2	8000	4
Volkswagen	Lupo (1999 - 2006)	PFF85-209BLK	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	8000	5
Volkswagen	Lupo (1999 - 2006)	PFF85-401BLK	Front Wishbone Inner Bush (front)		2	10500	1
Volkswagen	Lupo (1999 - 2006)	PFF85-402BLK	Front Wishbone Rear Bush		2	11500	2
Volkswagen	Lupo (1999 - 2006)	PFF85-403-18BLK	Front Anti Roll Bar Bush 18mm	18mm	2	9000	3
Volkswagen	Lupo (1999 - 2006)	PFF85-403-20BLK	Front Anti Roll Bar Bush 20mm	20mm	2	9000	3
Volkswagen	Lupo (1999 - 2006)	PFF85-403-22BLK	Front Anti Roll Bar Bush 22mm	22mm	2	9000	3
Volkswagen	Lupo (1999 - 2006)	PFF85-431BLK	Front Strut Top Mount Bush -10mm	-10mm	2	13500	11
Volkswagen	Lupo (1999 - 2006)	PFF85-920BLK	Lower Engine Mount Large Bush		1	9500	6
Volkswagen	Lupo (1999 - 2006)	PFF85-921BLK	Lower Engine Mount Large Bush		1	8250	6
Volkswagen	Lupo (1999 - 2006)	PFR85-615BLK	Rear Beam Mounting Bush	58mm	2	16500	7
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-201BLK	Front Wishbone Front Bush	30mm	2	11500	1
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-410BLK	Front Wishbone Rear Bush		2	13000	2
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-410PABLK	Front Wishbone Rear Bush		2	12000	
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-411-21BLK	Front Anti Roll Bar Mount 21mm	21mm	2	8500	3
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-411-23BLK	Front Anti Roll Bar Mount 23mm	23mm	2	8500	3
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-412BLK	Front Anti Roll Bar Link Bush Kit		2	11000	4
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-414BLK	Front Wishbone Rear Bush (Race Use)		2	34000	2
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-416BLK	Steering Rack Mount Bush		1	3500	7
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-420BLK	Front Engine Mount Dog Bone		1	5750	8
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-424BLK	Front Subframe Rear Bush		2	13500	24
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-430BLK	Front Strut Top Mount Bush		2	12000	11
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-431BLK	Front Strut Top Mount Bush -10mm	-10mm	2	13500	11
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFF85-505BLK	Front Engine Mount Dog Bone Small Bush		1	6000	9
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFR85-415BLK	Rear Beam Mounting Bush, 72.5mm	72.5mm	2	17000	5
Volkswagen	New Beetle & Cabrio 2WD (1998-2011)	PFR85-610BLK	Rear Beam Mounting Bush, 69mm	69mm	2	17000	5
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-201BLK	Front Wishbone Front Bush	30mm	2	11500	1
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-410BLK	Front Wishbone Rear Bush		2	13000	2
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-410PABLK	Front Wishbone Rear Bush		2	12000	
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-411-21BLK	Front Anti Roll Bar Mount 21mm	21mm	2	8500	3
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-412BLK	Front Anti Roll Bar Link Bush Kit		2	11000	4
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-416BLK	Steering Rack Mount Bush		1	3500	7
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-420BLK	Front Engine Mount Dog Bone		1	5750	8
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-424BLK	Front Subframe Rear Bush		2	13500	24
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-430BLK	Front Strut Top Mount Bush		2	12000	11
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-431BLK	Front Strut Top Mount Bush -10mm	-10mm	2	13500	11
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFF85-505BLK	Front Engine Mount Dog Bone Small Bush		1	6000	10
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR3-508BLK	Rear Trailing Arm Front Bush		2	13500	9
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR3-508GBLK	Rear Trailing Arm Front Bush Toe Adjust		2	17000	9
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR3-510GBLK	Rear Arm Inner Bush Camber Adjustable		4	44000	5
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR3-511-14BLK	Rear Anti Roll Bar Mounting 14mm	14mm	2	8500	6
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR3-511-15BLK	Rear Anti Roll Bar Mounting 15mm	15mm	2	8500	6
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR3-511-16BLK	Rear Anti Roll Bar Mounting 16mm	16mm	2	8500	6
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR3-511-19BLK	Rear Anti Roll Bar Mounting 19mm	19mm	2	8500	6
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR85-425BLK	Rear Diff Front Mounting Bush		2	13500	25
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR85-426BLK	Rear Diff Rear Mounting Bush		2	13500	26
Volkswagen	New Beetle & Cabrio 4Motion (1998-2011)	PFR85-427BLK	Rear Subframe Mounting Bush		4	29000	27
Volkswagen	Passat (1988 - 1996)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Passat (1988 - 1996)	PFF85-244BLK	Rear Lower Engine Mount Bush		1	13250	20
Volkswagen	Passat (1988 - 1996)	PFF85-245BLK	Rear Lower Engine Mount Insert		1	6250	20
Volkswagen	Passat (1988 - 1996)	PFF85-280BLK	Front Lower Engine Mounting Bush & Inserts		1	10000	20
Volkswagen	Passat B5 (1996 - 2005)4 Motion (1996 - 2005)	PFF3-201BLK	Front Lower Shock Mount		2	16500	1



Volkswagen	Passat B5 (1996 - 2005)4 Motion (1996 - 2005)	PFF3-202BLK	Front Tie Bar Rear Bush		2	24500	2
Volkswagen	Passat B5 (1996 - 2005)4 Motion (1996 - 2005)	PFF3-203BLK	Front Upper Arm To Chassis Bush		4	21000	3
Volkswagen	Passat B5 (1996 - 2005)4 Motion (1996 - 2005)	PFF3-203GBLK	Front Upper Arm To Chassis Bush Camber Adjustable		4	40000	3
Volkswagen	Passat B5 (1996 - 2005)4 Motion (1996 - 2005)	PFF3-204-29BLK	Front Anti Roll Bar Bush 29mm	29mm	2	8500	4
Volkswagen	Passat B5 (1996 - 2005)4 Motion (1996 - 2005)	PFF3-211BLK	Front Lower Arm Inner Bush		2	13500	11
Volkswagen	Passat B5 (1996 - 2005)4 Motion (1996 - 2005)	PFF3-213BLK	Front Anti Roll Bar Link Bush		4	20000	5
Volkswagen	Passat B5 (1996 - 2005)4 Motion (1996 - 2005)	PFF3-220BLK	Engine Snub Nose Mount		1	5750	16
Volkswagen	Passat B5 (1996 - 2005)4 Motion Estate (1996 - 2005)	PFF3-201BLK	Front Lower Shock Mount		2	16500	1
Volkswagen	Passat B5 (1996 - 2005)4 Motion Estate (1996 - 2005)	PFF3-202BLK	Front Tie Bar Rear Bush		2	24500	2
Volkswagen	Passat B5 (1996 - 2005)4 Motion Estate (1996 - 2005)	PFF3-203BLK	Front Upper Arm To Chassis Bush		4	21000	3
Volkswagen	Passat B5 (1996 - 2005)4 Motion Estate (1996 - 2005)	PFF3-203GBLK	Front Upper Arm To Chassis Bush Camber Adjustable		4	40000	3
Volkswagen	Passat B5 (1996 - 2005)4 Motion Estate (1996 - 2005)	PFF3-204-29BLK	Front Anti Roll Bar Bush 29mm	29mm	2	8500	4
Volkswagen	Passat B5 (1996 - 2005)4 Motion Estate (1996 - 2005)	PFF3-211BLK	Front Lower Arm Inner Bush		2	13500	11
Volkswagen	Passat B5 (1996 - 2005)4 Motion Estate (1996 - 2005)	PFF3-213BLK	Front Anti Roll Bar Link Bush		4	20000	5
Volkswagen	Passat B5 (1996 - 2005)4 Motion Estate (1996 - 2005)	PFF3-220BLK	Engine Snub Nose Mount		1	5750	16
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	BS2007K	Bump Stop Kit	Rear	1	16000	
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	PFF3-201BLK	Front Lower Shock Mount		2	16500	1
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	PFF3-202BLK	Front Tie Bar Rear Bush		2	24500	2
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	PFF3-203BLK	Front Upper Arm To Chassis Bush		4	21000	3
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	PFF3-203GBLK	Front Upper Arm To Chassis Bush Camber Adjustable		4	40000	3
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	PFF3-204-29BLK	Front Anti Roll Bar Bush 29mm	29mm	2	8500	4
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	PFF3-211BLK	Front Lower Arm Inner Bush		2	13500	11
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	PFF3-213BLK	Front Anti Roll Bar Link Bush		4	20000	5
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	PFF3-220BLK	Engine Snub Nose Mount		1	5750	16
Volkswagen	Passat B5 (1996 - 2005)Estate (1996-2005)	PFR3-215BLK	Rear Beam Mount Bush		2	20500	15
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	BS2007K	Bump Stop Kit	Rear	1	16000	
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	PFF3-201BLK	Front Lower Shock Mount		2	16500	1
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	PFF3-202BLK	Front Tie Bar Rear Bush		2	24500	2
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	PFF3-203BLK	Front Upper Arm To Chassis Bush		4	21000	3
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	PFF3-203GBLK	Front Upper Arm To Chassis Bush Camber Adjustable		4	40000	3
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	PFF3-204-29BLK	Front Anti Roll Bar Bush 29mm	29mm	2	8500	4
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	PFF3-211BLK	Front Lower Arm Inner Bush		2	13500	11
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	PFF3-213BLK	Front Anti Roll Bar Link Bush		4	20000	5
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	PFF3-220BLK	Engine Snub Nose Mount		1	5750	16
Volkswagen	Passat B5 (1996 - 2005)Saloon (1996 - 2005)	PFR3-215BLK	Rear Beam Mount Bush		2	20500	15
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-502BLK	Front Wishbone Rear Bush		2	15500	2
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-502G-5BLK	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	34500	2
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-503-22.5BLK	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	8500	3
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-503-22BLK	Front Anti Roll Bar Bush 22mm	22mm	2	8500	3
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-503-23.6BLK	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	8500	3
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-503-23BLK	Front Anti Roll Bar Bush 23mm	23mm	2	8500	3
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-503-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	8500	3
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-504BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-505BLK	Lower Engine Mount Small Bush		1	6000	5
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-531BLK	Upper Engine Mount Insert		1	8000	31
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-532BLK	Upper Engine Mount Insert		1	8000	31
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFF85-704BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-508BLK	Rear Tie Bar to Chassis Front Bush		2	11000	8
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-509BLK	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-510BLK	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-511BLK	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-512BLK	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-513BLK	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-514BLK	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-515-20.5BLK	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	9000	15
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-515-20.7BLK	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	9000	15
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-515-21.7BLK	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	9000	15

Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-527BLK	Rear Subframe Front Mounting Bush		2	19500	27
Volkswagen	Passat B6 & B7 Typ3C (2006-2012)	PFR85-528BLK	Rear Subframe Rear Mounting Bush		2	19500	28
Volkswagen	Passat B8 (2015 on)	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	Passat B8 (2015 on)	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	Passat B8 (2015 on)	PFF85-802GBLK	Front Wishbone Rear Bush, Caster Adjustable		2	33500	2
Volkswagen	Passat B8 (2015 on)	PFF85-830BLK	Lower Engine Mount Insert (Large)		1	8250	30
Volkswagen	Passat B8 (2015 on)	PFF85-831BLK	Front Lower Engine Mount Hybrid Bush (Large)		1	12750	30
Volkswagen	Passat B8 (2015 on)	PFF85-832BLK	Lower Engine Mount (Large) Insert		1	8250	30
Volkswagen	Passat B8 (2015 on)	PFF85-833BLK	Front Lower Engine Mount Hybrid Bush (Large)		1	12750	30
Volkswagen	Passat B8 (2015 on)	PFR85-513BLK	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Passat B8 (2015 on)	PFR85-514BLK	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Passat B8 (2015 on)	PFR85-524BLK	Rear Diff Front Mounting Bush		1	7750	24
Volkswagen	Passat B8 (2015 on)	PFR85-525BLK	Rear Diff Rear Mounting Bush		2	14500	25
Volkswagen	Passat B8 (2015 on)	PFR85-811BLK	Rear Tie Bar Outer Bush		2	15500	11
Volkswagen	Passat B8 (2015 on)	PFR85-812BLK	Rear Tie Bar Inner Bush		2	15500	12
Volkswagen	Passat B8 (2015 on)	PFR85-815-20.7BLK	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	9000	15
Volkswagen	Passat B8 (2015 on)	PFR85-815-21.7BLK	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	9000	15
Volkswagen	Passat B8 (2015 on)	PFR85-816BLK	Rear Trailing Arm Bush		2	17000	16
Volkswagen	Passat B8 (2015 on)	PFR85-817BLK	Rear Lower Arm Outer Bush		2	14000	17
Volkswagen	Passat CC 35 (2008-2012)	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	Passat CC 35 (2008-2012)	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	Passat CC 35 (2008-2012)	PFF85-502BLK	Front Wishbone Rear Bush		2	15500	2
Volkswagen	Passat CC 35 (2008-2012)	PFF85-502G-5BLK	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	34500	2
Volkswagen	Passat CC 35 (2008-2012)	PFF85-503-22.5BLK	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	8500	3
Volkswagen	Passat CC 35 (2008-2012)	PFF85-503-22BLK	Front Anti Roll Bar Bush 22mm	22mm	2	8500	3
Volkswagen	Passat CC 35 (2008-2012)	PFF85-503-23.6BLK	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	8500	3
Volkswagen	Passat CC 35 (2008-2012)	PFF85-503-23BLK	Front Anti Roll Bar Bush 23mm	23mm	2	8500	3
Volkswagen	Passat CC 35 (2008-2012)	PFF85-503-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	8500	3
Volkswagen	Passat CC 35 (2008-2012)	PFF85-504BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Passat CC 35 (2008-2012)	PFF85-505BLK	Lower Engine Mount Small Bush		1	6000	5
Volkswagen	Passat CC 35 (2008-2012)	PFF85-704BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Passat CC 35 (2008-2012)	PFR85-508BLK	Rear Tie Bar to Chassis Front Bush		2	11000	8
Volkswagen	Passat CC 35 (2008-2012)	PFR85-509BLK	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Passat CC 35 (2008-2012)	PFR85-510BLK	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Passat CC 35 (2008-2012)	PFR85-511BLK	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Passat CC 35 (2008-2012)	PFR85-512BLK	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Passat CC 35 (2008-2012)	PFR85-513BLK	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Passat CC 35 (2008-2012)	PFR85-514BLK	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Passat CC 35 (2008-2012)	PFR85-515-20.5BLK	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	9000	15
Volkswagen	Passat CC 35 (2008-2012)	PFR85-515-20.7BLK	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	9000	15
Volkswagen	Passat CC 35 (2008-2012)	PFR85-515-21.7BLK	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	9000	15
Volkswagen	Passat CC 35 (2008-2012)	PFR85-527BLK	Rear Subframe Front Mounting Bush		2	19500	27
Volkswagen	Passat CC 35 (2008-2012)	PFR85-528BLK	Rear Subframe Rear Mounting Bush		2	19500	28
Volkswagen	Polo (1975 - 1994)	EXH006	Exhaust Mounts		1	2250	
Volkswagen	Polo (1975 - 1994)	PFF85-101BLK	Front Wishbone Outer Bush		2	10500	1
Volkswagen	Polo (1975 - 1994)	PFF85-103BLK	Front Wishbone Inner Bush		2	9000	2
Volkswagen	Polo (1975 - 1994)	PFF85-105BLK	Front Anti Roll Bar Mount 18mm	18mm	2	8500	3
Volkswagen	Polo 6N (1995 - 2002)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Polo 6N (1995 - 2002)	PFF85-208-10BLK	Front Eye Bolt Mounting Bush 10mm (M8 nut)	10mm	2	8000	4
Volkswagen	Polo 6N (1995 - 2002)	PFF85-209-20BLK	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	8000	5
Volkswagen	Polo 6N (1995 - 2002)	PFF85-209BLK	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	8000	5
Volkswagen	Polo 6N (1995 - 2002)	PFF85-401BLK	Front Wishbone Inner Bush (front)		2	10500	1
Volkswagen	Polo 6N (1995 - 2002)	PFF85-402BLK	Front Wishbone Inner Bush (rear)		2	11500	2
Volkswagen	Polo 6N (1995 - 2002)	PFF85-403-18BLK	Front Anti Roll Bar Bush 18mm	18mm	2	9000	3
Volkswagen	Polo 6N (1995 - 2002)	PFF85-403-20BLK	Front Anti Roll Bar Bush 20mm	20mm	2	9000	3
Volkswagen	Polo 6N (1995 - 2002)	PFF85-403-22BLK	Front Anti Roll Bar Bush 22mm	22mm	2	9000	3
Volkswagen	Polo 6N (1995 - 2002)	PFF85-920BLK	Lower Engine Mount Large Bush		1	9500	6
Volkswagen	Polo 6N (1995 - 2002)	PFR85-240BLK	Rear Shock Top Mounting Bush		2	8000	8
Volkswagen	Polo 6N (1995 - 2002)	PFR85-615BLK	Rear Beam Mounting Bush	58mm	2	16500	7

Volkswagen	Polo 6N (1995 - 2002)	PFR85-915BLK	Rear Beam Mounting Bush	71.5mm	2	16500	7
Volkswagen	Polo 6R/6C (2009 - 2017)	PFF85-1202BLK	Front Arm Rear Bush		2	13500	2
Volkswagen	Polo 6R/6C (2009 - 2017)	PFF85-201BLK	Front Wishbone Front Bush		2	11500	1
Volkswagen	Polo 6R/6C (2009 - 2017)	PFF85-430BLK	Front Strut Top Mount Bush		2	12000	11
Volkswagen	Polo 6R/6C (2009 - 2017)	PFF85-431BLK	Front Strut Top Mount Bush -10mm	-10mm	2	13500	11
Volkswagen	Polo 6R/6C (2009 - 2017)	PFF85-603-18BLK	Front Anti Roll Bar Bush 18mm	18mm	2	8500	3
Volkswagen	Polo 6R/6C (2009 - 2017)	PFF85-603-19BLK	Front Anti Roll Bar Bush 19mm	19mm	2	8500	3
Volkswagen	Polo 6R/6C (2009 - 2017)	PFF85-603-20BLK	Front Anti Roll Bar Bush 20mm		2	8500	3
Volkswagen	Polo 6R/6C (2009 - 2017)	PFF85-620BLK	Lower Engine Mount Large Bush		1	8250	20
Volkswagen	Polo 6R/6C (2009 - 2017)	PFR85-415BLK	Rear Beam Mounting Bush, 72.5mm	72.5mm	2	17000	4
Volkswagen	Polo 6R/6C (2009 - 2017)	PFR85-610BLK	Rear Beam Mounting Bush, 69mm	69mm	2	17000	4
Volkswagen	Polo 9N/9N3 (2002 - 2008)	PFF85-201BLK	Front Wishbone Front Bush		2	11500	1
Volkswagen	Polo 9N/9N3 (2002 - 2008)	PFF85-602BLK	Front Wishbone Rear Bush		2	16500	2
Volkswagen	Polo 9N/9N3 (2002 - 2008)	PFF85-603-18BLK	Front Anti Roll Bar Bush 18mm	18mm	2	8500	3
Volkswagen	Polo 9N/9N3 (2002 - 2008)	PFF85-603-19BLK	Front Anti Roll Bar Bush 19mm	19mm	2	8500	3
Volkswagen	Polo 9N/9N3 (2002 - 2008)	PFF85-603-20BLK	Front Anti Roll Bar Bush 20mm		2	8500	3
Volkswagen	Polo 9N/9N3 (2002 - 2008)	PFF85-620BLK	Lower Engine Mount Large Bush		1	8250	20
Volkswagen	Polo 9N/9N3 (2002 - 2008)	PFR85-415BLK	Rear Beam Mounting Bush, 72.5mm	72.5mm	2	17000	4
Volkswagen	Polo 9N/9N3 (2002 - 2008)	PFR85-610BLK	Rear Beam Mounting Bush, 69mm	69mm	2	17000	4
Volkswagen	Scirocco (1973 - 1992)	BS2001K	Bump Stop Kit	Front	1	9250	
Volkswagen	Scirocco (1973 - 1992)	BS2004K	Bump Stop Kit	Rear	1	9750	
Volkswagen	Scirocco (1973 - 1992)	PFF85-211BLK	Front Wishbone Inner Bush		2	11000	1
Volkswagen	Scirocco (1973 - 1992)	PFF85-213BLK	Front Wishbone Rear Bush		2	11000	2
Volkswagen	Scirocco (1973 - 1992)	PFF85-215-22BLK	Front Anti Roll Bar Outer Mount 22mm	22mm	2	8500	4
Volkswagen	Scirocco (1973 - 1992)	PFF85-215BLK	Front Anti Roll Bar Outer Mount 16mm	16mm	2	8500	4
Volkswagen	Scirocco (1973 - 1992)	PFF85-216BLK	Front Anti Roll Bar Inner Mount		2	8500	3
Volkswagen	Scirocco (1973 - 1992)	PFF85-229BLK	Steering Rack Mount		1	3500	
Volkswagen	Scirocco (1973 - 1992)	PFF85-230BLK	Steering Rack Mount		1	3500	
Volkswagen	Scirocco (1973 - 1992)	PFF85-235BLK	Engine Mount Stopper Bush		1	4750	5
Volkswagen	Scirocco (1973 - 1992)	PFR85-220BLK	Rear Beam Mounting Bush		2	13000	7
Volkswagen	Scirocco (1973 - 1992)	PFR85-225BLK	Rear Anti Roll Bar Mount (Inner)	19.5mm	2	10000	8
Volkswagen	Scirocco (1973 - 1992)	PFR85-226-20.5BLK	Rear Anti Roll Bar Mount (Outer) 20.5mm	20.5mm	2	8000	9
Volkswagen	Scirocco (1973 - 1992)	PFR85-241BLK	Rear Shock Top Mounting Bush		2	11500	20
Volkswagen	Scirocco Mk3 (2008-)	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	Scirocco Mk3 (2008-)	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	Scirocco Mk3 (2008-)	PFF85-502BLK	Front Wishbone Rear Bush		2	15500	2
Volkswagen	Scirocco Mk3 (2008-)	PFF85-502GBLK	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	31500	2
Volkswagen	Scirocco Mk3 (2008-)	PFF85-503-22.5BLK	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	8500	3
Volkswagen	Scirocco Mk3 (2008-)	PFF85-503-22BLK	Front Anti Roll Bar Bush 22mm	22mm	2	8500	3
Volkswagen	Scirocco Mk3 (2008-)	PFF85-503-23.6BLK	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	8500	3
Volkswagen	Scirocco Mk3 (2008-)	PFF85-503-23BLK	Front Anti Roll Bar Bush 23mm	23mm	2	8500	3
Volkswagen	Scirocco Mk3 (2008-)	PFF85-503-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	8500	3
Volkswagen	Scirocco Mk3 (2008-)	PFF85-504BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Scirocco Mk3 (2008-)	PFF85-505BLK	Lower Engine Mount Small Bush		1	6000	5
Volkswagen	Scirocco Mk3 (2008-)	PFF85-530BLK	Transmission Mount Insert		1	8000	30
Volkswagen	Scirocco Mk3 (2008-)	PFF85-704BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Scirocco Mk3 (2008-)	PFR85-508BLK	Rear Tie Bar to Chassis Front Bush		2	11000	8
Volkswagen	Scirocco Mk3 (2008-)	PFR85-509BLK	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Scirocco Mk3 (2008-)	PFR85-510BLK	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Scirocco Mk3 (2008-)	PFR85-511BLK	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Scirocco Mk3 (2008-)	PFR85-512BLK	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Scirocco Mk3 (2008-)	PFR85-513BLK	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Scirocco Mk3 (2008-)	PFR85-514BLK	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Scirocco Mk3 (2008-)	PFR85-515-20.5BLK	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	9000	15
Volkswagen	Scirocco Mk3 (2008-)	PFR85-515-21.7BLK	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	9000	15
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFA100-14	PowerAlign Camber Bolt Kit (14mm)	14mm	1	4250	N/A
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFF85-1301BLK	Front Arm Front Bush		2	12000	1
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFF85-1301GBLK	Front Arm Front Bush, Camber Adjustable		2	19500	1
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFF85-1302BLK	Front Arm Rear Bush		2	15000	2

Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFF85-1302GBLK	Front Arm Rear Bush, Caster Adjustable		2	23000	2
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFF85-1303-22BLK	Front Anti Roll Bar Bush 22mm	22mm	2	9500	3
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFF85-1303-23BLK	Front Anti Roll Bar Bush 23mm	23mm	2	9500	3
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFF85-1303-25BLK	Front Anti Roll Bar Bush 25mm	25mm	2	9500	3
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFR85-1310BLK	Rear Arm Outer Bush		2	15000	10
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFR85-1310GBLK	Rear Arm Outer Bush, Adjustable		2	25500	10
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFR85-1311BLK	Rear Arm Inner Bush		2	17000	11
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFR85-1311GBLK	Rear Arm Inner Bush, Adjustable		2	29500	11
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFR85-1312-22BLK	Rear Anti Roll Bar Bush to Chassis 22mm	22mm	2	9500	12
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFR85-1312-24BLK	Rear Anti Roll Bar Bush to Chassis 24mm	24mm	2	9500	12
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFR85-1312-28BLK	Rear Anti Roll Bar Bush to Chassis 28mm	28mm	2	9500	12
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFR85-1313-22BLK	Rear Anti Roll Bar Bush to Arm 22mm	22mm	2	9500	13
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFR85-1313-24BLK	Rear Anti Roll Bar Bush to Arm 24mm	24mm	2	9500	13
Volkswagen	T5 Transporter inc. 4Motion (2003-2015)	PFR85-1313-28BLK	Rear Anti Roll Bar Bush to Arm 28mm	28mm	2	9500	13
Volkswagen	T6 Transporter (2015 - )	PFF85-1301BLK	Front Arm Front Bush		2	12000	1
Volkswagen	T6 Transporter (2015 - )	PFF85-1301GBLK	Front Arm Front Bush, Camber Adjustable		2	19500	1
Volkswagen	T6 Transporter (2015 - )	PFF85-1302BLK	Front Arm Rear Bush		2	15000	2
Volkswagen	T6 Transporter (2015 - )	PFF85-1302GBLK	Front Arm Rear Bush, Caster Adjustable		2	23000	2
Volkswagen	T6 Transporter (2015 - )	PFF85-1303-22BLK	Front Anti Roll Bar Bush 22mm	22mm	2	9500	3
Volkswagen	T6 Transporter (2015 - )	PFF85-1303-23BLK	Front Anti Roll Bar Bush 23mm	23mm	2	9500	3
Volkswagen	T6 Transporter (2015 - )	PFF85-1303-25BLK	Front Anti Roll Bar Bush 25mm	25mm	2	9500	3
Volkswagen	T6 Transporter (2015 - )	PFR85-1310BLK	Rear Arm Outer Bush		2	15000	10
Volkswagen	T6 Transporter (2015 - )	PFR85-1310GBLK	Rear Arm Outer Bush, Adjustable		2	25500	10
Volkswagen	T6 Transporter (2015 - )	PFR85-1311BLK	Rear Arm Inner Bush		2	17000	11
Volkswagen	T6 Transporter (2015 - )	PFR85-1311GBLK	Rear Arm Inner Bush, Adjustable		2	29500	11
Volkswagen	T6 Transporter (2015 - )	PFR85-1312-22BLK	Rear Anti Roll Bar Bush to Chassis 22mm	22mm	2	9500	12
Volkswagen	T6 Transporter (2015 - )	PFR85-1312-24BLK	Rear Anti Roll Bar Bush to Chassis 24mm	24mm	2	9500	12
Volkswagen	T6 Transporter (2015 - )	PFR85-1312-28BLK	Rear Anti Roll Bar Bush to Chassis 28mm	28mm	2	9500	12
Volkswagen	T6 Transporter (2015 - )	PFR85-1313-22BLK	Rear Anti Roll Bar Bush to Arm 22mm	22mm	2	9500	13
Volkswagen	T6 Transporter (2015 - )	PFR85-1313-24BLK	Rear Anti Roll Bar Bush to Arm 24mm	24mm	2	9500	13
Volkswagen	T6 Transporter (2015 - )	PFR85-1313-28BLK	Rear Anti Roll Bar Bush to Arm 28mm	28mm	2	9500	13
Volkswagen	Tiguan (2016 - )	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	Tiguan (2016 - )	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	Tiguan (2016 - )	PFF85-802GBLK	Front Wishbone Rear Bush, Caster Adjustable		2	33500	2
Volkswagen	Tiguan (2016 - )	PFF85-803-25BLK	Front Anti Roll Bar Bush 25mm	25mm	2	9000	3
Volkswagen	Tiguan (2016 - )	PFF85-830BLK	Lower Engine Mount Insert (Large)		1	8250	30
Volkswagen	Tiguan (2016 - )	PFF85-831BLK	Front Lower Engine Mount Hybrid Bush (Large)		1	12750	30
Volkswagen	Tiguan (2016 - )	PFF85-832BLK	Lower Engine Mount (Large) Insert		1	8250	30
Volkswagen	Tiguan (2016 - )	PFF85-833BLK	Front Lower Engine Mount Hybrid Bush (Large)		1	12750	30
Volkswagen	Tiguan (2016 - )	PFR85-513BLK	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Tiguan (2016 - )	PFR85-514BLK	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Tiguan (2016 - )	PFR85-815-21.7BLK	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	9000	15
Volkswagen	Tiguan (2016 - )	PFR85-816BLK	Rear Trailing Arm Bush		2	17000	16
Volkswagen	Tiguan (2016 - )	PFR85-817BLK	Rear Lower Arm Outer Bush		2	14000	17
Volkswagen	Tiguan (2016 - )	PFR85-818BLK	Rear Lower Arm Inner Bush		2	15500	18
Volkswagen	Touran (2017 - )	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	Touran (2017 - )	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	Touran (2017 - )	PFF85-802GBLK	Front Wishbone Rear Bush, Caster Adjustable		2	33500	2
Volkswagen	Touran (2017 - )	PFF85-803-25BLK	Front Anti Roll Bar Bush 25mm	25mm	2	9000	3
Volkswagen	Touran (2017 - )	PFF85-830BLK	Lower Engine Mount Insert (Large)		1	8250	30
Volkswagen	Touran (2017 - )	PFF85-831BLK	Front Lower Engine Mount Hybrid Bush (Large)		1	12750	30
Volkswagen	Touran (2017 - )	PFF85-832BLK	Lower Engine Mount (Large) Insert		1	8250	30
Volkswagen	Touran (2017 - )	PFF85-833BLK	Front Lower Engine Mount Hybrid Bush (Large)		1	12750	30
Volkswagen	Touran (2017 - )	PFR85-513BLK	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Touran (2017 - )	PFR85-514BLK	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Touran (2017 - )	PFR85-815-19.6BLK	Rear Anti Roll Bar Bush 19.6mm	19.6mm	2	9000	15
Volkswagen	Touran (2017 - )	PFR85-815-21.7BLK	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	9000	15
Volkswagen	Touran (2017 - )	PFR85-816BLK	Rear Trailing Arm Bush		2	17000	16
Volkswagen	Touran (2017 - )	PFR85-817BLK	Rear Lower Arm Outer Bush		2	14000	17

Volkswagen	Touran (2017 - )	PFR85-818BLK	Rear Lower Arm Inner Bush		2	15500	18
Volkswagen	Touran 1T (2003-)	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	Touran 1T (2003-)	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	Touran 1T (2003-)	PFF85-502BLK	Front Wishbone Rear Bush		2	15500	2
Volkswagen	Touran 1T (2003-)	PFF85-502GBLK	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	31500	2
Volkswagen	Touran 1T (2003-)	PFF85-503-23BLK	Front Anti Roll Bar Bush 23mm	23mm	2	8500	3
Volkswagen	Touran 1T (2003-)	PFF85-503-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	8500	3
Volkswagen	Touran 1T (2003-)	PFF85-504BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Touran 1T (2003-)	PFF85-505BLK	Lower Engine Mount Small Bush		1	6000	5
Volkswagen	Touran 1T (2003-)	PFF85-530BLK	Transmission Mount Insert		1	8000	30
Volkswagen	Touran 1T (2003-)	PFF85-531BLK	Upper Engine Mount Insert		1	8000	31
Volkswagen	Touran 1T (2003-)	PFF85-532BLK	Upper Engine Mount Insert		1	8000	31
Volkswagen	Touran 1T (2003-)	PFF85-704BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Touran 1T (2003-)	PFR85-508BLK	Rear Tie Bar to Chassis Front Bush		2	11000	8
Volkswagen	Touran 1T (2003-)	PFR85-509BLK	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Touran 1T (2003-)	PFR85-510BLK	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Touran 1T (2003-)	PFR85-511BLK	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Touran 1T (2003-)	PFR85-512BLK	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Touran 1T (2003-)	PFR85-513BLK	Rear Upper Link Outer Bush		2	9000	13
Volkswagen	Touran 1T (2003-)	PFR85-514BLK	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Touran 1T (2003-)	PFR85-515-20.5BLK	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	9000	15
Volkswagen	Touran 1T (2003-)	PFR85-515-20.7BLK	Rear Anti Roll Bar Bush 20.7mm	20.7mm	2	9000	15
Volkswagen	Touran 1T (2003-)	PFR85-515-21.7BLK	Rear Anti Roll Bar Bush 21.7mm	21.7mm	2	9000	15
Volkswagen	Vento (1992 - 1998)	BS006	Bump Stop, VW Front	54mm x 59mm x 19	2	6500	
Volkswagen	Vento (1992 - 1998)	BS008	Bump Stop, VW Rear	60mm x 58mm x 10	2	6500	
Volkswagen	Vento (1992 - 1998)	EXH006	Exhaust Mounts		1	2250	
Volkswagen	Vento (1992 - 1998)	PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	1	4250	N/A
Volkswagen	Vento (1992 - 1998)	PFF85-201BLK	Front Wishbone Front Bush	30mm	2	11500	1
Volkswagen	Vento (1992 - 1998)	PFF85-204BLK	Front Wishbone Rear Bush		2	11500	2
Volkswagen	Vento (1992 - 1998)	PFF85-205BLK	Front Anti Roll Bar Mount 18mm	18mm	2	10000	3
Volkswagen	Vento (1992 - 1998)	PFF85-208-10BLK	Front Eye Bolt Mounting Bush 10mm	10mm	2	8000	4
Volkswagen	Vento (1992 - 1998)	PFF85-208BLK	Front Eye Bolt Mounting Bush		2	8000	4
Volkswagen	Vento (1992 - 1998)	PFF85-209-20BLK	Front Anti Roll Bar Eye Bolt Bush 20mm	20mm	2	8000	5
Volkswagen	Vento (1992 - 1998)	PFF85-209BLK	Front Anti Roll Bar Eye Bolt Bush 18mm	18mm	2	8000	5
Volkswagen	Vento (1992 - 1998)	PFF85-231BLK	Non Power Steering Rack Mount		2	7000	9
Volkswagen	Vento (1992 - 1998)	PFF85-232BLK	Power Steering Rack Mount	18.5mm wide bracket	1	3500	9
Volkswagen	Vento (1992 - 1998)	PFF85-233BLK	Power Steering Rack Mount	15mm wide bracket	1	3500	9
Volkswagen	Vento (1992 - 1998)	PFF85-239BLK	Front Strut, Top Mount		2	13500	11
Volkswagen	Vento (1992 - 1998)	PFF85-250BLK	Front Cross Member Mounting Bush		4	12000	6
Volkswagen	Vento (1992 - 1998)	PFF85-280BLK	Front Lower Engine Mounting Bush & Inserts		1	10000	20
Volkswagen	Vento (1992 - 1998)	PFR85-206BLK	Rear Beam Mounting Bush		2	17000	7
Volkswagen	Vento (1992 - 1998)	PFR85-240BLK	Rear Shock Top Mounting Bush		2	8000	8
Volkswagen	Vento (2005 - 2010)	PFF85-501BLK	Front Wishbone Front Bush		2	12000	1
Volkswagen	Vento (2005 - 2010)	PFF85-501GBLK	Front Wishbone Front Bush Camber Adjustable		2	26000	1
Volkswagen	Vento (2005 - 2010)	PFF85-502BLK	Front Wishbone Rear Bush		2	15500	2
Volkswagen	Vento (2005 - 2010)	PFF85-502GBLK	Front Wishbone Rear Bush Anti-Lift & Caster Offset		2	31500	2
Volkswagen	Vento (2005 - 2010)	PFF85-503-22.5BLK	Front Anti Roll Bar Bush 22.5mm	22.5mm	2	8500	3
Volkswagen	Vento (2005 - 2010)	PFF85-503-23.6BLK	Front Anti Roll Bar Bush 23.6mm	23.6mm	2	8500	3
Volkswagen	Vento (2005 - 2010)	PFF85-503-23BLK	Front Anti Roll Bar Bush 23mm	23mm	2	8500	3
Volkswagen	Vento (2005 - 2010)	PFF85-503-24BLK	Front Anti Roll Bar Bush 24mm	24mm	2	8500	3
Volkswagen	Vento (2005 - 2010)	PFF85-504BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Vento (2005 - 2010)	PFF85-505BLK	Lower Engine Mount Small Bush		1	6000	5
Volkswagen	Vento (2005 - 2010)	PFF85-704BLK	Lower Engine Mount Insert (Large)		1	6500	4
Volkswagen	Vento (2005 - 2010)	PFR85-508BLK	Rear Tie Bar to Chassis Front Bush		2	11000	8
Volkswagen	Vento (2005 - 2010)	PFR85-509BLK	Rear Lower Spring Mount Outer		2	9000	9
Volkswagen	Vento (2005 - 2010)	PFR85-510BLK	Rear Lower Spring Mount Inner		2	9000	10
Volkswagen	Vento (2005 - 2010)	PFR85-511BLK	Rear Lower Link Outer Bush		2	10500	11
Volkswagen	Vento (2005 - 2010)	PFR85-512BLK	Rear Lower Link Inner Bush		2	10500	12
Volkswagen	Vento (2005 - 2010)	PFR85-513BLK	Rear Upper Link Outer Bush		2	9000	13

Volkswagen	Vento (2005 - 2010)	PFR85-514BLK	Rear Upper Link Inner Bush		2	9000	14
Volkswagen	Vento (2005 - 2010)	PFR85-515-20.5BLK	Rear Anti Roll Bar Bush 20.5mm	20.5mm	2	9000	15