

Make	Model	Variants	Part Number	Product Description	Bush Size	定価(税別)	SET入数	図面番号
Volvo	240 (1975 - 1993)		PFF88-201	Front Arm Front Bush		8360	2	1
Volvo	240 (1975 - 1993)		PFF88-202	Front Arm Rear Bush		13420	2	2
Volvo	240 (1975 - 1993)		PFF88-204	Front Anti Roll Bar Link To Arm Bush		7500	2	4
Volvo	240 (1975 - 1993)		PFF88-205	Front Anti Roll Bar Link To Bar Bush		5000	2	5
Volvo	240 (1975 - 1993)		PFF88-206-19.5	Front Anti Roll Bar Bush 19.5mm		5000	2	3
Volvo	240 (1975 - 1993)		PFF88-206-21	Front Anti Roll Bar Bush 21mm		5000	2	3
Volvo	240 (1975 - 1993)		PFF88-207-19.5	Front Anti Roll Bar Bush 19.5mm		6500	2	3
Volvo	240 (1975 - 1993)		PFF88-207-21	Front Anti Roll Bar Bush 21mm		6500	2	3
Volvo	240 (1975 - 1993)		PFR88-210	Rear Trailing Arm To Chassis Bush		8580	2	10
Volvo	240 (1975 - 1993)		PFR88-211	Rear Trailing Arm To Axle Bush		10560	2	11
Volvo	240 (1975 - 1993)		PFR88-212	Rear Upper Trailing Arm Bush		16720	4	12
Volvo	240 (1975 - 1993)		PFR88-213	Rear Panhard Rod To Axle Bush		4500	1	13
Volvo	240 (1975 - 1993)		PFR88-214	Rear Panhard Rod To Chassis Bush		4500	1	14
Volvo	240 (1975 - 1993)		PFR88-219	Rear Trailing Arm To Axle Bush Insert		5720	2	11
Volvo	260 (1975 -1985)		PFF88-201	Front Arm Front Bush		8360	2	1
Volvo	260 (1975 -1985)		PFF88-202	Front Arm Rear Bush		13420	2	2
Volvo	260 (1975 -1985)		PFF88-204	Front Anti Roll Bar Link To Arm Bush		7500	2	4
Volvo	260 (1975 -1985)		PFF88-205	Front Anti Roll Bar Link To Bar Bush		5000	2	5
Volvo	260 (1975 -1985)		PFF88-206-19.5	Front Anti Roll Bar Bush 19.5mm		5000	2	3
Volvo	260 (1975 -1985)		PFF88-206-21	Front Anti Roll Bar Bush 21mm		5000	2	3
Volvo	260 (1975 -1985)		PFF88-207-19.5	Front Anti Roll Bar Bush 19.5mm		6500	2	3
Volvo	260 (1975 -1985)		PFF88-207-21	Front Anti Roll Bar Bush 21mm		6500	2	3
Volvo	260 (1975 -1985)		PFR88-210	Rear Trailing Arm To Chassis Bush		8580	2	10
Volvo	260 (1975 -1985)		PFR88-211	Rear Trailing Arm To Axle Bush		10560	2	11
Volvo	260 (1975 -1985)		PFR88-212	Rear Upper Trailing Arm Bush		16720	4	12
Volvo	260 (1975 -1985)		PFR88-213	Rear Panhard Rod To Axle Bush		4500	1	13
Volvo	260 (1975 -1985)		PFR88-214	Rear Panhard Rod To Chassis Bush		4500	1	14
Volvo	260 (1975 -1985)		PFR88-219	Rear Trailing Arm To Axle Bush Insert		5720	2	11
Volvo	400 Series (1986 - 1997)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Volvo	850, S70, V70 up to 2000		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Volvo	850, S70, V70 up to 2000		PFF88-101	Front Wishbone Lower Bush		15400	4	1
Volvo	850, S70, V70 up to 2000		PFF88-105	Front Upper Engine Mounting		5500	1	2
Volvo	850, S70, V70 up to 2000		PFF88-106	Front Upper Bulkhead Mount 50mm	50mm	4750	1	3
Volvo	850, S70, V70 up to 2000		PFF88-107	Front Upper Bulkhead Mount 36mm	36mm	4750	1	3
Volvo	850, S70, V70 up to 2000		PFF88-611	Front Lower Engine Mount Small Bush		4500	1	11
Volvo	850, S70, V70 up to 2000		PFF88-711	Front Lower Engine Tie Bar Large Bush		4750	1	10
Volvo	850, S70, V70 up to 2000		PFR88-901	Rear Lower Shock Bush		8580	2	15
Volvo	960 (1995 - 1997)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Volvo	C30 (2006 onwards)		PFF19-1202	Front Lower Wishbone Rear Bush		14520	2	2
Volvo	C30 (2006 onwards)		PFF19-1220	Lower Engine Mount Insert		5250	1	20
Volvo	C30 (2006 onwards)		PFF19-1222	Lower Engine Mount Insert		5000	1	20
Volvo	C30 (2006 onwards)		PFF19-801	Front Wishbone Lower Front Bush	12mm bolt	8800	2	1
Volvo	C30 (2006 onwards)		PFF19-8011	Front Lower Wishbone Front Bush 14mm bolt	14mm bolt	8800	2	1
Volvo	C30 (2006 onwards)		PFR19-1204-21	Rear Anti Roll Bar To Chassis Bush 21mm	21mm	9500	2	4
Volvo	C30 (2006 onwards)		PFR19-1204-21	Front Anti Roll Bar To Chassis Bush 21mm	21mm	9500	2	3
Volvo	C30 (2006 onwards)		PFR19-810	Rear Upper Trailing Arm Bush		18260	4	10
Volvo	C30 (2006 onwards)		PFR19-811	Rear Lower Trailing Arm Bush		18260	4	11
Volvo	C30 (2006 onwards)		PFR88-307	Rear Track Control Arm Inner Bush		9240	2	7
Volvo	C30 (2006 onwards)		PFR88-308	Rear Track Control Arm Outer Bush		9240	2	8
Volvo	S40 (2004 onwards)		PFF19-1202	Front Lower Wishbone Rear Bush		14520	2	2
Volvo	S40 (2004 onwards)		PFF19-1220	Lower Engine Mount Insert		5250	1	20
Volvo	S40 (2004 onwards)		PFF19-1222	Lower Engine Mount Insert		5000	1	20
Volvo	S40 (2004 onwards)		PFF19-801	Front Wishbone Lower Front Bush	12mm bolt	8800	2	1
Volvo	S40 (2004 onwards)		PFF19-8011	Front Lower Wishbone Front Bush 14mm bolt	14mm bolt	8800	2	1
Volvo	S40 (2004 onwards)		PFR19-1204-21	Rear Anti Roll Bar To Chassis Bush 21mm	21mm	9500	2	4
Volvo	S40 (2004 onwards)		PFR19-1204-21	Front Anti Roll Bar To Chassis Bush 21mm	21mm	9500	2	3
Volvo	S40 (2004 onwards)		PFR19-810	Rear Upper Trailing Arm Bush		18260	4	10
Volvo	S40 (2004 onwards)		PFR19-811	Rear Lower Trailing Arm Bush		18260	4	11
Volvo	S40 (2004 onwards)		PFR88-307	Rear Track Control Arm Inner Bush		9240	2	7
Volvo	S40 (2004 onwards)		PFR88-308	Rear Track Control Arm Outer Bush		9240	2	8
Volvo	S40/V40 (1996 - 2004)		PFA100-12	PowerAlign Camber Bolt Kit (12mm)	12mm	4000	1	
Volvo	S60 (2001-2010), V70-Mk2, S80-Mk1 (2000-on)		PFA100-14	PowerAlign Camber Bolt Kit (14mm)	14mm	4250	1	
Volvo	S60 (2001-2010), V70-Mk2, S80-Mk1 (2000-on)		PFF88-103	Upper Engine Mount Large Round Bush Diesel		6750	1	12
Volvo	S60 (2001-2010), V70-Mk2, S80-Mk1 (2000-on)		PFF88-600	Front Arm Rear Bush		10560	2	16
Volvo	S60 (2001-2010), V70-Mk2, S80-Mk1 (2000-on)		PFF88-601	Front Lower Wishbone Front Bush		9020	2	1
Volvo	S60 (2001-2010), V70-Mk2, S80-Mk1 (2000-on)		PFF88-611	Front Lower Engine Mount Small Bush		4500	1	11
Volvo	S60 (2001-2010), V70-Mk2, S80-Mk1 (2000-on)		PFF88-612	Upper Engine Mount Large Round Bush Petrol		5500	1	12
Volvo	S60 (2001-2010), V70-Mk2, S80-Mk1 (2000-on)		PFF88-613	Upper Engine Mount Small Bush		5000	1	13
Volvo	S60 (2001-2010), V70-Mk2, S80-Mk1 (2000-on)		PFF88-614	Strut Brace Tensioning Kit		5060	2	14
Volvo	S60 (2001-2010), V70-Mk2, S80-Mk1 (2000-on)		PFF88-622	Upper Engine Mount Cross Shape Petrol		6750	1	12
Volvo	S60 (2001-2010), V70-Mk2, S80-Mk1 (2000-on)		PFF88-623	Upper Engine Mount Cross Shape Diesel		6750	1	12
Volvo	S60 (2001-2010), V70-Mk2, S80-Mk1 (2000-on)		PFF88-711	Front Lower Engine Tie Bar Large Bush		4750	1	10
Volvo	S60 AWD 2002		PFA100-14	PowerAlign Camber Bolt Kit (14mm)	14mm	4250	1	
Volvo	S60 AWD 2002		PFF88-600	Front Arm Rear Bush		10560	2	16
Volvo	S60 AWD 2002		PFF88-601	Front Lower Wishbone Front Bush		9020	2	1
Volvo	S60 AWD 2002		PFF88-611	Front Lower Engine Mount Small Bush		4500	1	11

Volvo	S60 AWD 2002		PFF88-612	Upper Engine Mount Large Round Bush Petrol		5500	1	12
Volvo	S60 AWD 2002		PFF88-613	Upper Engine Mount Small Bush		5000	1	13
Volvo	S60 AWD 2002		PFF88-614	Strut Brace Tensioning Kit		5060	2	14
Volvo	S60 AWD 2002		PFF88-711	Front Lower Engine Mount Large Bush		4750	1	15
Volvo	S60 AWD 2002		PFR88-602	Rear Beam Front Mounting Bush		9680	2	2
Volvo	S60 AWD 2002		PFR88-603	Rear Beam Rear Mounting Bush		9680	2	3
Volvo	S60 AWD 2002		PFR88-604	Rear Inner Rear Lower Arm		8800	2	4
Volvo	S60 AWD 2002		PFR88-605	Rear Toe Control Arm Bush Front		8800	2	5
Volvo	S60 AWD 2002		PFR88-606	Rear Lower Centre Arm Inner		8800	2	6
Volvo	S60 AWD 2002		PFR88-607	Rear Lower Centre Arm Outer		8800	2	7
Volvo	S60 AWD 2002		PFR88-608	Rear Toe Control Arm To Hub Bush		8800	2	8
Volvo	S60 AWD 2002		PFR88-609	Rear Outer Rear Lower Arm		8800	2	9
Volvo	S60 AWD 2002		PFR88-610	Rear Upper Link Y Arm Front Void Kit		5060	2	10
Volvo	V50 (2004 onwards)		PFF19-1202	Front Lower Wishbone Rear Bush		14520	2	2
Volvo	V50 (2004 onwards)		PFF19-1220	Lower Engine Mount Insert		5250	1	20
Volvo	V50 (2004 onwards)		PFF19-1222	Lower Engine Mount Insert		5000	1	20
Volvo	V50 (2004 onwards)		PFF19-801	Front Wishbone Lower Front Bush		8800	2	1
Volvo	V50 (2004 onwards)		PFF19-8011	Front Lower Wishbone Front Bush 14mm bolt	14mm bolt	8800	2	1
Volvo	V50 (2004 onwards)		PFR19-1204-21	Rear Anti Roll Bar To Chassis Bush 21mm	21mm	9500	2	4
Volvo	V50 (2004 onwards)		PFR19-1204-21	Front Anti Roll Bar To Chassis Bush 21mm	21mm	9500	2	3
Volvo	V50 (2004 onwards)		PFR19-810	Rear Upper Trailing Arm Bush		18260	4	10
Volvo	V50 (2004 onwards)		PFR19-811	Rear Lower Trailing Arm Bush		18260	4	11
Volvo	V50 (2004 onwards)		PFR88-307	Rear Track Control Arm Inner Bush		9240	2	7
Volvo	V50 (2004 onwards)		PFR88-308	Rear Track Control Arm Outer Bush		9240	2	8
Volvo	XC70/90 (2002 - 2011)		PFA100-14	PowerAlign Camber Bolt Kit (14mm)	14mm	4250	1	